



Ergonomic 290.250 GAC

Operating Instruction for Band Saw

Before transporting and using the machine,
please read the instructions thoroughly!

Service and Information

Your BOMAR dealer :

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

phone: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.07 / May 2016
rev. 1

© BOMAR, spol. s r.o. – Subject to modifications and amendments

EC Declaration of Conformity

1) We: BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, Czech Republic
Id. No: 48908827
declare herewith

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government. This statement applies exclusively to the machine device in conditions in which it was brought to the market. It does not apply to parts subsequently added by the end user or to modifications performed subsequently by the end user. In the event of any device modification not approved by us this declaration shall lose its validity

Name: Band Saw
Type : Ergonomic 290.250 GAC
Serial number:
Manufacturer BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno
Product data
Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics
Description: Stand, table, cutting unit with the arm, saw band and drive, hand clamping device, cooling system, machine control
Pneumatic ☐ NO ☒ YES Hydraulic ☐ NO ☒ YES Control system ☐ NO ☒ YES
Technical data: Cutting rate 40/80 m.min⁻¹ (variator)
20-90 m min⁻¹ (FC)
Cutting angle 0° - 60°
Total dimensions in mm (l×w×h) 2140×1710×1700
Total power requirement 2,6 kW
Weight 575 kg

Documentation:
Technical documentation for this machine device was elaborated in compliance with Government regulation no. 176/2008, Annex 7, part A.

The device meets relevant requirements of the given directives: 2006/42/ES
2004/108/ES

The applied harmonized standards, National standards and technical specifications:
ČSN EN ISO 12100:2011 ČSN EN 13898+A1:2009 ČSN EN ISO 13857:2008
ČSN EN ISO 4413:2011 ČSN EN 60204 -1 ed.2+A1:2009
ČSN EN 55011 ed.3+A1:2011 ČSN EN 61000-6-2 ed.3:2006 ČSN EN 61000-6-4 ed.2+A1:2011

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended.

The declaration of conformity was carried out in the cooperation with the TÜV SÜD Czech s.r.o, 2) , Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002.

The inspection certificate no 07.801.283 was issued.

Brno, 29.2.2016
BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827

Point of issue, datum


Alfred Pichlmann, Managing Director
Name and function of the responsible subject, signature

1) Person authorized to complete the technical documentation:: BOMAR, spol. s r. o., Těžební 1236/1, 627 00 Brno

2) Name, address and identification number of the subject issuing the conformity declaration (producer or importer)	
3) The authorized or accredited body co-operating on the conformity judging	
!	If the equipment is installed without safety equipment offered by BOMAR, spol. s ro or its agents and used by the customer (or buyer) then EC declaration loses validity. EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards. All machine elements and components that were built into the device by BOMAR, spol. s ro have been declared "identical" to a safety device, as offered by BOMAR, spol. s ro or its agents.

Content

1. BEZPEČNOSTNÍ POKYNY / SICHERHEITSHINWEISE / SAFETY NOTES.....	12
1.1. Machine determination.....	14
1.2. Protective clothing and personal safety.....	14
1.3. Safety instructions for machine operator.....	16
1.4. Safety notes for the servicing and repairs	18
1.5. Safety accessories of the machine.....	18
1.5.1. Total Stop	18
1.5.2. Saw arm cover	19
1.5.3. Saw band cover.....	19
1.5.4. Feeding vice cover.....	19
1.5.5. Saw band stretching and rupture inspection	20
1.6. Safety notes for the cooling.....	20
1.6.1. Instructions for first aid	20
1.7. Umístění štítku stroje / Maschinenschild position / Position of machine label	21
1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	22
2. DOKUMENTACE STROJE / DOKUMENTATION DER MASCHINE / MACHINE DOCUMENTATION	24
2.1. Technická data / Technische Daten / Technical data.....	26
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram	27
2.3. Popis / Beschreibung / Description.....	28
2.4. Transportation and stocking.....	29
2.4.1. Conditions for transportation and stocking.....	29
2.4.2. Transport and stocking preparations.....	29
2.4.3. Transport and stocking.....	29
2.5. Transportní schéma / Transport schéma / Transport scheme	30
2.6. Activation.....	31
2.6.1. Machine working conditions	31
2.7. Band saw unpacking and assembling	31
2.7.1. Machine installing and leveling.....	31
2.8. Machine disposal after lifetime	31
2.9. Kotevní plan / Verankerungsplan / Grounding plan	32
2.10. Electrical connection	33
2.10.1. Direction of the saw band check	33
2.10.2. Check machine connection into electrical network.....	35
2.11. Filling of the cooling system.....	35
2.12. Putting into operation of the hydraulic unit	35
2.12.1. Filling the reservoir with hydraulic oil.....	37
2.13. Machine functions check.....	37
2.14. Saw band.....	39
2.14.1. Saw band size	39
2.14.2. Selection of the saw band tooth system.....	39
2.14.3. Saw band running-in.....	39
2.15. Table for teeth selection	41
3. OVLÁDÁNÍ STROJE / MACHINE CONTROL / BEDIENUNG DER MASCHINE	43
3.1. Starting the saw.....	45
3.2. Control panel	46
3.2.1. Ergonomic 290.250 GAC without frequency converter	46
3.2.2. Ergonomic 290.250 GAC– with frequency converter	48
3.3. Referencing	50
3.4. Semi-automatic cycle	51

3.4.1. Cycle interruption	51
3.5. Automatic cycle programming	52
3.5.1. Program creation.....	52
3.5.2. Program storing.....	53
3.5.3. Program selection.....	54
3.5.4. Editing existing pre-selection	55
3.5.5. New pre-selection inserting	56
3.5.6. Clearing.....	57
3.6. Automatic cycle with trim cut.....	59
3.7. Automatic cycle without trim cut.....	60
3.7.1. Cycle interruption	61
3.8. Service menu	62
3.8.1. Entrance to service menu	62
3.8.2. Vice parameters	62
3.8.3. Cooling parameters.....	62
3.8.4. Cutting parameters	63
3.8.5. Length units selection	64
3.8.6. Service menu closing	66
3.9. Band saw adjusting.....	66
3.9.1. Support roller.....	66
3.9.2. Speed adjusting of the arm lowering.....	67
3.9.3. Cutting speed setting Ergonomic 290.250 GAC – without frequency converter	67
3.9.4. Cutting speed setting Ergonomic 290.250 GAC – with frequency converter.....	67
3.9.5. Angular cut setting.....	67
3.9.6. Optimal adjusting of the guide cubes span	69
3.9.7. Vice setting.....	70
3.9.8. Pressure adjusting to the cut	71
3.9.9. Swarf conveyor operation.....	72
3.9.10. Upper pressure adjustment	72
3.10. Vkládání materiálu.....	74
3.10.1. Volba manipulačního prostředku	74
3.10.2. Vkládání.....	74
3.10.3. Řezání ve svazku	74

4. ÚDRŽBA STROJE / WARTUNG / MACHINE MAINTENANCE ..76

4.1. Saw band dismantling.....	78
4.2. Saw band installation	79
4.3. Saw band stretching and inspection.....	80
4.3.1. Saw band stretching.....	80
4.3.2. Saw band run inspection.....	82
4.4. Adjustment.....	83
4.4.1. Saw band run adjustment.....	83
4.4.2. Hard metal guides adjustment	83
4.4.3. Setting of the guiding cubes.....	84
4.4.4. Setting of angular stops	84
4.4.5. Adjusting the limit switch of the saw band stretching.....	86
4.4.6. Saw frame lower position stop adjustment	86
4.4.7. Adjustment of the limit switch of saw frame lower stop.....	87
4.4.8. Setting of the feeder back position induction switch	87
4.4.9. Setting of the feeder front position induction switch.....	88
4.4.10. Pressure switch adjustment	88
4.4.11. System pressure adjustment.....	89
4.4.12. Adjustment of the feeder cylinder step setting securing cube.....	89
4.4.13. Setting of the throttle valve	90
4.4.14. Brush adjustment	91
4.4.15. Setting of the turning lever securing cube	92
4.5. Cooling agents and chip disposal	93
4.5.1. Coolant inspection.....	93
4.5.2. Chips disposal.....	94
4.6. Gearbox oils and greases.....	94
4.6.1. Gearbox oils	94

4.6.2.	Lubrication greases	95
4.6.3.	Lubrication.....	96
4.6.4.	Hydraulic oils.....	96
4.6.5.	Inspection of the hydraulic oil state.....	98
4.7.	Machine cleaning.....	98
4.8.	Worn pieces replacement.....	99
4.8.1.	Hard metal guides replacement.....	99
4.8.2.	Worn brush replacement.....	100
4.8.3.	Saw band guiding rollers replacement.....	100
4.8.4.	Stretching wheel replacement.....	102
4.8.5.	Driving wheel replacement.....	104
4.8.6.	Cooling pump replacement.....	106
5.	ZÁVADY / STÖRUNGEN / TROUBLESHOOTING	108
5.1.	Mechanical malfunctions.....	110
5.2.	Electrical malfunctions.....	115
5.3.	Hydraulic malfunctions	117
6.	SCHÉMATA / SCHEMAS / SCHEMATICS	119
6.1.	Elektrické schema /Elektroschema Wiring diagrams.....	121
6.1.1.	Ergonomic 290.250 GAC without frequency converter 3x400V+PE, 50Hz.....	121
6.1.2.	Ergonomic 290.250 GAC with frequency converter 3x400V+PE, 50Hz.....	142
6.1.3.	Ergonomic 290.250 GAC bez frekvenčního měniče 3x230V+PE, 50Hz.....	165
6.1.4.	Ergonomic 290.250 GAC s frekvenčním měničem 3x230V+PE, 50Hz	186
6.2.	Hydraulické schéma Hydraulisches Schéma Hydraulic diagram	210
7.	VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER.....	213
7.1.	ERGONOMIC 290.250 GAC.....	214
7.2.	Kusovník / Piece list / Stückliste - ERGONOMIC 290.250 GAC.....	215
7.3.	Válec zvedací / Lifting cylinder / Hebezyylinder	216
7.4.	Kusovník / Piece list / Stückliste - Válec zvedací / Lifting cylinder / Hebezyylinder.....	217
7.5.	Odměrování / Measuring / Gehrungsmessung	218
7.6.	Kusovník / Piece list / Stückliste - Odměrování / Measuring / Gehrungsmessung.....	219
7.7.	Konzola otočná / Turnable consol / Drehkonsole	220
7.8.	Kusovník / Piece list / Stückliste - Konzola otočná / Turnable consol / Drehkonsole	221
7.9.	Kartáč / Brush / Bürste.....	223
7.10.	Kryt podavače / Vorschubsleistedeckel / Feeders bracket cover.....	224
7.11.	Kusovník / Piece list / Stückliste - Kryt podavače / Vorschubsleistedeckel / Feeders bracket cover.....	225
7.12.	Podstavec / Base / Untersatz	226
7.13.	Kusovník / Piece list / Stückliste - Podstavec / Base / Untersatz.....	227
7.14.	Svěrák / Vice / Schraubstock.....	228
7.15.	Kusovník / Piece list / Stückliste - Svěrák / Vice / Schraubstock.....	229
7.16.	Chlazení / Cooling / Kühlung	230
7.17.	Čelo / Head / Stirn	231
7.18.	Podavač / Feeder / Vorschub.....	232
7.19.	Kusovník / Piece list / Stückliste - Podavač / Feeder / Vorschub.....	233
7.20.	Podavač / Feeder / Vorschub.....	234
7.21.	Kusovník / Piece list / Stückliste - Podavač / Feeder / Vorschub.....	235
7.22.	Válec upínací / Fixing cylinder / Spannzyylinder	236
7.23.	Kusovník / Piece list / Stückliste - Válec upínací / Fixing cylinder / Spannzyylinder	237
7.24.	Čelist / Jaw / Backe.....	238
7.25.	Kusovník / Piece list / Stückliste - Čelist / Jaw / Backe.....	239

7.26.	Konzola / Console / Konsole	240
7.27.	Trať / Track / Bahn	242
7.28.	Kusovník / Piece list / Stückliste - Trať / Track / Bahn	243
7.29.	Rameno / Shoulder / Sägerahmen	244
7.30.	Kusovník / Piece list / Stückliste - Rameno / Shoulder / Sägerahmen ..	245
7.31.	Rameno / Shoulder / Sägerahmen	246
7.32.	Kusovník / Piece list / Stückliste - Rameno / Shoulder / Sägerahmen ..	247
7.33.	Napínání / Tensioning / Spannung	248
7.34.	Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung ..	249
7.35.	Vedení pásu / Belt guide / Sägebandführung	250
7.36.	Kusovník / Piece list / Stückliste - Vedení pásu / Belt guide / Sägebandführung	251
7.37.	Kostka vodící / Lead cube / Führungsklotz	252
7.38.	Kusovník / Piece list / Stückliste - Kostka vodící / Lead cube / Führungsklotz	253
7.39.	Kostka vodící / Lead cube / Führungsklotz	254
7.40.	Kusovník / Piece list / Stückliste - Kostka vodící / Lead cube / Führungsklotz	255

1. **Bezpečnostní pokyny / Sicherheitshinweise / Safety notes**

The operating instructions must be read by any person, who gets in contact with the machine during transportation, installation, using, servicing, repair, stocking or removal!

The operating instructions include relevant information. **The operator must familiarize himself with the installation and operation, safety notes and machine servicing**, to reach maximum reliability and lifespan. The operating instructions serve to avoid risks, which are linked with work on the machine. **Before transporting and using the machine, please read the instructions thoroughly!**

Attention!

The operating instructions must be available at the machine! Keep the operating instructions in a good condition!

1.1. Machine determination

The band saw Ergonomic 290.250 GAC is determined for cutting and shortening of rolled bars, drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **with changeable cutting angle from 0° to 60°**.

Combustible materials are excluded from cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

The machine is equipped with safety and protective measures for both the operator and the machine to be protected. Nevertheless, these measures cannot prevent all injuries. All personnel must read this chapter and understand it, before they start to work on the machine. **Always follow the safety instructions!** The personnel must take into account other aspects of the risk, which include the conditions of the working place and the material.

Attention!

Mind the safety signs on the machine. Do not remove or damage them! Keep these labels always readable!

1.2. Protective clothing and personal safety

Attention!

An exclamation mark in a yellow triangle signifies a safety warning. Its meaning is described next to the symbol.

Wear fitting clothes! Loosely fitting clothes may be caught in moving machine parts and cause serious injuries.

Wear protective gloves! Material cuts and saw band have sharp edges and may cause injuries.

Attention!

Gloves can be worn only when manipulating with material or replacing parts! The machine and its accessories must be inactive!

If the machine is running, you must not wear gloves! There is a higher risk of getting caught in moving machinery!

Wear protective shoes with antiskid soles! Unsuitable shoes may cause loss of balance and following injury. Dropped blank cuts may cause injuries too.

Wear protective goggles! Flung chips and cooling liquid may damage your eyes.

Always wear ear protection! Most of the machines generate acoustic pressure up to 80 dB and may damage your unprotected hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough for work. Illnesses or injuries diminish concentration.

Avoid machine work, which may jeopardize the safety of you and your colleagues!

1.3. Safety instructions for machine operator

Attention!

Machine can only be operated by a person older than 18 years!

Machine can be operated only by a person physically and mentally fit for this activity.

Machine can only be operated only by one person at a time. Machine operator is responsible for other people present near the machine.

The person who is operating the machine using the control elements (control panel and other) must not either alone or with help of other workers move the cut or otherwise machined material at the same time.

Follow the instructions and directives for work safety!

Read the operating instructions before you start to work on the machine! Keep the operating instructions in good condition!

Close covers before starting the machine and check, if the covers are not damaged. Damaged covers must be repaired or replaced immediately. Do not start the machine, if any cover is removed!

Attention!

Do not connect the machine to electricity if the door or any covers are removed. Do not touch the high voltage

- Check, if the electric cables are not damaged.
- Do not hold or manipulate the material during clamping or cutting!
- Do not operate the buttons and switches on the control panel wearing gloves! You may press a wrong button.
- Make sure, that there is nobody in the working area of the machine (the working area of the vice, the saw band, the saw arm etc.) during a working cycle and when starting the machine.
- Under no circumstances touch any rotating elements.
- Use the machine only when it is in a good condition!
- Check at least once in a shift, if the machine is not visibly damaged. If you discover any such damage, you must bring the machine to a halt and inform your superior!
- Keep your working area and machine clean and uncluttered! Ensure sufficient lighting in the working area.
- Take off any spilt water or oil from the floor and dry it immediately to avoid a possibility of injury.
- Do not touch the cooling liquid with bare hands!

- Do not adjust the cooling liquid nozzle if the machine is running.
- Do not remove the chips from the working area of the machine, when the machine is running!
- Do not use compressed air for machine cleaning or for chip removal!
- Use protective gear for chip removal!

1.4. Safety notes for the servicing and repairs

Attention!

Only a qualified professional can carry out the servicing and repairs of the electrical equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always follow the work safety instructions! Otherwise, there is possibility of heavy injury!

Switch off the main switch and lock it, before you start service work! This way you eliminate a possibility of starting the machine accidentally.

Take care when manipulating the frequency converter. It is still energized for 20 minutes after machine shutdown.

Always adhere to the safety instructions!

Only an authorized professional can carry out the servicing and repairs.

For parts replacement, use only those, which are identical with the originals. Otherwise, there is possibility of health hazard.

Use only recommended types of hydraulic oils, oils and lubricants!

Do not remove or lock the limit switches or any other safety equipment!

Any use of the saw, accessories or machine parts other than that intended by BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be lost afterward and BOMAR, spol. s r.o. takes no responsibility for damage caused.

Do not turn the machine on if all covers are not in place.

1.5. Safety accessories of the machine

The machine is equipped with safety accessories. They protect the operator from injuries and the machine from damage. The safety accessories include blocking accessories, emergency switches and covers. Check the function of safety accessories regularly once a week. If the safety accessories are not fulfilling their function, interrupt your work and repair or replace the faulty accessory.

Enhanced risk!

*Do not come into or intervene in the cutting area.
Otherwise, there is a danger of injury, cutting or squeezing.*



1.5.1. Total Stop

TOTAL STOP button is used for emergency switching – off of the machine in a case of defect or health hazard. By pressing the **TOTAL STOP** button the supply of electrical power is interrupted.

If any faults or states of emergency appear, immediately press the **TOTAL STOP** button!

Release of pressed button is possible by twisting the upper part of the button.

1.5.2. Saw arm cover

If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The machine cannot be run with the arm cover open even in the service mode. The band saw can be first started, when the cover is closed!



1.5.3. Saw band cover

This protective cover envelops the saw band stretching from the guiding cube to the arm.

Never switch on the saw if this cover is not mounted!



1.5.4. Feeding vice cover

This cover prohibits access to the feeding vice during operation, thus protecting the workers from injury.

If the cover is opened during cutting, the limit switch is disconnected (see. arrow) and the machine is stopped. It is not possible to start the machine even in service mode.

The band saw can only be turned on, when the cover is closed!



1.5.5. Saw band stretching and rupture inspection

This device checks the saw band tension and causes immediate machine halt if the band accidentally ruptures.

The device includes a limit switch. Its adjustment is described in chapter „Maintenance“. Check the switch carefully and periodically – adjust it if necessary.



1.6. Safety notes for the cooling

Attention!

- *When handling the coolant always keep to the work safety directives and instructions of the manufacturer.*
- *When handling cooling agents always wear safety fluid-proof gloves!*
- *Wear protective goggles!*
- *Cooling liquid can get in contact with your eyes and may cause severe injuries*

1.6.1. Instructions for first aid

1. Pull off and safely remove polluted, soaked clothing.
 2. If inhaled, go outside on fresh air or look for first aid treatment.
 3. Wash with water and eventually treat with crème any points of contact with the skin.
 4. Rinse your eyes with water and seek out a doctor.
1. If swallowed, drink a lot of water and induce vomiting. Look for medical help.

- 1.7. Umístění štítku stroje /
Maschinenschild position /
Position of machine label





Machine label is placed on band saw's base.

1.8. Umístění bezpečnostních značek /
Verteilung der Sicherheitszeichen /
Position of safety symbols


NE

Nebezpečí úrazu
elektrickým proudem
Verletzungsgefahr vom
elektrischen Strom
Electrical hazard



Místo pro ližiny vozíku
Die stelle für Greifen mit den
Gabeln des gabelstaplers
Place for forklift's skides





PO:

Noste pevnou pracovní obuv
Tragen Sie Sicherheitsschuhe
Wear fixed protective shoes



CZ:

Přečíst návod k použití
Bedienungsanleitung lesen
Read the operating instructions



OBS:

Noste ochranné brýle a sluchátka
Tragen Sie eine Schutzbrille und Gehörschutz
Wear protective goggles and headphones




SP:

Směr pohybu
Bewegungsrichtung
Direction of motion



A




NR:

Nebezpečí říznutí
Schnittgefahr
Cutting or severing hazard



2. **Dokumentace stroje / Dokumentation der Maschine / Machine documentation**


2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:				
Hmotnost / Gewicht / Weight	575 kg			
Rozměry stroje / Maschinengröße / Machine size :				
- Délka / Länge / Lenght - Šířka / Breite / Width - Výška / Höhe / Height	2140 mm 1710 mm 1700 mm			
Elektrické vybavení / Elektrische Ausrüstung / Electrical equipment:				
- Napájení / Versorgungsspannung / Supply voltage - Příkon / Gesamtschlusswert / Total Input - Max.jištění / Max. Vorschaltsicherung / Max. Fuse - Krytí / Schutzart / Protection	~ 3×400V, 50H 2,6 kW 16 A IP 54			
Akustický tlak / Schalldruckpegel / Acoustic pressure:				
Ergonomic 290.250 GAC	L _{Aeqv} = 65 dB			
Pohon / Atrieb / Drive:				
- Typ / Typ / Type - Napájení / Versorgungsspannung / Supply voltage - Výkon / Leistung / Output - Jmenovité otáčky / Motorenndrehzahl / Nominal speed	TM90 2S B5 ~ 3×400 V/230 V, 50 Hz 1,5 kW 2850 min⁻¹			
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:				
- Výkon / Leistung / Output - Obsah nádrže / Volumen vom Kühlmittel / Capacity	0,05 kW 20 dm³			
Rozměr pásu / Sägebandedimension / Band size:				
2910×25 (27)×0,90 mm				
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:				
Variator: 40/80 m/min				
Frequency converter: 20–90 m/min				
Řezné rozsahy / Schnittbereiche / Cutting size:				
				
0°	 Ø250 mm	 290×230 mm	 290×230 mm	 240×240 mm
R 45° (+45°)	Ø210 mm	220×80 mm	190×230 mm	190×190 mm
R 60° (+60°)	Ø120 mm	120×80 mm	120×100 mm	100×100 mm


Level of acoustic pressure:

The equivalent level of the acoustic pressure A (noise) at the position of the operator is L_{Aeqv} = 65 dB. The values are indicating the emission levels and may not present safe working levels. Among factors, which influence real values of the operator's exposure, are properties of the workshop room, type of cut material and level of wear of the saw band – these may significantly influence the exposure levels.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Follow the recommendations of the manufacturer for transportation and stocking! If the recommendations are not kept, damage may occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have a license for it!
- Don't move under suspended loads! Fault in the lifting device may cause a serious injury.
- Keep a safe distance from the machine during transport.
- Temperature of the air must be between **-25°C and 55°C**, for a *short period* (max. 24 hours) up to 70°C.
- Do not expose the machine to radiation (microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating of the condition of the insulation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

- Tighten the vice and thoroughly oil all smooth surfaces.
- Lower the saw frame to the lowest position.
- Make sure to empty the machine of all traces of cooling agent.
- Fasten all loose parts securely to the machine.
- Pack and wrap the control panel securely to avoid damage during transport.
- Put stickers stating the minimum approximate machine weight to at least five well visible places.

The machine has to be screwed to a pallet for transportation. Make sure the pallet is firm enough to be able to hold the saw!

2.4.3. Transport and stocking

The machine must be secured sufficiently during transportation so it won't roll over or fall off the vehicle.


Fasten the pallet to the floor of the vehicle.

Beware of damaging the machine during transportation.

It is forbidden to handle the machine in any way different from that written in these operating instructions (for example lifting it by the saw arm); the machine could get damaged!

Store the machine only under conditions mentioned in the manual to avoid damaging it.

2.5. Transportní schéma / Transport schéma / Transport scheneme



2.6. Activation

2.6.1. Machine working conditions

Keep the conditions of the manufacturer for machine operation! If the recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At air temperature from **10°C to 40°C**; the temperature average during 24 hours must **not exceed 35°C**.
- At relative dampness of the air in the interval from 30% to 95% (not condensing). Altitude up to 1000 meters.
- Do not expose the machine to any radiation (microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorate the condition of the insulation.

2.7. Band saw unpacking and assembling

Remove the wrapping from the machine and unpack all parts.

Attention!
Switch off the main switch and lock it in position, before you start the assembly! Otherwise, there is a possibility of accidental machine starting.

2.7.1. Machine installing and leveling

Check the floor supporting capacity before installing the machine. If the floor capacity does not meet the requirements, you must ready a necessary base for the machine.

Minimal requirement:

machine weight – Ergonomic 290.250 GANC – 950 kg

+ weight of the accessories


+ maximum weight of material

1. The machine must be leveled horizontally. All feet of the machine must touch the floor after leveling.
2. The machine must be leveled by means of a calibrated spirit level. Put the spirit level on the loading surface of the vice. Adjust the roller conveyors according to the spirit level.
3. For machine leveling, take care that there is sufficient space available for operation, repair work, servicing of the machine and handling of the material.
4. The machine and all appended parts and accessories must be visible from the place of operation

2.8. Machine disposal after lifetime

Pour all service fluids (cooling liquid, hydraulic oil) from the machine over into designated reservoirs. Dismantle machine into separate parts and dispose of them in accordance with valid directives.

2.9. Kotevní plan / Verankerungsplan / Grounding plan



Kotvicí materiál / Verankerungsmaterial / Grouding material

- 4x Chemická hmoždina / Chemische Dübel / Chemical Plug
- 4x ø12mm Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 140 mm
- Šrouby / Schraube / Screws – 4xM12

- Šrouby podložit deskami o min. rozměrech P10×100-100
- Die Schrauben mit Platten mit Minimaldimensionen P10×100-100 unterlegen
- Screw must be bottomed with plates (min. dimensions P10×100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.10. Electrical connection

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with the electrical equipment. High voltage accident can have fatal consequences! Always follow instructions for work safety.

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V}$, 50 Hz, TN-C-S
- Total input / 2,6 kW
- Max. fuse: 16 A

Note:

Values of the cross section of the conductor and the rated current can be found in the regulations.

Before connecting the machine turn off the main power switch and ensure a dry area for the connection work.

Service voltage must agree with the line voltage! Cross section of the supply line must respond with the rated current for max. machine load.

Note:

A socket with fork can be used only for machines with the rated current less than 16 A and total input less than 3 kVA.

In case the machine is connected directly to the electrical network terminals, an extra main switch which can be locked in zero position must be added.

Attention!

In this case the extra switch on the electrical line becomes the primary switch and the main switch on the machine has only a secondary function.

2.10.1. Direction of the saw band check

After the machine has been successfully connected, switch on the machine and run the driving engine of the band briefly. The movement of the band must be in agreement with the direction of the arrow on the saw band cover.



If the direction of the saw band does not agree, the phases at the terminal line must be switched.

2.10.2. Check machine connection into electrical network



Attention!

**When you connect the machine to the electrical network observe correct connection of all phases!
ENGINE IN IN HYDRAULIC AGGREGATE CANNOT BE OPERATED WITH REVERSE TURNING MORE THEN 10 SECONDS!!!**



2.11. Filling of the cooling system

Prepare a mixture of water and a cooling liquid. Keep the concentration specified by manufacturer. Remove the cover from the drainage hole.

Pour the mixture into the tank of the cooling system.

When filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and that the tank does not overflow.

When adding anticorrosion agents, antifreeze and other chemicals follow the instructions of the manufacturer! By mixing various products poisonous and aggressive chemicals can be created that can damage your health or the cooling equipment of the machine.

Note:

If the machine is equipped with a Microniser, fill the Microniser with prescribed cooling liquid. This makes the Microniser ready for operation.

2.12. Putting into operation of the hydraulic unit

Before the first run check:

- the tank is filled with the prescribed oil to upper limit
- pump is not running in the opposite direction. Hydraulic generator must not be operated in opposite directions of rotation for longer than 5-10 seconds.
- connections are properly tightened, pipes assembled without internal stress
- wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise
- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load

- test the electrical equipment

- during operation monitor measuring equipment, noise, height and temperature of oil in the tank
- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.12.1. Filling the reservoir with hydraulic oil

Oil regulations and recommendations of the manufacturer in the technical documentation (appendix) are to be carefully observed. For standard power packs we recommend the oiltype OH-HM32 (DIN 51524) of all known oil manufacturers.

Power packs have to be filled up with clean, pre-filtered oil! The purity of the hydraulic fluid must correspond to the class 10 NAS 1638 (reachable with filter $\beta_{=75}$)!

Filling from container, such as barrels, buckets, etc. is not recommended or permitted!

The maximum oil level will be shown on the upper marking at the dipstick or the sight level glass. Overfilling has to be prevent. The maximum filling rate of 15 l/min shouldn't be exceed..

Oil type	Kinematic viscosity v in mm^2/s in relationship to the fluid temperatur					Freezing point
	0°C	20°C	40°C	60°C	80°C	°C
OH-HM 32	220	100	32	15	7	-40
OH-HV 32	180	67	32	17	11	-40

2.13. Machine functions check

Before you proceed with the check study the instructions in this manual thoroughly.

Do not proceed with the check if you did not fully understand all control elements and machine functions.

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if all covers are installed and functional.

Check (with the Tenzomat) if the saw band is correctly stretched. If it is necessary, stretch the saw band. Correct values of the saw band tension are on the Tenzomat.

Switch on the main switch and check the motors and aggregates (saw band drive, hydraulic pump, cooling pump, swarf conveyor).

Fully open and then close the main vice and the feeder vice. Move the feeder from one end to the other. Turn the saw frame of the band saw from one outer position to the other. Raise the saw frame to the top position and then lower the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for operation.

Carry out one cutting cycle without any material. Check, if the machine runs with no irregularities. If all machine functions run properly, the machine is ready for operation.

2.14. Saw band

Remove the saw band cover only after you have installed and stretched the saw band a bit. This way you minimize the risk of injury.



2.14.1. Saw band size

2910×25 (27)×0,90 mm

2.14.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth systems. The important factor for selection of the tooth system is the length of the cutting channel with respect to the size of the product.

1. *Constant tooth system* – the saw band has a constant tooth pitch all over its length. This type is suitable for cutting solid materials.
2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibrations of the saw band, increases service life of the saw band and quality of the cut.

BOMAR recommends variable tooth system for its band saws.

In the table below the type of the tooth system depending on the sizes and profile of the cutting material is advised.

Footnotes:

Z_pZ – teeth number on one inch S – tooth with zero angles of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:

32 S – number „32“ means 32 teeth per inch (constant tooth system), letter „S“ marks teeth with zero angle with respect to the band.

4–6 K – number „4–6“ means 4 to 6 teeth per inch (variable tooth system); letter „K“ marks teeth with positive angle with respect to the band

2.14.3. Saw band running-in

For reaching a full lifespan of the band we recommend performing a running-in.

Running-in: Perform a cut with the frame lowering speed at 50%. If vibrations occur increase or decrease the band's speed. When cutting large pieces run the band for approximately 15 minutes.












When the band has been run-in, increase the lowering speed of the arm to normal. The running in of the saw band avoids micro chips on the cutting edges of a new saw band ensuing from first excessive stress. This would decrease its lifespan substantially.



Note:
Run-in reground saw bands too.

The optimal running in of the saw band produces ideal rounded cutting edges and therefore the conditions for an optimal service life are met.

2.15. Table for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of selected profile. When cutting more pieces of the selected profile (bundle), you must double the corresponding wall thickness of the profile to get an accurate estimation (i.e., wall thickness equates to $2 \times S$). There are constant and variable tooth systems in the table.						
Size of the wall S [mm]	Tooth system ($Z_p Z$) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10-14 S	10-14 S
4	24 S	14 S	10-14 S	10-14 S	8-12 S	8-12 S
5	18 S	10-14 S	10-14 S	8-12 S	6-10 S	6-10 S
6	18 S	10-14 S	8-12 S	8-12 S	6-10 S	6-10 S
8	14 S	8-12 S	6-10 S	6-10 S	5-8 S	5-8 S
10	-	6-10 S	6-10 S	5-8 S	5-8 S	5-8 S
12	-	6-10 S	5-8 S	5-8 S	4-6 K	4-6 K
15	-	5-8 S	5-8 S	4-6 K	4-6 K	4-6 K
20	-	-	4-6 K	4-6 K	4-6 K	3-4 K
30	-	-	-	3-4 K	3-4 K	3-4 K
50	-	-	-	-	-	3-4 K
Size of the wall S [mm]	Tooth system ($Z_p Z$) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10-14 S	10-14 S	8-12 S	6-10 S	5-8 S	5-8 S
3	8-12 S	8-12 S	6-10 S	5-8 S	4-6 K	4-6 K
4	6-10 S	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K
5	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K	3-4 K
6	5-8 S	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K
8	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K	3-4 K
10	4-6 K	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K
12	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K
15	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K
20	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K	2-3 K
30	3-4 K	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K
50	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K
75	-	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K	0,75-1,25 K
100	-	-	1,4-2 K	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
150	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
200	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
SOLID MATERIAL ($D = \text{mm}$)						
						
Constant tooth system		Variable tooth system				
length of the cut D	tooth system ($Z_p Z$)	length of the cut D	tooth system ($Z_p Z$)			
to 3 mm	32	to 30 mm	10-14			
to 6 mm	24	20-50 mm	8-12			
to 10 mm	18	25-60 mm	6-10			
to 15 mm	14	35-80 mm	5-8			
15-30 mm	10	50-100 mm	4-6			
30-50 mm	8	70-120 mm	4-5			
50-80 mm	6	80-150 mm	3-4			
80-120 mm	4	120-350 mm	2-3			
120-200 mm	3	250-600 mm	1,4-2			
200-400 mm	2	500-3000 mm	0,75-1,25			
300-800 mm	1,25					
700-3000 mm	0,75					

In spite of the proposals above, consider your supplier's recommendations and ask him for professional advice even though the manufacturers will often recommend their own saw bands.

3. **Ovládání stroje / Machine control / Bedienung der Maschine**

3.1. Starting the saw

- » • Turn on the main switch of the ban saw. It is located on the switchboard of the control panel.




- Switch on the safety circuitry – button no. 10 on the control panel

Switching on of the safety circuits is indicated by a lit orange control light on button no. 10.

Without the safety circuits switched on it is impossible to start any of the machine regimes.

3.2. Control panel


3.2.1. Ergonomic 290.250 GAC without frequency converter



C	C button It is used for deleting of the set value.
E	E button It is used for confirming of the set value.
F1	F1 – Functional button Button function is described below in the text.
F2	F2 – Functional button Button function is described below in the text.
F3	F3 – Functional button Button function is described below in the text.
F4	F4 – Functional button Button function is described below in the text.
0	Switch off the band engine
1	Feeder to the forward position
2	Clamp the feeding vice

3	Clamp the main vice
4	Lift the saw arm up
5	Switch on the band engine
6	Feeder to the rear position
7	Open the feeding vice
8	Open the main vice
9	Lower the saw arm down
10	Switch on the safety circuit Switch on the safety circuit by pressing button.
11	Cooling system selection You can select from three possibilities:  Cooling with Microniser 0 Without cooling  Cooling with water
12	Mode selection You can select from three possibilities:  Manual mode 0 Resting state (service menu)  Automatic mode
13	START button It starts the cutting cycle.
14	STOP button It stops the cutting cycle.
15	TOTAL – STOP button Shutting the machine down in emergency!
16	Throttle valve Adjust the speed of the arm sinking to the cut by throttle valve. Notice: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.
17	Display It appears the actual operating mode and it allows the dialogue with operator.

3.2.2. Ergonomic 290.250 GAC– with frequency converter



C	C button It is used for deleting of the set value.
E	E button It is used for confirming of the set value.
F1	F1 – Functional button Button function is described below in the text.
F2	F2 – Functional button Button function is described below in the text.
F3	F3 – Functional button Button function is described below in the text.
F4	F4 – Functional button Button function is described below in the text.
0	Switch off the band engine
1	Feeder to the forward position
2	Clamp the feeding vice
3	Clamp the main vice
4	Lift the saw arm up
5	Switch on the band engine
6	Feeder to the rear position

7	Open the feeding vice
8	Open the main vice
9	Lower the saw arm down
10	Switch on the safety circuit Switch on the safety circuit by pressing button.
11	Cooling system selection You can select from three possibilities:  Cooling with Microniser  Without cooling  Cooling with water
12	Mode selection You can select from three possibilities:  Manual mode  Resting state (service menu)  Automatic mode
13	START button It starts the cutting cycle.
14	STOP button It stops the cutting cycle.
15	TOTAL – STOP button Shutting the machine down in emergency!
16	Frequency converter Turn to change the speed of the saw band
17	Governing valve Adjust the speed of the arm sinking to the cut by governing valve. Notice: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.
18	Display It appears the actual operating mode and it allows the dialogue with operator

3.3. Referencing

" MODE SELECTION "

" Mode select. Switch "

" is in position '0' "

"<REFER> <SERVICE>"




1. Press button **F1**, enter to menu: Reference.

" AUTOMATIC SETUP OF "

" REFERENCE POSITION "

" FEEDER "

" <START> "



2. Press button **F2**. Feeder drives to the reference position.

" REFERENCE POSITION "

" FEEDER "

" SET CORRECTLY "

" <OK> "



3. As soon as the notice "Feeder reference position is set correctly" appears on the display, press button **F2**. Reference position is set.

3.4. Semi-automatic cycle

It is possible to perform individual cuts in semi-automatic mode. Setting of the desired length is done semi-automatically.

1. Turn switch **12** into position .
2. Open the main and feeding vice with buttons **7** and **8**.
3. Insert material into the feeding vice.
4. Clamp the material with button no. **2** in the feeding vice.
5. With buttons **1** and **6** move the material into the desired length you want to cut.
6. Clamp the material in the main vice with button no. **3**.
7. Choose the type of cooling using switch no. **11**:

	Microniser cooling(should it be installed)
0	No cooling
	Water cooling

8. Now press the **START** button. The saw will cut the material.
9. After the cut is finished the saw arm will move into the upper position and the **START** button begins to flash. Now you can remove the cut material.

3.4.1. Cycle interruption

1.	Press the STOP button (no.14 – control panel) – the saw will interrupt the cut and the arm moves into the starting position, the saw band drive is stopped.
2.	Press the emergency TOTAL STOP button (no. 15 – control panel) in a case of emergency! The safety circuit is disengaged. The saw band drive is stopped as well.

3.5. Automatic cycle programming

The band saw allows preset and store 10 programmes. Each of the programs has 20 pre-selections.

You can change or clear the adjusted pre-selection in the stored program. You can insert the new pre-selection.

Definition explain:

Pre-selection is programme part, which includes the length of blank and pieces number of the set length.

Program consists of 20 pre-selections and it is performed during automatic cycle.

3.5.1. Program creation

```
" STEP No.:1 from 20 "  
" Length:    0.0 mm "  
" Pieces:    0 pcs."  
"<BACK>  <NEXT>  <-FN->"
```

1. Adjust the length of blank. Press button **F2**.



```
" STEP No.:1 from 20 "  
" Length:    0.0 mm "  
" Pieces:    0 pcs."  
"<BACK>  <NEXT>  <-FN->"
```

2. Adjust the pieces number. Press button **F2**.



```
" STEP No.:2 from 20 "  
" Length:    0.0 mm "  
" Pieces:    0 pcs."  
"<BACK>  <NEXT>  <-FN->"
```

3. Pre-set the other pre-selections by repeating points 1 and 2.



```
" STEP No.:3 from 20 "  
" Length:    0.0 mm "  
" Pieces:    0 pcs. "  
"<BACK>  <NEXT>  <-FN->"
```

4. Set „0” to the length and pieces number on the program end.



3.5.2. Program storing

```
" STEP No.:3 from 20 "  
" Length:      0.0 mm "  
" Pieces:      0 pcs."  
"< BACK> <NEXT> <-FN->"
```



1. Press button **F4**.

```
" EXTENDED EDITING: "  
" 1 = Step           "  
" 2 = Memory         "  
"<BACK>              <DONE>"
```



2. Press button **2** to enter to menu: Memory.

```
"***      MEMORY      ***"  
"F1 = Load program  "  
"F2 = Save program   "  
"                   <BACK>"
```



3. Press button **F2** to store the program.

```
"***      MEMORY      ***"  
" Rewrite mem. No:  X  "  
"                   "  
"<BACK>  <OK>         "
```



4. Set the memory number (**0-9**), where you want to store the program. Press button **F2**.

```
" Cutting program was"  
" successfully read  "  
" to memory No: X    "  
"                   <OK> "
```



5. Confirm the program storing by pressing button **F2**.

3.5.3. Program selection

```
" STEP No.:3 from 20 "
```

```
" Length:      0.0 mm "
```

```
" Pieces:      0 pcs."
```

```
"<BACK> <NEXT> <-FN->"
```



1. Press button **F4** to open the program.

```
" EXTENDED EDITING: "
```

```
" 1 = Step           "
```

```
" 2 = Memory         "
```

```
"<BACK>             <DONE>"
```



2. Press button **2** to entrance to menu: Memory.

```
"***      MEMORY      ***"
```

```
"F1 = Load program  "
```

```
"F2 = Save program   "
```

```
"                   <BACK>"
```



3. Press button **F1** to open the program.

```
"***      MEMORY      ***"
```

```
" Read memory No:  X  "
```

```
"                   "
```

```
"<BACK>  <OK>         "
```



4. Set the memory number (**0-9**), from which you want to open the program. Press button **F2**.

```
" Cutting program was"
```

```
" successfully read "
```

```
" from memory No: X "
```

```
"                   <OK>"
```



5. Confirm the program opening by pressing button **F2**.

3.5.4. Editing existing pre-selection

The length of blank or pieces number is possible to change this way:

" STEP No.:3 from 20 "
" Length: 200.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



1. Adjust the pre-selection, which you want to change by pressing buttons **F1** and **F2**.

" STEP No.:3 from 20 "
" Length: 200.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



2. Adjust the new length of the blank. Press button **F2**.

" STEP No.:1 from 20 "
" Length: 100.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



3. Adjust the new pieces number. Press button **F2**.

4. Now, you can change pre-selections by repeating points 2 to 4.

5. Store the program according to chapter: Program storing.

3.5.5. New pre-selection inserting

1. Open the program, in which you want to perform the change (see chapter: Program selection).
2. Select the pre-selection, where you want to insert the new pre-selection by pressing buttons **F1** and **F2**.

```
" STEP No.:3 from 20 "  
" Length: 200.0 mm "  
" Pieces: 2 pcs."  
"<BACK> <NEXT> <-FN->"
```



```
" STEP No.:3 from 20 "  
" Length: 200.0 mm "  
" Pieces: 2 pcs."  
"<BACK> <NEXT> <-FN->"
```



```
" EXTENDED EDITING: "  
" 1 = Step "  
" 2 = Memory "  
"<BACK> <DONE>"
```



```
"*** PROGRAM STEP ***"  
"F1= Insert step "  
"F2= Delete step "  
" <BACK>"
```



```
" STEP No.:3 from 20 "  
" Length: 0.0 mm "  
" Pieces: 0 pcs."  
"<BACK> <NEXT> <-FN->"
```



3. Press button **F4**.
4. Press button **1** to entrance to menu: Pre-selection.

5. Press button **F1** to insert the new pre-selection to the program. The other pre-selections are shifted.

6. Set the new length of the blank. Press button **F2**.

" STEP No.:1 from 20 "
" Length: 100.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



7. Set the new number of the pieces. Press button F2.

8. Now, you can insert the other pre-selections by repeating points 2 to 7.

9. Store the program according to the chapter: Program storing.

3.5.6. Clearing

Clear the adjusted pre-selection from the memory is possible this way:

" STEP No.:3 from 20 "
" Length: 200.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



1. Open the program, in which you want to perform the change (see chapter: Program selection).

2. Select the pre-selection, which you want to clear by pressing buttons F1 and F2.

" STEP No.:3 from 20 "
" Length: 200.0 mm "
" Pieces: 2 pcs."
"<BACK> <NEXT> <-FN->"



3. Press button F4.

" EXTENDED EDITING: "
" 1 = Step "
" 2 = Memory "
"<BACK> <DONE>"



4. Press button 1 to entrance to menu: Pre-selection.

**** PROGRAM STEP ****

"F1= Insert step "

"F2= Delete step "

" <BACK>"



5. Press button **F2** to clear the selected pre-selection from the program. The other pre-selections are shifted.

6. Now, you can clear the other pre-selections by repeating points 2 to 5.

7. Store the program according to chapter: Program storing.

3.6. Automatic cycle with trim cut

If you want to cut the material end before starting of the automatic cycle pre-set, you must continue this way:

1. Automatic cycle performs after pre-set finishing (or after stored program selection).

```
" STEP No.:3 from 20 "  
" Length:      0.0 mm "  
" Pieces:      0 pcs."  
"<BACK> <NEXT> <-FN->"
```



2. Press button **F4** to perform the automatic cycle.

```
" EXTENDED EDITING: "  
" 1 = Step           "  
" 2 = Memory         "  
"<BACK>              <DONE>"
```



3. Press button **F4**.

```
" SETTING THE HEIGHT "  
" OF ARM OVER MATERIAL "  
" for return after cut "  
"<BACK>              <DONE> "
```



4. An appeal for setting the height of the arm over material will appear.

The saw arm will return to set height after the cutting cycle has ended, if the option for ending the cycle with the arm in upper position was chosen (see Service menu, Cutting parameters).

Move the arm in desired height and confirm set height with pushing the F3 button; set height will be saved.

To cancel the setting push button F1; set height will not be saved.

```
" AUTOMATIC TRIM CUT "  
"                      "  
"<YES>                <NO>"
```



5. Press button **F1** <YES> for material trimming.

```
" AUTOMATIC TRIM CUT "  
" Press the START  "  
"                  "
```

6. Press button **START**. The saw makes the trim cut.

" AUTOMATIC TRIM CUT "
" Wait until "
" the cut is finished"

7. The report about course of cutting appears on the display during material cutting.

" AUTOMATIC CYCLE "
" Press button "
" START "
"

8. Press button **START** again. The saw makes the pre-set of automatic cycle.

9. Button **START** starts to blink after finishing of the automatic cycle. Now you can remove blanks.

3.7. Automatic cycle without trim cut

If you do not want to cut material end before starting of the automatic cycle pre-set, you must continue this way:

1. Automatic cycle performs after pre-set finishing (or after stored program selection).

" STEP No.:3 from 20 "
" Length: 0.0 mm "
" Pieces: 0 pcs."
"<BACK> <NEXT> <-FN->"

2. Press button **F4** to perform the automatic cycle.



" EXTENDED EDITING: "
" 1 = Step "
" 2 = Memory "
"<BACK> <DONE>"

3. Press button **F4**.



" SETTING THE HEIGHT "
" OF ARM OVER MATERIAL "
" for return after cut "
"<BACK> <DONE> "



4. An appeal for setting the height of the arm over material will appear.

The saw arm will return to set height after the cutting cycle has ended, if the option for ending the cycle with the arm in upper position was chosen (see Service menu, Cutting parameters).

Move the arm in desired height and confirm set height with pushing the F3 button; set height will be saved.

To cancel the setting push button F1; set height will not be saved.

" AUTOMATIC TRIM CUT "
"
"<YES> <NO> "



5. Press button **F4** <NO>, you do not want to trim the material.

" AUTOMATIC CYCLE "
" Press button "
" START "
"

6. Press button **START**. The saw makes the pre-set of automatic cycle.

7. Button **START** starts to blink after finishing of the automatic cycle. Now you can remove blanks.

3.7.1. Cycle interruption

1.

Press button **STOP** (button 14 – control panel) – the saw finishes the actual cut, arm lifts to the starting position and cycle is stopped.

2.

Press emergency button **TOTAL STOP** (button 15 – control panel) in emergency causes! The safety circuit is broken and saw band drive is broken too.

3.8. Service menu

3.8.1. Entrance to service menu

```
"  MODE SELECTION  "
" Mode select. Switch"
"  is in position '0'"
"<REFER>    <SERVICE>"
```

Turn switch (16) to position „0” and press button **F4** to entrance to service menu.



3.8.2. Vice parameters

By setting the time opening of both vices you can set, distance of the movable jaw vices opening, it means, the vice is opened any more, when the time is set longer. This function is used in case of the cutting of the rough materials. Is necessary to set longer vice opening, that the material will be released. Smooth materials has set shorter vice opening. Shorten the time of the cycle. Time of the vices opening is 1 second.

```
"1 = Clamp params.  "
"2 = Cooling params. "
"3 = Cutting params. "
"      <NEXT>  <DONE>"
```

1. Press button 1 to entrance to menu: Vice parameters.



```
" CLAMP OPENING TIME"
" <-]O[-> : x.x sec  "
" <-] [-> : x.x sec  "
"      <NEXT> <MENU>"
```

2. The feeding vice (upper row) – adjust the time, press button F2.

The main vice (lower row) – adjust the time, press button F4 for returning to main menu.



3.8.3. Cooling parameters

You can adjust the cooling stopping of the saw band after cutting finishing.

```
"1 = Clamp params.  "
"2 = Cooling params. "
"3 = Cutting params. "
"      <NEXT><DONE>  "
```

1. Press button **2** to entrance to menu: Cooling parameters.



```
"1 =In semi-automatic "
"2 =In automatic mode "
"3 =In both cases      "
"                        <MENU>"
```



```
"1=Top pos shutoff [1]"
"2=Bot.pos shutoff [ ]"
"3=No shutoff       [ ]"
"                  <MENU>"
```



2. Select, if you want to stop the cooling in semi-automatic or automatic mode, eventually in both modes.

Button **1** – adjust the cooling stopping of the saw band in **semi-automatic** mode.

Button **2** – adjust the cooling stopping of the saw band in **automatic** mode.

Button **3** – adjust the cooling stopping in the both modes.

3. Select the desired mode of cooling stopping. The selected item is marked with number.

Button **1** – stop the saw band cooling after cutting finishing in **top** position of the saw arm.

Button **2** – stop the saw band cooling after cutting finishing in **down** position of the saw arm.

Button **3** – **do not stop** the saw band cooling after cutting finishing.

4. Press button **F4**. The selected cooling type is stored and you can return to the previous menu

3.8.4. Cutting parameters

You can select, if you want to stop the saw band drive in upper or lower position of the saw arm, or do not stop the drive.

```
"1 = Clamp params  "
"2 = Cooling params "
"3 = Cutting params "
"                  <NEXT><DONE>"
```



1. Press button **3** to entrance to menu: Cutting parameters.

```
"1 =In semi-automatic "
```

```
"2 =In automatic mode "
```

```
"3 =In both cases "
```

```
" <MENU> "
```



```
"1=Top pos shutoff [1]"
```

```
„2=Bot.pos shutoff [ ]"
```

```
"3=No shutoff [ ]"
```

```
" <MENU> "
```



2. Select, if you want to adjust the drive stopping in semi-automatic or automatic mode, eventually in both modes.

Button 1 – adjust the drive stopping in **semi-automatic** mode.

Button 2 – adjust the drive stopping in **automatic** mode.

Button 3 – adjust the drive stopping in both modes.

3. Select the desired mode of the saw band stopping. The selected item is marked with number.

Button 1 – saw band stopping in **top** position after cutting finishing.

Button 2 – saw band stopping in **down** position after cutting finishing.

Button 3 – **do not stop** the saw band after cutting finishing.

4. Press button **F4**. The selected mode of band stopping is stored you can return to the previous menu.

3.8.5. Length units selection

You can select the length units: millimetres or inches.

```
"1 = Clamp params "
```

```
"2 = Cooling params "
```

```
"3 = Cutting params "
```

```
" <NEXT> <DONE> "
```



1. Press button **F2**. Shift to the next menu.

```
"1 = Machine params "
```

```
"2 = Language "
```

```
"3 = Swarf conve.mode"
```

```
"<BACK> <NEXT> <DONE> "
```



2. Press button **F2** – other. Shift to the menu: Units selection.

"F1= mm (1) inch (0) [1]"

" "

" "

" <MENU> "



3. Select the length units: millimetres or inches by repeated pressing button **F1**.

1 = millimetres

0 = inches

4. Press button **F4**. The selected parameters are stored and you can return to the previous menu.

3.8.6. Service menu closing

"1 = Machine params. " Press button **F4**. Service menu is closed.
 "2 = Language "
 "3 = Swarf conve.mode "
 "<BACK> <NEXT> <DONE>"




3.9. Band saw adjusting

3.9.1. Support roller

*If set length of the cut material is larger than 380 mm,
remove the support roller to avoid damaging the machine!*

In case the set length of feed (see chapter Automatic cycle) is smaller than 380 mm,
use the auxiliary roller to support the material.



Before insertion of the material fasten the roller so that even shorter pieces cannot fall through. Lay the supportive roller on the guiding rods in such a way, that the guiding rod runs through the fastening cube of the roller. Set the distance of the support roller and tighten the fastening cube with a star screw.



Do not try to slide the support roller if the star screw is not loosened.

3.9.2. Speed adjusting of the arm lowering

Set the speed of the arm lowering to the cut by control valve (position 16 – control panel).

Set the **lower** speed of the arm lowering to the cut by turning the switch **clockwise**.

Set the **higher** speed of the arm lowering to the cut by turning the switch **contra-clockwise**.

Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.9.3. Cutting speed setting Ergonomic 290.250 GAC – without frequency converter


The speed of the saw band can be set either to 40 m.min⁻¹ or 80 m.min⁻¹. The setting is performed by a turning switch located on an electric cupboard on the drive on the saw arm (see arrow).



3.9.4. Cutting speed setting Ergonomic 290.250 GAC – with frequency converter


The saw band speed can be changed continuously. The setting is as follows:

1. Turn the switch **12** into position  (semiautomatic cycle)
2. Set desired speed by the frequency converter knob **16**



3.9.5. Angular cut setting

Band saw **Ergonomic 290.250 GAC** could make angle cuttings varied from 0° to +60°. Angles 0°, 45° and +60° are set by means of the fixed stop.



Picture	How to
	1. Lift the saw arm by pressing button "Lift the saw arm" 2. Release the securing lever.
	3. Swivel the saw arm to the desired cutting angle.
	The scale is situated on the side of the turning console. 4. Check the adjustment according to the scale. 5. Tighten the securing lever again.

Angle setting to 45° and 60° using the default stops



If the angle is less than 45°, the pin does not have to be pulled out. Release securing lever only and turn the frame to the desired position.

If you want to set the angle at 45° using the default stop, do not pull out the pin and turn the frame to the default stop.

3.9.6. Optimal adjusting of the guide cubes span

In order to achieve smooth and precise cuts, the band guide cube should be positioned as close as possible to the material.



1. Release the splice plate of the left stretching listel.



2. Move the left part of the guide so that the edge of the left guide cube is as close to the material.

Attention!

If the cut material is thinner than 160 mm, check the distance of the left guide cube edge from the edge of the clamping table. Guide cube must not overlay the clamping table area and has to be positioned at least 10 mm from this area. If the cube touches the table, the machine cannot finish its cycle, because the saw arm cannot reach its lowest position.

Make sure that the guide cube does not collide with the vice. Guide cubes should be placed ca. 40 mm from the vice jaws.




3. Tighten the splice plate of the stretching listel.

3.9.7. Vice setting

The band saw does not have vices equipped with hydraulic cylinders with full lift, the vices have to be adjusted manually according to the diameter or width of the material to be cut.



1. Loosen the fastening levers of both vices.



2. Open both vices to insert the cutting material.




3. Adjust the vice jaws ca. 3 mm from the cutting material and tighten both clamping cubes of the vice cylinders.
4. Check that the distance between the material and the jaws match.

If the distance between the material and the jaw is too small, it may cause problems with the material feed (the friction of the jaws against material may occur).





3.9.8. Pressure adjusting to the cut

The band saw ergonomic is equipped with cutting pressure regulation on the right guiding cube.



Pressure setting is performed with regulation wheel on the guiding cube.

- Screw on the wheel – downfeed pressure is bigger.
- Screw off the wheel – downfeed pressure is smaller.

	<i>One visible neck</i> • Solid material over Ø200 mm
	<i>Two visible necks</i> • Plný materiál do Ø80 - Ø200 mm.
	<i>Three visible necks</i> • Pipes and shaped material with surface from 10 - 15 mm • I- shaped material from 200 - 280 mm • Solid material to Ø80 mm
	<i>Four visible necks</i> • Pipes and shapes material with surface to 10 mm • I - shaped material to 200 mm

3.9.9. Swarf conveyor operation

Attention!

The swarf conveyor is supplied to the band saw only by request.

In semi-automatic cycle

- Swarf conveyor **ON** – press together **F1** and **3** buttons.
- Swarf conveyor **OFF** – press together **F1** and **E** buttons.

In automatic cycle

- The swarf conveyor operation is adjusted according to chapter Service menu.

3.9.10. Upper pressure adjustment

Attention!

If the machine is equipped with upper pressure, bundle cutting is possible

1. Open both vices by pressing buttons *Feeding vice opening* and button *Main vice opening*.



2. Release levers of the vice cubes and open the vice to the maximum bundle width.



3. Release the clamping cube of the vertical clamping cylinder, pull the cylinder to the top position limit and tighten the clamping cube again.




4. Insert the first layer of the material, set the vices at a distance of 3 mm from material, and fasten the levers of gripping cubes.



5. Insert residual layers of the material. Release again the fastening cube of the vertical pushing cylinder and adjust its jaw to distance 3 mm from the material.
6. Fasten the clamping cube of the vertical cylinder.

Attention!

If the distance is too large, the machine displays „no material inserted“



7. Release the pressure roller and adjust it to press the bundle from the upper side on the feeder vice.

Make sure the roller is not too loose. The roller has to touch the material while moving; the material must be in contact with the roller and not move about freely.

Make sure the roller does not have too much pressure on it.

It is recommended to weld the layers together on the rear side during bundle cuts. Main switch must be switched off during welding.


3.10. Vkládání materiálu

- Nepohybujte se pod zdviženými břemeny
- Nevstupujte nikdy na válečkovou trať!
- Při upínání materiálu do svěráku materiál nepřidržíte ani s ním jinak nemanipulujte! Svěrák Vám může způsobit těžké zranění!

3.10.1. Volba manipulačního prostředku

- Používejte ke zvedání a přemísťování materiálu manipulační prostředky s dostatečnou nosností!
- Manipulovat s materiálem je možno pouze s vysokozdvizným vozíkem nebo použitím závěsných lan a jeřábu!
- Nepoužívejte vysokozdvizného vozíku nebo jeřábu v případě, že k tomu nemáte oprávnění!

3.10.2. Vkládání




Vkládejte materiál do svěráku tak, aby se po upnutí nemohl pohnout nebo vypadnout ze svěráku. Řezáte-li dlouhé kusy materiálu (např. tyče, trubky), použijte k jejich přisouvání k pásové pile válečkové tratě.

Přesvědčte se, zda je délka a šířka válečkové tratě dostatečná vzhledem k rozměrům materiálu, a zda je nosnost tratě dostatečná vzhledem k hmotnosti materiálu!


U kulatého materiálu dbejte na to, aby byl opřen minimálně o dva vertikální válečky a nemohl z válečkového dopravníku spadnout!

3.10.3. Řezání ve svazku



Pokud chcete řezat materiál ve svazku, uvádíme zde několik návrhů, jak materiál ukládat:

Ukládání kulatého materiálu do svazku: Dbejte speciálně u kulatého materiálu, aby tyče byly uloženy dle obrázku. Jestliže tyče uložíte jinak, může dojít k problémům při posuvu. Tyče se vůči sobě posouvají.



Doporučujeme materiál před řezáním ve svazku na konci svařit, aby se jednotlivé části svazku nemohli vůči sobě posouvat. **Pozor! Při svařování vypněte stroj pomocí hlavního vypínače! Magnetická pole při svařování by mohla poškodit řídicí systém.**

4. **Údržba stroje / Wartung / Machine maintenance**

4.1. Saw band dismantling

1. Set the arm lifting stop.
2. Lift the saw arm to the top position.



3. Remove the yellow safety cover(s) of the band. The covers are tightened with screws.



4. Dismantle the back cover of the arm. It is mounted with two M6 plastic head screws.



5. Loosen the holder of the brush and turn it away from the band so it does not hinder the dismantling of the band. It is fitted with one M6 hex bolt.



6. By turning the tightening star to the left loosen the stretching of the band.
7. Pull the saw band from the wheels.



8. After that pull out the band carefully from the guiding cubes.

4.2. Saw band installation



1. Prior to installation, clean the track wheels, guiding cubes and inner side of the arm thoroughly of all traces of chips and dirt. ***Keep in mind the teeth direction when installing the saw band.***



2. Insert a new saw band in the guide cubes. Make sure the saw band runs between both guiding rollers and that it is pushed all the way to the top.



- Put the saw band on both guiding wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Push the saw band as close to the rim as possible.



- Turn the tightening star to the right until you gently stretch the band.
- Now you can remove the plastic cover on the saw band.
- Mount the back cover.
- Adjust the brush to the saw band and tighten its holder screws to the saw arm.
- Mount the safety cover on the guiding lath of the band too.

4.3. Saw band stretching and inspection

Correct saw band stretching is one of the most important factors, which influences accuracy and saw band lifespan. Stretch the saw bands according to the band saw and the selected saw band type. Keep to the recommendation of your manufacturer.

Pilový pás Sägeband Saw band	Napětí pilového pásu Sägebandspannung Blade tension	Napětí pilového pásu PSI (pro Tenzomat) Sägebandspannung PSI (für Tenzomat) Blade tension PSI (for Tenzomat)
20 x 0,9 mm	160 N.mm ⁻²	23 500
27 x 0,9 mm	180 N.mm ⁻²	26 500
34 x 1,1 mm	210 N.mm ⁻²	30 500
41 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,6 mm	280 N.mm ⁻²	40 600
67 x 1,6 mm	290 N.mm ⁻²	42 000
80 x 1,6 mm	300 N.mm ⁻²	43 500

4.3.1. Saw band stretching

- After installation of the saw band stretch it gently, so it does not fall of the wheels.



- Mount the Tenzomat on the saw band and secure it with screws.

3. Stretch the saw band until it is stretched to the recommended value.


4.3.2. Saw band run inspection

If the band does not run correctly, following problems can appear:

- The band falls down from the wheels – the band or the protective cover of the band can be damaged.
- The band runs on the rim of the stretching wheel – the band or the rim of the wheel can be damaged.

Control procedure

1. Switch on briefly the saw band drive and then switch it off
2. Disconnect the saw from the electrical network.
3. Open cover of the wheels.



4. Check the position of the saw band on the both wheels.
 - If the distance between backside of the saw band and the wheel rim is **1 mm**, the setting is right.
 - If the distance is bigger than **1 mm**, or the saw band runs on the rim of the wheel, adjust the saw band.
5. Close cover of the saw band.

4.4. Adjustment

4.4.1. Saw band run adjustment

The saw band run is set with screw in the stretching cube on the saw frame. Optimal distance has been determined at **1mm**.



- Turn the screw to the right, the saw band closes to the stretching wheel rim
- Turn by screw to the left, the saw band departs from the stretching wheel rim

After setting check the saw band run again.

4.4.2. Hard metal guides adjustment

Hard metal guides adjustment is one of the most important criterions which influence cutting accuracy and saw band lifespan. Therefore it is essential to check that the adjustment of the hard metal guides is correct.



6. Tighten the positioning screw on the back side of guide cube so that the band cannot move.



7. Loosen the positioning screw slowly and at the same time check the clamping of the band. As soon as the band can be moved without resistance the hard metal guides are set correctly.
8. Make sure that the hard metal guides do not put up to much resistance against the movement of the band otherwise the lifetime of the saw band and drive will be decreased.

4.4.3. Setting of the guiding cubes

Cutting quality and saw band lifespan is also dependent on the guiding cubes adjustment. Therefore this adjustment has to be checked periodically.



1. Loosen both mounting screws on the guiding cube and push it carefully to the upper blunt edge of the band.

Make sure the saw does not bend; otherwise the cube will press against the band and damage it.

2. Fasten both tightening screws again.

Notice:

If the guide cube is correctly adjusted, the upper edge of the cube and the ruler are parallel.

4.4.4. Setting of angular stops

The setting of angular stops is to be checked periodically to avoid inaccurate slanting cuts.

There are two fixed stop with adjustable screws on the turning console of the machine (45°, 60°).

If you position the saw arm at a stop and measured angle does not precisely match the corresponding value, the block of the stop has to be adjusted.




1. Loosen the locking nut of the adjustable bolt.



2. Screw the adjustable nut in or out.



3. After setting the adjustable bolt tighten the locking nut again.



4. Check the angle setting with a protractor.

4.4.5. Adjusting the limit switch of the saw band stretching



After the saw band is replaced, the limit switch setting must be checked. If the limit switch is not set correctly, the band is stretched either too much or too little.

1. Stretch the band with help of the TENZOMAT to an optimal value.
2. Release the nut on the stop screw.
3. Start the band drive. Two scenarios may occur:
 - If the engine is switched on, but it does not run, turn the screw to the left until the engine starts to run
 - If the engine runs turn the screw to the right until it stops, then turn the screw shortly to the left until the engine starts running again
4. Fasten the stop screw with the nut and check the setting of the switch again.

4.4.6. Saw frame lower position stop adjustment

The lower stop limits the lowest position of the saw frame. This stop has to be checked at least once a month. If the lower stop is adjusted incorrectly, the loading surface of the table can be cut too deeply or the material will not be cut through completely.



1. Raise the saw frame to the upper position, so the adjustment screw can be manipulated with.
2. Release the nut of the adjusting screw.
3. Adjust the stop using the screw.
4. Fasten the adjusting screw with the nut again.
5. Set the limit switch of the lower arm position.

4.4.7. Adjustment of the limit switch of saw frame lower stop

If you have adjusted the lower stop of the saw frame, the limit switch adjustment inspection is required

Setting check

Lower the arm to the lowest position. If the arm is lying on the lower stop and the switch reacts, the setting is correct. In other case carry out the switch setting

Switch setting



1. Release the nut of the stop screw and screw in the stop screw.
2. Lower the arm to the lower stop and turn on the band drive.
3. Screw out the stop screw until the band drive stops.
4. Secure the screw with nut again and check the limit switch setting once more.

4.4.8. Setting of the feeder back position induction switch

If the feeder back position induction switch is not set correctly it can come to wrong function execution during the operation of the machine.

Therefore the setting of the induction switch is to be checked regularly.

The induction switch is screwed in a holder and tightened with two nuts. The holder is fastened to the lower side of the feeder cylinder.



1. Move the driver to the furthestmost position.
2. Unfasten the nuts on the induction switch and move the induction switch closer to the driver until a signal diode on the induction switch lights up (minimum distance of 0,5 mm)
3. Fasten the tightening nut carefully.
4. Check the setting of the switch by repeated movement of the driver.

4.4.9. Setting of the feeder front position induction switch

If the feeder front position induction switch is not set correctly it can come to wrong task execution during the operation of the machine.

Therefore the setting of the induction switch is to be checked regularly.



1. Move the driver to the utmost front position.
2. Unfasten the nuts on the induction switch and move the induction switch closer to the driver until a signal diode on the induction switch lights up.
3. Fasten the tightening nut carefully.
4. Check the setting of the switch by repeated movement of the driver.

4.4.10. Pressure switch adjustment


*Take extra precaution when working on hydraulic system!
There is still residual pressure in the hydraulic system after it has been shut down!*

The pressure switches for vice and feeder are located in the block of the hydraulic aggregate.



For setting the pressure switch of the vice (marked with yellow band **SQ xx**) or setting the pressure switch of the feeder (yellow band **SQ 1**) following steps are necessary:

1. Take off the rubber cover of the pressure switch (carefully – outlets must not be broken).
2. Set the sensitivity of the pressure switch by means of a small screwdriver.
3. Turn the screwdriver to the left to increase the sensitivity of the switch.
Turn screwdriver to the right to let the switch activate at a higher pressure.




Check limit switches adjustment.

- **The vice is clamped** – The signaling diode is lighted
- **The vice is opened** – The signaling diode is not lighted
- **The vice is moving** – The signaling diode is neither lighted nor blinking
 - After adjusting the pressure switch put the rubber cover back into place

4.4.11. System pressure adjustment

- Take off the black cover of the pressure valve.
- Release the nut of the pressure valve.



- Turn the pressure valve clockwise to increase the pressure.
- Turn the pressure valve anticlockwise to decrease the pressure.

Set the pressure by means of the pressure valve and check it on manometer. After adjusting the pressure tighten the nut again.

4.4.12. Adjustment of the feeder cylinder step setting securing cube

The locking lever is set correctly by the manufacturer but if the cylinder is not secured an adjustment of the clamping cube is necessary.

Check the functionality of the cube regularly, if the cylinder is not tightened correctly the feed will operate inaccurately.



1. Loosen the tightening screw of the locking lever until the lever can move freely.




2. Turn the lever to the left as far as possible and tighten the tightening bolt again.



3. Secure the cube with the lever and carry out a control.

4.4.13. Setting of the throttle valve

1. Turn off the main switch of the machine. Let the saw arm sink to the lower position. Close the throttle valve gently.



2. The grub screw (pos. A) must be near the stop screw (pos. B) when the valve is completely closed.




3. In the opposite case loosen the grub screw with a hex key and adjust the knob accordingly. Tighten the grub screw again.
4. Turn on the machine and check the function of the throttle valve.

4.4.14. Brush adjustment

Adjustment of the brush has essential influence on cutting performance, saw band lifespan, lifespan of the wheels and hard metal guides and cutting accuracy. Therefore the brush has to be checked every shift.



1. Loosen the mounting screws of the brush until the brush can be adjusted.



2. Adjust the brush to the saw band. The brush must touch the teeth of the saw band.
3. Tighten the mounting screws.

4.4.15. Setting of the turning lever securing cube

1. The securing cube is set correctly by the manufacturer but after multiple adjustments of cutting angle the cube has to be corrected. Check the functionality of the securing cube regularly, if the console is not tightened properly, it will come to inaccuracies during cutting.



1. Loosen the securing screw of the lever until the lever can be moved with freely.



2. Turn the lever to the left until it reaches the stop and tighten again firmly the securing screw.
3. Secure the console with the lever and check it.



4. If the setting is done correctly, the arm cannot be turned with and the locking lever is not touching the right side of the slit in the base.

4.5. Cooling agents and chip disposal

4.5.1. Coolant inspection

The state of the cooling agent has a significant influence on cutting quality and lifespan of the machine. Lifetime of the cooling liquid is 1 year, after that we recommend to change the cooling liquid. This time is dependent on the degree of pollution of the cooling liquid (especially with extraneous oils) and on other factors.

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
• use of contaminated water • oil contamination from the outside (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration	• corrosion protection is diminished • lubrication decreases • microbial attack is more likely	• the cooling ability is decreased • foam production increases • emulsions stability deteriorates • sticky residue develops



The coolant tank can be found in the base of the saw.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory and can't be improved, the cooling liquid must be replaced.

Check the state of the cooling agent accordingly to following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	check concentration, add water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by senses	unpleasant smell	good ventilation, add biocides or replace coolant
Contamination	daily	by senses	visible oil leaks, sludge, fungi	surface cleaning, fix leaks, add biocides or fungicides; clean the system with a cleanser* prior to the coolant replacement

Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquire the supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, fix with defoamer

* According to manufacturer's instructions

4.5.2. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Put the chips into a watertight container. Make sure that the container does not leak, because even after a long dripping time, the chips still contain coolant residues.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micronisation device, the chips must also be handed over to a disposal company.

4.6. Gearbox oils and greases

4.6.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox.



Use oils with DIN 51517 specification for the gearboxes. Select the ISO VG viscosity class according to the original oil.

Attention:

When replacing the oil, use oils recommended by BOMAR or oils from other manufacturers, which have comparable parameters.

Do not forget, that mineral and synthetic oils must not be mixed!

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Ergonomic 290.250 GAC	Paramo PP7	2,0 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
OMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.6.2. Lubrication greases

For lubrication we recommend using lithium based class NGLI-2 saponified grease. Different greases are mixable, if their oil bases and density classes are identical.

Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energrease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.6.3. Lubrication

There are several spots on the machine, which are necessary to be greased periodically to secure a correct function of the machine.



Upper pin of the lifting cylinder –drip oil 1x a week.

4.6.4. Hydraulic oils

We recommend replacing the hydraulic oil once every 2 years, because the oil properties can deteriorate and may not meet the requirements of the hydraulic unit. If the hydraulic system is equipped with a filter (2SF 56/48-0,063), replace the filter as well.

Use oils with DIN 51524-HLP, ISO 6743-4 specification and viscosity class ISO VG 32 for hydraulic aggregates.

Note:

When replacing the oil, use oils recommended by BOMAR or oils from other manufacturers which have comparable parameters. Do not forget, that mineral and synthetic oils must not be mixed!

Comparative table of hydraulic oils:


Manufacturer	Type	Manufacturer	Type
Agip	Oso 32	Ina	Hidraol 32 HD
Aral	Vitam GF 32	Klüber	Lamora HLP 32
Avia	Avilub RSL 32	Mađarsko	Hidrokomol P 32
Benzina	OH-HM 32	Mobil	Mobil DTE 25
BP	Energol HLP 32	OMV	HLP 32
Bulharsko	MX-M/32	Polsko	Hydrol 30
Castrol	Hyspin AWS 32	Rumunsko	H 32 EP
Čepro	Mogul HM 32	Rusko	IGP 30
DEA	Astron HLP 32	Shell	Tellus Oil 32
Elf	Elfolna 32	Sun	Sunvis 846 WR
Esso	Nuto H 32	Texaco	Rando HD B 32
Fam	HD 5040	Valvoline	Ultramax AW 32
Fina	Hydran 32		

4.6.5. Inspection of the hydraulic oil state

Check the state of the hydraulic oil. The oil level must be in the middle of both watermarks.



If needed, add hydraulic oil. Always use a filter (10 μ m or finer) when pouring the hydraulic oil into the unit to avoid contaminating the hydraulic system with impurities, which can cause malfunctions.



4.7. Machine cleaning


Clean the machine off cooling agent and impurities after every shift. Conserve the guiding surfaces, **mainly**:

- Guiding of the clamping jaws of the main and feeding vice.
- Guiding of the feeder.
- The loading surface of the main and feeder vices and the area below them.
- Threaded rod of the main and feeding vice.


4.8. Worn pieces replacement

4.8.1. Hard metal guides replacement


If the hard metal guides cannot be adjusted, they have to be replaced.



1. Remove the cooling agent hosepipe and dismantle the saw band and saw band guiding cube.



2. Fasten the guiding cube in a vice and screw out the fastening screws of both hard metal plates.



3. Screw out the adjustment screw of the adjustable guiding plate out of the cube, until it cannot be seen from the inside.
4. Insert new hard metal guides, screw the tightly and mount the guiding cube to the guiding lath.
5. Mount the saw band, set the hard metal guides and guiding cube.

4.8.2. Worn brush replacement

If the chip removing brush is so worn, that it does not fulfill its function, it must be replaced.

1. Release the nut on the brush, exchange the worn brush for a new one and screw in the nut.




2. Adjust the brush to the saw band.


4.8.3. Saw band guiding rollers replacement

If the saw band is not sufficiently guided by guiding rollers and/or if the rollers are visibly worn, they should be replaced.

Attention! Guiding rollers must be replaced together on both guide cubes!




1. Remove the cooling agent hosepipe and dismantle the saw band and guiding cube.




2. Grip the guide cube in a vice and screw out both fastening screws of the eccentrics.



3. Pull both guiding rollers from the eccentrics.




4. Put new guiding rollers on the eccentrics and mount the eccentrics to the guide cube.



5. Now insert a test piece of saw band (cca 15 - 20 cm) into the guide cube. Adjust both eccentrics so that the band runs in the middle of the milled groove. The groove is located between both eccentrics. Guide rollers must not press too much against the band but must be able to spin freely. Optimal distance between the band and guiding roller is 0,05 mm.
6. Install the cube on the guiding lath. Install the saw band and adjust the guiding cubes.

4.8.4. Stretching wheel replacement

1. Dismantle the saw band.



2. Screw off the stretching wheel fastening screw and remove the washer.
3. Screw the auxiliary screw onto the shaft of the stretching wheel.



4. Install a three-legged puller on the stretching wheel and pull the wheel carefully off the shaft.



5. If the lower bearing stays on the shaft, pull it off the shaft with a two-legged puller. Check both bearings; eventually replace them with new ones.



6. Insert a retaining ring into the opening of a new stretching wheel.



7. Insert a bearing into the hole in the wheel and push it to the retaining ring.



8. Clean the shaft and grease it. Install the new stretching wheel on the shaft.



9. Install a distance ring on the shaft and push it to the lower bearing.



10. Install a second bearing on the shaft and push it to the distance ring.



11. Insert a washer and fasten the stretching wheel firmly with a bolt.
12. Install the saw band. Wheel replacement is done.

4.8.5. Driving wheel replacement

1. Dismantle the saw band.



2. Screw out the fastening bolt of the driving wheel and pull off the washer.
3. Screw an auxiliary screw into the driving shaft.




4. Install a three-legged puller on the driving wheel and pull it carefully off the shaft.



5. Check, whether the spring and the driving shaft are damaged. Contact your supplier for parts replacement.



6. If the shaft and the spring are sound, clean them, grease them and install them on the driving shaft.



7. Insert a washer and fasten the driving wheel firmly with a bolt.
8. Install the saw band.

4.8.6. Cooling pump replacement


Only a qualified worker can carry out the connection! High-voltage accident may have fatal consequences.




1. Pull out the cooling agent tank from the machine base as far as possible.




2. Remove the hosepipe leading the cooling agent from the connection on the pump and unscrew the connection from the cooling pump. Unscrew the four screws on the cooling pump flange and pull out the pump from the metal sheet holder.



3. Remove the cover of the pump terminal switchboard. Disconnect the 4 terminal connectors of the input cables. Input cables are identified by red clamps.



4. Loosen the cable bushing and pull the cable out from the pump.



5. Dismantle the new pump's switchboard cover. Pull the cable through the bushing and connect it to the terminals.



6. Screw in the bushing of the cable and the cover of the terminals. Mind the correct sealing! Seal the coolant hose connection with a teflon band and screw it in again. Plug in the coolant hose, mount the pump on the metal sheet holder and fix it with screws.

5. **Závady / Störungen / Troubleshooting**

5.1. Mechanical malfunctions

Problem	Possible causes	Repair
1. Slanting cut	Wrongly adjusted hard metal guides	Set according to the chapter „Machine maintenance“
	Worn hard metal guides	Replace according to the chapter „Worn pieces replacement“
	Wrongly adjusted cubes of the saw band guiding	Set according to the chapter „Machine maintenance“
	Worn bearings of the saw band guiding	Replace according to the chapter „Worn pieces replacement“
	Wrongly adjusted swarf brush	Set according to the chapter „Machine maintenance“
	Worn swarf brush	Replace according to the chapter „Worn pieces replacement“
	Insufficient saw band stretching	Increase the saw band stretching and set the limit switch
	Wrongly chosen tooth system of the saw band	Replace the saw band; follow the instructions of the manufacturer for new saw band choice
	Worn saw band	Replace the saw band
	Wrongly leveled roller conveyor	Adjust the roller conveyor
	Dirty feeding board	Cleanse the feeding board from debris, chip and residue material
	Guiding rail and guiding cube are loosened	Tighten the guiding rail
	Guiding rail and cube are too far from the material	Set the guiding cube to the material
	Too fast rate of movement into the cut	Lower the material speed of descent of the arm
	Unexpected oscillation in material quality	Adjust the cutting parameters and feeding speed according to the material
2. The cut is not cut upon desired angle	Securing lever is loosened	Check the securing lever efficiency and carry out its adjustment according to chapter

Problem	Possible causes	Repair
		„Machine maintenance“
	Set angle does not match the cutting angle	Check the angle adjustment with a protractor and if need be adjust it according to chapter „Machine maintenance“
	Insufficient saw band stretching	Stretch the saw band and set the limit switch according to chapter „Machine maintenance“
	Guiding cube holder and guiding cube are loosened	Fasten the guiding holder and the cube
	Dirt between material and clamping jaw	Cleanse the material and mating jaw
3. Short lifetime of the saw band	Insufficient saw band stretching	Increase the tightening of the saw band and set the sensor of saw band tightening according to chapter „Machine maintenance“
	Worn swarf brush	Check the swarf brush condition and replace it in case of excessive wear as described in chapter „Worn pieces replacement“
	Wrongly adjusted swarf brush	Check swarf brush adjustment, set it according to chapter „Machine maintenance“
	Overly stretched saw band	Lower the stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Machine maintenance“
	Wrongly adjusted hard metal guides	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Machine maintenance“
	Worn hard metal guides of the saw band	Check the condition of the hard metal guides and if they are too worn, replace hard metal guides according to chapter „Worn pieces replacement“
	Worn saw band guide bearings	Check the guiding bearings and if you notice any excessive damage, replace them according to chapter „Worn pieces replacement“

Problem	Possible causes	Repair
		replacement"
	Wrongly adjusted guiding cubes of the saw band	Set the guiding cube according to chapter „Machine maintenance“
	Wrongly adjusted speed of descent of the arm and saw band speed	Adjust the descending speed and speed of the saw band according to values published by the saw band manufacturer
	Different material quality	Adjust the speed of descent and speed of the saw band according to desired material (perform a test cut)
	Low quality saw band	Replace the saw band (contact your local accessory supplier for more information)
	Wrongly chosen saw band tooth system	Replace the saw band, keep to the instructions of the manufacturer
	Wrongly adjusted run of the saw band	Check the space between the top of the saw band and driving wheel Adjust the tracking as described in chapter „Machine maintenance“ if need be
4. Insufficient cut output	Worn saw band	Replace the saw band, keep to the instructions of the manufacturer
	Wrong saw band tooth system	Replace the saw band, keep to the instructions of the manufacturer
	Wrongly adjusted speed of descent of the arm and saw band speed	Adjust the descending speed and speed of the saw band according to values published by the saw band manufacturer
5. The cut is not finished	Wrongly adjusted lower stop of the saw frame	Check the stop setting and adjust it
	Stop surface is messy	Cleanse the stop surface of the limit switch of debris and residue material
6. Regulation valve cannot be turned	Metal chips between the valve and the panel	Chips must be removed, then put an O Ring $\varnothing$ 10x2 mm onto the throttle valve shaft

Problem	Possible causes	Repair
	There are metal chips inside the valve	Valve must be cleaned or changed
7. Saw band drive cannot be started	Pressure switch is wrongly adjusted	Set the pressure switch according to chapter „Machine maintenance“
	Pressure switch is defective	Replace defective parts of the pressure switch
8. Saw bands tend to rupture	Wrongly adjusted band guiding (hard metal and bearings)	Hard metal pieces and bearings must be adjusted according to „Machine maintenance“
	Bearings of guiding cubes are worn out (rolling elements are damaged or outside ring of bearing has conical form)	Bearings of guiding cubes must be replaced Bearings must be adjusted according to operating instructions
	Wrong adjusted geometry of the stretching wheel	Adjust the distance of the saw band to approx. 2 mm according to the operating instructions
	Looseness in the lifting cylinder mounting	
	Worn out pin of the upper or bottom holder of the lifting cylinder	Exchange the upper or bottom holder of the lifting cylinder
9. Damage tooth system of the saw band	Geometry of hard metal guiding cubes is wrongly adjusted	Hard metal guiding cubes must be adjusted
	Bearings of guiding cubes are worn out	Bearings of guiding cubes must be replaced
10. The saw is undercutting	Grooving on the driving wheel is worn out	Driving wheel must be replaced
11. Cleansing of the saw band is not functional	Elastic wheel of the brush drive is worn out	Elastic wheel of the brush must be replaced
	The shaft of the brush drive is rusted	The shaft of the brush must be cleaned and oiled
	The brush position and the brush cover is adjusted incorrectly – the cover prevents the brush from turning	The brush cover must be repositioned, in order for the brush to be able to turn
12. The saw arm periodically rises and descends a few millimeters during the cut; this shortens	Backlash in driving wheel mounting on the shaft	Replace following parts: the driving shaft for a longer one, bearings, distance ring, driving wheel, spring, two covers on the forehead of the shaft +

Problem	Possible causes	Repair
the lifetime of the saw band considerably		screws
	Worn channel for spring	

5.2. Electrical malfunctions

Problem	Possible causes	Repair
1. Machine is not possible to start	No voltage in the socket	Line voltage must be checked
	Overload relay is defective (thermal protection)	Each FA overload relay's condition (on/off) must be checked
	Limit switch of either saw band stretching, band cover or saw arm is not closed	Check the saw band stretching and covers
2. When the cut is finished, the frame is not raised	Bottom limit switch is adjusted wrongly	Bottom limit switch must be adjusted according to chapter ADJUSTING
	A malfunction in the hydraulic (pneumatic) system The HYTOS (BOSCH) magnetic valve is not working	Function of magnetic valve must be checked, valve must be switched on, and voltage across its terminals and coil must be checked
3. Electric motor and pump are without voltage There is no voltage between the contactor and thermal protection	Wrong contactor	Replace the contactor of the engine
4. The speed indicator of the saw band is not functional	Sensor of speed is not adjusted	Sensor of speed must be adjusted
	Defective display	The display must be replaced
	Defective sensor – diode of indicator speed does not light	Sensor must be changed and adjusted
5. Occasional switching off of the hydraulic aggregate MA3 engine protection	Too big working pressure in the hydraulic system	Service engineer must reduce the pressure in hydraulic system
6. Hydraulic aggregate is switched on but the saw arm or the main vice can't be moved	Wrong connection of electrical supply The electrical phases are connected conversely	The phases must be switched Only service engineer is allowed to do this
7. Cooling is not active	Lack of cooling agent	Refill the tank with cooling agent
	Thermal relay is defective	Replace the thermal relay
	Input hosepipe is broken or clogged	Check the cooling circuit and eventually cleanse the cooling

Problem	Possible causes	Repair
		system
	Cooling pump protection is defective	Check the protection of the cooling pump and change it if need be
	Cooling pump is defective	Replace the cooling pump

5.3. Hydraulic malfunctions

Problem	Possible causes	Repair
1. Hydro generator is not supplying oil	Reversed rotation	Check the correct connection of each phase Reconnect the electrical phases properly
	Shortage of oil in the tank	Add hydraulic oil
	Oil viscosity does not correspond to the prescribed viscosity value	Change hydraulic oil
	Hydro generator malfunction	Call service
	Wrong power supply connection	Check the correct connection of each phase Reconnect the electrical phases properly
2. Hydraulic oil contains bubbles	Hydraulic circuit is not adequately bled	Bleed the hydraulic circuit
	Low level of oil	Add hydraulic oil
	The hydro generator gasket is damaged	Call service
3. Increased mechanical noise	Damaged clutch of the drive	Call service
	Damaged or destroyed motor bearings	Call service
	Air intake	Check for leaks
4. Low pressure, pump supplies oil	Failure on the safety valve	Wrong settings Check the settings and adjust the safety valve
	Wear of the hydro generator	Call service
	External or internal leakages	Call service
5. Hydro generator is seized	Damage by solid particles in oil	Perform oil filtration or call the service
	Not keeping the prescribed viscosity of oil	Change hydraulic oil
	Wrong type of oil	Change hydraulic oil
	Exceeded lifespan of the pump	Call service
6. Overheating oil	Cooler malfunction	Check the cooler function or call service
	Wear of the pump, energy is converted into heat	Call service
7. Hydraulic valve	Electromagnet has no signal (voltage)	Perform recheck

Problem	Possible causes	Repair
cannot be readjusted	broken supply lines	
	Electromagnet coil burnt	Replace coil – Call service
	The slider of the switchboard slackens	Replace slider – Call service

6. **Schémata / Schemas / Schematics**

- 6.1. Elektrické schema /Elektroschema Wiring diagrams
- 6.1.1. Ergonomic 290.250 GAC without frequency converter
3x400V+PE, 50Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Ergonomic 290.250 GAC ES-2300-201/202-V1.1 Wiring diagram 3x400V + PE / 50Hz									
 BOMAR s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Machine: Ergonomic 290.250 GAC		Uvodní stránka / Start page / Startseite		Číslo dok./Doc. No./Anzahl der Dokumenten.: ES-2300-201/202-V1.1 Napájení/Power supply/Einspeisung: 3x400V + PE / 50Hz Zeměnění/Protecting /Not verschaltet: I'm Kodak Datum/Date/Datum: 22.4.2016		Ver/Pages/ Seiten: 1 1 21	

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	22.4.2016
2	Obsah / Content / Inhalt	20.5.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
4	Umístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	25.4.2016
5	Ovládací panel na rozvaděči / Control panel / Bedienpult	25.4.2016
6	Silová část / Power part / Netzteil	25.4.2016
7	Připojení pohonů / Drivings connection / Antriebsanschluß	25.4.2016
8	Propojení napájecích obvodů / Feeding circuits / Stromversorgungsgebiete	25.4.2016
9	Sýkače / Contactors / Schütze	25.4.2016
10	Signály spouštěčů, klávesnice / Signal of shields, keyboard / Schaltersignal, Tastatursignal	25.4.2016
11	Hydraulika / Hydraulics / Hydraulik	25.4.2016
12	Signály koncových spínačů / Signals of limit switches / signale der Endschalter	25.4.2016
13	Připojení modulů / Modules connection / Anschluss der Modul	25.4.2016
14	Bezpečnostní obvod / Safety circuit / Sicherheitsschaltung	25.4.2016
15	Příslušenství / Accessories / Zubehör	25.4.2016
16	Signalizace LED diod	25.4.2016
17	Signalling LEDs	25.4.2016
18	LED Standanzeige	25.4.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	BT50	ABB	91.051.063	1	/14.5
-FA1	Motorový spouštěč - 0.4A Motor starter - 0.4A Motorstarter - 0.4A	MS116-0.4	ABB	91.045.017	1	/7.1
-FA1	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.1
-FA2	Motorový spouštěč - 1A Motor starter - 1A Motorstarter - 1A	MS116-1.00	ABB	91.045.019	1	/7.3
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.3
-FA3	Motorový spouštěč - 4A Motor starter - 4A Motorstarter - 4A	MS116-4.0	ABB	91.045.022	1	/7.5
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.5
-FA4	Motorový spouštěč - 4A Motor starter - 4A Motorstarter - 4A	MS116-4.0	ABB	91.045.022	1	/7.7
-FA4	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.7
-KM1	Minisýlač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.2
-KM2	Minisýlač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.4
-KM3	Minisýlač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.5

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/zdroj/Main page/Warne section: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc./No./Anzahl der Dokumente.: ES-2100-231/202-V1.1 Napájení/Power supply/Ernährung: 3x400V + PE / 50Hz Zpracování/Processing /Auf.vorbereitung: Třp. Kvalita	Lad/Práhy/ Seiten: 3 Lad/Práhy/ Seiten: 21

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM4	Minisýřač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.7
-KM11	Minisýřač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/14.7
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/14.7
-KM12	Minisýřač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/14.8
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/14.8
-PA1	Pojistkový odpínač E-90 - 2P Fuse disconnecter E-90 - 2P Sicherungstreiner E90 - 2P	E 92/32	ABB	91.241.013	1	/8.4
-QS1	3 pólový odpojovač 16A Disconnecter - 3p, 16A	OT16F3	ABB	91.170.015	1	/6.0
-A1.1	Sestavený modul CPU2-E (UNIVERSALNI) Assembled module CPU2-E (UNIVERSAL) Montiert Modul CPU2-E (UNIVERSAL)	CPU2-E	Bomar	266.222	1	/13.6
-A1.3	Sestavený modul JDI-2/2 Assembled module JDI-2/2 náhrada za 91.995.039	JDI-2/2	Bomar	266.216	1	/13.3
-A1.5	Sestavený modul JDO-2/0 (plně osazený) Assembled module JDO-2/0 (fully maimed) náhrada za 91.995.040	JDO-2/0	Bomar	266.224	1	/13.0
-DKL	Sestavený modul DKL-F5 (display) Assembled module DKL-F5 (display) náhrada za 91.995.048	DKL-F5	Bomar	266.219	1	/13.8
-DM1	Výrobek-deska OCHRANA3 Product board OCHRANA3 Produkt-board OCHRANA 3	OCHR3	Bomar	266.255	1	/8.3

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stručná/Machine: Ergonomic 290.250 GAC	Místní identifikace/parts list: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc./No./Anzahl der Dokumente: ES-2100-201/202-V1.1 Poskytnutí/Power supply/Ernährung: 3x400V + PE / 50Hz Zpracování/Processing/ Auf.vorbereitung: 17p. Korkka Datum/Date/Datum: 20.5.2016	List/Page/ 3.4
				Stránka/Seite/ 21
				Vydání/Version/ 1.0
				Datum/Date/ 20.5.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-TR1	Transformátor - 160VA - 400/18/26V Transformer 160VA - 400/18/26V Transformator 160VA - 400/18 / 26V	JBC E4040-0387	ELEKTROKOV	91.080.037	1	/8.4
-FU1	Pojistka trubičková - 1A/250V, pomalá, 5x20 Tube fuse - 1A/250V, slow, 5x20 Rohrsicherung - 1A / 250V, langsam, 5x20	T1A/250V	ESKA	91.230.031	1	/8.4
-FU2	Pojistka trubičková - 6,3A/250V, pomalá, 5x20 Tube fuse - 6,3A/250V, slow, 5x20 Rohrsicherung - T6,3A / 250V, langsam, 5x20	T6,3A/250V	ESKA	91.230.002	1	/8.4
-SB500	Total stop - Havize + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pilt - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/14.4
-SB500	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW E10	IDEC	91.061.044	1	/14.4
-RCF1	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.0
-RCF2	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.2
-RCF3	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.4
-RCF4	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.6
-RCF11	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/6.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ablieftenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/6.7
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QCS8	KEDU	91.173.012	1	/14.4

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Máster dělník/Planner page/Planner selbst: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-2300-201/202-V1.1 Hlavní/Power supply/Ernährung: 3x400V + PE / 50Hz Zpracovatel/Processor /Hat verarbeitet: Ing. Kouřka Datum/Date/Datum: 20.5.2016	Úroveň/Level: 3.b Seiten: 21
-----	--	--	---	---	---------------------------------------

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ22	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QCS8	KEDU	91.173.012	1	/14.2
-PA1	Poliská válcová - 1A, 10x38, pomalá Tube fuse - 1A, 10x38, slow Rohrsicherung - 1A, 10x38, langsam	PV10 1A 3M	OEZ	91.231.001	2	/8.4
-QS2	Spínač věčový - 2 polohy Switch cam - 2 positions Switcher schwarz - 2 Positionen	S10-60129	SAIZER ELECTRONICS LIMITED	91.171.006	1	/7.7
-SA1	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/10.4
-SA2	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/10.7
-SB1	hlavice zelená prosvětlená - Harmony Head green backlit - Harmony Kopf grün Hintergrundbeleuchtung - Harmony	ZB5AW33	TELEMECANIQUE	91.060.019	1	/10.5
-SB2	Hlavice tlačítka černá Button black head Taste Miltesser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/10.6
-SB801	Hlavice prosvětleného tlačítka žlutá The button head backlit yellow Der Knopf Kopf von hinten beleuchtet gelb	ZB5AW35	TELEMECANIQUE	91.060.023	1	/14.6
-RCF0	Vstupní odrušovací filtr 16A Input noise filter 16A Eingangsausschfilter 16A	16EB15/50	WIDECOM TECHNOLOGY s.r.o.	91.041.062	1	/6.1
-FU1	Sworka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/8.4
-FU2	Sworka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/8.4


The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Fluss page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.:	ES-2300-2301/200-V1.1	Lad/Pages/
			Regulární/Power supply/Einspannung:	3x400V + PE / 50Hz	Seite: 3x.
			Zpracovatel/Processed /Nad verarbeitet:	Tvo. Koutba	Lad/Pages/
				20.5.2016	Seite: 21




 BOMAR, s.r.o. Tržební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC	Ilustrace stříkacího paprsku seřízení: Rozmístění prvků v rozvaděči R1 / Platzierung der Elemente im Schaltkasten R1	Číslo dok. / Doc. / No. Zahl der Dokumente: ES-2300-201/202-V1.1 Kapaliny / Power supply / Flüssigkeit: 3x400V + PE / 230V Tržba / Koda: Tržba / Koda Datum / Datum: 25.4.2016	Ústř./Page/ Seite: 4 Ústř./Page/ Seite: 21

+OP1




 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC	Hlavní zdroj/Flame page/Name set: Ovládací panel na rozváděči / Control panel / Bedienpult	Číslo dok. / Doc. No./Anzahl der Dokumente:		ES-2100-231/202-V1.1	Lad/Pages/ Seiten: 5
			Regulim/Power supply/Einspeisung:		3x400V + PE / 50Hz	
			Zpracov/Processed / Ist verarbeitet:		Ing. Kozlák	Lad/Pages/ Seiten: 21
			Datum/Date/Datum:		25.4.2016	

















 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/ Machine/ Machine: Ergonomic 290.250 GAC	Název sdělsky/Name page/Name sdělsky: Hydraulika / Hydraulics / Hydraulik	Číslo dok./Doc./No./čísložl der Dokumenta.: ES-2300-201/203-V1.1	Stránky/ Pages/ Seite: 11	Naše/our/Naše supply/Emplausung: 3x400V - 50 Hz / 3x230V	Země/Origin/Provenance / Mit voreinander: Top Grafika	Stránky/ Pages/ Seite: 2x 5x 230 V
--	---	--	--	---	--	---	--




	BOMAR s.r.o. Těžeční 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Fluss page/Name schém: Signály koncových spínačů / Signale of limit switches / signale der Endschalter		Číslo dok. Doc. No./Anzahl der Dokumenten.: ES-2100-250/200-V1.1		Lad/Prüf/ Seite: 12	
			Náplň/Power supply/Einspannung: 3x400V + PE / 50Hz		Typ Kódika		Lad/Prüf/ Seite: 21	
			Zpracovatel/Processed /Hd. verantwortlich:		25.4.2016			
			Datum/Date/Datum:					





13	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Power supply/Energiequelle: Berpetronni obvod / Safety circuit / Sicherheitsschaltung	Číslo dok. Doc. No./Anzahl der Dokumente.: ES 2100-250/202-V1.1	Lad/Pages/ Seiten: 14
				Regulim/Power supply/Energiequelle: 3x400V + PE / 50Hz	Lad/Pages/ Seiten: 21
				Zpracoval/Processed / Not verified: Třp. Kozub	Lad/Pages/ Seiten: 21
				Datum/Date/Datum: 25.4.2016	Lad/Pages/ Seiten: 21



	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC	Název schémata/Name page/Name schém: Přístroj/Device / Accessories / Zubehör	Číslo sch. / Doc. No./Anzahl der Dokumenten.: ES-2300-231/200-V1.1 Napájení/Power supply/Ernährung: 3x400V + PE / 50Hz Zpracovatel/Processor /Auf.vorbereitet: Tvo. Kódka Datum/Date/Datum: 25.4.2016	LAD/Projekt/ Seite: 15 LAD/Projekt/ Seite: 21

15

 Bomar

BOMAR, s.r.o.
Těšební 1236/1
CZ 627 00, Brno

Stroj/Machine/Machine:
Ergonomic 290.250 GAC

Název stránky/Name page/Name sheet:
Signalling LEDs

Číslo dok. dok. Volání/doc. Call: RS-2100-250/202-V1.1
Název/description: Signalling LEDs
Zpracoval/Processed: J. J. J. J.
Datum/Dat/Date: 25.5.2016

Stránka/ Page: 17
List/Sheet: 21

JDO - Output state signalization	
16	
15	
14	Activate the microniser
13	Switch on the automatic cycle indicator
12	Vice the feeding jaw
11	
10	
9	Put the arm up
8	Put the arm down
7	Unlock the arm
6	Open the main gripper
5	Open the feeding gripper
4	Turn on the band motor
3	Turn on the hydraulic pump
2	Turn on the swarf-removal motor
1	Turn on the cooling motor

JDI - Input state signalization		
	Button released	Button pushed
16	Tight the sawband	
15		
14		
13		
12	The arm is down	
11	Main gripper is closed	
10	Feeding gripper is closed	
9	Total stop activated	
8	Automatic mode stopped	
7	Automatic mode started	
6	Manual control activated	Material is present - feeding gripper
5	Automatic control activated	Microniser activated
4	Band motor protection OK	Cooling motor activated
3	Hydraulic pump protection OK	Security circuit is OK
2	Swarf-rem. motor protection is OK	
1	Cooling motor protection OK	

CPU - unit state signalization	
12	Voltage 5V
11	Voltage 5V - KOM
10	Internal CAN - TXD
9	Internal CAN - RXD
8	External CAN - TXD
7	External CAN - RXD
6	
5	
4	Desired location reached
3	Feeder regulation is active
2	Feeder to the back
1	Feeder to the front

17

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	22.4.2016
2	Obsah / Content / Inhalt	20.5.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.d	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
4	Umístění prvků v rozvaděči R1, R2 / Placement of elements in enclosure R1, R2	25.4.2016
5	Ovládací panel na rozvaděči / Control panel / Bedienpult	22.4.2016
6	Silová část / Power part / Netzteil	25.4.2016
7	Připojení pohonů / Drivings connection / Antriebsanschub	25.4.2016
8	Pohon plového pásu / Saw belt drive / Saw Riemenantrieb	25.4.2016
9	Propojení napájecích obvodů / Feeding circuits / Stromversorgungsgebiete	25.4.2016
10	Sýkače / Contactors / Schütze	22.4.2016
11	Signály spouštěčů, klávesnice / Signal of shields, keyboard / Schaltsignal, Tastatursignal	22.4.2016
12	Hydraulika / Hydraulics / Hydraulik	22.4.2016
13	Signály koncových spínačů / Signals of limit switches / signale der Endschalter	25.4.2016
14	Připojení modulů / Modules connection / Anschluss der Moduln	25.4.2016
15	Bezpečnostní obvod / Safety circuit / Sicherheitsschaltung	25.4.2016
16	Příslušenství / Accessories / Zubehör	25.4.2016
17	Signalizace LED diod	22.4.2016
18	Description of the LED diodes signalization	22.4.2016
19	LED Standanzeige	22.4.2016

3

1	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Rechts/Machine: Ergonomic 290.250 GAC FM	Název stránky/Page page/Name side: Obsah / Content / Inhalt	Verze/Version/Version: Napájení/Power supply/Einspeisung: Datum/Dater/Datum: Zpracoval/Processed/Ver. verarbeitet: Jpg. Kozla	List: 2 2 23

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	BT50	ABB	91.051.063	1	/15.145
-FA1	Motorový spouštěč - 0.4A Motor starter - 0.4A Motorstarter - 0.4A	MS116-0,4	ABB	91.045.017	1	/7.62
-FA1	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.62
-FA2	Motorový spouštěč - 1A Motor starter - 1A Motorstarter - 1A	MS116-1,00	ABB	91.045.019	1	/7.64
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.64
-FA3	Motorový spouštěč - 4A Motor starter - 4A Motorstarter - 4A	MS116-4,0	ABB	91.045.022	1	/7.67
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.67
-KM1	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B65-30-01-1.7-71	ABB	91.040.049	1	/10.93
-KM2	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B65-30-01-1.7-71	ABB	91.040.049	1	/10.94
-KM3	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B65-30-01-1.7-71	ABB	91.040.049	1	/10.96
-KM11	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B65-30-01-1.7-71	ABB	91.040.049	1	/15.147
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/15.147

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Název artiklu/Name part/stückliste: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc. No./Anzahl der Dokumente:		ES-2100F-201/202-V1.1	List/Seite/ Seite: 3
			Diagram/Power supply/Impressionung:		3x400V + PE / 50Hz	List/Seite/ Seite: 23
			Zpracoval/Processed /Hat verarbeitet:		Trg. Kódika	
			Datum/Date/Datum:		20.5.2016	

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM12	Minisýlač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-3D-01-1.7-71	ABB	91.040.049	1	/15.148
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/15.148
-PA1	Pojistkový odřezáček pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylindersteckse - 3P	E93/32	ABB	91.241.014	1	/8.71
-PA2	Pojistkový odřezáček E-90 - 2P Fuse disconnector E-90 - 2P Sicherungsbrenner E90 - 2P	E 92/32	ABB	91.241.013	1	/9.84
-QS1	3 pólový odřezáček 16A Disconnector - 3P 16A Trenner - 3P 16A	OT16F3	ABB	91.170.015	1	/6.50
-RE1	Palice pro relé Relay socket Relaissocket	CR-PSS	ABB	91.051.048	1	/12.119
-RE1	Palčové relé CR-P Plug-in relay CR-P Stecken Sic in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/12.119
-A1.1	Sestavený modul CPU2-E (UNIVERSALNI) Assembled module CPU2-E (UNIVERSAL) Montiert Modul CPU2-E (UNIVERSAL)	CPU2-E	Bomar	266.222	1	/14.136
-A3.1	Sestavený modul JDI-2/2 Assembled module JDI-2/2 náhrada za 91.995.039	JDI-2/2	Bomar	266.216	1	/14.133
-A5.1	Sestavený modul JDO-2/0 (plně osazený) Assembled module JDO-2/0 (fully maimed) náhrada za 91.995.040	JDO-2/0	Bomar	266.224	1	/14.130
-DKL	Sestavený modul DKL-F5 (display) Assembled module DKL-F5 (display) náhrada za 91.995.048	DKL-F5	Bomar	266.219	1	/14.138
-DM1	Výrobek-deska OCHRANA3 Product board OCHRANA3 Produkt-board OCHRANA 3	OCHR3	Bomar	266.255	1	/9.83

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Mávor ábrólaj/Name pagellName: seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumenten.: ES-2100F-201/202-V1.1		Úč/Pages/ Seiten: 3, 4
			Napájení/Power supply/Einspannung: 3x400V + PE / 50Hz		Úč/Pages/ Seiten: 3, 4
			Datum/Date/Datum: 20.5.2016		Úč/Pages/ Seiten: 2, 3

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-FM1	Frekvenční měnič - 1,5kW, 3x400VAC Frequency converter - 1,5kW, 3x400VAC Frequenzumrichter - 1,5kW, 3x400VAC	VFD015EL43A	DELTA ELECTRONICS, INC.	91.012.122	1	/8.71
-FU1	Pojistka trubicová - 1A/250V, pomalá, 5x20 Tube fuse - 1A/250V, slow, 5x20 Rohrsicherung - 1A / 250V, langsam, 5x20	T1A/250V	ESKA	91.230.031	1	/9.85
-FU2	Pojistka trubicová - 6,3A/250V, pomalá, 5x20 Tube fuse - 6,3A/250V, slow, 5x20 Rohrsicherung - T6,3A / 250V, langsam, 5x20	T6,3A/250V	ESKA	91.230.002	1	/9.84
-RP1	Potenciometr 4k7 Potentiometer 4k7 Potentiometer 4k7	TP195 4k7/N20A	Elektronické součástky CZ, a.s	91.283.015	1	/8.75
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/8.75
-S8500	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pile - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/15.144
-S8500	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW-E10	IDEC	91.061.044	1	/15.144
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.61
-RCF2	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.63
-RCF3	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.66
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/6.56
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/6.57

The manufacturer reserves right to use an equivalent replacement device.

3.a	 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Název dílny/Name part/Name section: Kusovník artiklů / Parts list / Artikelschüdfiste	Číslo dok./Doc. No./Anzahl der Dokumente.: ES-2100F-201/202-V1.1		Verf./Page/ Seiten: 3,4		
				Hlavní zdroj/Power supply/Energieversorgung: 3x400V + PE / 50Hz		Ladění/Printed/ Serien: 23		
				Zpracoval/Processed /Nicht verarbeitet:				
				Datum/Date/Datum:				20.5.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsenschalter - 2x NC	QK58	KEDU	91.173.012	1	/15.144
-SQ22	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsenschalter - 2x NC	QK58	KEDU	91.173.012	1	/15.142
-PA1	Pojistka válcová - 6A, 10x38, rychlá Tube fuse - 6A, 10x38, fast Rohrsicherung - 6A, 10x38, schnell	PV10 6A 9G	OEZ	91.231.002	3	/8.71
-PA2	Pojistka válcová - 1A, 10x38, pomalá Tube fuse - 1A, 10x38, slow Rohrsicherung - 1A, 10x38, langsam	PV10 1A 9M	OEZ	91.231.001	2	/9.84
-SA1	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/11.104
-SA2	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/11.107
-SB1	Hlavice zelená prosvětlová - Harmony Head green backlit - Harmony Kopf grün Hintergrundbeleuchtung - Harmony	ZB5AW33	TELEMECANIQUE	91.060.019	1	/11.105
-SB2	Hlavice tlačítko černá Button black head Taste MItesser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/11.106
-SB501	Hlavice prosvětlového tlačítka žlutá The button head backlit yellow Der Knopf Kopf von hinten beleuchtet gelb	ZB5AW35	TELEMECANIQUE	91.060.023	1	/15.146
-RCF0	Vstupní odrušovací filtr 16A Input noise filter 16A Eingangsausschfilter 16A	16EB15/50	WIDECOM TECHNOLOGY s.r.o.	91.041.062	1	/6.51
-FU1	Sworka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/9.85

The manufacturer reserves right to use an equivalent replacement device.

3.b	 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Mávor alát/Utensilium pagellname: szék: Kusovník artiklů / Parts list / Artikelstückliste	Cílová dok. Doc. No./Anzahl der Dokumenten.: ES-2100F-201/202-V1.1		Leg./Page/ 3,4
				Inguligim/Power supply/Impingung: 3x400V + PE / 50Hz		Seiter:
				Zrinnocod/Procurement /Hlt. verordniet:		Leg./Page/ 3,4
				Datum/Date/Datum:		Seiten: 23



Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-R2	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/9.84


The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Rechner/Machine: Ergonomic 290.250 GAC FM	Název artiklu/Name part/Name article: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc. No./Anzahl der Dokumente.: ES-2100F-201/202-V1.1		Let/Page/ Seite: 3,4
			Napájení/Power supply/Alimentation: 3x400V + PE / 50Hz		Let/Page/ Seite: 2,3
			Zpracování/Processing /Nat. verarbeitet: Datum/Date/Datum: 17.9.2016		



	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Nameplate: Ergonomic 290.250 GAC FM	Název stříška/Name plate/Name selection: Rozšíření prvků v rozvaděči R4, R2 / Placement of elements in endocuse R1, R2 / Rozšíření prvky v rozvaděči R4, R2 / Placement of elements in the Schaltschrank R1, R2	Číslo dok./Doc.-No./číslo řádku dok./Document: ES-2008F-291202-V4.1 Inženýr/Power supply/Engineering: 3x400V + PE / 50Hz Zpracování/Processed /Not verified: Top. Grafika Datum vydání/Date: 25.5.2016.	List/Page/ Stránka / Seite: 4 Zpracování/Processed /Not verified: Top. Grafika Datum vydání/Date: 25.5.2016.
---	---	---	---	--	---

+OP1



-SB501
-H501

-SA2

-SA1


-SB1
-H2

-SB2

-SB500

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Slog/Machine/Numéro: Ergonomic 290.250 GAC FM	Ménor atiny/Frame page/Frame: selon: Ovládací panel na rozvaděči / Control panel / Bedienpult:	Číslo dok. Doc. No./Anzahl der Dokumente.:		ES-2100F-201/202-V1.1	Účel/Usage/ Seite: 5
			Nákladní/Power supply/Alimentierung:		3x400V + PE / 50Hz	
			Zpracováno/Processed / Not verified:		Ing. Koudela	
			Datum/Date/Date:		22.4.2016	23







6	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Rechner/Machine: Ergonomic 290.250 GAC FM Název schéma/Name of the scheme: Připojení pohonů / Drivings connection / Antriebsanschluß Číslo schéma/Doc. No./Anzahl der Dokumente: ES-2100F-201/202-V1.1 Legenda: Schlüssel: 7 L12/L22/L32 L13/L23/L33 L14/L24/L34 L15/L25/L35 L16/L26/L36 L17/L27/L37 L18/L28/L38 L19/L29/L39 L20/L30 L21/L31 L22/L32 L23/L33 L24/L34 L25/L35 L26/L36 L27/L37 L28/L38 L29/L39 L30/L40 L31/L41 L32/L42 L33/L43 L34/L44 L35/L45 L36/L46 L37/L47 L38/L48 L39/L49 L40/L50 L41/L51 L42/L52 L43/L53 L44/L54 L45/L55 L46/L56 L47/L57 L48/L58 L49/L59 L50/L60 L51/L61 L52/L62 L53/L63 L54/L64 L55/L65 L56/L66 L57/L67 L58/L68 L59/L69 L60/L70 L61/L71 L62/L72 L63/L73 L64/L74 L65/L75 L66/L76 L67/L77 L68/L78 L69/L79 L70/L80 L71/L81 L72/L82 L73/L83 L74/L84 L75/L85 L76/L86 L77/L87 L78/L88 L79/L89 L80/L90 L81/L91 L82/L92 L83/L93 L84/L94 L85/L95 L86/L96 L87/L97 L88/L98 L89/L99 L90/L100 L91/L101 L92/L102 L93/L103 L94/L104 L95/L105 L96/L106 L97/L107 L98/L108 L99/L109 L100/L110 L101/L111 L102/L112 L103/L113 L104/L114 L105/L115 L106/L116 L107/L117 L108/L118 L109/L119 L110/L120 L111/L121 L112/L122 L113/L123 L114/L124 L115/L125 L116/L126 L117/L127 L118/L128 L119/L129 L120/L130 L121/L131 L122/L132 L123/L133 L124/L134 L125/L135 L126/L136 L127/L137 L128/L138 L129/L139 L130/L140 L131/L141 L132/L142 L133/L143 L134/L144 L135/L145 L136/L146 L137/L147 L138/L148 L139/L149 L140/L150 L141/L151 L142/L152 L143/L153 L144/L154 L145/L155 L146/L156 L147/L157 L148/L158 L149/L159 L150/L160 L151/L161 L152/L162 L153/L163 L154/L164 L155/L165 L156/L166 L157/L167 L158/L168 L159/L169 L160/L170 L161/L171 L162/L172 L163/L173 L164/L174 L165/L175 L166/L176 L167/L177 L168/L178 L169/L179 L170/L180 L171/L181 L172/L182 L173/L183 L174/L184 L175/L185 L176/L186 L177/L187 L178/L188 L179/L189 L180/L190 L181/L191 L182/L192 L183/L193 L184/L194 L185/L195 L186/L196 L187/L197 L188/L198 L189/L199 L190/L200 L191/L201 L192/L202 L193/L203 L194/L204 L195/L205 L196/L206 L197/L207 L198/L208 L199/L209 L200/L210 L201/L211 L202/L212 L203/L213 L204/L214 L205/L215 L206/L216 L207/L217 L208/L218 L209/L219 L210/L220 L211/L221 L212/L222 L213/L223 L214/L224 L215/L225 L216/L226 L217/L227 L218/L228 L219/L229 L220/L230 L221/L231 L222/L232 L223/L233 L224/L234 L225/L235 L226/L236 L227/L237 L228/L238 L229/L239 L230/L240 L231/L241 L232/L242 L233/L243 L234/L244 L235/L245 L236/L246 L237/L247 L238/L248 L239/L249 L240/L250 L241/L251 L242/L252 L243/L253 L244/L254 L245/L255 L246/L256 L247/L257 L248/L258 L249/L259 L250/L260 L251/L261 L252/L262 L253/L263 L254/L264 L255/L265 L256/L266 L257/L267 L258/L268 L259/L269 L260/L270 L261/L271 L262/L272 L263/L273 L264/L274 L265/L275 L266/L276 L267/L277 L268/L278 L269/L279 L270/L280 L271/L281 L272/L282 L273/L283 L274/L284 L275/L285 L276/L286 L277/L287 L278/L288 L279/L289 L280/L290 L281/L291 L282/L292 L283/L293 L284/L294 L285/L295 L286/L296 L287/L297 L288/L298 L289/L299 L290/L300 L291/L301 L292/L302 L293/L303 L294/L304 L295/L305 L296/L306 L297/L307 L298/L308 L299/L309 L300/L310 L301/L311 L302/L312 L303/L313 L304/L314 L305/L315 L306/L316 L307/L317 L308/L318 L309/L319 L310/L320 L311/L321 L312/L322 L313/L323 L314/L324 L315/L325 L316/L326 L317/L327 L318/L328 L319/L329 L320/L330 L321/L331 L322/L332 L323/L333 L324/L334 L325/L335 L326/L336 L327/L337 L328/L338 L329/L339 L330/L340 L331/L341 L332/L342 L333/L343 L334/L344 L335/L345 L336/L346 L337/L347 L338/L348 L339/L349 L340/L350 L341/L351 L342/L352 L343/L353 L344/L354 L345/L355 L346/L356 L347/L357 L348/L358 L349/L359 L350/L360 L351/L361 L352/L362 L353/L363 L354/L364 L355/L365 L356/L366 L357/L367 L358/L368 L359/L369 L360/L370 L361/L371 L362/L372 L363/L373 L364/L374 L365/L375 L366/L376 L367/L377 L368/L378 L369/L379 L370/L380 L371/L381 L372/L382 L373/L383 L374/L384 L375/L385 L376/L386 L377/L387 L378/L388 L379/L389 L380/L390 L381/L391 L382/L392 L383/L393 L384/L394 L385/L395 L386/L396 L387/L397 L388/L398 L389/L399 L390/L400 L391/L401 L392/L402 L393/L403 L394/L404 L395/L405 L396/L406 L397/L407 L398/L408 L399/L409 L400/L410 L401/L411 L402/L412 L403/L413 L404/L414 L405/L415 L406/L416 L407/L417 L408/L418 L409/L419 L410/L420 L411/L421 L412/L422 L413/L423 L414/L424 L415/L425 L416/L426 L417/L427 L418/L428 L419/L429 L420/L430 L421/L431 L422/L432 L423/L433 L424/L434 L425/L435 L426/L436 L427/L437 L428/L438 L429/L439 L430/L440 L431/L441 L432/L442 L433/L443 L434/L444 L435/L445 L436/L446 L437/L447 L438/L448 L439/L449 L440/L450 L441/L451 L442/L452 L443/L453 L444/L454 L445/L455 L446/L456 L447/L457 L448/L458 L449/L459 L450/L460 L451/L461 L452/L462 L453/L463 L454/L464 L455/L465 L456/L466 L457/L467 L458/L468 L459/L469 L460/L470 L461/L471 L462/L472 L463/L473 L464/L474 L465/L475 L466/L476 L467/L477 L468/L478 L469/L479 L470/L480 L471/L481 L472/L482 L473/L483 L474/L484 L475/L485 L476/L486 L477/L487 L478/L488 L479/L489 L480/L490 L481/L491 L482/L492 L483/L493 L484/L494 L485/L495 L486/L496 L487/L497 L488/L498 L489/L499 L490/L500 L491/L501 L492/L502 L493/L503 L494/L504 L495/L505 L496/L506 L497/L507 L498/L508 L499/L509 L500/L510 L501/L511 L502/L512 L503/L513 L504/L514 L505/L515 L506/L516 L507/L517 L508/L518 L509/L519 L510/L520 L511/L521 L512/L522 L513/L523 L514/L524 L515/L525 L516/L526 L517/L527 L518/L528 L519/L529 L520/L530 L521/L531 L522/L532 L523/L533 L524/L534 L525/L535 L526/L536 L527/L537 L528/L538 L529/L539 L530/L540 L531/L541 L532/L542 L533/L543 L534/L544 L535/L545 L536/L546 L537/L547 L538/L548 L539/L549 L540/L550 L541/L551 L542/L552 L543/L553 L544/L554 L545/L555 L546/L556 L547/L557 L548/L558 L549/L559 L550/L560 L551/L561 L552/L562 L553/L563 L554/L564 L555/L565 L556/L566 L557/L567 L558/L568 L559/L569 L560/L570 L561/L571 L562/L572 L563/L573 L564/L574 L565/L575 L566/L576 L567/L577 L568/L578 L569/L579 L570/L580 L571/L581 L572/L582 L573/L583 L574/L584 L575/L585 L576/L586 L577/L587 L578/L588 L579/L589 L580/L590 L581/L591 L582/L592 L583/L593 L584/L594 L585/L595 L586/L596 L587/L597 L588/L598 L589/L599 L590/L600 L591/L601 L592/L602 L593/L603 L594/L604 L595/L605 L596/L606 L597/L607 L598/L608 L599/L609 L600/L610 L601/L611 L602/L612 L603/L613 L604/L614 L605/L615 L606/L616 L607/L617 L608/L618 L609/L619 L610/L620 L611/L621 L612/L622 L613/L623 L614/L624 L615/L625 L616/L626 L617/L627 L618/L628 L619/L629 L620/L630 L621/L631 L622/L632 L623/L633 L624/L634 L625/L635 L626/L636 L627/L637 L628/L638 L629/L639 L630/L640 L631/L641 L632/L642 L633/L643 L634/L644 L635/L645 L636/L646 L637/L647 L638/L648 L639/L649 L640/L650 L641/L651 L642/L652 L643/L653 L644/L654 L645/L655 L646/L656 L647/L657 L648/L658 L649/L659 L650/L660 L651/L661 L652/L662 L653/L663 L654/L664 L655/L665 L656/L666 L657/L667 L658/L668 L659/L669 L660/L670 L661/L671 L662/L672 L663/L673 L664/L674 L665/L675 L666/L676 L667/L677 L668/L678 L669/L679 L670/L680 L671/L681 L672/L682 L673/L683 L674/L684 L675/L685 L676/L686 L677/L687 L678/L688 L679/L689 L680/L690 L681/L691 L682/L692 L683/L693 L684/L694 L685/L695 L686/L696 L687/L697 L688/L698 L689/L699 L690/L700 L691/L701 L692/L702 L693/L703 L694/L704 L695/L705 L696/L706 L697/L707 L698/L708 L699/L709 L700/L710 L701/L711 L702/L712 L703/L713 L704/L714 L705/L715 L706/L716 L707/L717 L708/L718 L709/L719 L710/L720 L711/L721 L712/L722 L713/L723 L714/L724 L715/L725 L716/L726 L717/L727 L718/L728 L719/L729 L720/L730 L721/L731 L722/L732 L723/L733 L724/L734 L725/L735 L726/L736 L727/L737 L728/L738 L729/L739 L730/L740 L731/L741 L732/L742 L733/L743 L734/L744 L735/L745 L736/L746 L737/L747 L738/L748 L739/L749 L740/L750 L741/L751 L742/L752 L743/L753 L744/L754 L745/L755 L746/L756 L747/L757 L748/L758 L749/L759 L750/L760 L751/L761 L752/L762 L753/L763 L754/L764 L755/L765 L756/L766 L757/L767 L758/L768 L759/L769 L760/L770 L761/L771 L762/L772 L763/L773 L764/L774 L765/L775 L766/L776 L767/L777 L768/L778 L769/L779 L770/L780 L771/L781 L772/L782 L773/L783 L774/L784 L775/L785 L776/L786 L777/L787 L778/L788 L779/L789 L780/L790 L781/L791 L782/L792 L783/L793 L784/L794 L785/L795 L786/L796 L787/L797 L788/L798 L789/L799 L790/L800 L791/L801 L792/L802 L793/L803 L794/L804 L795/L805 L796/L806 L797/L807 L798/L808 L799/L809 L800/L810 L801/L811 L802/L812 L803/L813 L804/L814 L805/L815 L806/L816 L807/L817 L808/L818 L809/L819 L810/L820 L811/L821 L812/L822 L813/L823 L814/L824 L815/L825 L816/L826 L817/L827 L818/L828 L819/L829 L820/L830 L821/L831 L822/L832 L823/L833 L824/L834 L825/L835 L826/L836 L827/L837 L828/L838 L829/L839 L830/L840 L831/L841 L832/L842 L833/L843 L834/L844 L835/L845 L836/L846 L837/L847 L838/L848 L839/L849 L840/L850 L841/L851 L842/L852 L843/L853 L844/L854 L845/L855 L846/L856 L847/L857 L848/L858 L849/L859 L850/L860 L851/L861 L852/L862 L853/L863 L854/L864 L855/L865 L856/L866 L857/L867 L858/L868 L859/L869 L860/L870 L861/L871 L862/L872 L863/L873 L864/L874 L865/L875 L866/L876 L867/L877 L868/L878 L869/L879 L870/L880 L871/L881 L872/L882 L873/L883 L874/L884 L875/L885 L876/L886 L877/L887 L878/L888 L879/L889 L880/L890 L881/L891 L882/L892 L883/L893 L884/L894 L885/L895 L886/L896 L887/L897 L888/L898 L889/L899 L890/L900 L891/L901 L892/L902 L893/L903 L894/L904 L895/L905 L896/L906 L897/L907 L898/L908 L899/L909 L900/L910 L901/L911 L902/L912 L903/L913 L904/L914 L905/L915 L906/L916 L907/L917 L908/L918 L909/L919 L910/L920 L911/L921 L912/L922 L913/L923 L914/L924 L915/L925 L916/L926 L917/L927 L918/L928 L919/L929 L920/L930 L921/L931 L922/L932 L923/L933 L924/L934 L925/L935 L926/L936 L927/L937 L928/L938 L929/L939 L930/L940 L931/L941 L932/L942 L933/L943 L934/L944 L935/L945 L936/L946 L937/L947 L938/L948 L939/L949 L940/L950 L941/L951 L942/L952 L943/L953 L944/L954 L945/L955 L946/L956 L947/L957 L948/L958 L949/L959 L950/L960 L951/L961 L952/L962 L953/L963 L954/L964 L955/L965 L956/L966 L957/L967 L958/L968 L959/L969 L960/L970 L961/L971 L962/L972 L963/L973 L964/L974 L965/L975 L966/L976 L967/L977 L968/L978 L969/L979 L970/L980 L971/L981 L972/L982 L973/L983 L974/L984 L975/L985 L976/L986 L977/L987 L978/L988 L979/L989 L980/L990 L981/L991 L982/L992 L983/L993 L984/L994 L985/L995 L986/L996 L987/L997 L988/L998 L989/L999 L990/L1000 L991/L1001 L992/L1002 L993/L1003 L994/L1004 L995/L1005 L996/L1006 L997/L1007 L998/L1008 L999/L1009 L1000/L1010 L1001/L1011 L1002/L1012 L1003/L1013 L1004/L1014 L1005/L1015 L1006/L1016 L1007/L1017 L1008/L1018 L1009/L1019 L1010/L1020 L1011/L1021 L1012/L1022 L1013/L1023 L1014/L1024 L1015/L1025 L1016/L1026 L1017/L1027 L1018/L1028 L1019/L1029 L1020/L1030 L1021/L1031 L1022/L1032 L1023/L1033 L1024/L1034 L1025/L1035 L1026/L1036 L1027/L1037 L1028/L1038 L1029/L1039 L1030/L1040 L1031/L1041 L1032/L1042 L1033/L1043 L1034/L1044 L1035/L1045 L1036/L1046 L1037/L1047 L1038/L1048 L1039/L1049 L1040/L1050 L1041/L1051 L1042/L1052 L1043/L1053 L1044/L1054 L1045/L1055 L1046/L1056 L1047/L1057 L1048/L1058 L1049/L1059 L1050/L1060 L1051/L1061 L1052/L1062 L1053/L1063 L1054/L1064 L1055/L1065 L1056/L1066 L1057/L1067 L1058/L1068 L1059/L1069 L1060/L1070 L1061/L1071 L1062/L1072 L1063/L1073 L1064/L1074 L1065/L1075 L1066/L1076 L1067/L1077 L1068/L1078 L1069/L1079 L1070/L1080 L1071/L1081 L1072/L1082 L1073/L1083 L1074/L1084 L1075/L1085 L1076/L1086 L1077/L1087 L1078/L1088 L1079/L1089 L1080/L1090 L1081/L1091 L1082/L1092 L1083/L1093 L1084/L1094 L1085/L1095 L1086/L1096 L1087/L1097 L1088/L1098 L1089/L1099 L1090/L1100 L1091/L1101 L1092/L1102 L1093/L1103 L1094/L1104 L1095/L1105 L1096/L1106 L1097/L1107 L1098/L1108 L1099/L1109 L1100/L1110 L1101/L1111 L1102/L1112 L1103/L1113 L1104/L1114 L1105/L1115 L1106/L1116 L1107/L1117 L1108/L1118 L1109/L1119 L1110/L1120 L1111/L1121 L1112/L1122 L1113/L1123 L1114/L1124 L1115/L1125 L1116/L1126 L1117/L1127 L1118/L1128 L1119/L1129 L1120/L1130 L1121/L1131 L1122/L1132 L1123/L1133 L1124/L1134 L1125/L1135 L1126/L1136 L1127/L1137 L1128/L1138 L1129/L1139 L1130/L1140 L1131/L1141 L1132/L1142 L1133/L11
---	--	--




 BOMAR, s.r.o. Těšebří 1236/1 CZ 627 00, Brno	Step/Machine/Modèle: Ergonomic 290.250 GAC FM	Model at risk/Type paper/Name sellman: Pohon plového pásu / Saw belt drive / Saw Riemenantrieb	Číslo dok. / No. / Anzahl der Dokumente: : ES-2100F-250/202-V1.1	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser: 3x400V + PE / 32kVA	Verfasser:<
--	---	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	-----------------------













Manual version: 1.07 / May 2016
Manual rev.: 1



	BOMAR s.r.o. Třebíř 1236/1 CZ 627 00, Brno	Sřad/Machine/Machine: Ergonomic 290.250 GAC FM	Měro sřad/Machine/Machine: Připojení modulů / Modules connection / Anschluss der Module	(Číslo dok. Doc. No./Anzahl der Dokumente...) ES-2100F-201/202-V1.1 Instalace/Power supply/Installation: 3x400V + PE / 50Hz Zpracování/Processing /Not verarbeit. Trp. Kodice Datum/Date/Datum:	List/Page/ 14
					Seller: 14
					Trp. Kodice 14
					Datum/Date/Datum: 25.4.2016 23

[illegible]



15	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC FM	Název strojního příslušenství: Příslušenství / Accessories / Zubehör	Číslo dok. / Doc. No./Anzahl der Dokumenten.: ES-2100F-201/202-V1.1 Instalční/Power supply/Installation: 3x400V + PE / 50Hz Zeměpisná/Geographical/Not specified: 25.4.2016	LSP/Projekt: Seiten: 16 LSP/Projekt: Seiten: 23



JDO - Signalizace stavu výstupů	
16	
15	Spustit frekvenční měnič
14	Aktivovat mikronizér
13	Aktivovat kontrolku automatického režimu
12	Podávací čelist uchlout
11	
10	
9	Rameno nahoru
8	Rameno dolů
7	Rameno aretovat
6	Otevřít hlavní světlák
5	Otevřít podávací větrák
4	
3	Zapnout čerpadlo hydrauliky
2	Zapnout motor vynašeče
1	Zapnout motor chlazení

JDI - Signalizace stavu vstupů	
	Tlačítko uvolněno
16	Tlačítko stisknuto
15	Pás pily je napnutý
14	
13	Relé limit proudu frek. měniče sepnuto
12	Rameno je dole
11	Hlavní světlák upnut
10	Podávací světlák upnut
9	Total stop aktivován
8	Stop automatického režimu
7	Start automatického režimu
6	Aktivováno ruční ovládání
5	Aktivováno automatické ovládání
4	Poruchové relé frekv. měniče sepnuto
3	Ochrana čerpadla hydrauliky OK
2	Ochrana motoru vynašeče OK
1	Ochrana motoru chlazení OK

CPU - Signalizace stavu jednotky	
12	Napájení 5V
11	Napájení 5V - KOM
10	Interní CAN - TXD
9	Interní CAN - RXD
8	Externí CAN - TXD
7	Externí CAN - RXD
6	
5	
4	Zadaná pozice dosažena
3	Regulace podavače aktivní
2	Podavač dozadu
1	Podavač dopředu

JDO - Output state signalization	
16	
15	Start up speed controller
14	Activate the microniser
13	Switch on the automatic cycle indicator
12	Vice the feeding jaw
11	
10	
9	Put the arm up
8	Put the arm down
7	Unlock the arm
6	Open the main gripper
5	Open the feeding gripper
4	
3	Turn on the hydraulic pump
2	Turn on the swarf-removal motor
1	Turn on the cooling motor

JDI - Input state signalization	
16	Button released
15	The sawband is tight
14	
13	Speed controller current limit relay
12	The arm is down
11	Main gripper is closed
10	Feeding gripper is closed
9	Total stop activated
8	Automatic mode stopped
7	Automatic mode started
6	Manual control activated
5	Automatic control activated
4	Speed controller failure relay on state
3	Hydraulic pump protection OK
2	Swarf-rem. motor protection is OK
1	Cooling motor protection OK

CPU - unit state signalization	
12	Voltage 5V
11	Voltage 5V - KOM
10	Internal CAN - TXD
9	Internal CAN - RXD
8	External CAN - TXD
7	External CAN - RXD
6	
5	
4	Desired location reached
3	Feeder regulation is active
2	Feeder to the back
1	Feeder to the front

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stop/ Machines/ Machines: Ergonomic 290.250 GAC FM	Minor activity/ Name page/ Name action: Description of the LED diodes signalization	(Title, edic. Doc. No./ Anzahl der Dokumenten.: Instalation/ Power supply/ (Anspannung): Znamenkod/ Provenienz / (Hst. verzeichnet): Datum/ Date/ Datum:	ES-2100F-201/202-V1.1	Last/ Page/ Seite: 18
				3x400V + PE / 50Hz	Lack/ Papier/ Seiten: 23
				Typ. Kodex:	
				22.4.2016	

JDO - Ausgabe - Standanzeige	
16	
15	Frequenzumrichter einschalten
14	Microniser aktivieren
13	Kontrollleuchte (aut. Betrieb) aktivieren
12	Vorschubbacke spannen
11	
10	
9	Sägerahmen nach oben
8	Sägerahmen nach unten
7	Sägerahmen nicht arretieren
6	Hauptschraubstock öffnen
5	Vorschubschraubstock öffnen
4	
3	Hydraulikpumpe einschalten
2	Spänförderer einschalten
1	Kühlmittelpumpe einschalten

JDI - Eingabe - Standanzeige		
	Taste gelöst	Taste gedrückt
16	Sägeband gespannt	
15		
14		
13	Grenzstromrelais des Freq. eingeschaltet	
12	Sägerahmen unten	
11	Hauptschraubstock gespannt	
10	Vorschubschraubstock gespannt	
9	NON-AUS Taste	
8	STOP des automatischen Zyklus	
7	START des automatischen Zyklus	
6	Manuelles bedienen aktiviert	Material anwesend - Vorschubschraub.
5	Automatisches Bedienen aktiviert	Microniser aktiviert
4	Störungsrelais des Freq. eingeschaltet	Kühlmittelpumpe aktiviert
3	Schutz der Hydraulikpumpe OK	Sicherheitsschaltung verbunden
2	Schutz des Spänförderers OK	
1	Schutz der Kühlmittelpumpe OK	

CPU - Ausgabe - Einheitsstand	
12	Versorgung 5V
11	Versorgung 5V - KOM
10	Intern CAN - TXD
9	Intern CAN - RXD
8	Extern CAN - TXD
7	Extern CAN - RXD
6	
5	
4	vorschub in der gewünschten Position
3	Vorschubregulierung aktiv
2	Vorschub nach hinten
1	Vorschub nach vorne

6.1.3. Ergonomic 290.250 GAC bez frekvenčního měniče
3x230V+PE, 50Hz

6	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Ergonomic 290.250 GAC ES-2300-203-V1.1 Wiring diagram 3x230V + PE / 50Hz									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: Ergonomic 290.250 GAC		Hlavní stránka / Main page / Startseite: Úvodní strana / Start page / Startseite		Číslo dok. / Doc. No. / Anzahl der Dokumente.: Freigelegener Nachfragemantrag: Zinnmachtwort / Not vorzulegen: Datum / Date / Datum:		Vertrag / Liefer- Auftrag / Muster - 21	
		ES-2300-203-V1.1		3x230V + PE / 50Hz		21.6.2016			

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	22.4.2016
2	Obsah / Content / Inhalt	20.5.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
4	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	22.4.2016
5	Ovládací panel na rozvaděči / Control panel / Bedienpult	22.4.2016
6	Silová část / Power part / Netzteil	25.4.2016
7	Připojení pohonů / Drivings connection / Antriebsanschluss	25.4.2016
8	Propojení napájecích obvodů / Feeding circuits / Stromversorgungsgebiede	25.4.2016
9	Sýkače / Contactors / Schütze	25.4.2016
10	Signály spouštěčů, klávesnice / Signal of shields, keyboard / Schaltersignal, Tastatursignal	25.4.2016
11	Hydraulika / Hydraulics / Hydraulik	25.4.2016
12	Signály koncových spínačů / Signals of limit switches / signale der Endschalter	25.4.2016
13	Připojení modulů / Modules connection / Anschluss der Moduln	25.4.2016
14	Bezpečnostní obvod / Safety circuit / Sicherheitschaltung	25.4.2016
15	Příslušenství / Accessories / Zubehör	25.4.2016
16	Signalizace LED diod	22.4.2016
17	Signalling LEDs	22.4.2016
18	LED Standinzeige	22.4.2016

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	8150	ABB	91.051.063	1	/14.5
-FA1	Motorový spouštěč - 0.63A Motor starter - 0.63A Motorstarter - 0.63A	MS116-0.63	ABB	91.045.018	1	/7.1
-FA1	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.1
-FA2	Motorový spouštěč - 1.6A Motor starter - 1.6A Motorstarter - 1.6A	MS116-1.6	ABB	91.045.020	1	/7.3
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.3
-FA3	Motorový spouštěč - 6.3A Motor starter - 6.3A Motorstarter - 6.3A	MS116-6.3	ABB	91.045.023	1	/7.5
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.5
-FA4	Motorový spouštěč - 10A Motor starter - 10A Motorstarter - 10A	MS116-10.0	ABB	91.045.024	1	/7.7
-FA4	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.7
-KH1	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.2
-KH2	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.4
-KH3	Minisýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/9.5

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Name page/Name sheet: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumenten. : ES-2300-203-V1.1		Lad/Pages/ Seiten: 3	
			Napájení/Power supply/Einspeisung: 3x230V + PE / 50Hz		Lad/Pages/ Seiten: 3	
			Zpracovatel/Processed /Not verified: Tvo. Koutba		Lad/Pages/ Seiten: 21	
			Datum/Date/Date:		20.5.2016	

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM4	Minisýlač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-3D-01-1.7-71	ABB	91.040.049	1	/9.7
-KM11	Minisýlač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-3D-01-1.7-71	ABB	91.040.049	1	/14.7
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/14.7
-KM12	Minisýlač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-3D-01-1.7-71	ABB	91.040.049	1	/14.8
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/14.8
-PA1	Pojistkový odpínač E-90 - 2P Fuse disconnecter E-90 - 2P Sicherungstrener E90 - 2P	E 97/32	ABB	91.241.013	1	/8.4
-QS1	3 pólový odpojovač 16A Disconnecter - 3P 16A	OT16F3	ABB	91.170.015	1	/6.0
-A1.1	Sestavený modul CPU2-E (UNIVERSAL/INT) Assembled module CPU2-E (UNIVERSAL) Montiert Modul CPU2-E (UNIVERSAL)	CPU2-E	Bomar	266.222	1	/13.6
-A1.3	Sestavený modul JDI-2/2 Assembled module JDI-2/2 náhrada za 91.995.039	JDI-2/2	Bomar	266.216	1	/13.3
-A1.5	Sestavený modul JDO-2/0 (plně osazený) Assembled module JDO-2/0 (fully marned) náhrada za 91.995.040	JDO-2/0	Bomar	266.224	1	/13.0
-DKL	Sestavený modul DKL-F5 (display) Assembled module DKL-F5 (display) náhrada za 91.995.048	DKL-F5	Bomar	266.219	1	/13.8
-DM1	Výrobek-deska OCHRANA3 Product board OCHRANA3 Produkt-board OCHRANA 3	OCHR3	Bomar	266.255	1	/8.3

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Mazon ártikl/Name page/Name section: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumente.: ES-2100-203-V1.1 Regulární/Power supply/Einspannung: 3x230V + PE / 50Hz Zpracováno/Processed /Nicht verarbeitet: 17x Kódika Datum/Data/Datum: 20.5.2016	LAD/Projekt/ Sest.: 3.4
				LAD/Projekt/ Sest.: 3.4
				LAD/Projekt/ Sest.: 3.4
				LAD/Projekt/ Sest.: 3.4

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-H1	Pojistka trubičková - 1A/250V, pomalá, 5x20 Tube fuse - 1A/250V, slow, 5x20 Rohrsicherung - 1A / 250V, langsam, 5x20	T1A/250V	ESKA	91.230.031	1	/8.4
-F12	Pojistka trubičková - 6,3A/250V, pomalá, 5x20 Tube fuse - 6,3A/250V, slow, 5x20 Rohrsicherung - T6,3A / 250V, langsam, 5x20	T6,3A/250V	ESKA	91.230.002	1	/8.4
-S8500	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Plz - Taster + 3 xNC	YW1B-ME02R	IDEC	91.060.084	1	/14.4
-S8500	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW-E10	IDEC	91.061.044	1	/14.4
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/7.0
-RCF2	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/7.2
-RCF3	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/7.4
-RCF4	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/7.6
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/6.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL024	Ing. Miroslav Vlček	91.041.015	1	/6.7
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QK58	KEDU	91.173.012	1	/14.4
-SQ22	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QK58	KEDU	91.173.012	1	/14.2

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Součástí/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Fluss nach Name setzen: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumente.: ES-2100-2013-V1.1		Lad/Paper/
				Ing. Kodaň		Seiten: 21
				Datum/Date/Datum: 20.5.2016		

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-PA1	Pojistka válcová - 1A, 10x38, pomalá Tube fuse - 1A, 10x38, slow Rohrsicherung - 1A, 10x38, langsam	PV10 1A aM	OEZ	91.231.001	2	/8.4
-QS2	Spínač vačkový - 2 polohy Switch cam - 2 positions Switch cam - 2 positions	S10-60129	SALZER ELECTRONICS LIMITED	91.171.006	1	/7.7
-SA1	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/10.4
-SA2	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZB5-AD3	TELEMECANIQUE	91.060.024	1	/10.7
-SB1	Hlavice zelená prosvětlovací - Harmony Head green backlight - Harmony Kopf grün Hintergrundleuchtung - Harmony	ZB5AW33	TELEMECANIQUE	91.060.019	1	/10.5
-SB2	Hlavice tlačítka černá Button black head Taste Mlleser	ZB5AA2	TELEMECANIQUE	91.060.013	1	/10.6
-SB001	Hlavice prosvětlovacího tlačítka žlutá The button head backlight yellow Der Knopf Kopf von hinten beleuchtet gelb	ZB5AW35	TELEMECANIQUE	91.060.023	1	/14.6
-RCF0	Vstupní odrušovací filtr 16A Input noise filter 16A Eingangsgrauschfilter 16A	16EB15/50	WIDECOM TECHNOLOGY s.r.o.	91.041.062	1	/6.1
-FU1	Sworka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/8.4
-FU2	Sworka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/8.4

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC	Hlavní zdroj/Name page/Name sheet: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumente: ES-2380-203-V1.1		Lisť/Pages/
			Ing. Kozlák		3x
			20.5.2016		3x238V + PE / 50Hz
			20.5.2016		1481/Pages/
			20.5.2016		Setlist:



Stroj/Machine/Maschine:

Ergonomic 290.250 GAC

Název stránky/Name page/Name seiten:

Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1

⁵Isido dok./Doc.No./Anzahl der Dokumente.:

Capitem/Power supply/Einspeisung:


3x230V + PE

List/Page/

Seite: 4

List of Pages/
Seiten: 21

+OP1



-SB500

-SB2

-SB1
-H2


-SA1


-SA2

-SB501
-H501


 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC	Hlavní zdroj/Flüssigkeit page/Name set: Ovládací panel na rozváděči / Control panel / Bedienpult	Číslo dok. / Doc. No./Anzahl der Dokumente: ES-2100-203-V0.1		Lad/Pages/ Seiten: 5
			Regulární/Power supply/Einspeisung: 3x230V + PE / 50Hz		
			Zpracovatel/Processor / Ist. verantwortlich: Tř. Koutek		
			Datum/Date/Datum: 22.4.2016		









 BOMAR, s.r.o. Těšebří 1236/1 CZ 627 00, Brno	Stroj/Machine/Nameplate: Ergonomic 290.250 GAC	Název obilky/Name paper/Name seal/enc: Propojení napájecích obvodů / Feeding circuits / Stromversorgungsgeblede	Číslo dok./Doc. No./číslo řádku dok./Document: ES-2300-203-V1.1	List/Page/ Settle: 8
			Hruškové/Power supply/Impedance: 3x230V ~ 50 / 50Hz	
			Zpracování/Processed / list verze/edited: Třp. Gorkila	
			Datum/Dat./Date: 25.5.2016	List/Page/ Settle: 21







	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC	Motor výtahové OK Swarf conveyor motor OK Spärförderer Motor OK	Motor pilového pásu OK Saw belt motor OK Saw Bandmotor OK	Automatický režim Automatic mode Automatischer Modus	Manuální režim Manual mode Manueller Modus	STOP START Mikronizér Micronizer	Kontrolka Start Start indicator Starten Indikator
---	---	--	---	---	--	--	---	---




 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/ Machine/ Machine: Ergonomic 290.250 GAC	Název obchodní/Trade name/ Name, address: Hydraulika / Hydraulics / Hydraulik	Číslo dok./Doc.-No./Kazdařil der Dokumente: ES-2300-203-VI.1 Typ/Item/Item supply/Typausstattung: 3x230V + PE / 50Hz Značka/Brand/Mark/Hersteller: Top Konika Datum/Issue/Date: 25.6.2016.	Str./Page/Seite: 11 Str./Page/Seite: 21
--	---	--	--	---









JDO - Signalizace stavu výstupů	
16	
15	
14	Aktivovat mikronizér
13	Aktivovat kontrolku automatického režimu
12	Podávací čelist upnout
11	
10	
9	Rameno nahoru
8	Rameno dolů
7	Rameno aretovat
6	Otevřít hlavní světlák
5	Otevřít podávací větrák
4	Zapnout motor pásu
3	Zapnout čerpadlo hydrauliky
2	Zapnout motor vynašeče
1	Zapnout motor chlazení

JDI - Signalizace stavu vstupů		
	Tlačítko uvolněno	Tlačítko stisknuto
16	Pás pily napnout	
15		
14		
13		
12	Rameno je dole	
11	Hlavní světlák upnut	
10	Podávací světlák upnut	
9	Total stop aktivován	
8	Stop automatického režimu	
7	Start automatického režimu	
6	Aktivováno ruční ovládání	Materiál přítomen - podávací světlák
5	Aktivováno automatické ovládání	Aktivován mikronizér
4	Ochrana motoru pásu OK	Aktivován motor chlazení
3	Ochrana čerpadla hydrauliky OK	Bezpečnostní obvod uzavřen
2	Ochrana motoru vynašeče OK	
1	Ochrana motoru chlazení OK	

	CPU - Signalizace stavu jednotky
12	Napájení 5V
11	Napájení 5V - KOM
10	Interní CAN - TXD
9	Interní CAN - RXD
8	Externí CAN - TXD
7	Externí CAN - RXD
6	
5	
4	Zadaná poloha dosažena
3	Regulace podáváče aktivní
2	Podáváč dozadu
1	Podáváč dopředu



BOMAR, s.r.o.
Řezání L236/1

Seit/Maschine/Modell:
Ergonomic 290.250 GAC

Nazov skúšky/číslo papiera/číslo skúšky:
Signalizace LED diód

Číslo dok./Doc./Numl der Dokumente:
Napájení/Power supply/Einspeisung:
Zpracovávatel/Prot verarbeitend:

Ver./Page/
Ver./Page/
Ver./Page/

15

JDO - Output state signalization	
16	
15	
14	Activate the microniser
13	Switch on the automatic cycle indicator
12	Vice the feeding jaw
11	
10	
9	Put the arm up
8	Put the arm down
7	Unlock the arm
6	Open the main gripper
5	Open the feeding gripper
4	Turn on the band motor
3	Turn on the hydraulic pump
2	Turn on the swarf-removal motor
1	Turn on the cooling motor

JDI - Input state signalization	
	Button released
16	Tight the sawband
15	
14	
13	
12	The arm is down
11	Main gripper is closed
10	Feeding gripper is closed
9	Total stop activated
8	Automatic mode stopped
7	Automatic mode started
6	Manual control activated
5	Automatic control activated
4	Band motor protection OK
3	Hydraulic pump protection OK
2	Swarf-rem. motor protection is OK
1	Cooling motor protection OK

CPU - unit state signalization	
12	Voltage 5V
11	Voltage 5V - KOM
10	Internal CAN - TXD
9	Internal CAN - RXD
8	External CAN - TXD
7	External CAN - RXD
6	
5	
4	Desired location reached
3	Feeder regulation is active
2	Feeder to the back
1	Feeder to the front

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	22.4.2016
2	Obsah / Content / Inhalt	20.5.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
3.d	Kusovník artiklů / Parts list / Artikelstückliste	20.5.2016
4	Umístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	25.4.2016
5	Ovládací panel na rozvaděči / Control panel / Bedienpult	22.4.2016
6	Silová část / Power part / Netzteil	25.4.2016
7	Připojení pohonů / Drivings connection / Antriebsanschluss	25.4.2016
8	Pohon plového pásu / Saw belt drive / Saw Riemenantrieb	25.4.2016
9	Propojení napájecích obvodů / Feeding circuits / Stromversorgungsgebiete	25.4.2016
10	Sýkače / Contactors / Schütze	25.4.2016
11	Signály spouštěčů, klávesnice / Signal of shields, keyboard / Schaltersignal, Tastatursignal	25.4.2016
12	Hydraulika / Hydraulics / Hydraulik	25.4.2016
13	Signály koncových spínačů / Signals of limit switches / signale der Endschalter	25.4.2016
14	Připojení modulů / Modules connection / Anschluss der Moduln	25.4.2016
15	Bezpečnostní obvod / Safety circuit / Sicherheitsschaltung	25.4.2016
16	Příslušenství / Accessories / Zubehör	25.4.2016
17	Signalizace LED diod	22.4.2016
18	Description of the LED diodes signalization	22.4.2016
19	LED Standanzeige	22.4.2016

3

1	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Název strany/Page name/pageName schem: Obsah / Content / Inhalt	Verze/Version/Version: Napájení/Power supply/Einspeisung: Datum/Date/Datum: Zpracoval/Processed/Net. verarbeitet:	ES-2009F-203 V1.1 3x230V + PE / 50Hz 20.5.2016 Ing. Kozlák	List: 2 23

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	8150	ABB	91.051.063	1	/15.145
-FA1	Motorový spouštěč - 0.63A Motor starter - 0.63A Motorstarter - 0.63A	MS116-0.63	ABB	91.045.018	1	/7.62
-FA1	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.62
-FA2	Motorový spouštěč - 1.6A Motor starter - 1.6A Motorstarter - 1.6A	MS116-1.6	ABB	91.045.020	1	/7.64
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.64
-FA3	Motorový spouštěč - 6.3A Motor starter - 6.3A Motorstarter - 6.3A	MS116-6.3	ABB	91.045.023	1	/7.67
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/7.67
-KM1	Ministýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/10.93
-KM2	Ministýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/10.94
-KM3	Ministýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/10.96
-KM11	Ministýlač 4kW/400V Minicontactor 4kW/400V Minschutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/15.147
-KM11	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/15.147

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hlavní stránka/First page/Firste seite: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumente.: ES-2100F-233-V1.1 Napájení/Power supply/Einspeisung: 3x230V + PE / 50Hz Zpracovatel/Processed /Auf verarbeitet: Tř. Kvalita Datum/Date/Datum: 20.5.2016	LAD/Projekt/ Seiter: 3 LAD/Projekt/ Seiten: 23

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Part number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM12	Minisvídač 4kW/400V Minicontractor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/15.148
-KM12	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	CAF 6-11M	ABB	91.041.042	1	/15.148
-PA1	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylindersteckse - 3P	E93/32	ABB	91.241.014	1	/8.71
-PA2	Pojistkový odpínač E-90 - 2P Fuse disconnector E-90 - 2P Sicherungstrener E90 - 2P	E 92/32	ABB	91.241.013	1	/9.84
-QS1	3 pólový odpínač 16A Disconnector - 3P 16A Trenner - 3P 16A	OT16F3	ABB	91.170.015	1	/6.50
-RE1	Palice pro relé Relay socket Relaissocket	CR-PSS	ABB	91.051.048	1	/12.119
-RE1	Palčové relé CR-P Plug-in relay CR-P Stecken Sic in Relais CR-P	CR-P024DC2	ABB	91.051.049	1	/12.119
-A1.1	Sestavený modul CPU2-E (UNIVERSAL INT) Assembled module CPU2-E (UNIVERSAL) Montiert Modul CPU2-E (UNIVERSAL)	CPU2-E	Bomar	266.222	1	/14.136
-A3.1	Sestavený modul JDI-2/2 Assembled module JDI-2/2 náhrada za 91.995.039	JDI-2/2	Bomar	266.216	1	/14.133
-A5.1	Sestavený modul JDO-2/0 (plně osazený) Assembled module JDO-2/0 (fully marned) náhrada za 91.995.040	JDO-2/0	Bomar	266.224	1	/14.130
-DKL	Sestavený modul DKL-F5 (display) Assembled module DKL-F5 (display) náhrada za 91.995.048	DKL-F5	Bomar	266.219	1	/14.138
-DM1	Výrobek-oleka OCHRANA3 Product board OCHRANA3 Produkt-board OCHRANA 3	OCHR3	Bomar	266.255	1	/9.83

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hlavní oběžný/Fluss page/Name schen: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. Doc. No./Anzahl der Dokumenten.: ES-2100F-203-V1.1		Lad/Pages/ Seller: 3.4	
			Napájení/Power supply/Einspannung: 3x230V + PE / 50Hz		Lad/Pages/ 3.4	
			Zpracování/Processing /Auf verarbeitet:		Lad/Pages/ 3.4	
			Datum/Date/Datum:		Lad/Pages/ 3.4	

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-H1	Pojistka trubičková - 1A/250V, pomalá, 5x20 Tube fuse - 1A/250V, slow, 5x20 Rohrsicherung - 1A / 250V, langsam, 5x20	T1A/250V	ESKA	91.230.031	1	/9.85
-H2	Pojistka trubičková - 6.3A/250V, pomalá, 5x20 Tube fuse - 6.3A/250V, slow, 5x20 Rohrsicherung - T6.3A / 250V, langsam, 5x20	T6.3A/250V	ESKA	91.230.002	1	/9.84
-RP1	Potenciometr 4K7 Potentiometer 4K7	TP195 4K7/N20A	Elektronické součástky CZ, a.s	91.283.015	1	/8.75
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S5877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/8.75
-S8500	Total stop - Hlavice + 3xNC Emergency-stop mushroom push-button + 3xNC Not-Aus-Pitz - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/15.144
-S8500	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW-E10	IDEC	91.061.044	1	/15.144
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.61
-RCF2	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.63
-RCF3	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/7.66
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/6.56
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/6.57
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendeschalter - 2x NC	QK58	KEDU	91.173.012	1	/15.144

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hlavní zdroj/Flame page/Name section: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. / Doc. No./Anzahl der Dokumente.: ES-2100P-203-V1.1		Lad/Paper/
				Napájení/Power supply/Einspeisung: 3x230V + PE / 50Hz		Seiten: 3.a
				Zpracovatel/Processor/Not verarbeitet: Ing. Kralba		Lad/Paper/
				Datum/Date/Datum: 20.5.2016		Seiten: 23

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ22	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QCS8	KEDU	91.173.012	1	/15.142
-PA1	Pojistka válcová - 10A, 10x38, rychlá Tube fuse - 10A, 10x38, fast Rohrsicherung - 10A, 10x38, schnell	PV10 10A gG	OEZ	91.231.008	3	/8.71
-PA2	Pojistka válcová - 1A, 10x38, pomalá Tube fuse - 1A, 10x38, slow Rohrsicherung - 1A, 10x38, langsam	PV10 1A aM	OEZ	91.231.001	2	/9.84
-SA1	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZBS-AD3	TELEMECANIQUE	91.060.024	1	/11.104
-SA2	SPÍNAČ ČERNÝ 3 polohy - Harmony Switch black 3 positions - Harmony Schalter schwarz 3 Positionen - Harmony	ZBS-AD3	TELEMECANIQUE	91.060.024	1	/11.107
-SB1	Hlavice zelená prosvětlená - Harmony Head green backlit - Harmony Kopf grün Hintergrundbeleuchtung - Harmony	ZBSAW33	TELEMECANIQUE	91.060.019	1	/11.105
-SB2	Hlavice tlačítka černá Button black head Taste Milleser	ZBSAA2	TELEMECANIQUE	91.060.013	1	/11.106
-SB801	Hlavice prosvětleného tlačítka žlutá The button head backlit yellow Der Knopf Kopf von hinten beleuchtet gelb	ZBSAW35	TELEMECANIQUE	91.060.023	1	/15.146
-FM1	Frekvenční měnič - 2.2kW, 3x230V Frequency inverter - 2.2kW, 3x230V Frequenzumrichter - 2.2kW, 3x230V	VACONM010-3L-0011-2	VACON	91.012.067	1	/8.71
-RCF0	Vstupní odrušovací filtr 16A Input noise filter 16A Eingangsausschfilter 16A	16EB15/50	WIDECOM TECHNOLOGY s.r.o.	91.041.062	1	/6.51
-FU1	Sporka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/9.85

The manufacturer reserves right to use an equivalent replacement device.


 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hlavní zdroj/Fluss page/Name series: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc. No./Anzahl der Dokumente.: ES-2100F-203-V1.1 Náplň/Power supply/Ernährung: 3x230V + PE / 50Hz Zpracovatel/Not verarbeitet: Třp. Koutka Datum/Date: 20.5.2016	Lad/Page/ Seite:	3x
				Lad/Seite/ Seite:	23

Kusovník artiklů / Parts list / Stückliste


Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-H2	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS5U	WIELAND	91.251.102	1	/9.84

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok. / Doc. No./Anzahl der Dokumente.: ES-2100F-203-V1.1 Regulární/Powers supply/Einspeisung: 3x230V + PE / 50Hz Zpracováno/Processed /Nda. verarbeitet: 17x Kódika Datum/Data/Datum: 20.5.2016	Lad/Pages/ Seiten: 3,4 Lad/Pages/ Seiten: 23



+OP1



-SB501
-H501

-SA2


-SA1


-SB1
-H2

-SB2

-SB500

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC FM	Hlavní zdroj/Flame page/Name set: Ovládací panel na rozváděči / Control panel / Bedienpult	Číslo dok. Doc. No./Anzahl der Dokumente.: ES-2100P-213-V1.1		Lad/Pages/ Seiten: 5
			Regulární/Power supply/Ergebnisung: 3x230V + PE / 50Hz		
			Zpracoval/Processed / Hat verarbeitet: Ing. Koudla		Lad/Pages/ Seiten: 23 a 2016
			Datum/Date/Datum: 22.4.2016		









BOMAR, s.r.o.
Těžební 1236/1
CZ 627 00, Brno








 BOMAR, s.r.o. Těšebří 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Ergonomic 290.250 GAC FM	Název sítě/ky/Name pages/Name address: Signály spouštěčů, klávesnice / Signal of shields, keyboard / Schaltersignal / Tastatursignal	Číslo dok./Doc./No./Anzahl der Dokumenten.: ES-230MF-293-V4.1	Laž/Page/ Seite: 11
				Impulz/Power supply/Empfangung: 3220W + PE / 50Hz Zpracová/Presenter /Akt verarbeitet: 17p. Kordka Datum/Date/Date: 25.6.2016 Laž/Page/ Seite: 23




11


	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik
BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Ergonomic 290.250 GAC FM	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik	Hydraulika / Hydraulics / Hydraulik
ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1	ES-2100F-203-V1.1
3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz	3x230V + PE / 50Hz
Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka	Typ Kódka
25.4.2016	25.4.2016	25.4.2016	25.4.2016	25.4.2016	25.4.2016	25.4.2016	25.4.2016	25.4.2016


Schémas Schemas Schematics



 BOMAR, s.r.o. Tržební 1236/1 CZ 627 00, Brno	Stroj/Machine/Headline: Ergonomic 290.250 GAC FM	Ilustr. stávkový list na papíru: seřazené: Signály korcových spínačů / Signals of limit switches / signale der Endschalter	Účastník: ES-2006-2013-V1.1 Kopie/Power supply/Umpanung: 3x230V + PE / 50Hz Tržba/Kopie/Tržba: Tržba/Kopie/Tržba Datum/Power/Datum: 25.4.2016.	List/Page/ Seite: 13 List/Page/ Seite: 23
---	--	---	---	--









JDO - Signalizace stavu výstupů	
16	
15	Spustit frekvenční měnič
14	Aktivovat mikronizér
13	Aktivovat kontrolku automatického režimu
12	Podávací čelist upnout
11	
10	
9	Rameno nahoru
8	Rameno dolů
7	Rameno aretovat
6	Otevřít hlavní svěrák
5	Otevřít podávací věrák
4	
3	Zapnout čerpadlo hydrauliky
2	Zapnout motor vynašeče
1	Zapnout motor chlazení

JDI - Signalizace stavu vstupů	
	Tlačítko uvolněno
16	Tlačítko stisknuto
15	Pás pily je napnutý
14	
13	Relé limit proudu frek. měniče sepnuto
12	Rameno je dole
11	Hlavní svěrák upnut
10	Podávací svěrák upnut
9	Total stop aktivován
8	Stop automatického režimu
7	Start automatického režimu
6	Aktivováno ruční ovládání
5	Aktivováno automatické ovládání
4	Poruchové relé frekv. měniče sepnuto
3	Ochrana čerpadla hydrauliky OK
2	Ochrana motoru vynašeče OK
1	Ochrana motoru chlazení OK

CPU - Signalizace stavu jednotky	
12	Napájení 5V
11	Napájení 5V - KOM
10	Interní CAN - TXD
9	Interní CAN - RXD
8	Externí CAN - TXD
7	Externí CAN - RXD
6	
5	
4	Zadaná pozice dosažena
3	Regulace podavače aktivní
2	Podavač dozadu
1	Podavač dopředu

JDO - Output state signalization	
16	
15	Start up speed controller
14	Activate the microniser
13	Switch on the automatic cycle indicator
12	Vice the feeding jaw
11	
10	
9	Put the arm up
8	Put the arm down
7	Unlock the arm
6	Open the main gripper
5	Open the feeding gripper
4	
3	Turn on the hydraulic pump
2	Turn on the swarf-removal motor
1	Turn on the cooling motor


JDI - Input state signalization	
	Button released
16	Button pushed
15	The sawband is tight
14	
13	Speed controller current limit relay
12	The arm is down
11	Main gripper is closed
10	Feeding gripper is closed
9	Total stop activated
8	Automatic mode stopped
7	Automatic mode started
6	Manual control activated
5	Automatic control activated
4	Speed controller failure relay on state
3	Hydraulic pump protection OK
2	Swarf-rem. motor protection is OK
1	Cooling motor protection OK

CPU - unit state signalization	
12	Voltage 5V
11	Voltage 5V - KOM
10	Internal CAN - TXD
9	Internal CAN - RXD
8	External CAN - TXD
7	External CAN - RXD
6	
5	
4	Desired location reached
3	Feeder regulation is active
2	Feeder to the back
1	Feeder to the front

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Skup/Machine/Machine: Ergonomic 290.250 GAC FM	Muzer activity/Name page/Name action: Description of the LED diodes signalization	(Číslo dok. Doc. No./Anzahl der Dokumenten.: ES-2109F-203-V1.1 Ing. Kozák Datum/Date/Datum: 22.4.2016	List/Page/ 18
				Seller: 18
				List/Page/ 23
				Seller: 23

84

6.2. Hydraulické schéma Hydraulisches Schéma Hydraulic diagram



205.2316-200
ERGONOMIC 250 GAE

Základní technické parametry
Technische Spezifikation
Technical specification





Typ / Type / Type		Ergonomic 290.250 GAE
Hydraulický agregát / Hydroaggregat		SMA03-62/13.0-S11.X-H33M.0-
Hydro aggregat		-0456/02400, 92.001.028
Neuvedené světlosti / Unerwähnt Lichtbreite		JS6
Unlisted inside diameters		
Výstupní šroubení / Ausgangsschraubung		G1/4"
Output screwing		
p_{max}		3 Mpa
Q		8,2 dm ³ /min
n		1390 ot./min
P		0,55 kW

POZ.	NÁZEV	TYP	POPIS	POZNÁMKA	POČET
1	NÁDRŽ	speciál BOMAR	30 dm ³	750/7260	1
2	ELEKTROMOTOR	MA-AL 80-4 0,55 kW	400/230V / 50Hz	1,51A	1
3	HYDROGENERÁTOR	P2-6,2L.66017	6,2 cm ³ /ot.		1
4	JEDNOSMĚRNÝ VENT.	VJ01-06/SG-1			1
5	PŘEPOUŠTĚCÍ VENTIL	VPP2-04/S-6S		SEŘÍDIT NA 3 MPa	1
6	ZPĚTNÝ FILTR	FR043-166 (10 µm)	92.153.101 / 039	+VLOŽKA V3.0510-56	1
7	MANOMETR	Ø68 S GLYCERINEM		ROZSAH: 0-6 MPa	2(1)
8	ROZVADĚČ	RPE3-043Z11/02400E1K1	92.101.005		2
9	ROZVADĚČ	RPE3-042R11/02400E1K1	92.101.001		1
10	ROZVADĚČ	SD2E-A3/H2D21	92.101.022	NEBO: ROX-042D21/02400E1K1	2
11	JEDNOSMĚRNÝ VENT.	VJ01-06/SG			2
12	TLAKOVÝ SPINAČ	KÓD:166415031059	ROZSAH 20-50bar	SUCO S KRYTKOU	2
13	ZÁTKA			PRO REGULACI UPÍNACÍ SÍLY	1
14	ZASLEPENÍ				
15	STOP VENTIL	555-0607	92.153.013		1
16	REGULACE NA PÁSU	KOSTKA: 251.218			1
17	REDUKČNÍ VENTIL	VRN2-06/S-6R	V KOSTCE BOMAR		1(0)
18					
19					
20					


7. Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix Ergonomic 290.250 GAC) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Ergonomic 290.250 GAC), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).
- For spare parts order, you must always to allege: type of machine (for example Ergonomic 290.250 GAC), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. ERGONOMIC 290.250 GAC



NAZEV SYSTAVY PILA PASOVA	ČÍSLO SYSTAVY 201.2300-000	STROJ 250 GAC
Konstruoval: MARTINEK		
Datum: 11. 05.2016		
Meritko: 7:100		




7.2. Kusovník / Piece list / Stückliste - ERGONOMIC 290.250 GAC

Císlo Sestavy 201.2300-000	Ver. 3	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.0507-910	3	VALEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLINDER	251.231	1
2	201.0614-200	0	ODMEROVANI / MEASURING / GEHRUNGSMESSUNG		1
3	201.0702-000	2	KONZOLA OTOČNÁ / TURNABLE CONSOL / DREHKONSOLE		1
4	201.2114-520	3	KRYTÍ / COVERS / ABDECKUNGEN		1
5	201.2301-200	5	PODSTAVEC / BASE / UNTERSATZ		1
6	201.2303-200	2	SVERAK / VICE / SCHRAUBSTOCK		1
7	201.2306-200	1	CHLAZENÍ / COOLING / KÜHLUNG		1
8	201.2311-000	0	CELO / HEAD / STIRN		1
9	201.2311-100	1	PODAVAC / FEEDER / VORSCHUB		1
10	201.2311-210	0	KONZOLA / CONSOLE / KONSOLE		1
11	201.2312-210	1	TRAT / TRACK / BAHN		1
12	201.2804-000	8	RAMENO / SHOULDER / SÄGERAHMEN		1
13	30.0507-401	2	DRŽAK / HOLDER / HALTER		1
14	30.0704-035	1	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1.5x56	1
15	30.0704-038	1	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1.5x60	1
16	30.0704-321	1	KRYT PASU / BELT COVER / BANDABDECKUNG	P 1.5x98	1
17	30.2399-001	2	STÍTEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
18	31.0599-005	1	SAMOLEPKA / STICKER / AUFLEBER		2
19	90.013.27.003	1	SROUB / BOLT / SCHRAUBE	M5x10	2
20	90.013.27.017	1	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M4x6	6
21	92.001.027	0	AGREGÁT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
22	99.900.040	1	SAMOLEPKA / STICKER / AUFLEBER		1
23	99.900.045	1	SAMOLEPKA / STICKER / AUFLEBER		1
24	99.900.047	1	SAMOLEPKA / STICKER / AUFLEBER		1
25	99.900.048	1	SAMOLEPKA / STICKER / AUFLEBER		1
26	99.900.049	1	SAMOLEPKA / STICKER / AUFLEBER		1
27	99.900.053	1	SAMOLEPKA / STICKER / AUFLEBER		1
28	99.900.068	1	SAMOLEPKA / STICKER / AUFLEBER	použití vysokozvážnéno vozíku	4
29	99.901.032	1	SAMOLEPKA / STICKER / AUFLEBER	CETIFIKACNÍ SAMOLEPKA	1
1. DOPLNENÝ BEZPEČNOSTNÍ SAMOLEPKY 31.0599-005, 99.900.040, 99.900.045, 99.900.047, 99.900.048, 99.900.049, 99.900.053, 4x99.900.068, CERTIFIKACNÍ SAMOLEPKA 99.901.032, KRYT PASU 30.0704-321, 30.0704-035, 30.0704-038, 4xSROUB M4x6(90.013.27.017), 2xSROUB M5x10(90.013.27.003) 077/ZMI45 4.7.2014 SLEZACKOVA					
2. PRIDANÝ TYPOVÝ STÍTEK 30.2399-001. 001/ZM024 8.3.2016 SLEZACKOVA					
3. PRIDANÝ KRYTOVÁNÍ PODAVACE 201.2114-520. 060/ZMI02 27.4.2016 SLEZACKOVA					

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Verze položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position);
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.3. Válec zvedací / Lifting cylinder / Hebezyylinder



NAZEV SESTAVY VÁLEC ZVEDACÍ	ČÍSLO SESTAVY 201.0507-910	STROJ ERG0250GF.DGH
Konstruová : ZAJIC		
Datum: 17. 03. 2015		
Verze: 3.10		

7.4. Kusovník / Piece list / Stückliste - Válec zvedací / Lifting cylinder / Hebezyylinder

Císlo Sestavy 201.0507-910		Ver. 3	Název sestavy VALEC ZVEDACÍ/LIFTING CYLINDER/HEBEZYLINDER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0507-901	3	VALEC / ROLLER / ZYLINDER	TR 45/40H8	1
2	30.0507-902	0	PIST / PISTON / KOLBEN	d 45	1
3	30.0507-903	2	VÍKO / COVER / DECKEL	TYC 45	1
4	30.0507-911	2	DRŽAK / HOLDER / HALTER	d 40	1
5	30.0507-913(3)	2	POUZDRO / SLEEVE / BÜCHSE	d 16	1
6	30.0514-904	0	CEP / LUG / BOLZEN	d 18	1
7	30.0514-905	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 25x 5	1
8	30.0807-006	2	DRŽAK / HOLDER / HALTER	TYC 25x25	1
9	30.2807-003	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d20	1
10	31.0507-905(1)	0	VÍKO / COVER / DECKEL		1
11	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	1
12	90.001.25.059(3)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X35	1
13	90.101.55.003	0	MATICE / NUT / MUTTER	MATICE M16	1
14	90.150.50.007(3)	0	PODLOZKA / WASHER / UNTERLEGSCHEIBE	PODLOZKA 13	2
15	92.002.001	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4"	1
16	92.002.102	0	SROUBENÍ / BOLTING / VERSCHRAUBUNG	S-GEV-8LLR	1
17	95.800.008	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 18	2
18	95.801.005	0	SEGR DÍRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 40	4
19	96.001.010	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	36X2	1
20	96.002.017	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	34x3 NBR 70SH	1
21	96.041.002	0	MANŽETA TESNÍCÍ / /	20/28x4	1
22	96.060.002	0	KROUZEK STÍRAČÍ / SCRAPER RING / ABSTREIFRING	TK 20x28	1
23	96.082.001	0	KROUZEK TESNÍCÍ / SEAL RING / DICHTUNGSRING	10/14x1.5 CU	1
24	96.082.002	0	TESNENÍ / SEAL RING / DICHTUNGSRING	13/17x1.5 CU	1
25	96.900.015(2)	0	TESNENÍ PISTU / /	PT0200400-T46N	1

1.DOPL.31.0507-905,12.1.04 STASTNÝ

2.ZRUSENO TESNENÍ 96.900.002 A NAHRAZENO 96.900.015. 336/ZM006 11.1.2011 SLEZACKOVA



3.ZRUS.POUZDRO 30.0507-913 A NAHR.30.0507-005,ZRUS.SROUB M12x35(90.001.25.059) A NAHR.M8x35(90.001.25.035).
300/ZM010 29.1.2013 SLEZACKOVA

3.ZRUS.POUZDRO 30.0507-005 A NAHR.30.0507-913,ZRUS.PODLOZKA 8,4 (90.150.50.005) A NAHR.PODLOZKOU 13(90.150.50.007),
ZRUS.SROUB M8x35(90.001.25.035) A NAHR.M12x35(90.001.25.059).083/ZM085 20.3.2013 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position; Objednací číslo/Order number/Bestellnummer; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.5. Odměrování / Measuring / Gehrungsmessung




NAZEV SESTAVY ODMĚROVÁNÍ	CÍSLO SESTAVY 201.0614-200	STROJ
		
Konstruoval: &konstruoval		
Datum: 19. 02.2010		
Meritko: 2:1		

7.6. Kusovník / Piece list / Stückliste -
Odměřování / Measuring / Gehrungsmessung

Cílo Sestavy 201.0614-200		Ver. 0	Mazec sestavy ODMĚROVÁNÍ / MEASURING / GEHRUNGSMESSUNG		
Pos.	Objednací cílo	Ver.	Mazec položky	RozmĚr	Ks
1	30.0614-201	0	CEP / LUG / BOLZEN	d 16	1
2	30.0614-203	0	CLONA / CURTAIN / SCHÜRZE	FOLIE 0.3	1
3	30.0614-204	0	POUZDRO / SLEEVE / BÜCHSE	TR 13x1	1
4	30.0614-208	0	SRUB / BOLT / SCHRAUBE	TYC M10	1
5	31.0614-202	0	KRABICE / BOX / DOSE	VYLISEK-PLAST	1
6	31.0631-201	0	SRINAC / SENSOR / SENSOR		1
7	90.002.20.027	0	SRUB STAVEČ / ADJUSTMENT BOLT / STELLSCHRAUBE	SRUB M5x25	1
8	90.011.21.019	0	SRUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SRUB M5x40	1
9	90.014.50.004	0	SRUB / BOLT / SCHRAUBE	M2.5x14	2
10	90.100.55.003	0	MATICE / NUT / MUTTER	MATICE - M5	2
	91.070.010	0	PRŮCHOVKA / LEADTHROUGH / DURCHFÜHRUNG	M12x1.5 ČERNA	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.7. Konzola otočná / Turnable consol / Drehkonsole



7.8. Kusovník / Piece list / Stückliste -
Konzola otočná / Turnable consol / Drehkonsole


Císlo Sestavy 201.0702-000		Ver. 2	Název sestavy KONZOLA OTOČNÁ / TURNABLE CONSOL / DREHKONSOLE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.0704-100 (2)	0	KARTAC / BRUSH / BÜRSTE		1
2	30.0502-004 (1)	1	PAKA / LEVER / HEBEL	SVARENO	1
3	30.0514-603 (2)	0	DRŽAK / HOLDER / HALTER	P 5x20	1
4	30.0702-001	2	KONZOLA / CONSOL / KONSOLE		1
5	30.0702-002	2	CEP / LUG / BOLZEN	M30x173	1
6	30.0702-006	0	DORAZ / STOP PIECE / ANSCHLAG	TYC 20x20	2
7	30.0702-008	0	POUZDRO / SLEEVE / BÜCHSE	TR 70x5	1
8	30.0702-010	1	DRŽAK / HOLDER / HALTER		1
9	30.0702-012	0	VÍKO / COVER / DECKEL	d 70	1
10	30.0702-013	0	SROUB / BOLT / SCHRAUBE	M8	1
11	30.0707-011	1	DRŽAK / HOLDER / HALTER	TYC 20x20	1
12	31.0702-011	0	STUPNICE / SCALE / SKALA	P 0.5x15	1
13	90.001.25.017 (2)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16	1
14	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	4
15	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x20	1
16	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x35	5
17	90.002.20.017	0	SROUB STAVEČI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x16	1
18	90.005.55.015	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x20	3
19	90.005.55.034	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12x40	1
20	90.012.50.007	0	SROUB / ROLLER BOLT / ZYLINDERSCHRAUBE	SROUB M4x30	2
21	90.100.25.001 (1)	0	MATICE / NUT / MUTTER	MATICE - M30	1
22	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	4
23	90.100.55.007	0	MATICE / NUT / MUTTER	MATICE - M12	1
24	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 4,3	2
25	90.150.50.018 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 31	1
26	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER	-RIWK	1
27	94.004.502 (1)	0	RUKOJET / HANDLE / GRIFF	D22	1
28	95.300.002	0	LOŽISKO KUZELÍK / BEARING / LAGER	32008AX	2
29	96.001.008	0	O-KROUZEK STATICKÝ / STATIC O RING / O-RING STATISCH	26x2 NBR 70SH	1
30	96.001.018	0	O-KROUZEK STATICKÝ / STATIC O RING / O-RING STATISCH	63x2	2

1. ZM. Z KS. STROJE ZRUŠENO: 30.0301-012, 30.0502-002, 30.0502-001, 94.00.2.001, NOVE SOUCASTI: 30.0502-004
94.00.502.90.100.25.001, 90.150.50.018. 11.6.2008 VINOHRADSKÝ


2. PRIDAN KARTACEK 201.0704-100, DRŽAK KARTACKU 30.0514-603 A SROUB M6x16 (90.001.25.017. 183/ZM211 29.10.2009 SLEZACKOVA

7.9. Kartáč / Brush / Bürste

Cislo Sestavy 201.0704-100		Ver. 0		Název sestavy KARTAC/BRUSH/BÜRSTE	
Poz.	Objednací číslo	Ver.	Název položky	Rožmer	Ks
1	30.0104-022	0	DRŽAK / HOLDER / HALTER	HR 16x16	1
2	30.0704-029	0	HRDEL / SHAFT / WELLE	d 14	1
3	31.0704-031	0	KARTAC / BRUSH / BÜRSTE		1
4	90.150.50.006	0	PODLOŽKA DIN125 / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 10,5	1
5	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	1
6	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6,4	1
7	95.800.001	0	KROUZEK POJIST.VNEJŠ / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTINÝ KROUZEK 6	1
8	90.001.25.019	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x25	1



7.10. Kryt podavače / Vorschubsleistedeckel / Feeders bracket cover




NAZEV SESTAVY KRYT	CÍSLO SESTAVY 201.2114-520	STROJ 250GA
Konstruoval: NEUMANN		
Datum: 25. 04.2016		
Měřítko: 1:5		

7.11. Kusovník / Piece list / Stückliste -
Kryt podavače / Vorschubsleistedeckel / Feeders bracket
cover

Císlo Sestavy 201.2114-520		Ver. 0	Název sestavy KRYTY/COVERS/ABDECKUNGEN		
Poz.	Objednáací číslo	Ver.	Název položky	Rozměr	Ks
1	201.2114-525	0	PAKA / LEVER / HEBEL		1
2	201.2114-530	0	PODPERA / SUPPORT / STUTZE		1
3	30.2114-521	0	KRYT / COVER / ABDECKUNG		1
4	30.2114-522	0	PLECH / PLATE / BLECH	P 6x118	1
5	30.2114-527	0	KRYT / COVER / ABDECKUNG		1
6	30.2114-528	0	KRYT / COVER / ABDECKUNG		1
7	30.2114-529	0	DVERE / DOOR / TÜR		1
8	30.2114-533	0	DRŽAK / HOLDER / HALTER		1
9	30.2114-535	0	PLECH / PLATE / BLECH	P 2x45	1
10	99.205.001	0	PROFIL / PROFILE / PROFIL		1

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.12. Podstavec / Base / Untersatz




NAZEV SESTAVY PODSTAVEC	ČÍSLO SESTAVY 201.2301-200	STROJ 250 GAC
Konstruoval: MARTINEK		
Datum: 17. 06.2011		
Meritko: 1:10		

7.13. Kusovník / Piece list / Stückliste -
Podstavec / Base / Untersatz

Číslo Sestavy 201.2301-200		Ver. 4	Název sestavy PODSTAVEC/BASE/UNTERSATZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0501-002	1	SKLUZ / SLIDE / RUTSCH		1
2	30.2114-402	1	VALEČEK / CYLINDER / ROLLE	ø 20	1
3	30.2114-501	0	DVERE / DOOR / TÜR		1
4	30.2114-503	0	RAM / FRAME / RAHMEN		1
5	30.2114-511	0	KRYT / COVER / ABDECKUNG		1
6	30.2301-201	3	PODSTAVEC / BASE / UNTERSATZ		1
7	30.2301-202	0	SÍTO / SIEVE / GITTERWERK	PI-127	1
8	30.2301-204	1	PROFIL / PROFILE / PROFIL	JACKL 35x35x3	2
9	30.2301-205	0	VÍKO / COVER / DECKEL	P 2-170x138	1
10	30.2301-206	1	ÚHELNÍK / ANGLE / WINKEL	PROFIL 35x35x3	1
11	30.2301-207	0	PLECH / PLATE / BLECH	P 3 - 60	1
12	30.2314-012	1	DRŽÁK / HOLDER / HALTER	TVC 20x5	1
13	31.2399-001	1	ŠTÍTEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0.5 - 65	1
14	90.001.25.016	0	ŠROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	4
15	91.071.004	0	VÝVODKA / BUSHING / TÜLLE	VÝVODKA	2
16	91.072.007	0	MATICE / NUT / MUTTER	MATICE	2

7.14. Svěrák / Vice / Schraubstock



NÁZEV SESTAVY SVERÁK	ČÍSLO SESTAVY	STROJ
	201.2303-200	250 GAC
	Konstruoval: MARTINEK	
	Datum: 08. 09. 2011	
	Meritko: 11:50	

7.15. Kusovník / Piece list / Stückliste -
Svěrák / Vice / Schraubstock

Číslo Sešitový 201.2303-200		Ver. 2	Název sešitový SVĚRAK/VICE/SCHRAUBSTOCK		
Poz.	Objednací číslo	Ver.	Název položky	Rožmer	Ks
1	30.2111-006	1	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	ODLITEN	1
2	30.2114-001	0	DRŽAK / HOLDER / HALTER		1
3	30.2303-001	1	PODSTAVEC SVĚRAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
4	30.2303-002	0	CELIST / JAW / BACKE	HR 130x25	1
5	30.2303-003	2	DRŽAK / HOLDER / HALTER	TYC 80x50	1
6	30.2303-202	2	CELIST / JAW / BACKE	P5-279	1
7	30.2303-204	1	SKLUZ / SLIDE / RUTSCH	P 1.5x83	1
8	30.2303-205	2	CELIST / JAW / BACKE	P4-279	1
9	30.2307-220	0	VALEC UPÍNACÍ / FIXING CYLINDER / SPANNZYLINDER		1
10	30.2311-205	0	TYC VODÍČÍ / LEAD POLE / FÜHRUNGSSTANGE	40h6-766	2
11	30.2311-206	3	PLECH / PLATE / BLECH	P 2-258x755	1
12	30.2311-207	2	ROST / GRILL / GITTER		1
13	30.2803-022	1	TYC / POLE / STANGE	d 20	1
14	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X20	1
15	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X12	4
16	90.001.25.032	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	1
17	90.001.25.036	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X40	1
18	90.001.25.045	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X16	2
19	90.001.25.047	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X25	4
20	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X30	2
21	90.001.25.057	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x25	1
22	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X35	6
23	90.002.20.014	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M10X16	5
24	90.005.55.034	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X40	1
25	90.013.27.003	0	SROUB / BOLT / SCHRAUBE	M5X10	4
26	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	4
27	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	2
28	90.101.55.006	0	MATICE / NUT / MUTTER	MATICE M12	1
29	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 6,4	2
30	91.070.001	0	VÝVODKA / BUSHING / TÜLLE	PG7	1
31	91.172.009	0	SPÍNAC INKUTIVNÍ / /	JPS300081.5PNOFC	1
32	94.007.002	0	SROUB / BOLT / SCHRAUBE		1
33	94.008.006	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M10	1


1.VYMENA ODMEROVACÍ TYCE - ZRUSENA SOUC.30.2311-204 A NAHR. 30.2803-022. 571/ZM323 8.11.2006 SLEZACKOVA

2.ZRUS.SPÍNAC 91.172.001 A NAHR.91.172.009. 203/ZM245 8.9.2011 SLEZACKOVA

7.16. Chlazení / Cooling / Kühlung

Císlo Sestavy 201.2306-200		Ver. I	Název sestavy CHLAZENÍ / COOLING / KÜHLUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1806-001	4	NADRŽ / CONTAINER / BEHÄLTER		I
2	30.2306-201	0	VÍKO / COVER / DECKEL	P 1.5x330	I
3	91.020.032 (1)	0	CERPADLO CHLAZENÍ / COOLING PUMP / KÜHLMITTELPUMPE	230/400V	I
4	94.202.021 (1)	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	1/2"-10	I


I. ZRUS.CERPADOLO 91.020.004 A NAHR.91.020.032,ZRUS.REDUKCE 94.202.005 A NAHR.94.202.021. 024/ZM07I 14.3.2016 SLEZACKOVA



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.17. Čelo / Head / Stirn

Císlo Sestavy 201.2311-000		Ver. 0	Název sestavy CELO/HEAD/STIRN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.2107-000	0	PODAVAC / FEEDER / VORSCHUB		1
2	30.2311-001	0	CELO / HEAD / STIRN	P 25x145	1
3	30.2811-209	1	PŘILOŽKA / STRAP / LASCHE	HR 70x15	1
4	90.001.25.058	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X30	2
5	90.001.25.063	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X60	2
6	90.001.25.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	4
7	92.004.001	0	SROUBENÍ UHLOVE / ANGLE BOLTING / WINKELVERSCHRAUBUNG	37701	1
8	95.800.019	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 52	2



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.18. Podavač / Feeder / Vorschub




NAZEV SESTAVY PODAVAC	CÍSLO SESTAVY 201.2107-030	STROJ ERGO.250CAC
Konstruová : SVOBODA		
Datum: 13. 04. 2015		
Měřítko: 1:2		

7.19. Kusovník / Piece list / Stückliste - Podavač / Feeder / Vorschub

Císlo Sestavy 201.2107-000		Ver. 0	Název sestavy PODAVAC/FEEDER/VORSCHUB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2107-001	0	PIST / PISTON / KOLBEN	ø 45	1
2	30.2107-002	0	PŘÍRUBA / FLANGE / FLANSCH	TYC 45	1
3	30.2107-003	0	VÍKO / COVER / DECKEL	ø 45	1
4	30.2107-004	0	VÍKO / COVER / DECKEL	ø45	1
5	30.2111-011	1	REDUCE / REDUCTION / ADAPTOR / REDUKTION	TYC 17	1
6	30.2112-201	0	VALEC / ROLLER / ZYLINDER	TR 52/40H8	1
7	30.2112-202	0	PISTNICE / PISTON ROD / KOLBENSTANGE	ø 20	1
8	90.001.25.019	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x25	1
9	95.801.006	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNY KROUZEK 42	2
10	96.002.007	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	16x2 NBR 70SH	1
11	96.002.017	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	34x3 NBR 70SH	3
12	96.041.002	0	TESNENÍ / SEALING / DICHTUNG	20/28x4	1
13	96.060.002	0	KROUZEK STÍRACÍ / SCRAPER RING / ABSTREIFRING	KROUZEK STÍRACÍ 20	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.20. Podavač / Feeder / Vorschub



NAZEV SESTAVY PODAVAC	CÍSLO SESTAVY 201.2311-100	STROJ 250 GAC
Konstruoval: MARTINEK		
Datum: 08. 09.2011		
Meritko: 3:10		

7.21. Kusovník / Piece list / Stückliste -
Podavač / Feeder / Vorschub


Číslo Seřady 201.2311-100		Ver. 3	Název seřady PODAVAC/FEEDER/VORSCHUB		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.2307-200	0	VALEC UPÍNACÍ / FIXING CYLINDER / SPANNZYLINDER		1
2	201.2311-400	1	CELIST / JAW / BÄCKE		1
3	30.2311-102	2	VOZÍK / CART / WAGEN	ODLITEK	1
4	30.2311-103	2	DESKA / BOARD / PLATTE	TYC 120x25	1
5	30.2311-104 (2)	0	DORAZ / STOP PIECE / ANSCHLAG	L 30x 30x3	1
6	30.2311-105	1	TYC / POLE / STANGE	TYC 8	1
7	30.2311-111	1	DRŽÁK / HOLDER / HALTER	P20-79.9	1
8	30.2311-112	4	DRŽÁK / HOLDER / HALTER	HR 80x50	1
9	30.2911-029	0	DRŽÁK / HOLDER / HALTER	HR 50x50	1
10	30.2911-030	0	STERAC / WIPER / ABSTREIFER	P 0.2-26.5	2
11	90.001.25.023	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x50	2
12	90.001.25.036	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x40	2
13	90.001.25.076	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x18	1
14	90.001.55.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	2
15	90.013.27.005 (2)	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5x16	1
16	91.172.009 (3)	0	SPÍNACÍ INDUKTIVNÍ / /	JFS30D081.SPNOFC	1
17	91.270.006	0	SNÍMACÍ MAGNET. / MAGNETIC SENSOR / MAGNETSENSOR		1
18	93.010.002	0	SROUB / BOLT / SCHRAUBE	G1/4"	1
19	94.008.006	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M10	1
20	95.700.003	0	POUZDRO / SLEEVE / BÜCHSE	20x15	1
21	95.700.011	0	POUZDRO / SLEEVE / BÜCHSE	10x8	1
22	95.700.025 (1)	0	POUZDRO / SLEEVE / BÜCHSE	40x40	4
23	95.860.001 (1)	0	HĚLAVICE MAZACÍ / HEAD / KOPF	KM5	2
24	96.040.001	0	KROUZEK STÍRACÍ / SCRAPER RING / ABSTREIFRING	40x50	4
25	96.082.002	0	TESNĚNÍ / SEALING / DICHTUNG	KROUZEK CU 13/17	2

1. Doplněna souc. 95.860.001, pouzdro KU40x40 95.700.006 nahrazeno 95.700.025 24.3.05 Stasina

2. PRIDANA NOVA SOUCAST 30.2311-104, SROUB PULKULATY M5x16. 22.4.2005 SLEZACKOVA

3. ZRUS.SPINAC 91.172.001 A NAHR. 91.172.009. 203/ZM245 8.9.2011 SLEZACKOVA

7.22. Válec upínací / Fixing cylinder / Spannzyylinder




NAZEV SESTAVY VÁLEC UPÍNACÍ	CÍSLO SESTAVY 201.2307-230	STROJ 250 GAC
Konstruoval: MARTINEK		
Datum: 24. 03. 2015		
Měřítko: 1:2		

7.23. Kusovník / Piece list / Stückliste - Válec upínací / Fixing cylinder / Spannzyylinder

Císlo Sestavy 201.2307-200		Ver. 0	Název sestavy VALEC UPÍNAČI/FIXING CYLINDER/SPANNZYLINDER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	K's
1	30.2107-203	0	VÍKO / COVER / DECKEL	ø 45	1
2	30.2107-204	0	VALEC / ROLLER / ZYLINDER	TR 52/42	1
3	30.2107-205	0	DORAZ / STOP PIECE / ANSCHLAG	HR12	1
4	30.2307-201	0	CELIST / JAW / BACKE		1
5	31.2107-206	0	PRUŽINA / SPRING / FEDER	2x12x84x25,5	1
6	90.003.20.001	0	SROUB STAVEČI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5X6	1
7	90.012.50.012	0	SR. S VALC. HLAV. / ROLLER BOLT / ZYLINDERSCHRAUBE	SROUB M8X16	1
8	90.301.02.008	0	KOLÍK VALCOVÝ / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLÍK 8X20	1
9	90.301.02.017	0	KOLÍK VALCOVÝ / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLÍK 6X45	1
10	95.780.001	0	KROUZEK VODÍČI / LEAD RING / FÜHRUNGSRING	GR 4300160	1
11	95.801.006	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 42	1
12	96.002.017	0	KROUZEK O DYNAMICKÝ / DYNAMIC O RING / O-RING DYNAMISCH	34x3 NBR 70SH	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.24. Čelist / Jaw / Backe



NAZEV SESTAVY CELIST	CISLO SESTAVY 201.2311-400	STROJ 250 GAC
	Konstruoval: MARTINEK	
	Datum: 02. 07.2014	
	Meritko: 4:5	

7.25. Kusovník / Piece list / Stückliste - Čelist / Jaw / Backe


Číslo Sestavy 201.2311-400		Ver.	Název sestavy CELIST/JAW/BACKE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2111-101	1	DRŽAK / HOLDER / HALTER		1
2	30.2111-103	0	KLIN / WEDGE / KEIL	HR 25x25	1
3	30.2111-104	2	PISTNICE / PISTON ROD / KOLBENSTANGE	d 16	1
4	30.2111-105	0	PIST / PISTON / KOLBEN	d 45	1
5	30.2111-106	0	VALEC / ROLLER / ZYLINDER	TR 45/40H8	1
6	30.2111-107	1	VÍKO / COVER / DECKEL	d 45	1
7	30.2111-108	0	VÍKO / COVER / DECKEL	HR 50x30	1
8	30.2111-109	0	DORAZ / STOP PIECE / ANSCHLAG	HR 20x8	1
9	30.2111-110	1	KRYT / COVER / ABDECKUNG	PI. 5-107	1
10	30.2111-111	1	KRYT / COVER / ABDECKUNG	P 1-30	1
11	30.2111-112	0	DESKA / BOARD / PLATTE	d 16	1
12	30.2111-113	0	CEP / LUG / BOLZEN	d 14	1
13	30.2111-114	0	PŘILOŽKA / STRAP / LASCHE		2
14	30.2311-401	0	CELIST / JAW / BACKE		1
15	31.1003-016	0	PRUŽINA / SPRING / FEDER	12x2.24x56x16	2
16	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	1
17	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	1
18	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	4
19	90.001.25.089	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x22	4
20	90.002.20.021	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x20	1
21	90.004.20.008	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x16	1
22	90.151.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 5	1
23	92.004.001	0	SROUBENÍ UHLOVE / ANGLE BOLTING / WINKELVERSCHRÄUBUNG	37701	2
24	94.007.001	0	SROUB / BOLT / SCHRAUBE	M5x10	2
25	96.001.003	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	8x2	1
26	96.001.010	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	36x2	1
27	96.001.011	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	40x2	1
28	96.002.016	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	32x2	1
29	96.041.001	0	TESNĚNÍ / SEALING / DICHTUNG	16x24x4 UN	1
30	96.060.001	0	KROUZEK STIRACÍ / SCRAPER RING / ABSTREIFRING	16x22 NBR 70	1
31	96.900.002	0	TESNĚNÍ KOMBINOVANÉ / COMBINATION SEALING / KOMBIDICHTUNG	PW4200400-WJAO3	1

I. PRIDAN SROUB STAVECI M6x20. 408/ZM394 18.11.2008 SLEZACKOVA


Číslo sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.26. Konzola / Console / Konsole

Císlo Sestavy 201.2311-210		Ver. 0	Název sestavy KONZOLA / CONSOLE / KONSOLE		
Poz.	Objednací číslo	Ver.	Název položky	Rožmer	Ks
1	30.2112-104	0	POUZDRO / SLEEVE / BÜCHSE	SK 17(19)	2
2	30.2311-211	2	KONZOLA / CONSOLE / KONSOLE		1
3	30.2311-212	1	VALECEK / CYLINDER / ROLLE	TRUBKA 33.7x3.25	1
4	30.2311-213	0	TYC / POLE / STANGE	d12	1
5	90.003.20.001	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5x6	2
6	90.303.02.001	0	KOLIK / PIN / BOLZEN	KOLIK 3x16	2
7	94.006.002	0	SROUB / BOLT / SCHRAUBE	M8x25	1
8	95.001.005	0	LOŽISKO / BEARING / LAGER	6001 2RS	2



7.27. Trať / Track / Bahn



NAZEV SYSTÉMU TRAT	ČÍSLO SYSTÉMU 201.2312-210	STROJ 250 GAC
Konstruoval: MARTINEK		
Datum: 17. 12.2013		
Měřítko: 1:5		


7.28. Kusovník / Piece list / Stückliste -
Trať / Track / Bahn

Císlo Sestavy 201.2312-210		Ver. 1	Název sestavy TRAT/TRACK/BAHN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	203.1614-300.M330 (1)	0	NOHA DOPRAVNÍKU / FEEDER LEG / STANDER DES FOERDERERS		1
2	30.2312-211	0	RAM / FRAME / RAHMEN	P 3x570	1
3	30.2312-212	0	VALEČEK / CYLINDER / ROLLE	TRUBKA 44.5x6.3	3
4	30.2312-213	0	TYC / POLE / STANGE	TYC 15	3
5	30.2312-214	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TRUBKA 22x2	3
6	30.2312-215	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TRUBKA 25x5	3
7	30.2312-216	1	DÍL PŘIPOJOVACÍ / ATTACHMENT PART / ANSCHLUSSTEIL	P 3x141	1
8	90.001.25.018	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x20	3
9	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	2
10	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	2
11	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 6,4	3
12	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 8,4	4
13	95.001.015	0	LOŽISKO / BEARING / LAGER	6202 2RS	6

I.ZRUS.NOHA 203.1620-200 (253.102) A NAHR.203.1614-300(253.187). 325/ZM303 17.12.2013 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.29. Rameno / Shoulder / Sägerahmen




NAZEV SYSTÉMU RAMENO	CÍSLO SYSTÉMU 201.2804-000	STROJ ERG0250DGH
Konstruoval: STASTNY		
Datum: 22. 04.2014		
Meritko: 1:10		

7.30. Kusovník / Piece list / Stückliste -
Rameno / Shoulder / Sägerahmen

Císlo Sestavy 201.2804-000		Ver. 8	Název sestavy RAMENO/SHOULDER/SÄGERAHMEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.0508-000	0	NAPINANI / TENSIONING / SPANNUNG		1
2	201.2810-000	0	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
3	30.0104-029	0	UCHYTKA / CLIP / HALTER	P 2- 36	1
4	30.0105-007	0	PŘILOŽKA / STRAP / LASCHE	P 2.5x90	1
5	30.0504-010	1	DESKA ELEKTRO / ELECTRIC BOARD / PLATINE	P 1.5 - 95	1
6	30.0504-011	0	GUMA / RUBBER / GUMMI	TL 2-95	1
7	30.0504-604 (4)	2	KRYT / COVER / ABDECKUNG	P 1.5x84	1
8	30.0504-751 (1)	7	RAMENO / SHOULDER / SÄGERAHMEN	80.0504-701	1
9	30.0504-753 (5)	1	KRYT NAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 1.5x492	1
10	30.0505-007	2	HŘÍDEL / SHAFT / WELLE	TYC 35	1
11	30.0505-009	1	KROUZEK / RING / RING	Tr 44,5x8	1
12	30.0505-010	0	PŘILOŽKA / STRAP / LASCHE	P 2.5- 108	1
13	30.0505-013	0	ZATKA / PLUG / STOPFEN	d 55	1
14	30.0505-201	1	VÍKO / COVER / DECKEL	C.M.80.0705-001	1
15	30.0505-701	0	KOLO HNACÍ / DRIVE WHEEL / ANTRIEBSRAD		1
16	30.0508-002	0	PODLOŽKA / WASHER / UNTERLESCHEIBE	d 40	1
17	30.0704-007	5	KRYT NAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 6x80	1
18	30.0704-032	2	PŘILOŽKA / STRAP / LASCHE	P 2 - 15	1
19	30.11814-011	2	DRŽÁK / HOLDER / HALTER	P 3x76	1
20	31.0505-003	1	KOLO OZUBENÉ / COG WHEEL / ZAHNRAD	D 176	1
21	31.0505-004 (8)	1	PŘEDLOHA / SHAFT / WELLE	d40	1
22	31.0505-005 (8)	0	KOLO OZUBENÉ / COG WHEEL / ZAHNRAD	D 180	1
23	31.0505-202 (8)	1	PASTOREK / PINION / RITZEL	d 32	1
24	90.001.25.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	10
25	90.005.55.013	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x12	6
26	90.011.27.008	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10x20	1
27	90.013.27.008 (3)	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M8x16	6
28	90.302.02.002	0	KUŽEL, KOLÍK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLÍK 8x30	2
29	90.400.52.001	0	ZATKA / PLUG / STOPFEN	M10x1	1
30	90.400.52.002	0	ZATKA / PLUG / STOPFEN	M16x1.5	1
31	90.400.52.003 (2)	0	ZATKA / PLUG / STOPFEN	M 24x1.5	1
32	91.001.007	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR		1
33	91.071.004	0	VÝVODKA / BUSHING / TÜLLE	VÝVODKA	1
34	91.072.007	0	MATICE / NUT / MUTTER	MATICE	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.31. Rameno / Shoulder / Sägerahmen



NAZEV SESTAVY RAMENO	CÍSLO SESTAVY 201.2804-000	STROJ ERG0250DGH
Konstruoval: STASTNY		
Datum: 22. 04.2014		
Meritko: 1:10		


7.32. Kusovník / Piece list / Stückliste - Rameno / Shoulder / Sägerahmen

35	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER	- RIWK	I
36	91.173.012	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		I
37	91.190.004	0	KRABICE ELEKTRO / ELECTRO BOX / ELEKTRODOSE		I
38	94.007.002	0	SROUB / BOLT / SCHRAUBE		2
39	94.102.002	0	UCPAVKA / PLUG / STOPFEN	22	I
40	94.200.001	0	REDUCE / REDUCTION / ADAPTOR / REDUKTION	6	I
41	94.202.002	0	REDUCE / REDUCTION / ADAPTOR / REDUKTION	GES 6/R1/4"	2
42	95.001.018	0	LOŽISKO / BEARING / LAGER	6205 2RS	I
43	95.001.025	0	LOŽISKO / BEARING / LAGER	6306 2RS	I
44	95.003.002	0	LOŽISKO / BEARING / LAGER	6205AN	I
45	95.003.003	0	LOŽISKO / BEARING / LAGER	6306AN	I
46	95.800.012	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 25	3
47	95.800.013	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 30	I
48	95.810.006	0	PERO TESNE / TIGHT SPRING / PASSFEDER	PERO 8X7X20	I
49	95.810.007	0	PERO TESNE / TIGHT SPRING / PASSFEDER	PERO 8X7X25	I
50	95.810.023	0	PERO TESNE / TIGHT SPRING / PASSFEDER	PERO 8X7X22	I
51	95.830.005	0	GUFERO / GIT SEAL / DICHTUNG	GUFERO 40X72X7	I
52	95.002.024	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	30X2	I
53	96.081.001	0	KROUZEK TESNICI / SEAL RING / DICHTUNGSRING	23x15x3	I
54	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	I

1. VYMENA RAMENE A KRYTU RAMENE - ZRUSENA SOUCAST 30.0504-701 A NAHR. 30.0504-751, ZRUSENA SOUC. 30.0504-702 A NAHR. 30.0504-752. 558/ZM281 19.10.2006 SLEZACKOVA
2. PRIDAN OLEJOVNÁK 90.400.52.003. 633/ZM021 12.2.2007 SLEZACKOVA
3. ZRUS. KARTACEK 201.0704-100. PRID. KRYT 30.0504-603. ZRUS. SROUB IMBUS M6X16 (90.001.25.017) A NAHRÁZEN SROUBEM S PULKULATOU HLAVOU M6x16 (90.013.27.008). 183/ZM211 26.11.2009 SLEZACKOVA
4. ZRUS. KRYT KARTÁČKU 30.0504-603 A NAHRÁZEN 30.0504-604. 052/ZM050 22.2.2010 SLEZACKOVA
5. ZRUS. KRYT 30.0504-752 A NAHRÁZEN 30.0504-753. 036/ZM095 12.4.2010 SLEZACKOVA
7. ZRUS. KRYT 30.0704-021. 077/ZM088 22.4.2014 SLEZACKOVA
8. ZRUS. SOUC. 30.0505-004 A NAHR. 31.0505-002 A NAHR. 31.0505-202, ZRUS. 30.0505-005 A NAHR. 31.0505-005. 003/ZM005 16.1.2015 SLEZACKOVA

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Name sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Name položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.33. Napínání / Tensioning / Spannung



	MAZEV SESTAVY NAPINANI	CISLO SESTAVY 201.0508-000	STROJ ERGO 250GA
	Konstruktor: _____ Datum: 06. 11. 2009 Meritko: 33-100		


7.34. Kusovník / Piece list / Stückliste -
Napínání / Tensioning / Spannung

Číslo Sešitů 201.0508-000		Ver. 0	Název sešitů NAPÍNÁNÍ / TENSIONING / SPANNUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0104-002	0	HRANOL / BLOCK / PRISMA	HR 50x 30	1
2	30.0104-004	2	DRŽAK / HOLDER / HALTER		1
3	30.0303-005	0	SROUB / BOLT / SCHRAUBE	M16	1
4	30.0505-011	2	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	TYC 40	1
5	30.0508-004	0	CEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		1
6	30.0508-701	4	KOLO NAPÍNÁNÍ / TENSIONING WHEEL / UMLENNRAD		1
7	30.0702-023	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING		1
8	30.0704-025	3	DRŽAK / HOLDER / HALTER	P 4 x 36	1
9	31.0104-006	0	HVEZDICE / STAR WHEEL / STERN	PLAST	1
10	90.004.20.008	2	STAV SR S CIP / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8X16	1
11	90.005.55.017	0	6 HR SROUB ZIN / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8X30	1
12	90.005.55.023	0	6 HR SROUB ZIN / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10X20	1
13	90.100.55.005	0	MATICE DIN 934 / NUT / MUTTER	MATICE - M8	1
14	90.100.55.008	0	MATICE DIN 934 / NUT / MUTTER	MATICE - M16	1
15	90.300.02.012	0	KOLIK VALC. KAL. / PIN / BOLZEN	KOLIK 8X50	1
16	90.303.02.008	0	KOLIK PRUŽNÝ / PIN / BOLZEN	KOLIK 5X20	1
17	90.350.02.002	0	PRUŽINA TALIROVA / DISC SPRING / TELLERFEDER	35,5X18,3X2,0X2,8	7
18	95.001.018	2	LOŽISKO / BEARING / LAGER	6205 2RS	2
19	95.750.001	0	KROUZEK KU / KU RING / KU-RING	16x1	2
20	95.800.012	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNÝ KROUZEK 25	1
21	95.801.009	2	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 52	1

① ZMENA 30.0702-023 NA 30.0508-006, 0508-701 NA 0508-102, 0508-004 NA 0508-007, 0104-002 NA 0508-008, 95.001.018 NA 95.001.036
0505-011 NA 0508-002, 95.801.009 NA 95.801.010 14.5.2004 URICAR

2.ZRUSENA ZMENA 1. NEBYLA REALIZOVANA. 266/ZM255 28.7.2008 SLEZACKOVA

7.35. Vedení pásu / Belt guide / Sägebandführung




WZKY SESTAVY	CÍSLO SESTAVY	STUJ
VEDENÍ PÁSU	201.2810-000	STG 240A/GA
Konstruoval: 27. 11. 2009		
Datum: 27. 11. 2009		
Meritko: 1:2		

7.36. Kusovník / Piece list / Stückliste -
Vedení pásu / Belt guide / Sägebandführung

Číslo sestavy 201.2810-000		Ver. 0	Název sestavy VEDENÍ PASU/BELT GUIDE/SÄGEBANDFÜHRUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	251.218	0	REGULACE PRITLAKU / PRESSURE REGULATION / SCHNITTDRUCKREGULATION		1
2	201.0110-100	0	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
3	201.2810-200	0	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
4	30.0104-015	0	LISTA / TRIM / LEISTE	TYC 40x20	1
5	30.0504-961	0	PAS PÍLOVÝ / SAW BELT / SÄGEBAND	2910x25(7)±0.90	1
6	30.0704-010	0	UPINKA / FASTENER / SPANNEISEN	ODLITEK	1
7	30.0704-014	0	LISTA / TRIM / LEISTE	TYC 40x15	1
8	30.2804-001	0	DRŽAK / HOLDER / HALTER		1
9	30.3510-004	0	TRUBKA / TUBE / ROHR	TR 8x 1	1
10	90.001.25.018	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x20	2
11	90.001.25.032	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	4
12	90.001.25.104	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x22	2
13	90.163.00.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8	4
14	92.003.104	0	SROUBENÍ / BOLTING / VERSCHRAUBUNG	607002	2
15	94.008.009	0	PAKA UPINACÍ / ATTACHMENT LEVER / SPANNHEBEL	M12x50	1
16	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	GES 6/R1/4"	1
17	94.204.001	0	DRŽAK / HOLDER / HALTER		1
18	96.080.001	0	KROUZEK / RING / RING	17.8x13.5x2	1
19	99.260.001	0	VENTIL / VALVE / VENTIL		1

I.PRID. 4xPODLOŽKA NORD LOCK M8 90.163.00.002,ZRUS. 4xSROUB M8x16 A NAHRZEN SROUBEM M8x20 . 161/ZM148 13.5.2008 SLEZACKOVA

7.37. Kostka vodící / Lead cube / Führungsklotz



NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.0110-100	STROJ STG-240
	Konstruoval:	
	Datum:	06. 11. 2009
	Meritko:	4:5


7.38. Kusovník / Piece list / Stückliste -
Kostka vodící / Lead cube / Führungsklotz

Císlo Sestavy 201.0110-100		Ver. 0	Název sestavy KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0104-018	0	EXCENTR / CAM / EXZENTER	SK10	1
2	30.0104-019	0	EXCENTR / CAM / EXZENTER	SK10	1
3	30.0104-021 (1)	0	DRŽÁK / HOLDER / HALTER		2
4	30.0104-032 (1)	2	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	TYC 60x40	1
5	90.001.25.030	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x14	1
6	90.002.20.009	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x6	1
7	90.005.55.003	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M5x16	1
8	90.005.55.005	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M5x25	1
9	90.011.27.007	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8x12	1
10	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 5,3	2
11	95.001.001	0	LOŽISKO / BEARING / LAGER	608 2RS	2
12	99.040.002	0	TVRDOKOV / HARD METAL / HM-SEGMENT	d 12	1

1. ZRUS. KOSTKA 30.0104-017 A NAHR. 30.0104-032, ZRUS. DRŽÁK 30.0104-020 A NAHR. 30.0104-021. 297/272 12.8.2008 KRPEC

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.39. Kostka vodící / Lead cube / Führungsklotz



NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.2810-200	STROJ STG 240A/GA
	Konstruoval:	
	Datum: 06. 11. 2009	
	Meritko: 3:5	

7.40. Kusovník / Piece list / Stückliste -
Kostka vodící / Lead cube / Führungsklotz

Císlo Sestavy 201.2810-200		Ver. 0	Název sestavy KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0104-018	0	EXCENTR / CAM / EXZENTER	SK 10	1
2	30.0104-019	0	EXCENTR / CAM / EXZENTER	SK 10	1
3	30.0104-021	1	DRŽAK / HOLDER / HALTER		2
4	30.2804-012	1	KOSTKA VODICI /	HR 60x40	1
5	30.3510-002	1	DRŽAK TVRDOKOVU / POA HOLDER / HW-HALTER	TYC 16	1
6	90.001.25.030	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x14	1
7	90.002.20.009	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x6	1
8	90.004.20.017	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5x8	1
9	90.005.55.003	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M5x16	1
10	90.005.55.005	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M5x25	1
11	90.005.55.007	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M6x16	1
12	90.011.27.007	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8x12	1
13	90.100.55.004	0	MATICE / NUT / MÜTTER	MATICE - M6	1
14	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 5,3	2
15	95.001.001	0	LOŽISKO / BEARING / LAGER	608 2RS	2
16	99.040.002	0	TVRDOKOV / HARD METAL / HW-SEGMENT	d 12	1

I. ZRUS.KOSTKA 30.2804-002 A NAHR. 30.2804-012.ZRUS.DRŽAK 30.0104-020 A NAHR.201.0104-021. 340/ZM343 16.10.2008 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung