




Proline 420.350 H **Proline 420.350 Hsx**

Operating instructions

Before transporting and using the machine,
please read the instructions thoroughly!

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.16 / May 2024
rev. 1

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

^{1) 2)} We:

BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, Czech Republic
 Id. No: 48908827
declare herewith

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government.

This statement applies exclusively to the machine device in conditions in which it was brought to the market. It does not apply to parts subsequently added by the end user or to modifications performed subsequently by the end user.

In the event of any device modification not approved by us this declaration shall lose its validity

Name: **Band Saw**

Type : **Proline 420.350 H**
Proline 420.350 Hsx

Serial number: 011-100 000

Manufacturer **BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno**

Product data

Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics

Description: Stand, table, cutting unit with the saw band and drive, clamping device, cooling system, el. switch board with control panel.

Pneumatic ☒ NO ☐ YES

Hydraulic ☐ NO ☒ YES

Control system ☐ NO ☒ YES

Technical data:

Typ „H“

Typ „Hsx“

Cutting rate 20–120 m.min-1

Cutting angle 0°

Characteristic cutting range 420 x 350 mm

Documentation:

Technical documentation for this machine device was elaborated in compliance with Government regulation no. 176/2008, Annex 7, part A.

The device meets relevant requirements of the given directives:

2006/42/EC

2014/30/EG

The applied harmonized standards, National standards and technical specifications:

ČSN EN ISO 12100:2011

ČSN EN ISO 16093:2018

ČSN EN ISO 13857:2021

+ Opr.1:2020 + Opr.2 :2021

ČSN EN ISO 4413:2011

ČSN EN 60204 -1 ed.3:2019

ČSN EN 55011 ed.4:2017

ČSN EN 61000-6-2 ed.4:2019

ČSN EN IEC 61000-6-4 ed.3:2019

+ A1: 2017+ A11:2020 + A2:2020

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, art.3a), of the Law no. 22/1997 Coll. as amended.

Brno, 15.08.2022

Point of issue, datum

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIC: CZ48908827



Alfred Pichlmann, Managing Director

Name and function of the responsible subject, signature

1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)

2) Person authorized to complete the technical documentation

3) The authorized or accredited body co-operating on the conformity judging

!

If the equipment is installed without safety equipment offered by BOMAR, spol. s r.o or its agents and used by the customer (or buyer) then EC declaration loses validity.
 EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.
 All machine elements and components that were built into the device by BOMAR, spol. s r.o have been declared "identical" to a safety device, as offered by BOMAR, spol. s r.o or its agents.

Content

1. BEZPEČNOSTNÍ POKYNY / SICHERHEITSHINWEISE / SAFETY NOTES..... 9

1.1. Machine determination.....	11
1.2. Protective suit and personal safety.....	11
1.3. Safety notes for machine operator.....	12
1.4. Safety notes for the servicing and repairs.....	13
1.5. Safety instructions for laser radiation sources.....	13
1.6. Safety notes for the servicing and repairs on hydraulic unit.....	14
1.7. Safety machine accessories.....	14
1.7.1. Emergency Stop Switch.....	14
1.8. Arm covers.....	15
1.8.1. Band saw cover.....	15
1.8.2. Brush cover.....	15
1.9. Safety guidelines for laser beam.....	16
1.10. Safety notes for the cooling.....	16
1.10.1. Instructions for first help.....	16
1.11. Umístění štítku stroje / Maschinenschild position / Position of machine label.....	17
1.12. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	18

2. DOKUMENTACE STROJE / DOKUMENTATION DER MASCHINEN / MACHINE DOCUMENTATION..... 21

2.1. Technická data / Technische Daten / Technical data.....	23
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram.....	25
2.3. Popis / Beschreibung / Description.....	26
2.4. Transportation and stocking.....	27
2.4.1. Conditions for transportation and stocking.....	27
2.4.2. Transport and stocking preparations.....	27
2.4.3. Transport and stocking.....	27
2.4.4. Transportní schéma / Transport schema / Transport scheme.....	28
2.5. Activation.....	29
2.5.1. Machine working conditions.....	29
2.6. Band saw unpacking and assembling.....	29
2.6.1. Machine installing and leveling.....	29
2.6.2. First run of the power pack.....	30
2.6.3. Filling the reservoir with hydraulic oil.....	30
2.6.4. Kotevní plán / Verankerungsplan / Grounding plan.....	31
2.6.5. Electrical connection.....	32
2.6.6. Check the direction of the saw band.....	32
2.6.7. Check machine connection into electrical network.....	32
2.6.8. Filling of the cooling system.....	33
2.7. Check machine function.....	33
2.8. Machine disposal after lifetime.....	33
2.9. Saw band.....	34
2.9.1. Saw band size.....	34
2.9.2. Selection of the saw band tooth system.....	34
2.9.3. Saw band running-in.....	34
2.9.4. Tables for teeth selection.....	35

3. OVLÁDÁNÍ STROJE / BEDIENUNG DER MASCHINE / MACHINE CONTROL..... 37

3.1. Starting the band saw.....	39
3.2. Control panel.....	40
3.3. Machine control.....	42
3.4. Cycle breaking.....	42
3.5. Band saw adjusting.....	42
3.5.1. Cutting speed adjusting.....	42
3.5.2. Speed adjustment of the arm lowering.....	43
3.5.3. Electronic measuring device (optional accessories).....	43
3.5.4. Saw frame upper position stop adjustment – lift arm adjustment.....	45
3.5.5. Saw frame lower position stop adjustment.....	46
3.5.6. Adjusting band guides.....	47
3.5.7. Brush adjustment.....	47
3.5.8. Setting of a cooling method.....	48
3.5.9. Halogen lighting of working area (optional accessory).....	48
3.6. Material insertion.....	49
3.6.1. Handling agent selection.....	49
3.6.2. Insertion.....	49
3.6.3. Bundle material cutting.....	49

4. ÚDRŽBA STROJE / WARTUNG / MACHINE SERVICE..... 51

4.1. Saw band dismantling.....	53
4.2. Saw band instalation.....	54
4.3. Saw band stretching and inspection.....	55
4.3.1. Mechanical indicator of belt tightening.....	55
4.3.2. Hydraulic indicator of belt tightening (optional accessory)	56
4.4. Adjusting of the limit switch of the saw band stretching.....	57
4.4.1. Saw band run adjustment on stretching wheel.....	57
4.5. Cooling agents and chips disposal.....	58
4.5.1. Coolant device inspection	58
4.5.2. Chips disposal.....	59
4.5.3. Third coolant inflow (optional accessories).....	59
4.5.4. Gun cleaning machines from chip (optional accessories).....	60
4.6. Hydraulic, Greases and oils.....	61
4.6.1. Gearbox oils.....	61
4.6.2. Lubricant greases.....	62
4.6.3. Lubrication.....	62
4.6.4. Hydraulic oils.....	63
4.6.5. Hydraulic unit service	64
4.7. Machine cleaning.....	64
4.8. Worn pieces replacement.....	65
4.8.1. Hard metal guides replacement.....	65
4.8.2. Round brush replacement.....	65
4.8.3. Saw band guiding rollers replacement.....	66
4.8.4. Stretching wheel replacement.....	68
4.8.5. Driving wheel replacement.....	70
4.8.6. Cooling pump replacement	71

5. ZÁVADY / STÖRUNGEN / TROUBLESHOOTING..... 73

5.1. Mechanical problems.....	75
5.2. Electric and hydraulic problems.....	77
5.3. Hydraulic problems.....	78

6. SCHÉMATA / SCHEMAS / SCHEMATICS 81

6.1. Elektrické schéma / Elektroschema / Wiring diagrams – Proline 420.350 H.....	83
6.1.1. 3x400 V + PE, 50 Hz.....	83
6.1.2. 3x230 V + PE, 50 Hz.....	109
6.2. Elektrické schéma / Elektroschema / Wiring diagrams – Proline 420.350 Hsx.....	133
6.2.1. 3x400 V + PE, 50 Hz.....	133
6.2.2. 3x230 V + PE, 50 Hz.....	155
6.3. Hydraulické schéma / Hydraulikschema / Hydraulic scheme.....	178

7. VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER..... 183

7.1. 201.R300-700 PROLINE 420.350 H.....	184
7.1.1. 201.R300-700 Kusovník / Piece list / Stückliste - PROLINE 420.350 H.....	185
7.1.2. 201.R300-700 PROLINE 420.350 H.....	186
7.1.3. 201.R300-700 Kusovník / Piece list / Stückliste - PROLINE 420.350 H.....	187
7.2. 201.R300-800 PROLINE 420.350 Hsx.....	188
7.2.1. 201.R300-800 Kusovník / Piece list / Stückliste - PROLINE 420.350 H.....	189
7.2.2. 201.R300-800 PROLINE 420.350 H.....	190
7.2.3. 201.R300-800 Kusovník / Piece list / Stückliste - PROLINE 420.350 H.....	191
7.3. 201.R230-500 Ovladací panel / Control panel / Bedienpult	192
7.3.1. 201.R230-500 Kusovník / Piece list / Stückliste - Ovladací panel / Control panel / Bedienpult.....	193
7.4. 201.R302-050 Sloup / Pole / Säule.....	194
7.4.1. 201.R302-050 Kusovník / Piece list / Stückliste - Sloup / Pole / Säule.....	195
7.5. 201.R302-060 Sloup / Pole / Säule.....	196
7.6. 201.R303-000 Svěrák / Vice / Schraubstock.....	198
7.7. 201.R303-000 Kusovník / Piece list / Stückliste - Svěrák / Vice / Schraubstock.....	199
7.8. 201.3707-000 Válec / Roller / Zylinder.....	200
7.8.1. 201.3707-000 Kusovník / Piece list / Stückliste - Válec / Roller / Zylinder.....	201
7.9. 201.R303-050 Skluz / Slide / Rutsch.....	202
7.10. 201.Y307-010 Válec zvedací / Lifting cylinder / Hebezyylinder	204
7.10.1. 201.Y307-010 Kusovník / Piece list / Stückliste - Válec zvedací / Lifting cylinder / Hebezyylinder	205
7.11. 221.R301-700 Podstavec / Base / Untersatz.....	206
7.11.1. 221.R301-700 Kusovník / Piece list / Stückliste - Podstavec / Base / Untersatz.....	207
7.12. 201.R302-730 Odměřování / Pole / Säule.....	208
7.12.1. 201.R302-730 Kusovník / Piece list / Stückliste - Odměřování / Pole / Säule.....	209
7.13. 201.Y302-070 Odměřování / Measuring / Gehrung smessung	210
7.14. 201.R304-700 Rameno / Saw arm / Sägerahmen Proline 420.350 H.....	212

7.14.1.	201.R304-700 Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen Proline 420.350 H 213	
7.14.2.	201.R304-700 Rameno / Saw arm / Sägerahmen Proline 420.350 H.....	214
7.14.3.	201.R304-700 Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen Proline 420.350 H 215	
7.15.	201.R304-800 Rameno / Saw arm / Sägerahmen Proline 420.350 Hsx.....	216
7.15.1.	201.R304-800 Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen Proline 420.350 Hsx.....	217
7.15.2.	201.R304-800 Rameno / Saw arm / Sägerahmen Proline 420.350 Hsx.....	218
7.15.3.	201.R304-800 Kusovník / Piece list / Stückliste - Rameno / Saw arm / Sägerahmen Proline 420.350 Hsx.....	219
7.16.	201.M304-020 Kartáč / Brush / Bürste.....	220
7.16.1.	201.M304-020 Kusovník / Piece list / Stückliste - Kartáč / Brush / Bürste.....	221
7.17.	201.0814-204 Kolečko / Wheel / Rolle.....	222
7.18.	201.M308-100 Napínání / Tensioning / Spannung.....	224
7.19.	201.M308-100 Kusovník / Piece list / Stückliste - Napínání / Tensioning / Spannung.....	225
7.20.	201.R304-040 Konzola/ console/ Konsole.....	227
7.21.	201.R310-000 Vedení pásu/ Belt guide/ Sägebandführung.....	228
7.21.1.	201.R310-000 Kusovník / Piece list / Stückliste - Vedení pásu/ Belt guide/ Sägebandführung.....	229
7.22.	201.2016-000 Regulace přitlaku/ Pressure regulation/ Schnittdruckregulation.....	230
7.22.1.	201.2016-000 Kusovník / Piece list / Stückliste - Regulace přitlaku/ Pressure regulation/ Schnittdruckregulation.....	231
7.23.	201.Y310-300 Kostka vodící/ Lead cube/Führungsklotz.....	232
7.23.1.	201.Y310-300 Kusovník / Piece list / Stückliste - Kostka vodící/ Lead cube/Führungsklotz.....	233
7.24.	201.Y310-400 Kostka vodící/ Lead cube/Führungsklotz.....	234
7.24.1.	201.Y310-400 Kusovník / Piece list / Stückliste - Kostka vodící/ Lead cube/Führungsklotz.....	235
7.25.	201.M304-022 Kryt / Cover / Abdeckung Proline 420.350 H.....	236
7.26.	201.R404-022 Kryt / Cover / Abdeckung Proline 420.350 Hsx.....	237
7.27.	201.M305-000 Převodovka / Transmission / Getriebe.....	238
7.28.	201.R305-500 Pohon/ Drive/ Antrieb Proline 420.350 Hsx.....	239
7.28.1.	201.R305-500 Kusovník / Piece list / Stückliste - Pohon/ Drive/ Antrieb Proline 420.350 Hsx.....	240
7.29.	Volitelné příslušenství.....	241
7.29.1.	201.R314-100 Horní upínání/ Top clamping/ obere Klemm.....	241
7.29.2.	201.R314-100 Kusovník / Piece list / Stückliste - Horní upínání/ Top clamping/ obere Klemm	242
7.29.3.	201.R314-400 Horní upínání/ Top clamping/ obere Klemm.....	243
7.29.4.	201.R314-400 Kusovník / Piece list / Stückliste - Horní upínání/ Top clamping/ obere Klemm	244

1. Bezpečnostní pokyny / Sicherheitshinweise / Safety notes

The operating instructions must be read by the person, who keeps in touch with the machine before transportation, installation, using, servicing, reparation, stocking or removal!

Attention!

The operating instructions must be available at the machine! Keep the operating instructions in good condition!

The operating instructions include relevant information. The operator must familiarise himself with the install and operation, safety notes and machine servicing, because reliability and service life must be reached. The operating instructions must avoid risks, which are linked to work on the machine. Before transporting and using of the machine, please read the instructions thoroughly!

1.1. Machine determination

The band saw **Proline 420.350 H / Proline 420.350 Hsx** is determined for cutting and shortening of rolled bars and drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **without angle cutting**.

Combustible materials are excluded for cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

Attention!

Consider the safety signs on the machine. Do not remove or damage them!

The machine is equipped with safety and protective guarding for operator and machine protection. Nevertheless, this safety and protective guarding cannot prevent injury. Service personnel must read this chapter and comprehend it, before he starts to work on the machine. **Always keep instructions about work safety!** Service personnel must take into account other aspects of the risk, which refer to the ambient conditions and the material.

1.2. Protective suit and personal safety

Wear tight fitting overalls! Loose fitting clothes may be caught with machine parts and cause serious injury.

Wear protective gloves! Material cuts and saw band have sharp edges and may cause serious injuries.

Attention!

Gloves you can use only at working material replacement (saw band)! The machine and accessories must be inactive!

If the machine is running, you must not wear gloves! It is dangerous, because some parts of the machine can catch gloves!

Wear protective shoes with non-skid soles! The unsuitable shoes may cause balance loss and following injury. Falling work pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protections! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

1.3. Safety notes for machine operator

Attention!

**Machine can be operated by person older than 18 years!
Machine can be operated only person physically and mentally fit for this activity**

Only one person can operate machine. Machine operator is responsible for presence of other persons by the machine.

Close covers before the machine starting and check, if the covers are not damaged. Damaged covers must be repaired or changed. Do not start the machine, if the cover is removed! Check, if the electric cables are not damaged.

Keep instructions and orders about work safety!

Read the operating instructions, before you start to work on the machine! Keep the operating instructions in good condition!

- Do not hold the material for clamping to the vice and for cutting!

Attention!

Do not connect the machine to electricity if the covers are removed. Do not touch the electrical equipment.

- Do not operate with the buttons and the switches on the control panel, when you have gloves!
- For machine starting take care, that there is nobody in the working area of the machine (it means in the working area of the vice, the saw band, the saw arm etc.).
- In no circumstances, touch the rotating elements.
- Work on the machine only when the machine is in good condition!
- Check at least once in a shift, if the machine is not damaged. If the machine is damaged, you must bring the machine in order and you must inform your superior!
- Keep your working area clean! Ensure sufficient lighting in the working area.
- Take off the spilt water or the oil from the floor and dry it. Do not touch the cooling liquid with bare hands! Do not set the nozzle of the cooling liquid, when the machine is started on
- Do not remove the chips from the working area of the machine, when the machine is started on!
- Do not use the compressed air for the machine cleaning or for the chips removing!
- Use the protective instruments for chips removal!

1.4. Safety notes for the servicing and repairs

Attention!

Only a qualified professional can carry out the servicing and repairs of the electric equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety! Otherwise, there is possibility of heavy injury!

Switch off the main switch and lock it, before you start service work! Otherwise, there is possibility of hazardous machine starting.

Only qualified person can do the servicing and repairs. For parts changing, use only parts, which are identical with the originals. Otherwise, there is possibility of health hazard. Use only recommended type of the hydraulic oils and oils and lubricants!

Do not remove or do not lock the limit switches or safety equipments! Any use of the saw, accessories or machine parts other than that intended by the BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be afterward lost and BOMAR, spol. s r.o. takes no responsibility for caused damages.

1.5. Safety instructions for laser radiation sources

Laser radiation sources may be used on the machine.

Warning signs and information about the corresponding laser class are placed near each laser source.

It is forbidden to look into the laser beams!

Depending on the design and optional equipment of the saw, laser radiation sources can be located in particular:

- on the saw feeder
- before the main vice of the band saw
- on a safety fence (laser barrier)
- on the section line projection device



Commonly used laser safety classes:

- 1 (laser barriers)
- 1M (laser barriers)
- 3R (Laser-Liner)

Attention!

It is necessary for correct functionality of a laser to regularly check the patency of the laser ray on the sensor and to clean the laser from impurities (clean rag + spirit) after each shift. Be careful during the cleaning in order the laser was not been scratched and broken!.

1.6. Safety notes for the servicing and repairs on hydraulic unit

Compliance with the principles of cleanliness is basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are products made with high accuracy, and any contamination leads to a reduction lifetime or even malfunction. The consequences are very difficult to remove and expensive.

Always use clean tools. Parts and fasteners, which are part of a hydraulic circuit, never put away the dirty surface. The best cleaning agent is crepe paper, because the fibers of the cleaning cloths can also cause malfunction.

Protective cap from the threaded chamber remove just before the assembly of the unit.

Hoses and pipes before mounting flush with gasoline or other cleaning agent and blow compressed air.

All fittings must be properly tightened. However, do not raw power.

1.7. Safety machine accessories

Enhanced risk!

**Do not come into or intervene in the cutting area.
Otherwise, there is possibility of heavy injury.**

The machine is equipped with safety accessories. It protects the operator from injuries and the machine before damage. The safety accessories are blocking accessories, emergency switches and covers. Check once in a week the function of the safety accessories. If the safety accessories are functionless, you must stop work and repair or change the safety accessories.


1.7.1. Emergency Stop Switch

Emergency Stop Switch is used for emergency switching – off the machine in case defect or health hazard. By pressing **Emergency Stop Switch** will immediately stop all dangerous machine movements.

If any damages or fault appears, immediately press Emergency Stop Switch!

It is possible to release the pressed button by twisting of the upper part of the button.

The **Emergency Stop Switch** is placed at the control panel of the machine.



1.8. Arm covers

If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible to start in set mode.



The band saw is stated to the operation, when the covers is closed! Limit switched on saw arm control if covers are open or not.

1.8.1. Band saw cover

It covers the visible area of the saw band from left guiding cube to the frame.



Never switch on the saw band driver if this cover is not mounted!

1.8.2. Brush cover

It covers the brush for saw blade.



Never switch on the saw band driver if this cover is not mounted!

1.9. Safety guidelines for laser beam

Band saw for the accurate detection of their material during cutting uses a laser beam is placed near saw arm.



It is forbidden to look into the laser beam.

Near laser beam is safety sticker.

The laser device is used for Class 1M.



Warning!

It is necessary to check the patency of the laser beam at the sensor and cleaned regularly, the laser after each layer of impurities (clean rag + alcohol), because of the correct functioning of the laser. Careful when cleaning procedure to prevent scratches and damage to the laser.

1.10. Safety notes for the cooling


Attention!

- ***When handling cooling agents always wear hazardous fluid-proof gloves!***
- ***Wear protective goggles!***
- ***Cooling liquid can get in contact with your eyes and may cause permanent severe injuries***

1.10.1. Instructions for first help


1. Pull off and safely remove polluted, soaked clothing.
2. For breathing, go out in the fresh air or look for first aid treatment.
3. Wash with water or use crèmes for contact with the skin.
4. Flush with water for eyes and look for first aid treatment.
5. For swallowing, drink a lot of water and induce vomiting. Look for medical help.


**1.11. Umístění štítku stroje /
Maschinenschild position /
Position of machine label**



Machine label is placed on saw frame.


1.12. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols





NE

Nebezpečí úrazu
elektrickým proudem
Verletzungsgefahr vom
elektrischen Strom
Electrical hazard



HV

Hlavní vypínač
Hauptschalter
Main switch




2. **Dokumentace stroje / Dokumentation der Maschinen / Machine documentation**

2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:		
• Hmotnost / Gewicht / Weight		800 kg
Rozměry stroje / Maschinengröße / Machine size :		
• Délka / Länge / Lenght		2 276 mm
• Šířka / Breite / Width		1 197 mm
• Výška / Höhe / Height		1 997 mm
Elektrické vybavení / Elektrische Ausrüstung / Electical equipment:		
• Napájení / Versorgungsspannun / Supply voltage	~3 x 400/230 V, 50Hz, TN-C-S/TN-C	
• Příkon / Gesamtschlusswert / Total Input		
	Proline 420.350 H	5 kW
	Proline 420.350 Hsx	8 kW
• Max.jištění / Max. Vorschaltsicherung / Max. Fuse		
	Proline 420.350 H	16 A
	Proline 420.350 Hsx	40 A
• Krytí / Schutzart / Protection		IP 54
Akustický tlak / Schalldruckpegel / Acoustic pressure:		
• Proline 420.350 H		L _{Aeqv} =76,3 dB
• Proline 420.350 Hsx		
• Pohon / Atrieb / Drive - Proline 420.350 H		
• Typ / Typ / Type		00086182
	4P; 230/400V; B14-FT130; size100	
• Napájení / Versorgungsspannung / Supply voltage		~3x400V, 50Hz
• Výkon / Leistung / Output		3 kW
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed		1440 min ⁻¹
• Pohon / Atrieb / Drive - Proline 420.350 Hsx		
• Typ / Typ / Type		W22 MHERAXXL 112-04 IE2
	4P; 230/400V; B5, CSA/UL; size 112	
• Napájení / Versorgungsspannung / Supply voltage		~3x400V, 50Hz
• Výkon / Leistung / Output		5,5 kW
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed		1440 min ⁻¹
Hydraulické zařízení / Hydraulikeinrichtung / Hydraulic equipment:		
• Typ / Typ / Type	PPM-AC0,48(0,6 kW/300/1500-P61/2,5-TM20-CB03-FRS001_137_1 (92.001.077)	
• Výkon / Leistung / Output		0,6 kW
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:		
• Typ / Typ / Type	41POMPA70120+22FILT0-PA	
• Obsah nádrže / Volumen vom Kühlmittel / Capacity		45 l
Rozměr pásu / Sägebandedimension / Band size:		
4780x34(32)x1,1 mm		
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:		
20-120 m/min		

Řezné rozsaHy / Schnittbereiche / Cutting size:

				
0°	Ø350 mm	420x350 mm	420x350 mm	350x350 mm

Warning:


If the material detection device is installed on the machine then maximal workpiece height is 10 mm shorter.

If machine has bundle device then material maximal height is half.


Level of acoustic pressure:

Equivalent level of acoustic pressure A (noise) at operator position are $L_{Aeqv}=76,3$ dB. Mentioned values are levels of emission which doesn't have to represent safe levels. Factors which influence real level of acoustic pressure on machine operator are: working place characteristics, cut material, saw band. These factors have significantly influence on acoustic pressure.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Keep recommendations for the manufacturers for transportation and stocking! If the recommendations are not kept, damage can occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have license for it!
- Don't move under suspended loads! Fault in lifting device may cause serious injury.
- Keep a safe distance from the machine during the transport.
- Temperature of the air from -25°C to 55°C , for a *short term* (max. 24 hours) temperature of the air until 70°C
- Do not expose the machine to radiation (for example microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all blank surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.

Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.


Fix the stickers stating the minimum approximate machine weight to at least five well visible places.

2.4.3. Transport and stocking

The machine must be secured during transportation. Screw on the palette to the floor of the van or the trailer. Be careful that the machine is not damaged during transportation. Store the machine only under conditions mentioned in the manual, to avoid damage of the machine.

It is forbidden to handle the machine any other way, than it is written in this operating instructions, the machine can be damaged.

2.4.4. Transportní schéma / Transport schema / Transport schneeme



2.5. Activation

2.5.1. Machine working conditions

Keep the conditions of the manufacturer for machine operating! If recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At temperature air from **10°C to 40°C**, the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the extend from 30% to 95% (not concentrate). Altitude lower than 1000 metres.
- Do not expose the machine to the radiation (for example microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.

Attention!

If the ambient temperature drops below 15 ° C is required before operating the machine to have switch on hydraulic unit around 10 minutes and then made several motion few times (for example, in manual mode) by all hydraulic cylinders. The reason is to heat hydraulic oil to the operating temperature for proper function of the pressure switches (and choke).

2.6. Band saw unpacking and assembling

Remove the packing from the machine and unpack all parts.

Attention!

Switch off the main switch and lock it, before you start assembly! Otherwise, there is possibility of hazardous machine starting.

If the hydraulic unit is outside the machine (the machine only connected hoses and cables), it needs to be placed and mounted on a solid basis (floors, etc.). The mounting holes are used on the bottom (bases) of the tank.

2.6.1. Machine installing and leveling

Check the floor supporting capacity before machine installing. If the floor capacity does not agree with requirements, you must prepare the necessary base for the machine.

Minimal requirement:

machine weight – Proline 420.350 H / Proline 420.350 Hsx – 800 kg

+ weight of accessories

+ maximum weight of material

- The machine must be leveled at the horizontal position. All feet of the machine must touch with the floor after leveling
- The machine must be leveled by means of the calibrated spirit level. Spirit level is put on the vice area. Set the roller conveyors according to the spirit level.
- For machine leveling, take care that there is sufficient available space for operation, repair work, servicing of the machine and handling the material.
- The machine including appended parts and accessories must be visible from the place of operation.

2.6.2. First run of the power pack

Before the first run check:

- The direction of the Pump, while run the power pack for max. 2seconds.
- The cooling fan of the motor has to rotate in the same direction as the arrow on the top of the motor cowling indicates.
- In case of wrong rotational direction, the electrical phase in the connection box is to be changed. This check is required after every disconnection from the power source
- Wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise
- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load
- test the electrical equipment
- during operation monitor measuring equipment, noise, height and temperature of oil in the tank
- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.6.3. Filling the reservoir with hydraulic oil

Oil regulations and recommendations of the manufacturer in the technical documentation (appendix) are to be carefully observed. For standard power packs we recommend the oiltype OH-HM32 (DIN 51524) of all known oil manufacturers.


Power packs have to be filled up with clean, pre-filtered oil! The purity of the hydraulic fluid must correspond to the class 10 NAS 1638 (reachable with filter $\beta = 75$)!

Filling from container, such as barrels, buckets, etc. is not recommended or permitted!

The maximum oil level will be shown on the upper marking at the dipstick or the sight level glass. Overfilling has to be prevent. The maximum filling rate of 15 l/min shouldn't be exceed.

Oil type	Kinematic viscosity ν in mm^2/s in relationship to the fluid temperatur					Freezing point
	0°C	20°C	40°C	60°C	80°C	°C
OH-HM 32	220	100	32	15	7	-40
OH-HV 32	180	67	32	17	11	-40

2.6.4. Kotevní plan / Verankerungsplan / Grounding plan



Kotvicí materiál / Verankerungsmaterial / Grouding material

- 4x Chemická kotva/ Chemische Anker / Chemical anchor – 14 mm
- Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 95 mm
- Šrouby / Schraube / Screws – M16 x 135 mm

Šrouby podložit deskami o min. rozměrech P10×100-100

- Die Schrauben mit Platten mit Minimaldimensionen P10×100-100 unterlegen
- Screw must be bottomed with plates (min. dimensions P10×100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.6.5. Electrical connection

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety.

Electrical parameters of the machine: See technical parameters chapter 2.

Note:

The values of the crosscut of the conductor and the rated current are in the norms.

Before connecting switch off the main switch of the power supply circuit for the machine and ensure dry place when doing connecting works!

Service voltage must agree with the line voltage! Crosscut of the supply line must respond with rated current for max. machine load.

Note:

The socket with the fork can be used only at the machines with the rated current less than 16 A and total input less than 3 kW.

Attention!

In this case the extra main switch becomes primary and the main switch on the machine has only secondary function.

In case the machine is connected with a direct connection, an extra main switch must be added which can be locked in zero position.

2.6.6. Check the direction of the saw band



After the machine has been successfully connected, briefly switch on the machine and put the driving engine of the band in the running position. The direction must be in accordance with the arrow direction on the saw band cover. In case the direction of the saw band does not match, two phases at the terminal strip must be switched.

2.6.7. Check machine connection into electrical network

Attention!

When you connect the machine to the electrical network secure a correct connection of all phases!

THE HYDRAULIC AGGREGATE ENGINE MUST NOT BE OPERATED IN REVERSED DIRECTION FOR MORE THEN 10 SECONDS!!!

2.6.8. Filling of the cooling system

Prepare the mixture of the water and the cooling liquid. Keep the concentration specified by manufacturer. Shift away the cover from the drainage hole. Fill the mixture of the water and the cooling liquid to the tank of the cooling system. Area of the tank for the cooling liquid is discovered from the chapter *Technical data*.

Let the drainage hole opened and with the sieve during operation, because it secures the right work of the cooling system. Filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and the tank does not overflowed.

Note:

If machine is equipped with microniser, fill microniser with prescribed cooling liquid. This made the Microniser ready for use.

2.7. Check machine function

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if covers are installed and functional. Check by means of the Tenzomat if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Values of the saw band stretching are on the Tenzomat. Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to other outer position. Raise the saw frame to the top position and drop the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for the operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are right, the machine is ready for operation..

2.8. Machine disposal after lifetime

Blown out all service fluids (cooling liquid, hydraulic oil) into designated reservoir. Dismantle machine into separate parts and dispose them in accordance with valid directives.

2.9. Saw band

Refit the saw band cover only after you have installed and tightened the saw band.



2.9.1. Saw band size

4780x34(32)x1,1 mm

2.9.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth system. The important factor for selection of the tooth system is length of the cutting canal with respect to the size of the product

BOMAR recommended Variable tooth system for band saw.

1. *Constant tooth system* – the saw band has parallel tooth pitch all over length. This way is suitable for cutting of solid material.
2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cutting area.

In tables, there are advised type of the tooth system depending on sizes and form of the cutting material.

Footnotes:

Z – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:


32 S – number „32“ means 32 teeth on one inch (that means constant tooth system), letter „S“ marks teeth with zero angle of the tooth.

4–6 K – number „4–6“ means 4 till 6 teeth on one inch (that means variable tooth system); letter „K“ marks teeth with positive angle of the teeth.

2.9.3. Saw band running-in





Running-in: Cut the material with the frame lowering reduced to 50% only. When vibrations occur increase or decrease the band speed.

When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for 15 minutes approximately. When the band has been run, increase the lowering-speed to normal speed. The running in of the saw band avoids micro-breaks on the cutting edges of new saw band ensuing from first excessive stress. This would decrease service life substantially. The optimal running in of the saw band produces ideal rounded cutting edges and therefore the conditions for an optimal service life.








Note: Run regrinding saw bands too.

2.9.4. Tables for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to 2xS). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system ($Z_p Z$) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10–14 S	10–14 S
4	24 S	14 S	10–14 S	10–14 S	8–12 S	8–12 S
5	18 S	10–14 S	10–14 S	8–12 S	6–10 S	6–10 S
6	18 S	10–14 S	8–12 S	8–12 S	6–10 S	6–10 S
8	14 S	8–12 S	6–10 S	6–10 S	5–8 S	5–8 S
10	-	6–10 S	6–10 S	5–8 S	5–8 S	5–8 S
12	-	6–10 S	5–8 S	5–8 S	4–6 K	4–6 K
15	-	5–8 S	5–8 S	4–6 K	4–6 K	4–6 K
20	-	-	4–6 K	4–6 K	4–6 K	3–4 K
30	-	-	-	3–4 K	3–4 K	3–4 K
50	-	-	-	-	-	3–4 K


Size of the wall S [mm]	Tooth system ($Z_p Z$) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10–14 S	10–14 S	8–12 S	6–10 S	5–8 S	5–8 S
3	8–12 S	8–12 S	6–10 S	5–8 S	4–6 K	4–6 K
4	6–10 S	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K
5	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K	3–4 K
6	5–8 S	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K
8	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K	3–4 K
10	4–6 K	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K
12	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K
15	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K
20	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K	2–3 K
30	3–4 K	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K
50	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K
75	-	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K	0,75–1,25 K
100	-	-	1,4–2 K	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
150	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
200	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K

SOLID MATERIAL ($D = \text{mm}$)				
				
Constant tooth system			Variable tooth system	
length of the cut D		tooth system ($Z_p Z$)	tooth system ($Z_p Z$)	
to 3 mm		32	10–14	
to 6 mm		24	8–12	
to 10 mm		18	6–10	
to 15 mm		14	5–8	
15–30 mm		10	4–6	
30–50 mm		8	4–5	
50–80 mm		6	3–4	
80–120 mm		4	2–3	
120–200 mm		3	1,4–2	
200–400 mm		2	0,75–1,25	
300–800 mm		1,25		
700–3000 mm		0,75		


3. **Ovládání stroje / Bedienung der Maschine / Machine control**

3.1. Starting the band saw

- » 1. Switch on the main switch of the band saw. The main switch is placed on the switchboard side.




2. Switch the saw's safety (control) circuit on – button **No.4** at the control panel of the saw.



3.2. Control panel

Ovládání stroje
Bedienung der Maschine
Machine control



1	Emergency Stop Switch In a case of emergency turns the machine immediately off..
2	Cooling system selection You can select from three possibilities: See chapter "Setting of a cooling method"
3	Frequency converter Frequency converter sets the speed of saw band in the range of 20-120 m.min ⁻¹
4	Safety circuit Button switch on the control circuit of control system
5	START/STOP - Switch on / off the working cycle Push of a button START starts the cutting cycle Button STOP stops or brake cutting cycle.
6	Open/Clamp main vice Pressing and holding the button in manual mode allows voltage and solve the main chip stocks. The feed vice must always be clamped earlier than the main vice
7	Lift/Lower the saw arm Pressing and holding button lifts or drops saw arm by the lifting hydraulic cylinder. It is possible to lift the arm using the whole range of the lifting hydraulic cylinder. As you move down saw arm, you can activate rapid lowering by pressing both buttons simultaneously
8	Regulation valve Regulation valve sets the lowering speed of the frame into the cut. The speed is limited by the adjustment of the pressure regulation in the cut on the guiding cubes. Note: If the throttle valve is closed too tightly, the valve seat may be damaged and may start to leak. Tighten the valve lightly.
9	Laserliner – optional accessory Switcher of the laser beam

3.3. Machine control

1. Lift the saw arm so that the lower portion of the bandsaw blade (cut) about 10 mm above the material is located (starting position). Raising the arm is ensured by the establishment ..
2. When pressing the START button to start the cutting cycle
3. Pressing the START button starts the saw blade drive, the arm begins to sink into the cut. After the cutting process, the arm moves to the preset lower position (see the lower arm position adjustment of the stop) and then raises the arm to the starting position. When pressing the START button, the starting position of the key is stored, ie that the arm after the cut returned to the position in which the START button is pressed.

3.4. Cycle breaking

- » • **STOP button**
- Semi-automatic cycle is interrupted by pressing **STOP** of the cycle
- The arm stops fall into cut and saw blade is stopped.
- By pressing button **START** of the working cycle, you can start the cycle.
- **Emergency Stop Switch**
- In case of the risk, press **Emergency Stop Switch**.
- After pressing button, saw band drive is immediately broken and the arm sinking is stopped.
- **Reactivation**
1. Turn **Emergency Stop Switch** according to the arrows (on the button).
 2. Switch the saw's safety (control) circuit on –button **No.4** at the control panel of the saw.
 3. Lift saw arm above cut material and push START button.

3.5. Band saw adjusting

3.5.1. Cutting speed adjusting


Band speed is possible adjusted continuously from 20 to 120 m / min.



Use the frequency convertor on control panel (pos. 3) to adjust requested speed of the saw band.

3.5.2. Speed adjustment of the arm lowering

Speed of the arm lowering is adjusted by regulation valve on control panel (pos.8)



- Set the **lower speed** of the arm lowering to the cut by turning the switch **clockwise**.
- Set the **higher speed** of the arm lowering to the cut by turning the switch **anti-clockwise**.

Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.5.3. Electronic measuring device (optional accessories)

The current speed of vertical movement of the arm is displayed on a digital display which is mounted on the saw arm.

The measuring unit is set by the manufacturer.


However, its further functions may be easily controlled with four keys.

Digital indicator is placed on the band saw pedestal:



Zero position setting

Push the Incr/Abs key (even several times) until "0" is shown on the display.



Digital measuring adjustment

Position	Description
1	Current position
2	Unit, measuring mode
3	Active additional constant (* key)
4	Battery status
5	Reference record shall be made – after the apparatus is switched on.

Description of key functions:

Key	Stop mode	Setting mode
	Basic key	Entering parameters (3 sec) Saving parameters and returning (3 sec)
	Reference recording (P09 value)	-
	Change of displaying in inches	Selection of following decade
	Absolute and incremental measuring	Change of active decade o +1
	Selection of additional constant	Change of sign ☒

Description of key functions at measuring initialisation:

Key	Description
	Induces calibration of the apparatus when it is switched on (battery inserted).
	Induces calibration of the apparatus and sets default values when the apparatus is switched on.

Description of digital measuring parameters:

Parameter	Description	Default value
P01 A	Measuring configuration: A = 0: positive direction of measuring A = 1: negative direction of measuring	0
P02 A	Measuring unit: A = 0: mm / symbol "mm" A = 1: inch / symbol "Inch" A = 2: mm / symbol "m" A = 3: mm / symbol "on" A = 4: mm / no symbol	0
P03 A	Decimal point (0...4) > only for mm	2
P05 ABC	Key blocking: A: "Set" key (0 = active / 1 = inactive) B: "Incr/Abs" key (0 = active / 1 = inactive) C: "*" key (0 = active / 1 = inactive)	000
P08	Correction factor (0.0001...9.9999)	1.0000
P09	Reference (-9999999...+9999999)	0
P10	Additional constant 1 (-9999999...+9999999)	0
P11	Additional constant 2 (-9999999...+9999999)	0
P12	Additional constant 3 (-9999999...+9999999)	0
P13 A	Configuration of additional constants (0...3) A = 0: inactive (cannot be selected) A = 1: Additional constant 1 active A = 2: Additional constants 1 & 2 active A = 3: Additional constants 1 & 2 & 3 active	3
P90	No function	0
P99	Displaying firmware version	x.xx

3.5.4. Saw frame upper position stop adjustment – lift arm adjustment

The position of the guide arm is monitored by a transducer which is located in the rear arm portion. In order to shorten the cycle time, the amount of Armhubs can be adjusted according to the height of the material to be cut.

1. Insert material in a vice
2. Take arm using the **Arm up** to a position above the material.
3. Carefully pull off the arm of the material using the **Arm down**, or rapid move. Arm stops 5-10 mm above the cut material
4. Adjust the height of Armhubs material according to height so that the top of the adjustable eccentric with a scale indicating the desired value (the value of the eccentric-scale corresponds to the value of the material height)
5. Pressing the START button for the beginning of the cutting cycle.



Setting the Armhubs using the incremental transducer of the upper arm position (optional accessories):

1. Insert material in a vice
2. Take arm using the **Arm up** to a position above the material.
3. Carefully pull off the arm of the material using the **Arm down**, or rapid move. Arm stops 5-10 mm above the cut material
4. Pressing the START button for the beginning of the cutting cycle
5. Of the saw, the material is cut to the lower arm position and moves back into the upper arm position in which the START button has been pressed (the saw notes the position - upper arm stop)



3.5.5. Saw frame lower position stop adjustment

The lower arm stop separates the bottom arm position.

This stopper is to be set according to the amount of material to be cut (the scale).

An incorrect setting of this attack, the saw can cut too deeply into the table of a vice or the material is not completely cut through.



Adjustment of the stop of the lower arm position with the aid of the adjustable eccentric to the column of the arm.

The limit is set by the manufacturer, this is not readjust

3.5.6. Adjusting band guides


If you want to achieve a smooth and precise cut, it is helpful to position the guide cube as close as possible to the material.



1. Release the stopping lever of the listel. Move the left part of the guide so that the left edge of the guide blocks is as close as possible cutted material.
2. Lower the frame to the lower position and check the position of the guide cube towards vice loading area. The guide cube must be a distance of at least 10 mm from the vice loading area.
3. Tighten the lever of the gib and check the guide cube setting once more for possible collision with binding table or vice jaw.

3.5.7. Brush adjustment

The brush for chip removal from the saw band influences cutting durability saw band lifetime and wheels lifetime, hard metal guides and finally the cut accuracy. Brush adjustment must be checked every shift.



1. Release the fixative screw of the brush. It is possible to move with the brush.
2. Set the brush to the saw band according to the picture.

Attention!

The brush must not touch the bottom of the saw teeth!


3. Tighten the fixative screw.
4. In case, that the brush is not turned right (driving wheel slips on the driving wheels of the saw band), push by means of the screw (see arrow) driving wheel of the brush to the driving wheel of the saw band.

Attention!

The screw must not be tightened with heavy force, because driving wheel of the brush can be damaged or the lifetime of the bearings of the driving wheel of the band can be lowered!

3.5.8. Setting of a cooling method

Required cooling method can be selected using a switch no. 3 on control panel.



Liquid cooling

1. Coolant pump runs when the drive of the belt is switched off (rinse)
2. Saw band runs without cooling
3. Cooling starts while starting of the drive of the saw band .

Oil mist – Micronizer (optional accessory)

4. Saw band runs without cooling
5. Cooling starts while starting of the drive of the saw band

3.5.9. Halogen lighting of working area (optional accessory)


Light the working area of the machine with natural light and helps to facilitate cutting with a band saw.

Proper lighting in your work area greatly enhances ergonomics machines



Thanks flexible arm halogen light can accurately adjust to the desired location.

Turn on and off light switch is made directly to the halogen light.



Design lighting unit meets IP54 - Protection against water jets.

Technical data halogen light :

Supply voltage	230 V
Lenght flexible arm	300 mm
average	Ø 5,5 mm
lenght	80 mm


3.6. Material insertion

- Never walk under a suspended load!
- Never climb onto the gravity-roller conveyor!
- Do not hold the material for clamping material to the vice! The vice can cause injury!

3.6.1. Handling agent selection

- Use the strong handling agents to lift and transfer the material!
- Handle with the material only with the lift truck or use the suspension strands and the crane!
- Do not use the lift truck or crane in case that you do not have the license to handle with it!

3.6.2. Insertion



Insert material to the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you cut long pieces of the material (for example rod, tube), you must use the roller conveyors for material shifting to the band saw. Contact Bomar for more information about roller conveyors

Make sure the conveyor is long enough and the material cannot tip off the conveyor.

Be especially careful with round materials that it always stays on two vertical rollers and that it cannot fall off the conveyor!


3.6.3. Bundle material cutting

Attention:

Manual bundle clamping device is not standard equipment. Without this device is a not possible cut bundle.


Attention!

If machine has bundle device then material maximal height is half.



If you want to cut the material in the bundle, there are suggestions for the positioning of bundles

Round material bundle: Take care especially with round material that the bars are put according to the picture. If the bars are put differently, you may have problems with movement.



Always weld the material at the rear end of the bundle to secure it from moving.

Before welding always, switch the machine off at the main switch! The magnetic fields, which often occur during welding, may damage the controls!

Attention:

Not all material shapes are suitable for bundle cuts. Keep the recommendation of your supplier of the saw bands for material insertion to the bundle.

4. **Údržba stroje / Wartung / Machine service**

4.1. Saw band dismantling

During the dismantling, take care that you do not damage the limit switch if the saw band stretching.

1. Lift the saw frame to the top position. Stop the saw frame in top position by control valve.



2. Dismantle yellow protective cover of the saw band. The cover is clamped with two screws.



3. Open the cover of the arm.
4. Turn by stretching star to the left side, release saw band stretching and pull saw band from blade wheels.



5. Pull up the saw band from the guiding cubes

4.2. Saw band instalation

During the installation, take care that you do not damage the limit switch if the saw band stretching!

1. Prior to installation, clean all track wheels, guide cubes and inner side of the arm thoroughly of all traces of chips and dirt. **Keep in mind the teeth direction when installing the saw band.**



2. Insert new saw band in the guide cubes. Make sure the saw band runs between both guide rollers and it is pushed all the way to the top.



3. Put the saw band on both guide wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Then push the saw band as far back as possible.
4. By turning the stretching star to the right, you will stretch the saw band slightly. Remove the plastic cover of the saw band teeth.
5. Close the cover of the arm.



6. Install the yellow protective cover of the band. The arrow on the cover must match the direction of the arrow on the band. If it does not, you must turn the band round.

4.3. Saw band stretching and inspection


Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer.

Pilový pás Sägeband Saw band	Napětí pilového pásu Sägebandspannung Blade tension	Napětí pilového pásu PSI (pro Tenzomat) Sägebandspannung PSI (für Tenzomat) Blade tension PSI (for Tenzomat)
20 x 0,9 mm	160 N.mm ⁻²	23 500
27 x 0,9 mm	180 N.mm ⁻²	26 500
34 x 1,1 mm	210 N.mm ⁻²	30 500
41 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,6 mm	280 N.mm ⁻²	40 600
67 x 1,6 mm	290 N.mm ⁻²	42 000
80 x 1,6 mm	300 N.mm ⁻²	43 500

4.3.1. Mechanical indicator of belt tightening

To facilitate tightening of the belt, a mechanical indicator is installed on the machine by default, enabling the belt to be tightened to the optimum value easily and quickly.

Mechanical indicator of belt tightening




1	Tightening screw
2	Yellow ring – indicator of correct belt tightening
3	Bush

1. After the belt replacement, the tightening screw (Pos. 1) must be tightened so that the face of the yellow ring (Pos. 2) be aligned with the face of the bush (Pos.3)

The areas indicated in red in Fig. 1 must be aligned.

Fig.1



NOTE:

The belt length with deviations within normal tolerances has no influence on the method of the belt tightening indication!

If the belt length deviations fall within normal tolerances and the belt is tightened correctly, the face of the yellow ring (Pos. 2) is always aligned with the face of the bush (Pos. 3), regardless of the real dimension of the belt.

Belts with deviations outside the normal tolerances must not be mounted on the machine!

4.3.2. Hydraulic indicator of belt tightening (optional accessory)

If the machine is equipped with a hydraulic indicator of the belt tightening (optional accessory), the belt tightening value can be seen on the indicator gauge.

The optimum working tightening value of the belt is indicated with a green arrow.



4.4. Adjusting of the limit switch of the saw band stretching



After the saw band is replaced, the saw band stretching must be checked. If the limit switch is not adjusted correctly, the band is stretched too little or too much.

1. Dismantle the protective cover




2. Tighten the saw band on the optimal value using TENZOMAT (see table for TENZOMAT)
 - If the drive engine is switched on, but it is not running, turn with the screw clockwise, until the engine begins run..
 - If the drive engine is possible switched on, turn with the screw anticlockwise, until the engine is stopped and then turn with the screw clockwise, until the engine begins run.
3. Install the protective cover.

4.4.1. Saw band run adjustment on stretching wheel

Saw band run on the stretching wheel must be regularly inspected. The inspection has to follow every saw band replacement

If the band drive is not set correctly, the following problems may occur:

- The saw band falls off the wheel – the saw band and protective cover can be damaged.
 - The saw band runs on the wheel rim – The saw band and wheel rim can be damaged
1. Turn the saw band drive and then again
 2. Turn off the main switch!
 3. Open the cover and check the saw band run
 4. Check the saw band run to the wheels.



- if the distance between backside of the saw band and the offset wheel is **1 – 3 mm**, setting is right
- if the distance is bigger than **3 mm**, or the saw band is on the offset of the wheel, set the saw band

The saw band run is adjusted with the adjustment screw.

The saw band run is adjusted with an Allen screw in the tension prism of the arm. If the distance of the rear part of the saw band from wheel rim is **1 mm**, setting is right.

- Turn the adjusting screw to the right, then the bandsaw moves closer to the border.
- Turn the screw to the left, then the bandsaw moves further from the border.

After adjustment check the saw band run again.

4.5. Cooling agents and chips disposal

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
• use of contaminated water • impurity • outside oil contamination (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration	• corrosion protection is diminished • lubrication decreases • microbial attack is more likely	• the cooling ability is decreased • foam behavior increases • emulsions stability deteriorates • sticky residue develops

4.5.1. Coolant device inspection

The state of the cooling agent has significant influence on the cutting quality and on the operational life of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution cooling liquid (especially with oils) and on the other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be changed.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	after concentration check, refill with water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or renew coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides, or coolant renewal after added system cleanser*
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquiries to supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, ix with defoamer

* According to manufacturers' instructions

4.5.2. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Fill a watertight container with the chips! Be careful that the container does not leak, because even after a long dripping time, they still contain coolant residue.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micro-spray installation, the chips must also be handed over to a disposal company.

4.5.3. Third coolant inflow (optional accessories)

Flexible coolant supply allows to bring the coolant to the desired location. Third, easily routable and adjustable coolant supply with nozzle ensures sufficient lubrication and cooling of the strip in the middle of the cut material



Particularly suitable for cutting materials with a larger average, where the opening of the guide blocks larger blade and prevents proper lubrication and cooling of the entire length of the cut. For normal cutting off the third coolant inflow may be easily disconnected by closure.



The third coolant inflow get in the package complete package including all jumpers and hoses - just connect to existing cooling divorce
Complete package includes: flexible hose (length 600 mm), shunt valve, inlet plastic hose (depending on the type of machine - min. 1m), interconnection schedule, holderto the machine screws (2xM5), transformer and wiring.



The entire portfolio of BOMAR saws can be extended to a third feed.

4.5.4. Gun cleaning machines from chip (optional accessories)

Tool cleaning machines from chips after cutting.



With custom pump (min. capacity 16 l / min.) The coolant gets into the rinsing pistol with the trigger lever.

Sufficient pressure to the chips and debris were eliminated from the bearing surfaces of the base material and the saw.

Gun cleaning machine from the chip is supplied with a sufficient supply hose for easy handling (diameter of 12/8 mm).

Package includes:

1. Ergonomic handle allows easy handling of the gun during cleaning machine.



2. Brass adjustable nozzle allows for smooth width rinse stream.



3. Valve for setting maximum coolant flow



4. Also included is a convenient holder for postponement gun after use!



Suitable for machine brand Bomar

4.6. Hydraulic, Greases and oils

4.6.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Use oils with specification DIN 51517 in the gearboxes. Select the viscosity grade ISO VG according to the original oil fill.

Attention:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers.

Do not forget, that mineral and synthetic oils must not be mixed!

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Proline 420.350 H Proline 420.350 Hsx	Shell Tivela S 320	1,0 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
ÖMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.6.2. Lubricant greases

We recommend using lithium based saponified grease, class NGLI-2 for lubrication. Different greases are mixable, if their oil bases and consistence type are identical.


Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energrease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.6.3. Lubrication

There are several places on the machine, which are necessary to grease periodically. It secures the right function of the machine.

Lubrication place	Lubrication
	The guiding cubes leading – grease with oil from both sides once a week.



4 x linear carriage for moving the saw arm

Linear guide of the saw arm - every three months. Lubricate with a grease (see Chapter greases). Every carriage of the linear guide grease with about 3-5g of grease. Use for lubrication grease gun. During the lubrication shut down the linear carriage 3 to 5 times back and forth.

4.6.4. Hydraulic oils

Replace the hydraulic oil once in 2 years, because the oil can deteriorate its properties and cause problems the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity grade ISO VG 32 in hydraulic aggregates. Hydraulic oils quantity – see chapter **Hydraulic oil level check**.

Note:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils may not be mixed!

Comparative table of the hydraulic oils

Manufacturer	Type	Manufacturer	Type
Agip	Oso 32	Ina	Hidraol 32 HD
Aral	Vitam GF 32	Klüber	Lamora HLP 32
Avia	Avilub RSL 32	Hungary	Hidrokomol P 32
Benzina	OH-HM 32	Mobil	Mobil DTE 25
BP	Energol HLP 32	ÖMV	HLP 32
Bulgaria	MX-M/32	Poland	Hydrol 30
Castrol	Hyspin AWS 32	Rumania	H 32 EP
Čepro	Mogul HM 32	Russia	IGP 30
DEA	Astron HLP 4hy6	Shell	Tellus Oil 32
Elf	Elfolna 32	Sun	Sunvis 832 WR
Esso	Nuto H 32	Texaco	Rando HD B 32
Fam	HD 5040	Valvoline	Ultramax AW 32
Fina	Hydran 32		

4.6.5. Hydraulic unit service

After 50 hours working time, or the latest 3 months after the first run, the first service should be carried out. This includes:

- checking off all screws and connections, fixing points, tubes and hoses for leakage
- Check hydraulic oil level
- During time of duty the oil temperature shouldn't exceed 60-70°C
- check function of signaling components (thermometer, level gauge, dirty filter indicator)
- Check the adjustment of working pressure



To realize a high reliability of the power pack, the manufacturer lays down following inspection intervals

Interval	daily	weekly	monthly	three monthly	six monthly	annually
Hydraulic fluid						
Level	-	•	-	-	-	-
Temperature	-	•	-	-	-	-
Condition	-	-	•	-	-	-
Change interval	-	-	-	-	-	•
Filter						
Change interval	-	-	-	-	-	-
Other checks						
External Leakages	•	-	-	-	-	-
Contamination	•	-	-	-	-	-
Damages	•	•	-	-	-	-
Noise-(level)	•	-	-	-	-	-
Gauges	-	-	•	-	-	-

4.7. Machine cleaning

Clean the machine from the cooling liquid and impurities after every shift stopping. Conserve the guiding surfaces, mainly.

- Clamping jaws guiding of the vice.
- The guiding of the feeder.
- Loading surface of the vice.

4.8. Worn pieces replacement

4.8.1. Hard metal guides replacement

If the hard metal guides cannot be adjusted, they have to be replaced.

1. Dismantle the saw band. Remove the hosepipe leading the cooling agent. Dismantle guide cube of the saw band.



2. Loosen the adjusting screws of the metal guide.



3. Loosen the binding screw of first metal guide. Remove adjustable hard metal guide.



4. Loosen the binding screw of second metal guide. Remove the hard metal guide
5. Insert new hard metal guides and fasten them tightly.
6. Mount the saw band. Adjust the hard metal guides.

4.8.2. Round brush replacement

If the chip removing brush is so worn, that it does not fulfill its function, the brush must be replaced.



1. Release the nut of the brush, exchange old brush to new brush and screw on the nut of the brush.

2. Set the brush to the saw band.

4.8.3. Saw band guiding rollers replacement

If the saw band is not sufficiently guided by guiding pulleys or if the pulleys are obviously worn, the pulleys should be replaced.

ATTENTION!

Guiding pulleys must be replaced together on both guiding cubes!!

1. Dismantle the saw band.
1. Disconnect the hose from the cooling agent, screw off the pressure regulation. Let the pressure regulation connected to the hydraulic system. Dismantle the guiding cube of the saw band.



2. Tighten the guiding cube to the vice and dismantle both eccentrics with bearings following way.

ATTENTION!

Mark both eccentrics placing and components on the eccentric! Eccentrics must not be replaced with each other!!

3. Screw off nuts from eccentrics..



4. Remove eccentrics from bearings by means of the swager



5. Change all bearings and other worn parts.



ATTENTION!
Do not replace the eccentrics placing in the cube

6. Install eccentrics to the cubes. Install components on both eccentrics in given order. Put bearings by means of the preparation on eccentrics.



7. Screw on nuts on both eccentrics and tighten them.



8. Insert the saw band to the guiding cube (ca. 15 – 20 cm). Set the eccentrics by means of the wrenches, the saw band must run in the centre. Guide pulleys must not press too much on the band, but must spin freely during the band run.
9. Tighten nuts on both eccentrics.
10. Remove the testing piece of saw band from the cube lead. Install the guiding cube on the machine and connect the pressure regulation to the cut and cooling. Install the saw band.

4.8.4. Stretching wheel replacement

1. Dismantle the saw band.




2. Screw off the screw and take down the washer.



3. Pull off the wheel from the shaft by means of the three-armed puller. If bearing stayed on the shaft, pull off it too
4. Check score of the bearings of the stretching wheel and replace them for new.



5. Clean the shaft and grease it with oil. Insert retaining ring to the groove.



6. Install bearing on the shaft and move it to the retaining ring. Insert the distance ring on the shaft and move it to the bearing.



7. Insert the retaining ring to the hole in the wheel.



8. Insert the bearing to the hole in the wheel and press it to the retaining ring.



9. Put the wheel on the shaft and screw on the preparation to the wheel stretching to the hole in the shaft.



10. Pull on the wheel on the shaft.




11. Screw on washer and screw back.
12. Install the saw band. Wheel replacement is ready.

4.8.5. Driving wheel replacement


1. Dismantle the saw band



2. Screw off the screw and remove the washer.



3. Pull off the wheel from the shaft by means of the three-armed puller.



4. Install the wheel on the shaft. Insert the feather to the groove.



5. Screw on the preparation to the wheel stretching to the hole in the shaft. Pull on the wheel on the shaft.



6. Screw on washer and screw back.
7. Install the saw band. Wheel replacement is ready.

4.8.6. Cooling pump replacement

Only a qualified worker can carry out the connection!

High-voltage shock may have fatal results


1. Pull the tank with the liquid from the pedestal..
2. Remove the hosepipe leading to the cooling agent from the plug on the pump. Screw off four screws from the cooling pump flange and pull out the pump from the sheet metal holder.



3. Remove the cover of the pump terminal switchboard. Disconnect 4 terminal connectors of the input cables. Cables are identified according to the red clamps..



4. Loosen the bushing and pull the cable out from the pump.



5. Dismantle new pump switchboard cover. Push the cable through the bushing and fasten it.



6. Screw on the cable bushing and cover of the terminal block. Do not forget the rubber gasket! Tighten the cooling liquid hose with non-stick tape and screw it again. Install cooling liquid hose, place the pump on the sheet metal holder and screw it

5. **Závady / Störungen / Troubleshooting**

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment“
	- Worn hard metal guides.	Replace to the chapter „Worn pieces replacement“
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment“
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment“
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement“
	- Insufficient saw band stretching.	Rise the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band and keep the instructions of manufacturer on new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Set the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding arm and guiding cube are loosened.	Clamp the guiding arm.
	- Guiding arm and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast cutting rate.	Lower the material feeding speed.
2. The cut is not cut upon desired angle	- Unexpected oscillation in material quality.	Set the cut and feeding speed to the relevant material.
	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment“.
	- Set angle does not match the cut angle.	Check the angle adjustment with a protractor and possibly set it according to chapter „Servicing and adjustment“.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment“.
	- Guiding arm and guiding cube are loosened.	Fasten the guiding arm and the cube.
3. Short lifetime of the saw band	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
	- Insufficient saw band stretching.	Raise the tightening of the saw band set the scanner of saw band tightening according to chapter „Servicing and adjustment“.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive use as described in chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment“
	- Over stretched saw band	Lower stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw	Check the condition of the hard metal guide and

Problem	Possible causes	Repair
	band.	if it is too worn, replace hard metal guides according to chapter „Worn pieces replacement“
	- Worn saw band guide bearings.	Check guiding bearings and if you notice some sort of excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted down feed and saw band speed.	Adjust the feeding and speed of a saw band according to values published by saw band manufacturer.
	- Different material quality.	Adjust feeding and speed of a saw band according to desired material (try cut-test).
	- Low-class saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly adjusted tracking.	Check the space between top of a saw band and driving wheel. Perhaps adjust the tracking as described in chapter „Servicing and adjustment“
4. Insufficient cut output.	- Worn saw band.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrong saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly set down feed and speed of a saw band.	Set feed and speed of a saw band according to values published by saw band manufacturer.
5. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messed-up.	Cleanse stop point surface of the limit switch from debris and residue material.
6. By choke is not possible turn	- Metal clamps between valve and panel.	Clamps must be removed and put on the shaft O-Ring about 10x2 mm.
	- Metal clams are in body of valve.	Valve must be cleared or changed.
7. Saw band drive cannot be started.	- Pressure switch is adjusted wrong.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
8. The saw bands are cracked.	- In stretching wheel is wrong adjusting geometry.	Adjust distance band from recess wheel c.2 mm according to operating instructions.
	- Hard metal plates of circuit saw band are not adjusting.	Hard metal plates of circuit saw band must be adjusting according to operating instructions.
	- Guiding cubes are not adjusting (bearings + hard metal circuit)	Guiding cubes must be adjusting (bearings + hard metal circuit) according to operating instructions.
	- Bearings of guiding cubes are used (rolling elements are damaged or outside ring of bearing has conical form).	Bearings of guiding cubes must be replaced. Bearings must be adjusting according to operating instructions.
9. Damage tooth system of the saw band	- In gripping the lifting cylinder is backlash.	
	- Squeezed pin upper or downer holder of the lifting cylinder.	Exchange complete upper or downer holder of lifting cylinder.
10. The saw is cut downing.	- Geometry of hardmetal guiding cubes is wrong adjusted.	Hardmetal guiding cubes must be adjusted.
	- Bearings of guiding cubes are used.	Bearings of guiding cubes must be replaced.
11. Cleansing of the saw band is not functional.	- Elastic wheel of the brush drive is worn-down.	Elastic wheel of the brush must be changed.

Problem	Possible causes	Repair
	- Knurling of the driving wheel is worn-down.	Driving wheel must be changed.
	- The shaft of the brush drive is rusted.	The shaft of the brush must be cleaned and oiled.
	- The brush position and the brush cover is adjusted wrong – with the brush cannot be turned.	The brush cover must be posed, in order to the brush can be turned.
12. The saw arm periodically rise and fall during the cut; this cause short lifetime of the saw band.	- Backlash in driving wheel lodgement on the shaft.	Change the driving shaft for a long one, new bearings, distance ring, new driving wheel, spring, two covers on the forehead of the shaft + screws.
	- Worn channel for spring.	

5.2. Electric and hydraulic problems

Problem	Possible causes	Repair
1. Machine is not possible start.	- In socket is not voltage	Line voltage must be checked.
	- Transfer relay is closed (thermal protector)	Each FA relay must be checked.
	- Limit switch of saw band stretching, cover of frame or cover of saw band is not started.	Check of saw band stretching and covers closing.
2. When cut is finished, the frame is not raising.	- Bottom limit switch is adjusted wrong.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- In hydraulic (pneumatic) ring is error. HYTOS (BOSCH) is not acting to frame uplift.	Function of magnetic valve must be checked, valve must be closed, voltage of clamps and inductor must be checked.
3. Electric motor and pump are without voltage. Between contactor and thermal protector is not voltage.	- Wrong contactor.	Replace contactor of engine.
4. The indicator of speed saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be changed.
	- Wrong sensor – diode of indicator speed is not light.	Sensor must be changed and adjusted.
5. Protector is switched off from engine hydraulic aggregate MA3 sometimes.	- Into hydraulic system is high working pressure.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on motor starter FA1.
7. Hydraulic aggregate is switched on but the saw arm or the main vice is not functional	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer can do this.
8. Cooling is not active	Lack of cooling agent.	Fill the tank with cooling agent.
	- Thermal relay is defective	Change the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and perhaps cleanse

Problem	Possible causes	Repair
		cooling system.
	- Cooling pump protection is defective	Check the protection of cooling pump if need change it.
	- Cooling pump is defective.	Replace the cooling pump.

5.3. Hydraulic problems

Problem	Possible causes	Repair
1. Hydrogenerator not supplying oil	• reverse rotation	Check the connections of each phase. Reconnect properly connection of the electrical phases.
	• shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond prescribed viscosity value	Change hydraulic oil.
	• Hydrogenerator malfunction	Call service
	• Wrong power supply connection.	Check the connections of each phase. Reconnect properly connection of the electrical phases.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately deaerated	Make deaeration of hydraulic circuit.
	• Low oil level	Add hydraulic oil
	• the pump shaft seals damaged	Call service
3. Increased mechanical noise	• damaged joint drive	Call service
	• damaged or destroyed motor bearings	Call service
	• air intake	Check for leaks.
4. Low pressure, pump supplies oil	• problem in the safety valve	Wrong settings. Check the settings and adjust the safety valve.
	• pump wear	Call service
	• external or internal leakage	Call service
5. Hydrogenerator is seized	• damage by solid particles in oil	Make oil filtration, or call the service.
	• non-prescribed oil	Change hydraulic oil.
	• wrong type of oil	Change hydraulic oil.
	• exceeding the life of the pump	Call service

6. Overheating oil	• cooler malfunction	Check the cooler function or call service.
	• wear the pump, the energy is converted into heat	Call service
7. Hydraulic valve can not be readjusted	• electromagnet has no signal (voltage) - interrupted supply lines	Check again.
	• Electromagnet coil burnt	Replace coil – Call service.
	• spool valve sticking	Replace valve – Call service

6. **Schémata / Schemas / Schematics**

6.1. Elektrické schéma / Elektroschema / Wiring diagrams – Proline 420.350 H

6.1.1. 3×400 V + PE, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Proline 420.350 H ES-101.335-B1/B2-V5.2 Wiring diagram 3x400V+PE, 50Hz									
		BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: Proline 420.350 H		Název stránky/Name page/Name seiten: Úvodní strana / Start page / Startseite		Číslo dok./Doc.No./Numm. der Dokumente: ES-101.335-B1/B2-V5.2 Napájecí/Power supply/Empfangung: 3x400V+PE, 50Hz Zpracoval/Processed /Mit verarbeitet: 10.01.2022 Datum/Dated/Datum:	
		BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: Proline 420.350 H		Název stránky/Name page/Name seiten: Úvodní strana / Start page / Startseite		Číslo dok./Doc.No./Numm. der Dokumente: ES-101.335-B1/B2-V5.2 Napájecí/Power supply/Empfangung: 3x400V+PE, 50Hz Zpracoval/Processed /Mit verarbeitet: 10.01.2022 Datum/Dated/Datum:	
		BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: Proline 420.350 H		Název stránky/Name page/Name seiten: Úvodní strana / Start page / Startseite		Číslo dok./Doc.No./Numm. der Dokumente: ES-101.335-B1/B2-V5.2 Napájecí/Power supply/Empfangung: 3x400V+PE, 50Hz Zpracoval/Processed /Mit verarbeitet: 10.01.2022 Datum/Dated/Datum:	

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
/1	Úvodní strana / Start page / Startseite	18.01.2022
/2	Obsah / Table of contents / Inhaltsverzeichnis	10.02.2022
/3	Kusovník artiklů / Parts list / Artikelstückliste	18.01.2022
/3.a	Kusovník artiklů / Parts list / Artikelstückliste	18.01.2022
/3.b	Kusovník artiklů / Parts list / Artikelstückliste	18.01.2022
/3.c	Kusovník artiklů / Parts list / Artikelstückliste	10.02.2022
/3.d	Kusovník artiklů / Parts list / Artikelstückliste	10.02.2022
/3.e	Kusovník artiklů / Parts list / Artikelstückliste	10.02.2022
/3.f	Kusovník artiklů / Parts list / Artikelstückliste	10.02.2022
/3.g	Kusovník artiklů / Parts list / Artikelstückliste	10.02.2022
/4	Ovládací panel OP1 / Control panel OP1 / Bedienpult OP1	18.01.2022
/5	Rozmístění hydraulických ventilů / Placement of Hydraulic valves / Platzierung die Hydroventile	08.06.2021
/6	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	18.01.2022
/7	Silová část M1 / Power part M1 / Feld partie M1	10.02.2022
/8	Silová část M2,M3 / Power part M2,M3 / Feld partie M2,M3	18.01.2022
/9	Silová část M4, M5 / Power part M4, M5 / Feld partie M4, M5	10.02.2022
/10	Řídicí systém / Control system / Steuersystem	10.02.2022
/11	Tlačítka ovládací panel OP1 / Button control panel OP1 / Taste Bedienpult OP1	18.01.2022
/12	Vstupy / Inputs / Eingänge	10.02.2022
/13	Hydraulické ventily / Hydraulic valves / Hydroventile	19.01.2022
/14	Stykače motorů / Motor contactors / Motor-Schutzschalter	18.01.2022
/15	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	18.01.2022
/16	Snímač výšky ramene / Sawframe position sensor / Rahmenposition sensor	18.01.2022
/17	Příslušenství / Accessories / Zubehör	19.01.2022
/18	SyncFree / SyncFree / SyncFree	18.01.2022

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO/1NC Safety relay 24VDC, 3NO/1NC Sicherheitsrelais 24VDC, 3NO/1NC	ABB.2TLA010040R0000	ABB	91.051.076	1	/15.5
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+ 1xNC	HKF1-11	ABB	91.046.002	1	/8.2
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+ 1xNC	HKF1-11	ABB	91.046.002	1	/8.6
-SN10.4	Indukční snímač vzdálenosti Inductive proximity sensor Induktive Näherungssensor	BAW R06AC-UAF20B-EP03	BALLUFF	91.172.016	1	/17.6
-A10.4	Odhylka pásu Band deviation Bandabweichung	BDM2	BOMAR s.r.o.	266.254	1	/17.2
-SN1	Snímač výšky ramene Arm height sensor Arm Höhensensor	DHB	BOMAR s.r.o.	251.232	1	/16.4
-TR1	Držák Holder Inhaber	30.6030-413	BOMAR s.r.o.	30.6030-413	1	/7.6
-HL1	Signálka LED červená na adaptér Red LED light for adapter Red LED-Licht für Adapter	M22-LED-R	EATON	91.061.027	1	/14.1
-KM2A	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/14.5
-KM2A	Mechanické blokování Mechanical interlock unit Mechanische Interlockeinheit	VM4	ABB	91.041.045	1	/14.5
-KM2B	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/14.7
-KM2B	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	2	/14.7

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/B2-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Hat verarbeitet: 18.01.2022	List/Page/ Seite: 3
				List/Page/ Seite: 25
				Datum/Date/Datum:

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SA1	Hlavice s otočným přepínačem - 4 polohy Head with rotary switch - 4 positions Kopf mit Drehschalter - 4 Positionen	M22 - WRK4	EATON	91.060.087	1	/11.7
-FU1	Pojistka trubičková - 4A/250V, pomalá, 5x20 Tube fuse - 4A/250V, slow, 5x20 Rohrsicherung - 4A / 250V, langsam, 5x20	T4A/250V	ESKA	91.230.015	1	/7.8
-FU5	Pojistka trubičková - 500mA/250V, pomalá, 5x20 Tube fuse - 500mA/250V, slow, 5x20 Rohrsicherung - 500 mA / 250 V, langsam, 5x20	T500mA/250V	ESKA	91.230.011	1	/17.9
-RP1	Potenciometr 4k7 Potentiometer 4k7 Potentiometer 4k7	TP195 4k7/N20A	Elektronické součástky CZ, a.s	91.283.015	1	/9.5
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/9.5
-HA1	Laser Laser Laser	Laser 24AC/DC	HOFMAN SYSTEMS s.r.o.	91.100.109	1	/17.1
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.3
-RCF2A	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.1
-RCF3	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.7
-RCF6B	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.4
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.7

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2		Let/Page/ Seite: 3.a
			Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz		Let/Page/ Seite: 25
			Zpracováno/Processed /Hat verarbeitet:		
			Datum/Date/Datum: 18.01.2022		

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-+R2	Kleštinová vývodka Cable gland Kabelverschraubung	AG-1545.12.06	Schmachtl CZ s.r.o.	91.070.010	2	/16.4
-+R2	Matice černá Nut black Nuss schwarz	AG8245.12	Schmachtl CZ s.r.o.	91.072.010	2	/16.4
--+R10.4	Kleštinová vývodka Cable gland Kabelverschraubung	AG-1545.12.06	Schmachtl CZ s.r.o.	91.070.010	2	/17.6
--+R10.4	Matice černá Nut black Nuss schwarz	AG8245.12	Schmachtl CZ s.r.o.	91.072.010	2	/17.6
-FA1	Tepečné relé - 0.31A Thermal relay - 0.31A Thermische Relais - 0.31A	T16-0.31	ABB	91.050.020	1	/7.4
-FA2	Motorový spouštěč - 2.5A Motor starter - 2.5A Motorstarter - 2.5A	MS116-2,5	ABB	91.045.021	1	/8.2
-FA3	Motorový spouštěč - 1A Motor starter - 1A Motorstarter - 1A	MS116-1,00	ABB	91.045.019	1	/8.6
-FU4	Pojistka trubičková - 200mA/250V, pomalá, 5x20 Tube fuse - 200mA/250V, slow, 5x20 Rohrsicherung - 160mA / 250V, langsam, 5x20	T200mA/250V	ESKA	91.230.037	1	/17.1
-FU4	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THSI5U	WIELAND	91.251.102	1	/17.1
-FU5	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THSI5U	WIELAND	91.251.102	1	/17.9
-H10.4	Maják - základna Lighthouse - Base Leuchtturm - Basis	SL7-CB-100	EATON	91.063.058	1	/17.3
-H10.4	Maják - žlutý Lighthouse - yellow Leuchtturm - gelb	SL7-L-Y	EATON	91.063.059	1	/17.3

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Het. verarbeitet: 18.01.2022	Účt./Page/ Seite: 3.b Účt./Page/ Seite: 25
-----	--	--	---	---	---



Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-H10.4	Žárovka 24V Lamp 24V Lampe 24V	SL7-L24	EATON	91.063.061	1	/17.3
-KM1	Ministýkač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/14.2
-KM2A	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1. xNC	CA4-01	ABB	91.041.043	1	/14.5
-KM2B	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1. xNC	CA4-01	ABB	91.041.043	1	/14.7
-KM3	Ministýkač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/14.3
-KM11	Stýkač 5,5kW/400V Contactor 5.5kW/400V Schütz 5.5kW/400V	AF12-30-01-11	ABB	91.040.051	1	/15.7
-KM11	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	1	/15.7
-KM12	Stýkač 5,5kW/400V Contactor 5.5kW/400V Schütz 5.5kW/400V	AF12-30-01-11	ABB	91.040.051	1	/15.8
-KM12	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	1	/15.8
-PA2	Pojistkový odpojovač E-90 - 2P Fuse disconnector E-90 - 2P Sicherungstrenner E90 - 2P	E 92/32	ABB	91.241.013	1	/7.5
-QS1	3 pólový odpínač, 25A Disconnector - 3P, 25A Trennschalter - 3P, 25A	OT25FT3	ABB	91.170.016	2	/7.2
-QS1	Rukojeť odpínače - černá Handle switch - black Griffschalter - schwarz	OHBS2RJ	ABB	91.180.015	1	/7.2

The manufacturer reserves right to use an equivalent replacement device.

3.b	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Hat verarbeitet: 10.02.2022	Účt./Page/ Seite: 3.c Účt./Page/ Seite: 25
-----	--	--	---	--	---

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-RE1	Minisťkač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1-7-71	ABB	91.040.049	1	/14.8
-RP1	Svorka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/9.5
-SA1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.7
-SA1	Kontaktní blok - 1NO; na panel Contact block - 1NO; on the panel Kontaktblock - 1NO; auf dem panel	M22-K10	EATON	91.061.022	2	/11.7
-SA1	Upevňovací adaptér Mounting adapter Montageadapter	M22-A4	EATON	91.061.045	1	/11.7
-SB1	Hlavice dvoutlačítka bílá/černá start/stop Double button head white/black start/stop Doppelrundkopf weiß/schwarz Start/Stopp	M22-DDL-WS-GB1/GB0	EATON	91.060.034	1	/11.1
-SB1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.1
-SB2	Kontaktní blok - 1NO; na panel Contact block - 1NO; on the panel Kontaktblock - 1NO; auf dem panel	M22-K10	EATON	91.061.022	1	/11.2
-SB3	Hlavice dvoutlačítka bílá/černá, zavřít/otevřít Double button head white/black, arrow close/open Doppelrundkopf weiß / schwarz, Pfeil Schließen / Öffnen	M22-DDL-WS-*	EATON	91.060.055	1	/11.2
-SB3	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.2
-SB4	Kontaktní blok - 1NO; na panel Contact block - 1NO; on the panel Kontaktblock - 1NO; auf dem panel	M22-K10	EATON	91.061.022	1	/11.3
-SB5	Hlavice dvoutlačítka bílá/černá šipka nahoru/dolů Double button head white/black, arrow up/down Doppelrundkopf weiß / schwarz, Pfeil nach oben / unten	M22-DDL-WS-**-*	EATON	91.060.054	1	/11.4

The manufacturer reserves right to use an equivalent replacement device.

3.c

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Hat verarbeitet: 10.02.2022	List/Page/ Seite: 3.d
				List/Page/ Seite:
				List/Page/ Seite: 25

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SB5	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.4
-SB6	Kontaktní blok - 1NO; na panel Contact block - 1NO; on the panel Kontaktblock - 1NO; auf dem panel	M22-K10	EATON	91.061.022	1	/11.5
-SB7	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	2	/15.6;/17.1
-SB7	Hlavice prosvětleného tlačítka modrá Blue transparent switch Blau transparent Schalter	M22-DL-B	EATON	91.060.132	1	/15.6
-SB7	Přepínač 2 polohy Switch 2 positions Schalter 2 Positionen	M22 - WKV	EATON	91.060.037	1	/17.1
-SB7	Nosič štítků Moeller Moeller label holder Moeller Etikettenhalter	M22S-ST-X	EATON	91.062.009	1	/17.1
-SB501	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Platz - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/15.4
-SB501	Kontakt - 1x NC Contact - 1x NC Kontakt - 1x NC	YW-E01	IDEC	91.061.054	1	/15.4
-TR1	Toroidní transformátor - 400V/230V/20V 4,5A 90VA Toroidal transformer - 400V / 230V / 20V 4,5A 90VA Ringkerntransformator - 400V / 230V / 20V 4,5A 90VA	400V/230V/20V 4,5A 90VA	KARBAN s.r.o.	91.080.023	1	/7.6
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QKS8	KEDU	91.173.012	1	/15.4
-PA1	Pojistka válcová - 12A, 10x38, rychlá Tube fuse - 12A, 10x38, fast Rohrsicherung - 12A, 10x38, schnell	PV10 12A gG	OEZ	91.231.007	2	/9.1
-PA2	Pojistka válcová - 2A, 10x38, pomalá Tube fuse - 2A, 10x38, slow Rohrsicherung - 2A, 10x38, langsam	PV10 2A gG	OEZ	91.230.034	2	/7.5

The manufacturer reserves right to use an equivalent replacement device.

3.d	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Hat verarbeitet: 10.02.2022	Účt./Page/ Seite: 3.e Účt./Page/ Seite: 25
-----	--	--	---	--	---

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ4	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/12.7
-SQ1	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 605-M2	PIZZATO	91.173.009	1	/12.3
-SQ2	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 615-M2	PIZZATO	91.173.044	1	/12.4
-SQ3	Koncový spínač - 1NO + 1NC, dlouhá nastavitelná kladka, M2, snap action Limit switch - 1NO + 1NC, long adjustable pulley, M2, snap action Endschalter - 1NO + 1NC, lange verstellbare rolle, M2, schnapp	FR 655-M2	PIZZATO	91.173.045	1	/12.6
-FM1	Frekvenční měnič - 3.7kW, 3x400VAC Frequency converter - 3.7kW, 3x400VAC Frequenzumrichter - 3.7kW, 3x400VAC	VFD9A0ME43AFNAA	DELTA ELECTRONICS, INC.	91.012.191	1	/9.1
-M1	Čerpadlo chlazení 120W Cooling pump 120W Kühlpumpe 120W	PA70/120	SAP srl	91.020.032	1	/7.4
-+R2	PS 41x89x74mm - šedá PS 41x89x74mm - grey PS 41x89x74mm - grau	Z54	SOS Electronic, spol. s r.o.	91.190.036	1	/16.4
-+R10.4	PS 41x89x74mm - šedá PS 41x89x74mm - grey PS 41x89x74mm - grau	Z54	SOS Electronic, spol. s r.o.	91.190.036	1	/17.6
-CU1	Řídicí obvod Control unit Steuerinheit	SMA_4.01W	Bomar	265.918	1	/10.0
-+R2	Svorka Clamp Klemmen	WAGO.260-301	WAGO	91.250.008	1	/16.4
-+R2	Koncová bočnice End side Endseite	WAGO.260-361	WAGO	91.252.003	1	/16.4
-+R10.4	Svorka Clamp Klemmen	WAGO.260-301	WAGO	91.250.008	1	/17.6

The manufacturer reserves right to use an equivalent replacement device.

3.e

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/BE-V5.2 Napájení/Power supply/Einspeisung: 3x400V+PE, 50Hz Zpracováno/Processed /Hat verarbeitet: 10.02.2022	Lišt/Page/ Seite: 3.f Lišt/Page/ Seite: 25
---	--	---	--	---

93

0

1

2

3

4

5

6

7

8

9

8 10 12.1 12.2 14

		Svěrák upnout Vice clamp Schraubstock spannen
A		
HV8	B	Svěrák povolit Release vice Schraubstock lösen
		Nezapojeno Not connected Nicht angeschlossen
HV10		
		Nezapojeno Not connected Nicht angeschlossen
HV12.1		
		Rameno dolů Arm down Rahmen nach unten
	A	
HV12.2	B	Rameno nahoru Arm up Rahmen nach oben
		Rameno rychle dolů Arm quickly down Rahmen schnell nach unten
HV14	A	

BOMAR, s.r.o.
Třezbří 1236/1
CZ 627 00, Brno

Stroj/Machine/Maschine: Proline 420.350 H


Název stránky/Name page/Name seiten:
Rozmístění hydraulických ventilů / Placement of hydraulic valves /
Platzierung die Hydroventile Placement of elements in enclosure R1

Cílo odk./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/B2-V5.2
Napájení/Power supply/Einspeisung: 3x400V+PE, 50Hz
Zpracováno/Processed /Fkt. verarbeitet:
Datum/Date/Datum: 08.06.2021

Let/Page/
Seite: 5
Let/Page/
Seite: 25


ROZVÁDĚČ: 30.R230-201

+R1




5

	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B1/R2-V5.2 Napájení/Power supply/Einspeisung: 3~400V+PE, 50Hz Zpracováno/Processed /Hat. verarbeitet: Datum/Date/Datum: 18.01.2022	Lid/Page/ Seite: 6 Lid/Page/ Seite: 25








 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojí/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Silová část M2,M3 / Power part M2,M3 Silová část M2,M3 / Feld partie M2,M3	Číslo dok./Doc.No/Anzahl der Dokumente.: ES-101.335-B1/B2-V5.2	List/Page/ Seite: 8
				Napájení/Power supply/Einspeisung: 3x400V-PE, 50Hz Zpracoval/Processed /Hat verarbeitet: Datum/Date/Datum: 18.01.2022 List/Page/ Seiten: 25

















105





6.1.2. 3x230 V + PE, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Proline 420.350 H ES-101.335-B3-V5.2 Wiring diagram 3x230V+PE, 50/60Hz Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Stroj/Machine/Maschine: Proline 420.350 H		Název stránky/Name page/Name sheet: Úvodní strana / Start page / Startseite		GdG dok./Doc.No/Anzahl der Dokumenta.: ES-101.335-B3-V5.2 Název/Power supply/Einspeisung: 3x230V+PE, 50/60Hz Zpracováno/Processed /Hat. verarbeitet: 10.02.2022		Link/Page/ Seite: 1 Link/Page/ Seite: 24

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
/1	Úvodní strana / Start page / Startseite	10.02.2022
/2	Obsah / Table of contents / Inhaltsverzeichnis	10.02.2022
/3	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.a	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.b	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.c	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.d	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.e	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/3.f	Kusovník artiklů / Parts list / Artikelstückliste	19.01.2022
/4.a	Ovládací panel OP1 / Control panel OP1 / Bedienpult OP1	19.01.2022
/5	Rozmístění hydraulických ventilů / Placement of Hydraulic valves / Platzierung die Hydroventile	19.01.2022
/6	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	19.01.2022
/7	Silová část M1 / Power part M1 / Feld partie M1	19.01.2022
/8	Silová část M2, M3 / Power part M2, M3 / Feld partie M2, M3	19.01.2022
/9	Silová část M4, M5 / Power part M4, M5 / Feld partie M4, M5	10.02.2022
/10	Řídicí systém / Control system / Steuersystem	24.01.2022
/11	Tlačítka ovládací panel OP1 / Button control panel OP1 / Taste Bedienpult OP1	19.01.2022
/12	Vstupy / Inputs / Eingänge	19.01.2022
/13	Hydraulické ventily / Hydraulic valves / Hydroventile	19.01.2022
/14	Stykače motorů / Motor contactors / Motor-Schutzschalter	19.01.2022
/15	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	19.01.2022
/16	Snímač výšky ramene / Sawframe position sensor / Rahmenposition sensor	19.01.2022
/17	Příslušenství / Accessories / Zubehör	19.01.2022
/18	SyncFree / SyncFree / SyncFree	19.01.2022

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Page name/Name der Seite: Obsah / Table of contents / Inhaltsverzeichnis	Číslo dok./Doc.No./Anzahl der Dokumente.: Napájení/Power supply/Einspeisung: Zpracování/Processed /Hat verarbeitet: Datum/Date/Datum:	ES-101.335-B5-V5.2	2	24
				3x230V+PE, 50/60Hz		
				10.02.2022		

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO/1NC Safety relay 24VDC, 3NO/1NC Sicherheitsrelais 24VDC, 3NO/1NC	ABB.2TLA010040R0000	ABB	91.051.076	1	/15.5
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+ 1xNC	HKF1-11	ABB	91.046.002	1	/8.2
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+ 1xNC	HKF1-11	ABB	91.046.002	1	/8.6
-SN10.4	Indukční snímač vzdálenosti Inductive proximity sensor Induktive Näherungssensor	BAW R06AC-UAF20B-EP03	BALLUFF	91.172.016	1	/17.6
-A10.4	Odhylka pásu Band deviation Bandabweichung	BDM2	BOMAR s.r.o.	266.254	1	/17.2
-SN1	Snímač výšky ramene Arm height sensor Arm Höhensensor	DHB	BOMAR s.r.o.	251.232	1	/16.4
-HL1	Signálka LED červená na adaptér Red LED light for adapter Red LED-Licht für Adapter	M22-LED-R	EATON	91.061.027	1	/14.1
-KM2A	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/14.5
-KM2A	Mechanické blokování Mechanical interlock unit Mechanische Interlockeinheit	VM4	ABB	91.041.045	1	/14.5
-KM2B	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/14.7
-KM2B	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	2	/14.7
-SA1	Hlavice s otočným přepínačem - 4 polohy Head with rotary switch - 4 positions Kopř mit Drehschalter - 4 Positionen	M22 - WRK4	EATON	91.060.087	1	/11.7

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2		List/Page/ Seite: 3
			Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz		List/Page/ Seite: 24
			Zpracováno/Processed /Hat. verarbeitet: 19.01.2022		List/Page/ Seite: 24

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-FU1	Pojistka trubičková - 4A/250V, pomalá, 5x20 Tube fuse - 4A/250V, slow, 5x20 Rohrsicherung - 4A / 250V, langsam, 5x20	T4A/250V	ESKA	91.230.015	1	/7.8
-RP1	Potenciometr 4k7 Potentiometer 4k7 Potentiometer 4k7	TP195 4k7/N20A	Elektronické součástky CZ, a.s	91.283.015	1	/9.5
-FA1	Tepelné relé - 0.74A Thermal relay - 0.74A Thermische Relais - 0.74A	T16-0.74	ABB	91.050.021	1	/7.4
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/9.5
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.3
-RCF2A	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.1
-RCF3	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.7
-RCF6B	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/8.4
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/7.7
+R2	Kleštinová vývodka Cable gland Kabelverschraubung	AG-1545.12.06	Schmachtl CZ s.r.o.	91.070.010	2	/16.4
+R2	Matice černá Nut black Nuss schwarz	AG8245.12	Schmachtl CZ s.r.o.	91.072.010	2	/16.4

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2		Účt./Page/ Seite: 3.a
			Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz		Účt./Page/ Seite: 24
			Zpracováno/Processed /Fkt. verarbeitet: 19.01.2022		Účt./Page/ Seite: 24

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
--R10.4	Kleštinová vývodka Cable gland Kabelverschraubung	AG-1545-12.06	Schmachtl CZ s.r.o.	91.070.010	2	/17.6
--R10.4	Matice černá Nut black Nuss schwarz	AG8245.12	Schmachtl CZ s.r.o.	91.072.010	2	/17.6
-FA2	Motorový spouštěč - 2.5A Motor starter - 2.5A Motorstarter - 2.5A	MS116-2,5	ABB	91.045.021	1	/8.2
-FA3	Motorový spouštěč - 1.6A Motor starter - 1.6A Motorstarter - 1.6A	MS116-1,6	ABB	91.045.020	1	/8.6
-H10.4	Maják - základna Lighthouse - Base Leuchtturm - Basis	SL7-CB-100	EATON	91.063.058	1	/17.3
-H10.4	Maják - žlutý Lighthouse - yellow Leuchtturm - gelb	SL7-L-Y	EATON	91.063.059	1	/17.3
-H10.4	Žárovka 24V Lamp 24V Lampe 24V	SL7-L24	EATON	91.063.061	1	/17.3
-KM1	Ministrykač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schutz - 4kW / 400V, 3P	B6S-30-01-1-7-71	ABB	91.040.049	1	/14.2
-KM2A	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/14.5
-KM2B	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/14.7
-KM3	Ministrykač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schutz - 4kW / 400V, 3P	B6S-30-01-1-7-71	ABB	91.040.049	1	/14.3
-KM11	Stykač - 5,5kW/400V, 3P Contactor - 5,5kW/400V, 3P Schütz - 5,5kW / 400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/15.7

The manufacturer reserves right to use an equivalent replacement device.

3.a	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2 Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz Zpracováno/Processed /Hat verarbeitet: 19.01.2022	Liš/Pagel/ Seite: 3.b Liš/Pagel/ Seite: 24
-----	--	--	--	--	---

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM11	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	1	/15.7
-KM12	Stykač - 5,5kW/400V, 3P Contactor - 5,5kW/400V, 3P Schütz - 5,5kW / 400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/15.8
-KM12	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	1	/15.8
-M5	Ventilátor 24VDC, 5W Fan 24VDC, 5W Fan 24VDC, 5W	EEC025281-A99	SUNON	91.015.139	1	/9.8
-PA1	Pojistkový odpalovač E-90 - 2P Fuse disconnector E-90 - 2P Sicherungstrenner E90 - 2P	E 92/32	ABB	91.241.013	1	/7.5
-QS1	3 pólový odpináč, 40A Disconnecter - 3P, 40A Trennschalter - 3P, 40A	OT40FT3	ABB	91.170.019	1	/7.0
-QS1	Rukojeť odpináče - černá Handle switch - black Griffschalter - schwarz	OHBS2RJ	ABB	91.180.015	1	/7.0
-QS1	Kryt svorek Terminal shroud Klemmenabdeckung	OTS40T3	ABB	91.170.017	1	/7.0
-RE1	Ministýkač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/14.8
-RP1	Svorka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/9.5
-SA1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.7
-SA1	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	2	/11.7

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2		Let/Pagel/
			Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz		Seite: 3.c
			Zpracováno/Processed /Hat verarbeitet:		Let(Pagel/
			Datum/Date/Datum: 19.01.2022		Seite: 24

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SA1	Upevňovací adaptér Mounting adapter Montageadapter	M22-A4	EATON	91.061.045	1	/11.7
-SB1	Hlavice dvoutlačítka bílá/černá start/stop Double button head white/black start/stop Doppelrundkopf weiß/schwarz Start/Stopp	M22-DDL-WS-GB1/GB0	EATON	91.060.034	1	/11.1
-SB1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.1
-SB2	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/11.2
-SB3	Hlavice dvoutlačítka bílá/černá, zavřít/otevřít Double button head white/black, arrow close/open Doppelrundkopf weiß / schwarz, Pfeil Schließen / Öffnen	M22-DDL-WS-*	EATON	91.060.055	1	/11.2
-SB3	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.2
-SB4	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/11.3
-SB5	Hlavice dvoutlačítka bílá/černá šipka nahoru/dolů Double button head white/black, arrow up/down Doppelrundkopf weiß / schwarz, Pfeil nach oben / unten	M22-DDL-WS-*	EATON	91.060.054	1	/11.4
-SB5	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.4
-SB6	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	1	/11.5
-SB7	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/15.6
-SB7	Hlavice prosvětleného tlačítka modrá Blue transparent switch Blaue transparent Schalter	M22-DL-B	EATON	91.060.132	1	/15.6

The manufacturer reserves right to use an equivalent replacement device.

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2		Účt./Page/ Seite: 3 d
			Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz		Účt./Page/ Seite: 3 d
			Zpracováno/Processed /Hst. verarbeitet: 19.01.2022		Účt./Page/ Seite: 24


Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SB501	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pliz - Taster + 3 xNC	YW1B-V4E02R	IDEC	91.060.084	1	/15.4
-SB501	Kontakt - 1x NC Contact - 1x NC Kontakt - 1x NC	YW-E01	IDEC	91.061.054	1	/15.4
-TR1	Toroidní transformátor - 400V/230V/20V 4,5A 90VA Toroidal transformer - 400V / 230V / 20V 4,5A 90VA Ringkerntransformator - 400V / 230V / 20V 4,5A 90VA	400V/230V/20V 4,5A 90VA	KARBAN s.r.o.	91.080.023	1	/7.6
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsschalter - 2x NC	QXS8	KEDU	91.173.012	1	/15.4
-PA1	Pojistka válcová - 2A, 10x38, pomalá Tube fuse - 2A, 10x38, slow Rohrsicherung - 2A, 10x38, langsam	PV10 2A GG	OEZ	91.230.034	2	/7.5
-PA2	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylindereinsätze - 3P	E 93/32	ABB	91.241.014	1	/9.1
-PA2	Pojistka válcová - 25A, 10x38, rychlá Tube fuse - 25A, 10x38, fast Rohrsicherung - 25A, 10x38, schnell	PV10 25A GG	OEZ	91.230.021	1	/9.1
-SQ4	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/12.7
-SQ4	Koncový spínač - 1NC+1NO, M20, pomalý Limit switch - 1NC+1NO, M20, slow Endschalter -1NC+1NO, M20, langsam	D4N-4A32	OMRON	91.173.010	1	/12.7
-SQ1	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 605-M2	PIZZATO	91.173.009	1	/12.3
-SQ2	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 615-M2	PIZZATO	91.173.044	1	/12.4
-SQ3	Koncový spínač - 1NO + 1NC, dlouhá nastavitelná kladka, M2, snap action Limit switch - 1NO + 1NC, long adjustable pulley, M2, snap action Endschalter - 1NO + 1NC, lange verstellbare rolle, M2, schnapp	FR 655-M2	PIZZATO	91.173.045	1	/12.6

The manufacturer reserves right to use an equivalent replacement device.


 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H	Název stránky/Name page/Name seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo odk./Doc.No./Anzahl der Dokumente.: ES-101.335-B5-V5.2		Let/Pagel/
			Napájení/Power supply/Einspeisung: 3x230V+PE, 50/60Hz		Seite: 3.e
			Zpracováno/Processed /Hat verarbeitet: 19.01.2022		Letl(Pages)/ Seiten: 24

3.f



ROZVÁDĚČ: 30.R230-201

+R1











 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00. Brno	Strojí/Machine/Machine: Proline 420.350 H	Název stránky/Name page/Name seiten: Slová část M4, M5 / Power part M4, M5 / Feld partie M4, M5	Číslo dok./Doc.No./Anzahl der Dokumente.: E5-101.335-B3-V5.2 Náplaví/Power supply/Einspeisung: 3x230V/4PE, 50/60Hz Zpracováno/Processed /Hat verarbeitet: Datum/Data/Datum: 10.02.2022	List/Page/ Seller: 9 List/Page/ Seller: 24
---	--	---	--	---













130





6.2. Elektrické schéma / Elektroschema / Wiring diagrams – Proline 420.350 Hsx

6.2.1. 3x400 V + PE, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Proline 420.350 H SX ES-R3800-201/202-V2.5 Wiring diagram 3x400V+PE, 50Hz									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Sevyl/Machine/Maschine: Proline 420.350 H SX			Název stránky/Name page/Name seite: Úvodní strana / Start page / Startseite			Číslo dok./Doc./Auftr./zahl. der Dokumente.: ES-R3800-201/202-V2.5 Název/Prover. s.úhry/Ergebnisprüfung: 3x400V+PE, 50Hz Zpracování/Procesus/Ver. verarbeitet: 30.3.2016 Číslo/Objekt/Objektum: 30.3.2016
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Sevyl/Machine/Maschine: Proline 420.350 H SX			Název stránky/Name page/Name seite: Úvodní strana / Start page / Startseite			Číslo dok./Doc./Auftr./zahl. der Dokumente.: ES-R3800-201/202-V2.5 Název/Prover. s.úhry/Ergebnisprüfung: 3x400V+PE, 50Hz Zpracování/Procesus/Ver. verarbeitet: 30.3.2016 Číslo/Objekt/Objektum: 30.3.2016

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	30.3.2016
2	Obsah / Table of contents / Inhaltsverzeichnis	4.10.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	14.7.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.d	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
4	Ovládací panel OP1 / Control panel OP1 / Bedienpult OP1	23.3.2016
5	Rozmístění hydraulických ventilů / Placement of Hydraulic valves / Platzierung die Hydroventile	23.3.2016
6	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	4.10.2016
7	Silová část M1 / Power part M1 / Feld partie M1	4.10.2016
8	Silová část M2,M3 / Power part M2,M3 / Feld partie M2,M3	4.10.2016
9	Silová část M4 M5 / Power part M4, M5 / Feld partie M4, M5	4.10.2016
10	Řídicí systém / Control system / Steuersystem	13.4.2016
12	Tlačítka ovládací panel OP1 / Button control panel OP1 / Taste Bedienpult OP1	23.3.2016
13	Vstupy / Inputs / Eingänge	4.10.2016
14	Hydraulické ventily / Hydraulic valves / Hydroventile	23.3.2016
15	Stykače motorů / Motor contactors / Motor-Schutzschalter	4.10.2016
16	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	4.10.2016
18	Snímač výšky ramene / Sawframe position sensor / Rahmenposition sensor	23.3.2016
19	Příslušenství / Accessories / Zubehör	23.3.2016
20	SyncFree / SyncFree / SyncFree	13.7.2016

The manufacturer reserves right to use an equivalent replacement device.

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/9.5
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Viček	91.041.015	1	/7.3
-RCF2A	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Viček	91.041.015	1	/8.1
-RCF6B	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Viček	91.041.015	1	/8.4
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Viček	91.041.015	1	/7.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Viček	91.041.015	1	/7.7
-FA2	Motorový spouštěč - 2.5A Motor starter - 2.5A Motorstarter - 2.5A	MS116-2,5	ABB	91.045.021	1	/8.2
-FA3	Motorový spouštěč - 1A Motor starter - 1A Motorstarter - 1A	MS116-1,00	ABB	91.045.019	1	/8.6
-KM1	Ministrykač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B6S-30-01-1,7-71	ABB	91.040.049	1	/15.2
-KM2A	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/15.4
-KM2B	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/15.6
-KM11	Stykač - 5,5kW/400V, 3P Contactor - 5,5kW/400V, 3P Schütz - 5,5kW / 400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/16.7

The manufacturer reserves right to use an equivalent replacement device.

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM12	Stykač - 5,5kW/400V, 3P Contactor - 5,5kW/400V, 3P Schütz - 5,5kW / 400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/16.8
-PA1	Pojistkový odpojovač E-90 - 2P Fuse disconnecter E-90 - 2P Sicherungstreiner E90 - 2P	E 92/32	ABB	91.241.013	1	/7.5
-QS1	3 pólový odpínač, 25A Disconnecter - 3P, 25A Trennschalter - 3P, 25A	QT25FT3	ABB	91.170.016	1	/7.0
-RE1	Ministýkač - 4kW/400V, 3P Mini contactor - 4kW/400V, 3P Mini-Schütz - 4kW / 400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/15.8
-RP1	Svorka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/9.5
-SA1	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.7
-SA1	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	2	/12.7
-SB1	Hlavice dvoutlačítka bílá/černá start/stop Double button head white/black start/stop Doppelrundkopf weiß/schwarz Start/Stop	M22-DDL-WS-GB1/GB0	EATON	91.060.034	1	/12.1
-SB1	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.1
-SB2	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.2
-SB3	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.2
-SB3	Hlavice dvoutlačítka bílá/černá, zavřít/otevřít Double button head white/black, arrow close/open Doppelrundkopf weiß / schwarz, Pfeil Schließen / Öffnen	M22-DDL-WS-*	EATON	91.060.055	1	/12.2

The manufacturer reserves right to use an equivalent replacement device.

3.a	 BOMAR, s.r.o. Těšební 1256/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Celo cok./Doc.No./Anzahl der Dokumente: ES-R3600-201/202-V2.5 Napájení/Power supply/Einspeisung: 3x400V / PE, 50Hz Zpracování/Processed Part: verarbeitet: Datum/Data/Datum: 4.10.2016	Liš/Pager/ Seite: 3.b List/Pages/ Seite: 22
-----	---	--	--	---	--

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SB4	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.3
-SB5	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.4
-SB5	Hlavice dvoutlačítka bílá/černá šipka nahoru/dolů Double button head white/black, arrow up/down Doppelrundkopf weiß / schwarz, Pfeil nach oben / unten	M22-DDL-WS-+-*	EATON	91.060.054	1	/12.4
-SB6	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.5
-SB7	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/16.6
-SB7	Hlavice prosvětleného tlačítka žlutá Yellow transparent switch Leiter beleuchtet gelbe Taste	M22-DL-Y	EATON	91.060.053	1	/16.6
-SB501	Total stop - hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pilz - Taster + 3 xNC	YW1B-VAE02R	IDEC	91.060.084	1	/16.4
-SB501	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW-E10	IDEC	91.061.044	1	/16.4
-TR1	Toroidní transformátor - 400V/230V/20V 4,5A 90VA Toroidal transformer - 400V / 230V / 20V 4,5A 90VA Ringkerntransformator - 400V / 230V / 20V 4,5A 90VA	400V/230V/20V 4,5A 90VA	KARBAN s.r.o.	91.080.023	1	/7.6
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QKS8	KEDU	91.173.012	1	/16.4
-PA1	Pojistka válcová - 2A, 10x38, pomalá Tube fuse - 2A, 10x38, slow Rohrsicherung - 2A, 10x38, langsam	PV10 2A gG	OEZ	91.230.034	2	/7.5
-PA2	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylindersteckse - 3P	E 93/32	ABB	91.241.014	1	/9.1

The manufacturer reserves right to use an equivalent replacement device.

3.b	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-R3600-201/202-V2.5 Napájení/Power supply/Einspeisung: 3x400V / PE, 50-Hz Zpracování/Processed Part: verarbeitet: Datum/Data/Datum: 4.10.2016	Úkl./Page/ Seite: 3.c List./Pages/ Seite: 22
-----	--	--	--	--	---


Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-PA2	Pojistka válcová - 16A, 10x38, rychlá Tube fuse - 16A, 10x38, fast Rohrsicherung - 16A, 10x38, schnell	PV10 16A gG	OEZ	91.230.020	1	/9.1
-SQ4	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/13.7
-SQ1	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 605-M2	PIZZATO	91.173.009	1	/13.3
-SQ2	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 615-M2	PIZZATO	91.173.044	1	/13.4
-SQ3	Koncový spínač - 1NO + 1NC, dlouhá nastavitelná kladka, M2, snap action Limit switch - 1NO + 1NC, long adjustable pulley, M2, snap action Endschalter - 1NO + 1NC, lange verstellbare rolle, M2, schnapp	FR 655-M2	PIZZATO	91.173.045	1	/13.6
-FM1	Frekvenční měnič - 5,5kW, 3x400VAC Frequency converter - 5,5kW, 3x400VAC Frequenzumrichter - 5,5kW, 3x400VAC	VFD055E43A	DELTA ELECTRONICS, INC.	91.012.129	1	/9.1
-QS1	Rukojeť odpináče 48x48mm - černá Handle switch 48x48mm - black Griffschalter 48x48mm - Schwarz	OHBS3PH	ABB	91.180.018	1	/7.0
-CU1	Řídicí obvod Control unit Steereinheit	SMA_4.01W	Bomar	265.918	1	/10.0
-RCF0	Vstupní odrušovací filtr 16A Input noise filter 16A Eingangsgerausfilter 16A	16EB15/50	WIDECOM TECHNOLOGY s.r.o.	91.041.062	1	/7.1
-FU1	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THSI5U	WIELAND	91.251.102	1	/7.8
-M5	Ventilátor 24VDC, 154CFM Fan 24VDC, 154CFM Fan 24VDC, 154CFM	RDH1238 B2	Xinruilian Electronic Co.	91.015.126	1	/9.8

The manufacturer reserves right to use an equivalent replacement device.

3.c

	BOMAR, s.r.o. Těšební 1256/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-R3600-201/202-V2.5 Napájení/Power supply/Einspeisung: 3x400V / PE, 50Hz Zpracování/Processed Part: verarbeitet: Datum/Data/Datum: 4.10.2016	Liš/Pages/ Seiten: 3.c List/Pages/ Seiten: 22
---	--	--	--	---	--



0	1	2	3	4	5	6	7	8	9
HV1A Svěrák upnout Vice clamp Schraubstock spannen HV2A Rameno dořů Arm down Rahmen nach unten HV1B Svěrák povolit Release vice Schraubstock lösen HV2B Rameno nahoru Arm up Rahmen nach oben HV3 Rameno rychle dořů Arm quickly down Rahmen schnell nach unten									
4									
 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno			Stroj/Headline/Headline: Proline 420.350 H SX			Název stránky/Name page/Name sheet: Rozmístění hydraulických ventilů / Placement of hydraulic valves / Platzierung die Hydroventile Placement of elements in enclosure RL			Číslo odk./Doc.No/Anzahl der Dokumente.: ES-R3600-201/202-V2.5 Napájení/Power supply/Fitingspannung: 3x400V / 1 PE, 50-Hz Zpracoval/Processed /Her verarbeitet: Kofka Datum/Data/Datum: 23.3.2016
									Ln/Page/ Seite: 5 List/Pages/ Seiten: 22











8	 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojí/Machine/Machine: Proline 420.350 H SX	Název stránky/Name page/Noms Seiten: Silová část M4 M5 / Power part M4, M5 / Silová část M4 M5 / Feld partie M4, M5	Číslo dok./Doc.No./Anzahl der Dokumente : ES-R3800-2012-02-V2.5	List/Page/ Seite: 9 Napájení/Power supply/Einspeisung: 3x400V + PE, 50-Hz Travníková/Processed /Her. verarbeitet: Kostka Datum/Data/Datum: 4.10.2016 List/Page/ Seite: 22
---	--	--	--	---	--













152





6.2.2. 3×230 V + PE, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Proline 420.350 H SX ES-R3800-203-V2.5 Wiring diagram 3x230V+PE, 50Hz									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Sevoj/Machine/Maschine: Proline 420.350 H SX			Název stránky/Name page/Name seite: Úvodní strana / Start page / Startseite			Číslo dok./Doc. kuf./Dok. der Dokumente.: ES-R3800-203-V2.5 Název přívodu a.s./Zuf./Einspeisung: 3x230V+PE, 50Hz Zpracování/Processing/Verarbeiten: 13.7.2016
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Sevoj/Machine/Maschine: Proline 420.350 H SX			Název stránky/Name page/Name seite: Úvodní strana / Start page / Startseite			Číslo dok./Doc. kuf./Dok. der Dokumente.: ES-R3800-203-V2.5 Název přívodu a.s./Zuf./Einspeisung: 3x230V+PE, 50Hz Zpracování/Processing/Verarbeiten: 13.7.2016

Obsah / Table of contents / Inhalt

Strana Page Seite	Název strany Page name Seitenname	Datum Date Datum
1	Úvodní strana / Start page / Startseite	13.7.2016
2	Obsah / Table of contents / Inhaltsverzeichnis	4.10.2016
3	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.a	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.b	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.c	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.d	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
3.e	Kusovník artiklů / Parts list / Artikelstückliste	4.10.2016
4	Rozmístění prvků v rozvaděči R1 / Placement of elements in enclosure R1 / Platzierung der Elemente im Schaltschrank R1	4.10.2016
5	Ovládací panel OP1 / Control panel OP1 / Bedienpult OP1	23.3.2016
6	Rozmístění hydraulických ventilů / Placement of Hydraulic valves / Platzierung die Hydroventile	23.3.2016
7	Silová část M1 / Power part M1 / Feld partie M1	4.10.2016
8	Silová část M2, M3 / Power part M2, M3 / Feld partie M2, M3	4.10.2016
9	Silová část M4, M5 / Power part M4, M5 / Feld partie M4, M5	4.10.2016
10	Řídicí systém / Control system / Steuersystem	4.10.2016
12	Tlačítka ovládací panel OP1 / Button control panel OP1 / Taste Bedienpult OP1	23.3.2016
13	Vstupy / Inputs / Eingänge	4.10.2016
14	Hydraulické ventily / Hydraulic valves / Hydroventile	23.3.2016
15	Stykače motorů / Motor contactors / Motor-Schutzschalter	4.10.2016
16	Bezpečnostní okruh / Safety circle / Sicherheitsbereich	4.10.2016
18	Snímač výšky ramene / Sawframe position sensor / Rahmenposition sensor	23.3.2016
19	Příslušenství / Accessories / Zubehör	23.3.2016
20	SyncFree / SyncFree / SyncFree	13.7.2016

Číslo dok./Doc.No./Anzahl der Dokumente:	ES-R3600-203-V2.5	Úkl./Page/
Název dok./Power supply/Einspeisung:	3x230V / PE 50-Hz	Seite: 2
Zpracoval/Processed/Verarbeitet:	Kostka	List./Pages/
Datum/Data/Datum:	4.10.2016	Seite: 22

Název stránky/Page name/Name der Seite:	Obsah / Table of contents / Inhaltsverzeichnis
---	--

Stroj/Machine/Maschine:	Proline 420.350 H SX
-------------------------	----------------------

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-BM1	Bezpečnostní relé 24VDC, 3NO Safety relay 24VDC, 3NO Sicherheitsrelais 24VDC, 3NO	BT50	ABB	91.051.063	1	/16.5
-PA2	Pojistkový odpínač pro válcové vložky - 3P Switch fuse for the cylinder inserts - 3P Schalter Sicherung für den Zylinderinsätze - 3P	E93/32	ABB	91.241.014	1	/9.1
-FA2	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/8.2
-FA3	Pomocné kontakty - 1xNO+1xNC Auxiliary contacts - 1xNO+1xNC Hilfskontakte - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/8.6
-HL1	Signálka LED červená na adaptér Red LED light for adapter Red LED-Licht für Adapter	M22-LED-R	EATON	91.061.027	1	/15.1
-KM2A	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/15.4
-KM2A	Mechanické blokování Mechanical interlock unit Mechanische Interlockeinheit	VM4	ABB	91.041.045	1	/15.4
-KM2B	Stykač - 4kW/400V, 3P Contactor - 4kW/400V, 3P Schütz - 4 kW / 400V, 3P	AF09-30-01-11	ABB	91.040.047	1	/15.6
-KM2B	Pomocný kontakt - 1xNO Auxiliary contact - 1xNO Hilfskontakt - 1xNO	CA4-10	ABB	91.041.044	2	/15.6
-SA1	Hlavice s otočným přepínačem - 4 polohy Head with rotary switch - 4 positions Kopf mit Drehschalter - 4 Positionen	M22 - WRK4	EATON	91.060.087	1	/12.7
-FU1	Pojistka trubičková - 4A/250V, pomalá, 5x20 Tube fuse - 4A/250V, slow, 5x20 Rohrsicherung - 4A / 250V, langsam, 5x20	T4A/250V	ESKA	91.230.015	1	/7.8
-M5	Ventilátor 24VDC, 154CFM Fan 24VDC, 154CFM	RDH1238 B2	Xinnulian Electronic Co.	91.015.126	1	/9.8

The manufacturer reserves right to use an equivalent replacement device.

	BOMAR, s.r.o. Těšební 1256/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Celo cel./Doc.No./Anzahl der Dokumente: ES-R3600-203-V2.5 Napájení/Power supply/Einspeisung: 3x230V / PE, 50Hz Zpracování/Processed Part: verarbeitet: Datum/Data/Datum: 4.10.2016	Liš/Pages/ Seiten: 3 List/Pages/ Seiten: 22
---	--	--	--	---	--

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-RP1	Potenciometr 4k7 Potentiometer 4k7	TP195 4k7/N20A	Elektronické součástky CZ, a.s	91.283.015	1	/9.5
-FA1	Teplotní relé - 0.74A Thermal relay - 0.74A Thermische Relais - 0.74A	T16-0,74	ABB	91.050.021	1	/7.4
-RP1	Hlavice potenciometru - 24mm Head of potentiometer 24mm Leiter Potentiometer 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/9.5
-RCF1	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Víček	91.041.015	1	/7.3
-RCF2A	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Víček	91.041.015	1	/8.1
-RCF6B	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Víček	91.041.015	1	/8.4
-RCF11	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Víček	91.041.015	1	/7.6
-RCF12	Filtr RFC vývodový Effluent RFC filter Ableitenden RFC Filter	FBOPR1624	Ing. Miroslav Víček	91.041.015	1	/7.7
-FA2	Motorový spouštěč - 2.5A Motor starter - 2.5A Motorstarter - 2.5A	MS116-2,5	ABB	91.045.021	1	/8.2
-FA3	Motorový spouštěč - 1.6A Motor starter - 1.6A Motorstarter - 1.6A	MS116-1,6	ABB	91.045.020	1	/8.6
-KM1	Minisys/kač 4kW/400V Minicontactor 4kW/400V Minischutz 4kW/400V	B6S-30-01-1-7-71	ABB	91.040.049	1	/15.2
-KM2A	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/15.4

The manufacturer reserves right to use an equivalent replacement device.

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-KM2B	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/15.6
-KM11	Stýkač 7,5kW/400V Contactor 7,5kW/400V Schütz 7,5kW/400V	AF16-30-10-11	ABB	91.040.056	1	/16.7
-KM11	Pomocný kontakt - 1xNC Auxiliary contact - 1xNC Hilfskontakt - 1 xNC	CA4-01	ABB	91.041.043	1	/16.7
-KM12	Stýkač 5,5kW/400V Contactor 5,5kW/400V Schütz 5,5kW/400V	AF12-30-01-11	ABB	91.040.051	1	/16.8
-PA1	Pojistkový odpojovač E-90 - 2P Fuse disconnecter E-90 - 2P Sicherungstrenner E90 - 2P	E 92/32	ABB	91.241.013	1	/7.5
-QS1	3 pólový odpináč, 40A Disconnecter - 3P, 40A Trennschalter - 3P, 40A	OT40FT3	ABB	91.170.019	1	/7.0
-RE1	Minisýkač 4kW/400V Minicontactor 4kW/400V Minischütz 4kW/400V	B6S-30-01-1.7-71	ABB	91.040.049	1	/15.8
-RP1	Svorka rychloupínací Fastconnect clamp Fast Connect Klemm	WAGO 224-112	WAGO	91.250.009	3	/9.5
-SA1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/12.7
-SA1	Kontaktní blok - 1NO Contact block - 1NO Kontaktblock - 1NO	M22-K10	EATON	91.061.022	2	/12.7
-SB1	Hlavice dvoutlačítka bílá/černá start/stop Double button head white/black start/stop Doppelrundkopf weiß/schwarz Start/Stop	M22-DDL-WS-GB1/GB0	EATON	91.060.034	1	/12.1
-SB1	Upevňovací adaptér + 1NO Attaching adapter + 1NO Montageadapter + 1NO	M22-AK10	EATON	91.061.021	1	/12.1

The manufacturer reserves right to use an equivalent replacement device.

3.a	 BOMAR, s.r.o. Těšební 1256/1 CZ 627 00, Brno	Scrol/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente: Napájení/Power supply/Einspeisung: Zpracování/Processed Part: verarbeitet: Datum/Data/Datum:	ES-R3600-203-V2.5 3x230V / PE, 50Hz Kódka 4.10.2016	Liř/Pages/ Seiten: 3.b List/Pages/ Seiten: 22
-----	---	--	--	--	--	--

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednáací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SB2	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.2
-SB3	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.3
-SB3	Hlavice dvoutlačítka bílá/černá, zavřít/otevřít Double button head white/black, arrow close/open Doppelrundkopf weiß / schwarz, Pfeil Schließen / Öffnen	M22-DDL-WS-*	EATON	91.060.055	1	/12.3
-SB4	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.4
-SB5	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/12.5
-SB5	Hlavice dvoutlačítka bílá/černá šipka nahoru/dolů Double button head white/black, arrow up/down Doppelrundkopf weiß / schwarz, Pfeil nach oben / unten	M22-DDL-WS-*	EATON	91.060.054	1	/12.5
-SB6	Kontaktní blok - INO Contact block - INO Kontaktblock - INO	M22-K10	EATON	91.061.022	1	/12.6
-SB7	Upevňovací adaptér + INO Attaching adapter + INO Montageadapter + INO	M22-AK10	EATON	91.061.021	1	/16.6
-SB7	Hlavice prosvitěného tlačítka žlutá Yellow transparent switch Leiter beleuchtet gelbe Taste	M22-DL-Y	EATON	91.060.053	1	/16.6
-SB501	Total stop - Hlavice + 3xNC Emergency-stop mushroom push - button + 3xNC Not-Aus-Pilz - Taster + 3 xNC	YW1B-VAE02R	IDEC	91.060.084	1	/16.4
-SB501	Kontakt - 1x NO Contact - 1x NO Kontakt - 1x NO	YW-E10	IDEC	91.061.044	1	/16.4
-TR1	Toroidní transformátor - 400V/230V/20V 4,5A 90VA Toroidal transformer - 400V / 230V / 20V 4,5A 90VA Ringkerntransformator - 400V / 230V / 20V 4,5A 90VA	400V/230V/20V 4,5A 90VA	KARBAN s.r.o.	91.080.023	1	/7.6

The manufacturer reserves right to use an equivalent replacement device.

Kusovník artiklů / Parts list / Stückliste

Označení přístroje Device identification Geräteidentifikation	Typ přístroje Device description Gerätebeschreibung	Objednávací číslo Type number Typennummer	Výrobce Manufacturer Hersteller	Skladové číslo Part number Lagernummer	Množství Quantity Menge	Umístění Location Stelle
-SQ21	Bezpečnostní koncový spínač - 2xNC Safety Limit Switch - 2x NC Sicherheitsendschalter - 2x NC	QKS8	KEDU	91.173.012	1	/16.4
-PA1	Pojistka válcová - 2A, 10x38, pomalá Tube fuse - 2A, 10x38, slow Rohrsicherung - 2A, 10x38, langsam	PV10 2A gG	OEZ	91.230.034	2	/7.5
-SQ4	Koncový spínač - 1NC+1NO Limit switch - 1NC+1NO Endschalter - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/13.7
-SQ1	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 605-M2	PIZZATO	91.173.009	1	/13.3
-SQ2	Koncový spínač - 1NO + 1NC, kladka, pomalá akce Limit switch - 1NO + 1NC, pulley, slow action Endschalter - 1NO + 1NC, rolle, langsame Einwirkung	FR 615-M2	PIZZATO	91.173.044	1	/13.4
-SQ3	Koncový spínač - 1NO + 1NC, dlouhá nastavitelná kladka, M2, snap action Limit switch - 1NO + 1NC, long adjustable pulley, M2, snap action Endschalter - 1NO + 1NC, lange verstellbare rolle, M2, schnapp	FR 655-M2	PIZZATO	91.173.045	1	/13.6
-FM1	Frekvenční měnič - 5,5kW, 3x230VAC Frequency converter - 5,5kW, 3x230VAC Frequenzumrichter - 5,5kW, 3x230VAC	VFD05SE23A	DELTA ELECTRONICS, INC.	91.012.135	1	/9.1
-PA2	Pojistka válcová - 32A, 10x38, gG Tube fuse - 32A, 10x38, fast Rohrsicherung - 32A, 10x38, schnell	PV10 32A gG	OEZ	91.230.019	3	/9.1
-QS1	Rukojeť odpínače 48x48mm - černá Handle switch 48x48mm - black Griffschalter 48x48mm - Schwarz	OHBS3PH	ABB	91.180.018	1	/7.0
-CU1	Řídicí obvod Control unit Steuerereinheit	SMA_4.01W	Bomar	265.918	1	/10.0
-RCF0	Odrušovací filtr 32A Noise filter 32A Rauschfilter 32A	32EB15/50/C2	WIDECOM TECHNOLOGY s.r.o.	91.041.066	1	/9.1
-FU1	Svorka pojistková Fuse terminal Sicherungsklemme	WK4/THS1U	WIELAND	91.251.102	1	/7.8

The manufacturer reserves right to use an equivalent replacement device.

3.c


	BOMAR, s.r.o. Těšební 1256/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Proline 420.350 H SX	Název stránky/Name page/Namen seiten: Kusovník artiklů / Parts list / Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente: ES-R3600-203-V2.5 Napájení/Power supply/Einspeisung: 3x230V / PE, 50Hz Zpracování/Processed Part: verarbeitet: Datum/Data/Datum: 4.10.2016	Liš/Pages/ Seiten: 3.d List/Pages/ Seiten: 22
---	--	--	--	--	--




5

<










Control board SMA-4-xxW







 BOMAR, s.r.o. Težební 1236/1 CZ 627 00, Brno	Strojířina/Name: Proline 420.350 H SX	Název stáří/Name page/Name set: Hydraulické ventily / Hydroventile	Úložiřek /Doc./Kofinálřek der Dokument: ES-R3000-203-V2.5	Lis/Page/ Seřts: 14	Napářní/Power supply/Einspehrung: 3x230V / PE, 50+Hz	Lis7/Page/7: Seřts: 22	7-manual/Processed /Her verarbeitet: Kofka	Datum/Data/Datum: 23.3.2016
---	---	--	--	-------------------------------	---	----------------------------------	---	--------------------------------





	BOMAR, s.r.o. Třební 1236/1 CZ 627 00, Brno		Stroj/Machine/Maschine: Proline 420.350 H SX		Název stránky/Name page/Name seiten: Stylace motorů / Motor contactors / Motor-Schutzschalter		Číslo odk./Doc.No./Anzahl der Dokumente.: ES-R3600-203-v2.5		Ln/Page/ Seite: 15
							Napájení/Power supply/Einspeisung: 3x230V / 1 PE, 50-Hz		Ln/Page/ Seite: 15
							Zpracování/Processed /Bear.vorgefertigt: Koska		Ln/Page/ Seite: 22
							Datum/Data/Datum: 4.10.2016		Ln/Page/ Seite: 22



174







U stroje velikosti 460 jsou 2 vodící regul. kostky (poz. 14) paralelně propojené a mají hydraulický přítlak do řezu, redukcák (19.2+20.2) klasicky v ovlád.pultu a napojen např. pomocí vývodu X, / Bei der Anlage Gr. 460 sind 2 Führungswürfel (Pos. 14) parallel verbunden und haben hydraulischen Andruck in den Schnitt, Reduzierventil (19.2+20.2) traditionell in Bedienungstafel und z.B. mittels Ausgangs X, Y angeschlossen Y/ For the machine size 460, there are 2 guide control cubes (pos. 14) connected parallelly, which have hydraulic thrust to cut, reducer (19.2+20.2) at the control panel as usual, connected, for example, by means of the outlet X, Y

Typ / Type / Type	Proline 280/350/450 H
Hydraulický agregát / Hydroaggregat / Hydro aggregat	92.001.077 (FMW), S001-137-2, PPM-AC0, 48/0, 6kW/300/1500-PG1/2,5-TM20-CB03-FR
Neuvedené světlosti / Unerwähnt Lichtbreite / Unlisted inside diameters	JS6
Výstupní šroubení / Ausgangsschraubung / Output screewing	G1/4"
P_{max}	4,5 MPa
Q	3,3 / 6,6 dm ³ /min
n	1500 / 3000 ot./min
P	0,48 / 0,6 kW

Poz.	Název položky		ks	Číslo skladové položky
Pos.	Bezeichnung		Menge	Artikelnummer im Lagerhaus
Pos.	Item		Pcs.	Stock Item Number
1	Nádrž / Behälter / Tank	TM 13,5/S, SPEC. (cca20dm3)	1	
2	Elektromotor / Elektromotor / Electromotor	0,48/0,6 kW 400/230 V, 50 Hz	1	
3	Hydrogenerátor / Hydraulikgenerator / Hydrogenerator	10A2, 5X053G, 2,5 cm3/ot.	1	92.153.132
4	Zpětný filtr / Rückschlagfilter / Charge-back filter	MPF0301AG1	1	92.153.131
5	Nalévací zátka / Stopfen / Fill stopper	CPT-MD-FA/1"	1	92.019.007
6	Přepouštěcí ventil / Bypassventil / By pass valve	MO-020/32	1	92.159.001
7	Jednosměrný ventil / Einwegventil / One-way valve	CV08-20-0-N-4 V205-007-1-01	1	92.160.001
8	Rozváděč / Schaltschrank / Switchboard	DVE03-S01-B4-C24-20-T1-M1	1	92.101.041
9	Manometr / Manometer / Manometer	Ø68 s/mit/with Glycerin	1	
10	--	--	--	
11	-	-	-	
12	Rozváděč / Schaltschrank / Switchboard	DVE03-S04-Bx-C24/20/T1-M1	1	92.101.034
13	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	PC08-30-0-N	1	92.103.007
14	Sedlový ventil / Sattelventil/ Saddle valve	SV08-20-0-N-24EG	1	92.101.035
15	Tlakový spínač / Druckschalter / Pressure switch	Kod/Kode/Code 0166415031059 20-50bar	1	92.201.003
16	Škrťací ventil / Drosselventil / Throttle-valve	VS01-04-R2, 5-0S	2	92.152.001
17	Kostka regulace / Regulationklotz / Regulation cube	Manuální přítlak/Manuellen Druck/Manual pressure - (Proline 320.280 a/und/ and Proline 420.350)	1	251.078

		Hydraulický přítlak/Hydraulikdruck/Hydr aulic pressure (Proline 520.450)	2	251.346
18	Ventil pojistný / Sicherungsventil / Retaining valve	VPNH 1/4"	1	92.151.001
19	Redukční ventil / Reduktionsventil / Control valve	VRN1-06/RV-6,3,	2/1/0	92.154.001
20	Manometr / Manometer / Manometer	Ø68 , 0-60 bar	2/1/0	
21	Zpětný ventil / Rückschlagfilter / Charge-back filter	VJS3-06-005-G1-150	2/0	
22	Kulový ventil / Kugelventil / Globe valve		4/0	
23	Redukční ventil / Reduktionsventil / Control valve	VRN2-06/S-6R	1/0	92.154.001

Attention!


After all work and cuts on the saw have been completed, the saw arm should always remain in the lower position (e.g. during a long break between cuts, during the saw's resting state or overnight). If the arm remains in the upper position, the hydraulics of the saw arm can be expected to be loaded and overloaded, leading to damage. (The saw arm will start to drop down spontaneously).

It is also important that there is no material left on the saw that needs to be removed from the saw area.

7. Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. Proline 320.280 H) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Proline 320.280 H), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).
- For spare parts order, you must always to allege: type of machine (for example Proline 320.280 H), serial number and year of construction (for example 1999).

7.1. 201.R300-700
PROLINE 420.350 H



NAZEV SESTAVY PILA PASOVA	CÍSLO SESTAVY 201.R300-700	STROJ Prolin350H
Konstruoval: KOLESA		
Datum: 26. 03.2015		
Meritko: 7:100		


7.1.1. 201.R300-700
Kusovník / Piece list / Stückliste -
PROLINE 420.350 H

Císlo Sestavy 201.R300-700		Ver. 3	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks	
1	201.R300-500 (3)	0	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1	
2	201.R302-050	2	SLOUP / POLE / SAULE		1	
3	201.R302-060 (1)	0	SLOUP / POLE / SAULE		1	
4	201.R303-000	4	SVERAK / VICE / SCHRAUBSTOCK		1	
5	201.Y307-010	4	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDER		1	
6	221.R301-700	2	PODSTAVEC / BASE / UNTERSATZ		1	
7	221.R302-730	0	ODMEROVANI / POLE / SAULE		1	
8	221.R304-700	5	RAMENO / SAW ARM / SÄGERAHMEN		1	
9	30.R399-701	2	STITEK TYPOVY / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1	
10	92.001.077	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1	
11	99.900.039	0	SAMOLEPKA / STICKER / AUFLEBER	NEBEZP. STLACENI	1	
12	99.900.040	0	SAMOLEPKA / STICKER / AUFLEBER		2	
13	99.900.047	0	SAMOLEPKA / STICKER / AUFLEBER		1	
14	99.900.048	0	SAMOLEPKA / STICKER / AUFLEBER		1	
15	99.900.049	0	SAMOLEPKA / STICKER / AUFLEBER		1	
16	99.900.053	0	SAMOLEPKA / STICKER / AUFLEBER		1	
17	99.900.068	0	SAMOLEPKA / STICKER / AUFLEBER	pouziti: vysokozvizenno vozikku	4	
18	99.901.044	2	SAMOLEPKA / STICKER / AUFLEBER		1	
1. ZRUSEN SLOUP 201.R302-020 A NAHR.201.R302-060. 229/ZM249 15.10.2013 SLEZACKOVA						
2. ZRUSEN OVLADACI PANEL 221.M230-700 A NAHR.221.M230-800/69/ZM247 8.12.2014 SLEZACKOVA						
3. ZRUSEN OVLADACI PANEL 201.M230-800 A NAHR.201.R230-500. 093/ZM061 7.4.2015 SLEZACKOVA						

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position; Objednací číslo/Purchase order number/Bestellnummer; Verze (Ver.)/Version/Version; Název položky/Value title/Name der Baugruppe; Rozměr/Stock size/Lagermaße

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.1.2. 201.R300-700
PROLINE 420.350 H



NAZEV SESTAVY PILA PASOVA	CÍSLO SESTAVY 201.R300-700	STROJ Proline350H
Konstruoval: KOLESA		
Datum: 26. 03.2015		
Meritko: 7:100		

7.1.3. 201.R300-700
Kusovník / Piece list / Stückliste -
PROLINE 420.350 H

Císlo Sestavy 201.R300-700		Ver. 3	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.R230-500 (3)	0	OVLADACÍ PANEL / CONTROL PANEL / BEDIENPULT		1
2	201.R302-050	2	SLOUP / POLE / SAULE		1
3	201.R302-060 (1)	0	SLOUP / POLE / SAULE		1
4	201.R303-000	4	SVERAK / VICE / SCHRAUBSTOCK		1
5	201.Y307-010	4	VALEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLINDER		1
6	221.R301-700	2	PODSTAVEC / BASE / UNTERSATZ		1
7	221.R302-730	0	ODMEROVANI / POLE / SAULE		1
8	221.R304-700	5	RAMENO / SAW ARM / SÄGERAHMEN		1
9	30.R399-701	2	STÍTEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
10	92.901.077	0	AGREGAT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
11	99.900.039	0	SAMOLEPKA / STICKER / AUFLEBER	NEBEZP.STLACENI	1
12	99.900.040	0	SAMOLEPKA / STICKER / AUFLEBER		2
13	99.900.047	0	SAMOLEPKA / STICKER / AUFLEBER		1
14	99.900.048	0	SAMOLEPKA / STICKER / AUFLEBER		1
15	99.900.049	0	SAMOLEPKA / STICKER / AUFLEBER		1
16	99.900.053	0	SAMOLEPKA / STICKER / AUFLEBER		1
17	99.900.068	0	SAMOLEPKA / STICKER / AUFLEBER	použití: vysokozvážnéno vozíku	4
18	99.901.044	2	SAMOLEPKA / STICKER / AUFLEBER		1

1.ZRUSEN SLOUP 201.R302-020 A NAHR.201.R302-060. 229/ZM249 15.10.2013 SLEZACKOVA


2.ZRUSEN OVLADACÍ PANEL 221.M230-700 A NAHR.221.M230-800/69/ZM247 8.12.2014 SLEZACKOVA

3.ZRUSEN OVLADACÍ PANEL 201.M230-800 A NAHR.201.R230-500. 093/ZM061 7.4.2015 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Versión; Název sestavy/Assembly title/Name der Baugruppe; Požice (Poz./Position/Position; Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.2. 201.R300-800 PROLINE 420.350 Hsx




NAZEV SYSTÉMU PILA PASOVA	ČÍSLO SYSTÉMU 201.R300-800	STROJ PL350Hsx
Konstruoval: ODVARKA		
Datum: 30. 08.2016		
Meritko: 7:100		

7.2.1. 201.R300-800
Kusovník / Piece list / Stückliste -
PROLINE 420.350 H

Císlo Sestavy 201.R300-800		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozmer	Ks
1	201.R230-500	0	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1
2	201.R302-050	2	SLOUP / POLE / SÄULE		1
3	201.R302-060	0	SLOUP / POLE / SÄULE		1
4	201.R303-000	4	SVERAK / VICE / SCHRAUBSTOCK		1
5	201.R304-800	0	RAMENO / SAW ARM / SÄGERAHMEN		1
6	201.Y307-010	4	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDER		1
7	221.R301-700	3	PODSTAVEC / BASE / UNTERSATZ		1
8	221.R302-730	0	ODMEROVANI / POLE / SÄULE		1
9	30.R399-801	0	STITEK TYPOVY / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
10	92.001.077	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
11	99.900.039	0	SAMOLEPKA / STICKER / AUFLEBER	NEBEZP.STLACENI	1
12	99.900.040	0	SAMOLEPKA / STICKER / AUFLEBER		2
13	99.900.047	0	SAMOLEPKA / STICKER / AUFLEBER		1
14	99.900.048	0	SAMOLEPKA / STICKER / AUFLEBER		1
15	99.900.049	0	SAMOLEPKA / STICKER / AUFLEBER		1
16	99.900.053	0	SAMOLEPKA / STICKER / AUFLEBER		1
17	99.900.068	0	SAMOLEPKA / STICKER / AUFLEBER		1
18	99.901.032	0	SAMOLEPKA / STICKER / AUFLEBER	použití vysokoúvňženo vozíku	4
19	99.901.044	2	SAMOLEPKA / STICKER / AUFLEBER	CETIFIKACNI SAMOLEPKA	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.2.2. 201.R300-800
PROLINE 420.350 H





NAZEV SYSTÉMU PILA PASOVA	ČÍSLO SYSTÉMU 201.R300-800	STROJ PL350Hsx
Konstruoval: ODVARKA		
Datum: 30. 08.2016		
Meritko: 7:100		

7.2.3. 201.R300-800
Kusovník / Piece list / Stückliste -
PROLINE 420.350 H

Císlo Sestavy 201.R300-800		Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSÄGE		
Poz.	Objednací číslo	Ver.	Název položky	Rozmer	Ks
1	201.R230-500	0	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1
2	201.R302-050	2	SLOUP / POLE / SÄULE		1
3	201.R302-060	0	SLOUP / POLE / SÄULE		1
4	201.R303-000	4	SVERAK / VICE / SCHRAUBSTOCK		1
5	201.R304-800	0	RAMENO / SAW ARM / SÄGERAHMEN		1
6	201.Y307-010	4	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLYNDER		1
7	221.R301-700	3	PODSTAVEC / BASE / UNTERSATZ		1
8	221.R302-730	0	ODMEROVANI / POLE / SÄULE		1
9	30.R399-801	0	STITEK TYPOVÝ / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
10	92.001.077	0	AGREGAT HYDRAULICKÝ / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT		1
11	99.900.039	0	SAMOLEPKA / STICKER / AUFLEBER	NEBEZP.STLACENI	1
12	99.900.040	0	SAMOLEPKA / STICKER / AUFLEBER		2
13	99.900.047	0	SAMOLEPKA / STICKER / AUFLEBER		1
14	99.900.048	0	SAMOLEPKA / STICKER / AUFLEBER		1
15	99.900.049	0	SAMOLEPKA / STICKER / AUFLEBER		1
16	99.900.053	0	SAMOLEPKA / STICKER / AUFLEBER		1
17	99.900.068	0	SAMOLEPKA / STICKER / AUFLEBER		1
18	99.901.032	0	SAMOLEPKA / STICKER / AUFLEBER	použití vysokoúvňženo vozíku	4
9	99.901.044	2	SAMOLEPKA / STICKER / AUFLEBER	CETIFIKACNI SAMOLEPKA	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.3. 201.R230-500 Ovladací panel / Control panel / Bedienpult



INSTRUKCE OVLADACÍ PANEL	ČÍSLO ŘEŠENÍ 201.R230-500	STROJ PL H 280,350
Konstruktor: Datum:	ODVÁRKA 12. 08. 2019	Meritko: 13:100


7.3.1. 201.R230-500
Kusovník / Piece list / Stückliste -
Ovladač panel / Control panel / Bedienpult

Císlo Sestavy 201.R230-500		Ver. I	Název sestavy OVLADACÍ PANEL/CONTROL PANEL/BEDIENPULT		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.6130-012	0	VÍKO / COVER / DECKEL	P 0.5x30	1
2	30.6130-018	0	HLAVICE / HEAD / KOPF	VYLISEK	1
3	251.653	0	PANEL / PANEL / PANEL		1
4	251.863	0	PANEL ELEKTRO / ELECTRO PANEL / PANEL		1
5	30.R230-201	4	SKŘIN / BOX / KASTEN		1
6	30.R230-204	1	PLECH / PLATE / BLECH	P 1x220	1
7	30.R230-206	2	PLECH / PLATE / BLECH	P 1x220	1
8	61.352.001	0	TESNĚNÍ / SEALING / DICHTUNG	TESNĚNÍ 19x10	1
9	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE _ M6	4
10	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	PODLOŽKA 6,4	4
11	91.060.034	0	HLAVICE / HEAD / KOPF	START/STOP	1
12	91.060.051	0	PREPINAC / SWITCH / UMSCHALTER		1
13	91.060.053	0	HLAVICE / HEAD / KOPF		1
14	91.060.054	0	HLAVICE / HEAD / KOPF	NAHORU/DOLU	1
15	91.060.055	0	HLAVICE / HEAD / KOPF	SV. ZAVRZOTEV	1
16	91.060.084	0	HLAVICE TOTAL STOP / TOTAL STOP HEAD / TASTE TOTAL STOP		1
17	91.071.022	0	VÝVODKA / BUSHING / TÜLLE		3
18	91.072.016	0	MATICE / NUT / MUTTER		3
19	91.170.003	0	SPINAC VACKOVÝ / CAM SWITCH / SCHALTER	LE2-12-1763	1
20	91.180.001	0	DESKA SPINACE / ELECTRIC BOARD / PLATINE		1
21	92.002.103	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4" tr12	1
22	92.004.001	0	SROUBENÍ UHLÍVE / ANGLE BOLTING / WINKELVERSCHRAUBUNG	37701	1
23	92.152.001	0	VENTIL SKŘTICÍ / CHOKE VALVE / DROSSELVENTIL	VS01-04/R 2.5-0	1
24	96.082.002	0	TESNĚNÍ / SEAL RING / DICHTUNGSRING	13/17x1.5 CU	1
25	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK ČINSKY	2
26	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
27	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1

I.7RUSENO 91.060.030 A NAHRAZENO 91.060.084. 235/ZM329 12.08.2019 KOSYK

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.4. 201.R302-050
Sloup / Pole / Säule



NAZEV SESTAVY SLOUP	CISLO SESTAVY 201.R302-050	STROJ PL 350
	Konstruoval: ODVARKA	
	Datum: 23. 01.2015	
	Meritko: 7:50	

7.4.1. 201.R302-050
Kusovník / Piece list / Stückliste -
Sloup / Pole / Säule


Císlo Sestavy 201.R302-050		Ver. 2	Název sestavy SLOUP/POLE/SÄULE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.R302-013	0	DRŽÁK / HOLDER / HALTER	P 5x75	1
2	30.R302-051	1	SLOUP / POLE / SÄULE		1
3	90.001.25.017 (2)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16	4
4	90.001.25.019	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x25	17
5	90.001.25.063	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x60	8
6	90.302.07.003	0	KUŽEL. KOLÍK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 8x36	2
7	99.200.296 (1)	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FÜHRUNG	MSA 25x1000 20/20N	1

1. ZRUS. LIN. VEDENÍ 99.200.204 A NAHR. 99.200.296 , 22.3.2012 SLEZACKOVA
2. PRIDAN 4xSROUB M6x16(90.001.25.017). 236/ZM010 23.1.2015 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.5. 201.R302-060
Sloup / Pole / Säule

Císlo Sestavy 201.R302-060		Ver. 0	Název sestavy SLOUP/POLE / SÄULE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.R302-061	0	SLOUP / POLE / SÄULE		1
2	90.001.25.057	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x25	4
3	90.302.02.003	0	KUZEL, KOLIK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 8x36	2
4	99.200.274	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FÜHRUNG	MSA20R 540 30//30N	1
5	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x16	9



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožměr/Stock size/Abmessung

7.6. 201.R303-000
Svěrák / Vice / Schraubstock



NÁZEV SOBRANY SVĚRÁK	ČÍSLO SOBRANY 201.R303-000	STUPEŇ Worč.350h
Konstruoval: VINOHRADSKÝ	Datum: 11. 05. 2017	Verze: 29.100

7.7.


201.R303-000

Kusovník / Piece list / Stückliste -
Svěrák / Vice / Schraubstock

Císlo Sestavy 201.R303-000		Ver. 5	Název sestavy SVERAK/VICE/SCHRAUBSTOCK		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.3707-000	1	VALEC / ROLLER / ZYLINDER		1
2	201.R303-050	1	SKLUZ / SLIDE / RUTSCH		1
3	30.2011-010	0	PRÍLOŽKA / STRAP / LASCHE	HR 80x10	1
4	30.5503-015	3	BOCNICE / SIDE PLATE / SEITENTEIL	P 3x230	1
5	30.6903-109	2	LISTA CELISTI / JAW TRIM / BACKENLEISTE	HR 30x10	2
6	30.D311-235 (1)	2	LISTA / TRIM / LEISTE	HR 30x10	2
7	30.R203-007 (4)	0	BOCNICE / SIDE PLATE / SEITENTEIL	P 4x237	1
8	30.R203-018 (4)	2	CELIST PEVNÁ / SOLID JAW / FESTE BACKE		1
9	30.R303-001	8	SVERAK / VICE / SCHRAUBSTOCK		1
10	30.R303-004	1	VEDENÍ / GUIDE / BACKENFÜHRUNG	HR 40x25	2
11	30.R303-005	1	LISTA / TRIM / LEISTE	HR 20x20	1
12	30.R303-014	2	CELIST POHYBLIVÁ / MOVING JAW / BEWEGLICHE BACKE	ODLITEK	1
13	30.R303-016	1	VLOŽKA / INSERT / EINLAGE	HR 40x30	3
14	30.R303-017	1	VLOŽKA / INSERT / EINLAGE	TYC 60x40	2
15	30.R303-018	1	VLOŽKA / INSERT / EINLAGE	HR 120x40	2
16	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	2
17	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	2
18	90.001.25.056	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x20	2
19	90.001.25.058 (2)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x30	2
20	90.001.25.062 (5)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x50	4
21	90.001.25.063	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x60	4
22	90.001.25.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	17
23	90.011.27.005 (4)	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKTSCHRAUBE	SROUB M6x12	3
24	90.011.27.007	0	SROUB / BOLT / SCHRAUBE	M8x12	12
25	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 6,4	2
26	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8,4	4
27	95.800.021	0	SEGR HRÍDEL / SAFETY RING / SICHERUNGSRING	POJISTNÝ KROUZEK 62	1
1. ZRUS.LISTA 30.6903-110 A NAHR.30.D311-325,ZRUS.CELIST 30.R203-012 A NAHR.30.R203-015,ZRUS.CELIST 30.R203-002 A NAHR.30.R203-016, ZRUS.6xSROUB M12x35(90.001.25.059) A NAHR.4xSROUB M12x70(90.001.25.064) A 2xSROUB M12x30(90.001.25.058). 112/ZM129 30.5.2011 SLEZACKOVA					
2. ZRUS.CELIST 30.R203-015,30.R203-016 A NAHR.30.R203-017,ZRUS.4xSROUB M12x70 (90.001.25.064) A NAHR.2xSROUB M12x30 (90.001.25.058).					
196/ZM003 10.1.2013 SLEZACKOVA					
3. ZRUS.CELIST 30.R203-017 A NAHR.30.R203-018. 192/ZM226 30.10.2014 SLEZACKOVA					
4. ZRUS.CELIST 30.R203-017 A NAHR.30.R203-018,ZRUS.BOCNICE 30.R303-015 A NAHR.30.R203-007,ZRUS.2xSROUB M6x16(90.001.25.017) A NAHR.2xSROUB M6x12(90.011.27.005). 192/ZM242 8.12.2014 SLEZACKOVA					
5. ZRUS.SROUB M12x35(90.001.059) A NAHR.M12x50(90.001.25.062). 107/ZM169 11.5.2017 SLEZACKOVA					
Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position; Objednací číslo/Purchase order number/Bestellnummer; Verze položky/Verze položky/Volumen title/Name der Position; Rozměr/Stock size/Abmessung					

Císlo sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.8. 201.3707-000
Válec / Roller / Zylinder



NAZEV SESTAVY VÁLEC	CÍSLO SESTAVY 201.3707-000	STROJ STG 320GA
Konstruoval: ZEZULA		
Datum: 17. 03.2015		
Měřítko: 1:5		

7.8.1. 201.3707-000
Kusovník / Piece list / Stückliste -
Válec / Roller / Zylinder

Císlo Sestavy 201.3707-000		Ver. I	Název sestavy VALEC/ROLLER/ZYLINDER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0607-102	I	PISTNICE / PISTON ROD / KOLBENSTANGE	d 28	I
2	30.1807-104	2	VÍKO / COVER / DECKEL	TYC 55	I
3	30.2007-302	0	PIST / PISTON / KOLBEN	d 55	I
4	30.2007-304	I	VÍKO / COVER / DECKEL	d 55	I
5	30.3707-001	3	VALEC SVĚRAKU / VICE CYLINDER / SCHRAUBSTOCKZYLINDER	TR 62/50H8	I
6	90.001.25.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSHSCRAUBE	M8X30	I
7	95.801.009	0	SEGR DIRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 52	2
8	96.001.007	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	25x2 NBR 70SH	I
9	96.001.013	0	O-KROUZEK STATIC / STATIC O RING / O-RING STATISCH	45X2	2
10	96.002.014	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	28X3	I
11	96.020.005(1)	0	KROUZEK TESNICÍ / SEAL RING / DICHTUNGSRING	39.2X5.33	I
12	96.041.003	0	TESNĚNÍ / SEALING / DICHTUNG	601-28x36x7.1	I
13	96.060.003	0	KROUZEK STÍRACÍ / SCRAPER RING / ABSTREIFRING	KROUZEK STÍRACÍ 28	I


(1) O-KROUZEK 96.002.014 NAHRAZEN MANZETOU 96.041.003 24.4.2003 ROZKOSNY

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.9. 201.R303-050
Skluz / Slide / Rutsch

Číslo Sestavy 201.R303-050		Ver. I	Název sestavy SKLUZ/SLIDE/RUTSCH		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.R303-051	I	STUL / TABLE / TISCH		1
2	30.R303-052	0	SKLUZ / SLIDE / RUTSCH	P 1.5x260	1
3	30.3509-015	I	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 8x1	2
4	90.001.25.009 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x16	2

I.ZRUS.SROUB M6x16 (90.001.25.017) A NAHR. M5x16 (90.001.25.009). 191/ZM204 19.8.2011 SLEZACKOVA



7.10. 201.Y307-010
Válec zvedací / Lifting cylinder / Hebezyylinder



NAZEV SESTAVY VALEC ZVEDACI		CISLO SESTAVY 201.Y307-010	STROJ 1360
	Konstruoval: MUSIL		
	Datum: 09. 03.2011		
	Meritko: 1:2		

7.10.1. 201.Y307-010

Kusovník / Piece list / Stückliste -

Válec zvedací / Lifting cylinder / Hebezyylinder

Císlo Sestavy 201.Y307-010		Ver. 5	Název sestavy VÁLEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLYNDER		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0807-008	3	DRŽÁK / HOLDER / HALTER	HR 40x40	1
2	30.0807-009	2	ČEP / LUG / BOLZEN	d 16h9	1
3	30.8307-205	0	ČEP / LUG / BOLZEN	d 16h9	1
4	30.8607-001	1	DRŽÁK / HOLDER / HALTER	HR 25x25	1
5	30.C407-012	2	VÍKO / COVER / DECKEL	d 55	1
6	30.Y307-002	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d 28 f8	1
7	30.Y307-003 (3)	3	VÍKO / COVER / DECKEL	d 55	1
8	30.Y307-011	5	VÁLEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLYNDER	TR 62/50	1
9	30.Y307-012 (3)	1	PIST / PISTON / KOLBEN	d 55	1
10	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	2
11	90.001.55.083	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	1
12	90.101.55.003	0	MATICE / NUT / MUTTER	MATICE M16	1
13	92.002.001 (3)	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	GES 08LR	2
14	92.151.008 (4)	0	VENTIL POJISTNÝ / SAFETY VALVE / SICHERUNGSVENTIL	VPN-H 1/4"	1
15	95.800.007	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 16	2
16	95.801.009	0	SEGR DÍRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 52	1
17	95.801.018 (3)	0	KROUZEK POJIST.VNITR / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 50	2
18	96.002.011	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	24X2	1
19	96.002.019	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	46x2 NBR 70SH	2
20	96.061.009	0	KROUZEK STÍRAČÍ / SCRAPER RING / ABSTREIFRING	WD2200280 Z201	1
21	96.082.002 (5)	0	TESNENÍ / SEAL RING / DICHTUNGSRING	13/17x1.5 CU	1
22	96.084.001	0	KROUZEK VODÍČÍ / LEAD RING / FÜHRUNGSRING	GP6500500-T47	1
23	96.084.006	0	KROUZEK VODÍČÍ / LEAD RING / FÜHRUNGSRING	GR4300280-T47	1
24	96.900.013 (2)	0	TESNENÍ KOMBINOVANÉ / COMBINATION SEALING / KOMBIDICHTUNG	PT0200500	1
25	96.900.021	0	TESNENÍ KOMBINOVANÉ / COMBINATION SEALING / KOMBIDICHTUNG	RSK200280-46N	1

1.ZRUS.SROUBENÍ 92.002.005 A NAHR.92.003.001,ZRUS.SROUBENÍ 30.6107-510 A NAHR.30.9107-509.,ZRUS.1xTESNENÍ 96.082.002 (ZUSTAVAJÍ 2ks).071/ZM097 12.4.2010 SLEZACKOVA


2.ZRUSENO TESNENÍ 96.900.001 A NAHR.96.900.013. 336/ZM006 10.1.2011 SLEZACKOVA

3.ZRUS.REDUKCE 30.9107-509,ZRUS.SROUBENÍ 30.1807-005,ZRUS.VÍKO 30.Y307-005 A NAHR.30.Y307-003,ZRUS.SROUBENÍ 92.003.001 A NAHR.92.002.001,ZRUS.PIST 30.LM07-504 A NAHR.30.Y307-012,ZRUS.KROUZEK 95.801.009 A NAHR.95.801.018. 026/ZM027 24.2.2011 SLEZACKOVA

4.VENTIL 92.151.001 PRECISLOVAN NA 92.151.008. 222/ZM211 29.7.2013 SLEZACKOVA

5.ZRUS. 2xTESNENÍ 96.082.002. 290/ZM003 8.1.2019 SZABARI

7.11. 221.R301-700
Podstavec / Base / Untersatz



NAZEV SYSTÉMU PODSTAVEC	ČÍSLO SYSTÉMU 221.R301-700	STROJ PL 350H
Konstruoval: ODVARKA		
Datum: 10. 08.2016		
Měřítko: 1:100		

7.11.1. 221.R301-700

Kusovník / Piece list / Stückliste -
Podstavec / Base / Untersatz

Císlo Sestavy 221.R301-700		Ver. 3	Název sestavy PODSTAVEC/BASE/UNTERSATZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	262.007	0	KONEKTOR / CONNECTOR / STECKVERBINDER		1
2	30.M201-005	2	DRŽAK / HOLDER / HALTER	P 4x173	1
3	30.M201-006 (2)	2	DRŽAK / HOLDER / HALTER	P 4x173	1
4	30.R201-056	1	VÍKO / COVER / DECKEL	P 4x100	1
5	30.R301-053	1	KRYT / COVER / ABDECKUNG		1
6	30.R301-701	1	PODSTAVEC / BASE / UNTERSATZ		1
7	30.R301-703	1	KRYT / COVER / ABDECKUNG		1
8	30.R314-260	0	KRYT / COVER / ABDECKUNG		1
9	30.R401-006 (1)	0	VANA / TANK / WANNE		1
10	91.020.032 (3)	0	CERPADLO CHLAZENÍ / COOLING PUMP / KÜHLMITTELpumpe	230/400V	1
11	91.071.022 (2)	0	VÝVODKA / BUSHING / TÜLLE		3
12	91.072.016 (2)	0	MATICE / NUT / MUTTER		3
13	94.101.039	0	ZASLEPKA / PLUG / BLINDELANSCH	154x154x4	1
14	94.202.020 (3)	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	1/2"-6	1


1. ZRUSENA VANA 30.R206-001 A NAHR. 30.R401-006. 108/ZM131 15.4.2013 SLEZACKOVA

2. ZRUS. KONZOLA 30.R301-704, 30.R301-705 A NAHR. DRŽAK 30.R201-056, PRID. VÝVODKA 91.071.022, MATICE 91.072.016. 093/ZM061 3.4.2015 SLEZACKOVA

3. ZRUS. CERPADLO 91.020.015 A NAHR. 91.020.032, PRID. REDUKCE 94.202.020. 001/ZM243 10.8.2016 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.12. 201.R302-730
Odměrování / Pole / Säule



NAZEV SESTAVY ODMEROVANI	CISLO SESTAVY 221.R302-730	STROJ Prolin350H
	Konstruoval: KOLESA	
	Datum: 21. 08.2012	
	Meritko: 3:10	

7.12.1. 201.R302-730


Kusovník / Piece list / Stückliste -
Odměrování / Pole / Säule

Císlo Sestavy 221.R302-730		Ver. 0	Název sestavy ODMĚROVÁNÍ / POLE / SAULE		
Por.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.Y302-070	0	ODMĚROVÁNÍ / MEASURING / GEHRUNGSMESSUNG	SESTAVA	1
2	30.6130-012	0	VÍKO / COVER / DECKEL	P 0.5x 30x30	1
3	30.6130-020	0	OVLADÁNÍ / CONTROLS / STEUERUNG	VTLÍSEK	1
4	30.R202-031	0	DRŽÁK / HOLDER / HALTER	HR 20x5	1
5	30.R202-033	1	OSA / AXLE / Achse	SVARENĚ	1
6	30.R302-034	0	STUPNICE / SCALE / SKALA	Plx41	1
7	30.R314-701	0	DRŽÁK / HOLDER / HALTER	P 3x311	1
8	30.Y302-058	1	VLOŽKA / INSERT / EINLAGE	d 32	1
9	30.Y302-153	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	Pl,5-72	1
10	31.K107-006	1	GUMA / RUBBER / GUMMI	d35	1
11	31.T302-054	0	PRŮŽINA / SPRING / FEDER	d 2.24	1
12	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x12	2


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.13. 201.Y302-070
Odměrování / Measuring / Gehrung smessung

Cislo Setuhy 201.Y302-070		Ver. 0	Název sestavy ODMEROVÁNÍ / MEASURING / GEHRUNGSMESSUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozebr	Ks
1	30.6114-023	0	DRŽÁK / HOLDER / HALTER	P 3x20	2
2	30.Y302-071	0	TYC / POLE / STANGE	d 20	1
3	30.2014-001	0	KLUZÁK / GLIDER / GLEITER		1
4	90.001.25.092	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x14	4
5	94.007.001	0	SROUB / BOLT / SCHRAUBE	M5x10	1



7.14. 201.R304-700
 Rameno / Saw arm / Sägerahmen
 Proline 420.350 H



WZŁĘCZYSTY RAMENO	CZĘŚĆ ZESTAWU 221.R304-700	STRONA Proline 350
Konstruował: VINOHRADSKY	Datum: 03. 04. 2015	Meritko: 11:100


7.14.1. 201.R304-700

Kusovník / Piece list / Stückliste -
Ramenno / Saw arm / Sägerahmen
Proline 420.350 H

Císlo Sestavy 221.R304-700		Ver. 5	Název sestavy RAMENO/SAW ARM/SÄGERAHMEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.M304-020	0	KARTAC / BRUSH / BÜRSTE		1
2	201.M304-022 (5)	0	KRYT / COVER / ABDECKUNG		1
3	201.M305-000	1	PREVODOVKA / TRANSMISSION / GETRIEBE		1
4	201.M308-100 (1)	0	NAPÍNÁNÍ / TENSIONING / SPANNUNG		1
5	201.R304-040 (2)	0	KONZOLA / CONSOLE / KONSOLE		1
6	201.R310-000	1	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
7	30.1814-011	2	DRŽAK / HOLDER / HALTER	P 3x76	1
8	30.2904-003	3	KOLO HNACÍ / DRIVE WHEEL / ANTRIEBSRAD	ODLITEK	1
9	30.M304-009	0	KRYT KARTACKU / BRUSH COVER / BÜRSTENABDECKUNG		1
10	30.M304-017	0	KRYT NAPÍNÁNÍ / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 1.5x310	1
11	30.M304-070 (4)	0	VENTILATOR / VENTILATOR / VENTILATOR		1
12	30.R304-006	3	PANT / BOARD / PLATTE	PROFIL	2
13	30.R304-007	2	PANT / BOARD / PLATTE	PROFIL	2
14	30.R304-008	0	DRŽAK / HOLDER / HALTER	P 6x80	1
15	30.R304-009	0	DRŽAK / HOLDER / HALTER	P 6x74	1
16	30.R304-012 (3)	0	KRYT / COVER / ABDECKUNG		1
17	30.R304-016	1	KRYT PASU / BELT COVER / BANDABDECKUNG		1
18	30.R304-201	4	RAMENO / SAW ARM / SÄGERAHMEN		1
19	30.T304-014	0	DRŽAK / HOLDER / HALTER	P 4x100	1
20	30.Y304-018	0	TYC ZAVÍTOVÁ / THREADED POLE / GEWINDESTANGE	M10	2
21	44.104.003	0	PAS PÍLOVÝ 330 / SAW BELT / SÄGEBAND	4780x32(4)x0.90	1
22	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	4
23	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	2
24	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	6
25	90.151.50.002		PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 12	2
26	90.302.07.003		KUZEL. KOLIK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 8x36	2
27	90.307.02.001	0	KOLIK / PIN / BOLZEN	D6	2
28	91.001.053	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	MDERA 100-32pro	1
29	91.070.011	0	VÝVODKA / BUSHING / TÜLLE	M16x1.5	1
30	91.070.012	0	VÝVODKA / BUSHING / TÜLLE	M20x1.5	1
31	91.173.007	0	SPÍNACÍ KNOŽKA / END SWITCH / ENDSCHALTER	-RIWK	1

Císlo sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednáci číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.14.2. 201.R304-700
 Rameno / Saw arm / Sägerahmen
 Proline 420.350 H



WZV BEZVY RAMENO	CÍLOVÝ BEZVY 221.R304-700	STUPEŇ Proline 350
Konstruoval: VINOHRADSKÝ		
Datum: 03. 04. 2015		
Měřitko: 1:100		


7.14.3. 201.R304-700
Kusovník / Piece list / Stückliste -
Rameno / Saw arm / Sägerahmen
Proline 420.350 H

32	91.173.008	0	SPINAC KONCOVY / END SWITCH / ENDSCHALTER			1
33	91.173.009		SPINAC KONC.S KLADK. / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE	PZ-FR605-M2		1
34	91.173.012	0	SPINAC KONCOVY / END SWITCH / ENDSCHALTER			1
35	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/11/4"		2
36	96.081.001	0	KROUZEK TESNICI / SEAL RING / DICHTRINGRING	23x15x3		1
37	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK CINSKY		2
38	99.170.001	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	0555.030.075.100		15
39	99.173.001	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	KONCOVKA VNEJ		1
40	99.173.002	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	KONCOVKA VNIT		1
41	99.201.046	0	VEDENI LINEARNI / LINEAR GUIDE / LINEARE FÜHRUNG	MSA25E SS FO N		2
42	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"		1

1. ZRUS.NAPINANI 201.M308-000 A NAHR.201.M308-100. 045/ZM225 18.9.2013 SLEZACKOVA
2. ZRUS.KONZOLA 201.R204-020 A NAHRAZENA 201.R304-040. 229/ZM249 15.10.2013 SLEZACKOVA
3. ZRUS.KRYT 30.M304-011 A NAHR.30.R304-012. 090/ZM108 14.5.2014 SLEZACKOVA
4. ZRUS.VENTILATOR 30.M304-060 A NAHR.30.M304-060. 120/ZM142 24.6.2014 SLEZACKOVA
5. PRIDAN KRYT PREVODOVKY 201.M304-022. 005/ZM061 3.4.2015 SLEZACKOVA

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.15. 201.R304-800
 Rameno / Saw arm / Sägerahmen
 Proline 420.350 Hsx




NÁZEV SOUSTAVY RAMENO	ČÍSLO SOUSTAVY 201.R304-800	STROJ PL350Hsx
Konstruoval: ODVARKA		
Datum: 23. 08. 2018		
Meritko: 7:100		

7.15.1. 201.R304-800
Kusovník / Piece list / Stückliste -
Rameno / Saw arm / Sägerahmen
Proline 420.350 Hsx

Cislo Sestavy 201.R304-800		Ver. 2	Název sestavy RAMENO / SAW ARM / SÄGERAHMEN		Ver.	Název položky	Rožmer	Ks
1	201.M304-020	0	KARTAC / BRUSH / BÜRSTE					1
2	201.M308-100	1	NAPINANI / TENSIONING / SPANNUNG					1
3	201.R304-040	0	KONZOLA / CONSOLE / KONSOLE					1
4	201.R305-500	0	POHON / TRANSMISSION / GETRIEBE					1
5	201.R310-000	1	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG					1
6	201.R404-022	0	KRYT / COVER / ABDECKUNG				P 3x76	1
7	30.1814-011	2	DRŽAK / HOLDER / HALTER				ODLITEK	1
8	30.2904-003	3	KOLO HNACI / DRIVE WHEEL / ANTRIEBSRAD				4780x32(4)x1,1	1
9	30.2904-913	0	PAS PÍLOVÝ / SAW BELT / SÄGEBAND					1
10	30.4304-018	4	VENTILATOR / VENTILATOR / VENTILATOR					1
11	30.M304-009	0	KRYT KARTACKU / BRUSH COVER / BÜRSTENABDECKUNG					1
12	30.M304-017	0	KRYT NAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG				P 1.5x310	1
13	30.R304-006	3	PANT / BOARD / PLATTE				PROFIL	2
14	30.R304-007	2	PANT / BOARD / PLATTE				PROFIL	2
15	30.R304-008	0	DRŽAK / HOLDER / HALTER				P 6x80	1
16	30.R304-009	1	DRŽAK / HOLDER / HALTER				P 6x74	1
17	30.R304-012	1	KRYT / COVER / ABDECKUNG					1
18	30.R304-016	1	KRYT PASU / BELT COVER / BANDABDECKUNG					1
19	30.R304-201	5	RAMENO / SAW ARM / SÄGERAHMEN				P 4x100	1
20	30.T304-014	1	DRŽAK / HOLDER / HALTER				M5X10	4
21	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE				8x20	2
22	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE				SROUB M10X80	2
23	90.005.55.080	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE				M4x30	2
24	90.013.92.104	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE				MATICE - M10	4
25	90.100.55.006	0	MATICE / NUT / MUTTER				PODLOŽKA 12	2
26	90.151.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE				KOLÍK BX36	2
27	90.302.02.003	0	KUZEL. KOLÍK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE				D6	2
28	90.307.02.001	0	KOLÍK / PIN / BOLZEN				W22-WHERAXL-112M-04	1
29	91.001.197	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR				VENTILATOR RDH1238,B2	1
30	91.015.126	0	VENTILATOR / VENTILATOR / VENTILATOR				M16x1.5	1
31	91.070.011	0	VÝVODKA / BUSHING / TÜLLE				M20x1.5	1
32	91.070.012	0	VÝVODKA / BUSHING / TÜLLE				-RIWK	1
33	91.173.007	0	SPÍNAC KONCOVÝ / END SWITCH / ENDSCHALTER					1
34	91.173.008	0	SPÍNAC KONCOVÝ / END SWITCH / ENDSCHALTER					1

Cislo Sestavy/Number of assembly/Nummer der Baugruppe: Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position);
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.15.2. 201.R304-800
 Rameno / Saw arm / Sägerahmen
 Proline 420.350 Hsx



NÁZEV SESTAVY RAMENO	ČÍSLO SESTAVY 201.R304-800	STROJ PL350Hsx
Konstruoval: ODVARKA		
Datum: 23. 08.2018		
Meritko: 7:100		


7.15.3. 201.R304-800
Kusovník / Piece list / Stückliste -
Rameno / Saw arm / Sägerahmen
Proline 420.350 Hsx

35	91.173.009	0	SPINAC KONC.S KLADK. / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE	PZ-FR605-M2	1
36	91.173.012	0	SPINAC KONCOVY / END SWITCH / ENDSCHALTER		1
37	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	2
38	96.081.001	0	KROUZEK TESNICI / SEAL RING / DICHTUNGSRING	23x15x3	1
39	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK CINSKY	2
40	99.170.001	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	0555.030.075.100	15
41	99.173.001	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	KONCOVKA VNEJ	1
42	99.173.002	0	RETEZ ENERGII / ENERGY BELT / ENERGIEKETTE	KONCOVKA VNIT	1
43	99.201.046	0	VEDENI LINEARNI / LINEAR GUIDE / LINEARE FÜHRUNG	MS425E SS FO N	2
44	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

1. ZRUSENA TYC 30.M404-056 A NAHR.SROUBEM 90.005.55.080. 291/ZM046 19.2.2018 SLEZACKOVA
2. PRID. 2xSROUB M4x30 90.013.9Z.104. 171/ZM290 23.8.2018 SZABARI

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.16. 201.M304-020
Kartáč / Brush / Bürste



NAZEV SESTAVY KARTAC	CISLO SESTAVY 201.M304-020	STROJ WORK350
Konstruoval: VINOHRADSKY		
Datum: 16. 02.2015		
Meritko: 7:10		

7.16.1. 201.M304-020


Kusovník / Piece list / Stückliste -
Kartáč / Brush / Bürste

Císlo Sestavy 201.M304-020		Ver. 0	Nazev sestavy KARTAC/BRUSH/BÜRSTE		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozmer	Ks
1	201.0814-204	0	KOLEČKO / WHEEL / ROLLE	SESTAVA	1
2	30.0814-207	0	KROUZEK / RING / RING	d 25	2
3	30.9214-301	2	DRŽAK / HOLDER / HALTER		1
4	30.M304-021	0	HRDEL / SHAFT / WELLE	d 12	1
5	31.0305-211	0	PRUŽINA / SPRING / FEDER	2x12x50x15.5	1
6	31.0814-208	0	KARTAC / BRUSH / BÜRSTE		1
7	31.1506-115	0	PRUŽINA / SPRING / FEDER	1.6x12x25x7.5	2
8	90.001.25.038	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x50	1
9	90.001.25.095	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x70	2
10	90.003.20.001	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M5x6	3
11	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
12	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 8,4	1
3	95.001.005	0	LOŽISKO / BEARING / LAGER	6001 2RS	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.17. 201.0814-204
Kolečko / Wheel / Rolle

Císlo Sestavy 201.0814-204		Ver. 0	Název sestavy KOLEČKO/WHEEL/ROLLE	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr
1	30.0814-204.1	0	KOLEČKO / /	d 35
2	30.0814-204.2	0	NABOJ / /	d 20
				Ks
				1
				1



Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.18. 201.M308-100
Napínání / Tensioning / Spannung



NAZEV SESTAVY NAPÍNÁNÍ	ČÍSLO SESTAVY 201.M308-100	STROJ WORK 350
Konstruoval: VINOHRADSKÝ		
Datum: 13. 02. 2017		
Verze: 3:10		

7.19.

201.M308-100

Kusovník / Piece list / Stückliste -
Napínání / Tensioning / Spannung


Císlo Sestavy 201.M308-100		Ver. I	Název sestavy NAPÍNÁNÍ/TENSIONING/SPANNUNG		
Poz.	Objednáací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0808-001	I	KOSTKA NAPÍNÁNÍ / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	80x30	I
2	30.0808-002	I	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLEISTE	30x20	2
3	30.0808-006	I	LISTA / TRIM / LEISTE	HR 30x10	2
4	30.0808-007	0	SROUB / BOLT / SCHRAUBE	M8x60	I
5	30.1708-004	4	DRŽÁK / HOLDER / HALTER	HR 20x8	I
6	30.2908-001	I	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	d 50	I
7	30.2908-103	2	KOLO NAPÍNACÍ / TENSIONING WHEEL / UMLENKRAD	ODLITEK	I
8	30.4008-001	2	SROUB / BOLT / SCHRAUBE		I
9	30.4808-101	4	ČEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		I
10	30.4808-103	I	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 45x5	I
11	30.6908-102	I	DRŽÁK / HOLDER / HALTER		I
12	30.M208-001	0	KROUZEK / RING / RING	TR 35x6	I
13	90.001.25.052	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	6
14	90.002.20.013	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x25	I
15	90.011.27.008	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10x20	I
16	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	I
17	90.300.07.003	0	KOLÍK VALC. KAL. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLÍK 16x80	I
18	90.350.07.002	0	PRUŽINA TALÍŘOVÁ / DISC SPRING / TELLERFEDER	35,5x18,3x2,0x2,8	6
19	95.001.026	0	LOŽISKO / BEARING / LAGER	6307 2RS	2
20	95.800.014	0	SEGR HRÍDEL / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 35	I
21	95.801.013	0	SEGR DÍRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 80	2

I.ZRUSEN KROUZEK 30.3508-004 A NAHR.30.M208-001. 0177M050 13.2.2017 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.20. 201.R304-040
Konzola/ console/ Konsole

Cislo sestavy 201.R304-040		Ver. 0		Název sestavy KONZOLA/CONSOLE/KONSOLE	
Poz.	Objednací číslo	Ver.	Název položky	Rožmer	Ks
1	30.R204-041	0	KONZOLA / CONSOLE / KONSOLE	HR 70x20	1
2	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	PODLOŽKA 10,5	2
3	90.001.25.113	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x80	2
4	99.201.060	0	VOZÍK LINEARNIHO VEDENÍ / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA20S SS FO N	1
5	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	4



Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.21. 201.R310-000 Vedení pásu/ Belt guide/ Sägebandführung



NAZEV SESTAVY VEDENÍ PÁSU	CÍSLO SESTAVY 201.R310-000	STROJ prolin350
Konstruoval: VINOHRADSKÝ		
Datum: 14. 05.2014		
Měřítko: 1:4		

7.21.1. 201.R310-000

Kusovník / Piece list / Stückliste -


Vedení pásu/ Belt guide/ Sägebandführung

Císlo Sestavy 201.R310-000		Ver. 1	Název sestavy VEDENÍ PASU/BELT GUIDE/SÄGEBANDFÜHRUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2016-006	0	DESKA / BOARD / PLATTE	HR 40x12	1
2	30.3510-004	0	TRUBKA / TUBE / ROHR	TR 8x 1	2
3	30.9010-003	0	DRŽAK / HOLDER / HALTER	PL 5x10	2
4	201.2016-000	0	REGULACE PRÍTLAKU / PRESSURE REGULATION / SCHNITTDRUCKREGULATION		1
5	201.Y310-300	1	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
6	201.Y310-400	1	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ		1
7	30.M210-008	0	LISTA / TRIM / LEISTE	HR 25x6	1
8	30.M310-002	3	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLISTE	HR 90x20	1
9	30.M310-004	1	KONZOLA / CONSOLE / KONSOLE		1
10	30.M310-056 ①	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x95	1
11	30.M310-057 ①	0	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x95	1
12	30.Y310-008	0	DRŽAK / HOLDER / HALTER	P3-50	1
13	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	2
14	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x12	8
15	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	1
16	90.001.25.105	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x18	6
17	90.002.20.022	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x30	2
18	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	2
19	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 5,3	2
20	90.303.02.021	0	KOLÍK PRUŽNÝ / PIN / BOLZEN	KOLÍK 8x28	2
21	92.002.102	0	SROUBENÍ / BOLTING / VERSCHRAUBUNG	S-GEV-8LLR	2
22	94.008.003	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M8x40	1
23	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	2
24	96.081.001	0	KROUZEK TESNICÍ / SEAL RING / DICHTUNGSRING	23x15x3	1
25	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

1.ZRUS.KRYT PASU 30.M310-006 A NAHR.30.M310-056.ZRUS.KRYT PASU 30.M310-007 A NAHR.30.M310-057.
090/ZM108 15.5.2014 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.22. 201.2016-000
Regulace přítlaku/ Pressure regulation/
Schnittdruckregulation



NAZEV SESTAVY REGULACE PRITLAKU	CISLO SESTAVY 201.2016-000	STROJ STG340DGS
	Konstruoval: &konstruoval	
	Datum: 19. 02.2010	
	Meritko: 1:2	

7.22.1. 201.2016-000


Kusovník / Piece list / Stückliste -

Regulace přítlaku/ Pressure regulation/ Schnittdruckregulation

Číslo Sestavy 201.2016-000		Ver. 0	Název sestavy REGULACE PŘÍTLAKU/PRESSURE REGULATION/SCHNITTDRUCKREGULATION		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2016-001	2	TELESO / BODY / KÖRPER	HR 40 x 40	1
2	30.2016-002	0	JEHLA / NEEDLE / NADEL	KR 8	1
3	30.2016-003	0	SROUB / BOLT / SCHRAUBE	d 16	1
4	30.2016-004	0	ČIDLO / SENSOR / SENSOR	d 10	1
5	30.2016-005	0	KOLEČKO / WHEEL / ROLLE	d 32	1
6	30.2016-009	0	KROUZEK / RING / RING	TR 10x1	1
7	31.2016-007	0	PRUŽINA / SPRING / FEDER	d 11,6x11,6	1
8	31.2016-008	0	PRUŽINA / SPRING / FEDER	0.25x3,6x12x9,5	1
9	90.099.002	0	SROUB PULKULATÝ / HALF ROUND BOLT / HALBRUNDSCHRAUBE	4x6	1
10	90.151.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 4	1
11	95.690.001	0	JEHLA / NEEDLE / NADEL	1,5x11,8	1
12	95.691.001	0	KULICKÁ LOŽISKA / BALL / KUGEL	RB 4,5	1
13	96.001.003	0	KROUZEK O STATICKÝ / STATIC O RING / O-RING STATISCH	8x2	1
14	96.002.001	0	KROUZEK O DYNAMICKÝ / DYNAMIC O RING / O-RING DYNAMISCH	4x2	2

Číslo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.23. 201.Y310-300
Kostka vodící/ Lead cube/Führungsklotz



NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.Y310-300	STROJ IND360
	Konstruoval: HLADIL	
	Datum: 16. 12.2019	
	Meritko: 4:5	

7.23.1. 201.Y310-300
Kusovník / Piece list / Stückliste -
Kostka vodící/ Lead cube/Führungsklotz


Číslo Sestavy 201.Y310-300		Ver. 2	Název sestavy KOSTKA VODICÍ/LEAD CUBE/FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.C210-403	1	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
2	30.Y310-212	3	EXCENTR / CAM / EXCENTER	M12	2
3	30.Y310-301	3	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	1
4	30.Y310-306	1	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
5	30.Y310-310	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER		1
6	30.Y310-320	0	DRŽÁK TVRDOKOVU / POA HOLDER / HM-HALTER		1
7	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
8	90.002.20.016	0	SROUB STAVEC / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x10	1
9	90.011.27.008 (2)	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10x20	1
10	90.011.27.017	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
11	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10	2
12	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5	4
13	90.154.50.001 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	10x16x0,1	2
14	90.301.02.001	0	KOLÍK VALCOVÝ / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLÍK 10x28	1
15	90.350.02.005	0	PRŮŽINA TALIROVÁ / DISC SPRING / TELLERFEDER	20x10.2x1	6
16	95.001.014	0	LOŽISKO / BEARING / LAGER	6200 2RS	5
17	95.800.002	0	SEGR HRÍDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUŽEK 8	1

1. PRIDANÁ PODLOŽKA 90.154.50.001. 277/ZM294 1.1.2010 SLEZACKOVA

2. PRIDANÝ SROUB ZAPUSTNÝ M10x20 90.011.27.008. 003/ZM004 4.1.2016 SLEZACKOVA

Číslo sestavy/Number of assembly/Nummer der Baugruppe: Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position);
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Block size/Abmessung

7.24. 201.Y310-400
Kostka vodící/ Lead cube/Führungsklotz



NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.Y310-400	STROJ IN360
	Konstruoval: HLADIL	
	Datum: 05. 02.2016	
	Meritko: 7:10	

7.24.1. 201.Y310-400
Kusovník / Piece list / Stückliste -
Kostka vodící/ Lead cube/Führungsklotz


Císlo Sestavy 201.Y310-400		Ver. 2	Název sestavy KOSTKA VODICI/LEAD CUBE/FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1810-102	3	DRŽAK / HOLDER / HALTER	TYC 28	1
2	30.C210-403	1	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
3	30.Y310-212	2	EXCENTR / CAM / EXZENTER	d 15	2
4	30.Y310-306	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
5	30.Y310-310	0	DRŽAK TVRDOKOVU / POA HOLDER / HW-HALTER		1
6	30.Y310-320	0	DRŽAK TVRDOKOVU / POA HOLDER / HW-HALTER		1
7	30.Y310-401	4	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	1
8	90.001.25.143 (2)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x18	3
9	90.004.20.002	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x12	1
10	90.005.55.015 (2)	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSMANTSCHRAUBE	SROUB M8x20	1
11	90.011.27.017	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
12	90.101.55.001 (2)	0	MATICE / NUT / MUTTER	MATICE M8	1
13	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10	2
14	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5	2
15	90.154.50.001 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	10x16x0,1	2
16	90.301.07.009	0	KOLIK VALCOVY / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLIK 10x26	1
17	90.350.07.005	0	PRUŽINA TALIROVA / DISC SPRING / TELLERFEDER	20x10.2x1	6
18	95.001.004	0	LOŽISKO / BEARING / LAGER	6000 2RS	1
19	95.001.014	0	LOŽISKO / BEARING / LAGER	6200 2RS	4
20	95.800.002	0	SEGR HRÍDEL / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 8	1

1. PRIDANA PODLOŽKA 90.154.50.001 .277/ZM294 1.11.2010 SLEZACKOVA
2. ZRUS.SROUB M8x30(90.005.55.017) A NAHR.M8x20(90.005.55.015),ZRUS.MATICE M8(90.100.55.005) A NAHR.MATICE M8(90.101.55.001),ZRUS.SROUB M5x20(90.001.25.010) A NAHR.M8x18(90.001.25.143).
021/ZM04 1 5.2.2016 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version); Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position);
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.25. 201.M304-022
Kryt / Cover / Abdeckung
Proline 420.350 H

Císlo Sestavy 201.M304-022		Ver. 0	Nazev sestavy KRYT/COVER/ABDECKUNG		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozmer	Ks
1	30.M304-023	0	PLECH / PLATE / BLECH	Plx238	1
2	90.013.27.028	0	SROUB / BOLT / SCHRAUBE	M12X30-ISO-7380	3
3	90.152.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	M12 DIN6798	3
4	90.100.55.007	0	MATICE / NUT / MUTTER	MATICE - M12	3




2 : 5

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.26. 201.R404-022
Kryt / Cover / Abdeckung
Proline 420.350 Hsx

Císlo Sestavy 201.R404-022		Ver. 0		Název sestavy KRYT/COVER/ABDECKUNG	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.R404-023	0	PLECH / PLATE / BLECH	Plx238	1
2	90.013.27.29	0	SROUB / BOLT / SCHRAUBE	M12X40 - ISO-7380	2
3	90.100.55.007	0	MATICE / NUT / MUTTER	MATICE - M12	2
4	90.152.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	M12 DIN6798	2




Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.27. 201.M305-000
Převodovka / Transmission / Getriebe


Císlu Sestavy 201.M305-000		Ver. I	Název sestavy PŘEVODOVKA/TRANSMISSION /GETRIEBE	
Poz.	Objednací číslo	Ver.	Název položky	Rožmer Ks
1	30.1804-010	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	d 70
2	30.2904-005	0	DISTANC / DISTANCE / DISTANZ	TR 55x8
3	30.2904-006	0	PERO / SPRING / FEDER	HR 14x14
4	30.2908-001	1	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	d 50
5	30.M305-003	2	HRÍDEL / SHAFT / WELLE	d 65
6	30.M305-005	0	PŘÍRUBA / FLANGE / FLANSCH	ODLITEK
7	30.M305-008	0	PERO / SPRING / FEDER	HR 10x8
8	90.005.55.025	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10X30
9	90.005.55.035	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X45
10	90.011.27.025	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M12X25
11	90.011.27.036 (1)	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M10X25
12	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10.5
13	95.001.027	0	LOŽISKO / BEARING / LAGER	6309 2RS
14	99.001.129	0	PŘEVODOVKA SNEKOVÁ / WORM GEAR TRANSMISSION / SCHNECKENGETRIEBE	

I.ZRUS.1xSROUB M12x25(90.011.27.025) A NAHR.1xSROUBEM M10x25(90.011.27.036). 110/ZM112 25.6.2012 SLEZACKOVA



Císlu Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.28. 201.R305-500
Pohon/ Drive/ Antrieb
Proline 420.350 Hsx



NAZEV SESTAVY POHON	CÍSLO SESTAVY 201.R305-500	STROJ PL350ASX
Konstruoval: ODVARKA		
Datum: 19. 06. 2019		
Meritko: 3:10		

7.28.1. 201.R305-500
Kusovník / Piece list / Stückliste -
Pohon/ Drive/ Antrieb
Proline 420.350 Hsx

Císlo Sestavy 201.R305-500		Ver. 1	Název sestavy POHON/TRANSMISSION /GETRIEBE		
Poz.	Objednací číslo	Ver.	Název položky	Rožmer	Ks
1	30.1804-010	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	P 6x70	1
2	30.2904-006	0	PERO / SPRING / FEDER	HR 14x14	1
3	30.7901-018	1	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	P8x60	1
4	30.R305-501	0	REDUCE / REDUCTION / ADAPTOR / REDUKTION	d 120	1
5	30.R305-502	0	DISTANC / DISTANCE / DISTANZ	TR 55x8	1
6	30.R305-503	1	HRIDEL / SHAFT / WELLE	d 65	1
7	30.R305-505	0	PRIHRUBA / FLANGE / FLANSCH	ODLITEK	1
8	30.Y605-002	0	PERO / SPRING / FEDER	HR 14x9	1
9	90.001.25.046 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x20	1
10	90.005.55.025	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x30	8
11	90.005.55.035	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12x45	8
12	90.011.27.009	0	ZAPUSTNY IMBUS / COUNTERSINK BOLT / SENKSCHEUBE	SROUB M12x20	1
13	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5	8
14	95.001.027	0	LOŽISKO / BEARING / LAGER	6309 2RS	2
15	99.003.028	0	PREVODOVKA KUZELOCEL / CONICAL TRANSMISSION / KEGLRADGETRIEBE	MBH80C PAM112	1
17.R305. SROUB ZAPUSTNY M10x20 90.011.27.008 A NAHR. SROUBEM M10x20 90.001.25.046. 189/259 19.6.2019 SZABARI					


1.ZRUS. SROUB ZAPUSTNY M10x20 90.011.27.008 A NAHR. SROUBEM M10x20 90.001.25.046. 189/259 19.6.2019 SZABARI

Císlo Sestavy/Number of assembly/Nummer der Baugruppe: Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.29. Volitelné příslušenství

7.29.1. 201.R314-100

Horní upínání/ Top clamping/ obere Klemm




MAZEV SESTAVY UPÍNÁNÍ HORNÍ	CÍSLO SESTAVY 201.R314-100	STROJ PL 350
Konstruoval: ODVARKA		
Datum: 10. 06.2011		
Meritko: 1:2		

7.29.2. 201.R314-100
Kusovník / Piece list / Stückliste -
Horní upínání/ Top clamping/ obere Klemm

Císlu Sestavy 201.R314-100		Ver. 0	Název sestavy UPÍNANÍ HORNÍ / TOP CLAM/SPANNVORRICHTUNG OBEN		
Poz	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.R307-500	0	VALEC POMOCNÝ / AUXILIARY CYLINDER / HILFSZYLINDER		1
2	30.R214-103	0	DESKA / BOARD / PLATTE	HR 40x15	1
3	30.R214-104	0	DESKA / BOARD / PLATTE	HR 80x10	1
4	30.R214-105	0	KOSTKA / CUBE / WÜRFEL	HR 80x80	1
5	30.R214-107	0	KROUZEK DISTANČNÍ / LUG / BOLZEN	d 13	2
6	30.R314-101	0	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLEISTE	HR 60x25	1
7	30.R314-102	0	DRŽÁK / LEAD TRIM / FÜHRUNGSLEISTE	HR 50x25	1
8	30.R314-103	0	TYC / POLE / STANGE	D10	1
9	30.R314-104	0	DESKA / LEAD TRIM / FÜHRUNGSLEISTE	HR 25x25	1
10	30.R314-108	0	PLECH / PLATE / BLECH	P 4x80	1
11	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	2
12	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	4
13	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	2
14	90.001.25.034	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x30	2
15	90.001.25.045	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x16	1
16	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x30	1
17	90.001.55.035	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x35	2
18	90.002.20.008	0	SROUB STAVEČNÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x16	1
19	90.163.00.002	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	PODLOŽKA 8	2
20	92.060.007	0	RYCHLOSPŮJKA / QUICK CONNECT / SCHNELLKUPPLUNG	6 G1/4"	2
21	92.060.008	0	RYCHLOSPŮJKA / QUICK CONNECT / SCHNELLKUPPLUNG	6 G1/4"	2
22	94.008.007	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M10	1

Císlu Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rožmer/Stock size/Abmessung

7.29.3. 201.R314-400
Horní upínání/ Top clamping/ obere Klemm



NAZEV SESTAVY UPINANI HORNI	CISLO SESTAVY 201.R314-400	STROJ PROLINE 350
	Konstruoval: ODVARKA	
	Datum: 12. 12.2016	
	Meritko: 17:100	

7.29.4. 201.R314-400
Kusovník / Piece list / Stückliste -
Horní upínání/ Top clamping/ obere Klemm

Císlu sestavy 201.R314-400		Ver. 0	Název sestavy UPÍNÁNÍ HORNÍ / TOP CLAM/SPANNVORRICHTUNG OBEN			
Poz.	Objednací číslo	Ver.	Název položky		Rozměr	Ks
1	201.D307-140	0	VALEC NAPÍNACÍ / TENSIONING CYLINDER / SPANNZYLINDER		D30/16	1
2	30.D311-126	0	DRŽÁK / HOLDER / HALTER		P 8x58	1
3	30.R214-404	0	DESKA / BOARD / PLATTE		HR 60x60	2
4	30.R314-401	0	CELIST / JAW / BÄCKE			1
5	30.R314-402	0	SLOUP / POLE / SAULE			1
6	30.R314-403	0	DESKA / BOARD / PLATTE		HR 90x20	1
7	30.R314-405	0	DESKA / BOARD / PLATTE		6HR 24	1
8	30.R314-406	0	LISTA / TRIM / LEISTE		HR 15x8	1
9	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M5x20	8
10	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		8x20	1
11	90.001.25.039	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M8x55	4
12	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M10x30	2
13	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M12x35	2
14	90.001.25.064	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M12x70	2
15	90.001.25.066	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M12x120	4
16	90.001.25.087	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE		M5x14	9
17	99.200.297	0	VEDENÍ LINEARNÍ / LINEAR GUIDE / LINEARE FÜHRUNG		MSA20R	1
18	99.201.060	0	VOZÍK LINEARNÍHO VEDENÍ / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN		MSA20S	2

Císlu sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos./Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung