




Transverse 610.440 DGH

Operating instructions

**Before transporting and using the machine,
please read the instructions thoroughly!**

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

2.20 / Nov. 2013
rev. 2

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

1) We

BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, The Czech Republic
Id.no: 48908827

declare herewith,

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government. In the event of any device modification not approved by us this declaration shall lose its validity.

Name: **Band Saw**

Type range: **Transverse 610.440 DGH**

Serial number:

Manufacturer: **BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno**

Product data

Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics.

Description: stand, table, cutting unit with the saw band and drive, clamping device, cooling system, el. switch board with control panel.

Hydraulic YES ☒ NO ☐ Control system YES ☒ NO ☐

Technical data: Cutting rate 20–90 m.min⁻¹, cutting angle from - 60° to 60°

Total dimensions in mm (l×w×h) 2560x1520x1450

Supply voltage 3×400 V TN-C-S/3×400 V TN-C/3×230 TN-C/1×230 V TN-C

Total power requirement 5,2 kVA, weight 1007 kg

The applied decrees of governments: **No. 176/2008 Coll.** (Directive 2006/42/EC)
No. 616/2006 Coll. (Directive 2004/108/EC)
No. 17/2003 Coll. (Directive 2006/95/EC)

The applied harmonized standards,

National standards and technical specifications: ČSN EN ISO 12 100-2:2004, ČSN EN 13 898+A1:2009, ČSN EN ISO 13857:2008, ČSN EN 982+A1:2008, ČSN EN 61000-6-2 ed. 2:2007, ČSN EN 61000-6-4:2002 ed.2:2007, ČSN EN 60204-1 ed.2:2007

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended

2) ²⁾ The declaration of conformity was carried out in the cooperation with the TÜV SÜD Czech s.r.o, Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002

The inspection certificate no. 01.122.123/09/07/02/0 was issued.

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827



Alfred Pichlmann, Managing Director

Point of issue, datum

Name and function
of the responsible subject

Signature

1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)
2) The authorized or accredited body co-operating on the conformity judging



If the equipment is installed without safety equipment offered by BOMAR, spol. s r.o or its agents and used by the customer (or buyer) then EC declaration loses validity.
EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.
All machine elements and components that were built into the device by BOMAR, spol. s r.o have been declared "identical" to a safety device, as offered by BOMAR, spol. s r.o or its agents.

Content

1. SAFETY NOTES.....7

1.1. Machine determination.....	9
1.2. Protective suit and personal safety.....	9
1.3. Safety notes for machine operator.....	10
1.4. Safety notes for the servicing and repairs.....	10
1.4.1. Safety notes for the servicing and repairs on hydraulic unit.....	11
1.5. Safety machine accessories.....	11
1.5.1. Total Stop.....	11
1.5.2. Saw arm cover.....	11
1.5.3. Saw band stretching and rupture inspection.....	12
1.5.4. Saw band cover.....	12
1.6. Safety notes for the cooling.....	12
1.6.1. Instructions for first help.....	12
1.7. Umístění štítku stroje / Maschinenschild position / Position of machine label.....	13
1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	14

2. MACHINE DOCUMENTATION.....15

2.1. Technická data / Technische Daten / Technical data.....	17
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram.....	18
2.3. Popis / Beschreibung / Description.....	19
2.4. Transportation and stocking.....	20
2.4.1. Conditions for transportation and stocking.....	20
2.4.2. Transport and stocking preparations.....	20
2.4.3. Transport and stocking.....	20
2.4.4. Transportní schéma / Transport schema / Transport scheme.....	21
2.5. Activation.....	22
2.5.1. Machine working conditions.....	22
2.6. Band saw unpacking and assembling.....	22
2.6.1. Machine installing and levelling.....	23
2.6.2. Machine disposal after lifetime.....	23
2.6.3. First run of the power pack.....	23
2.6.4. Filling the reservoir with hydraulic oil.....	24
2.6.5. Kotevní plan / Verankerungsplan / Grounding plan.....	25
2.7. Electrical connection.....	26
2.7.1. Check the direction of the saw band.....	26
2.8. Filling of the cooling system.....	26
2.9. Check machine function.....	28
2.10. Saw band.....	28
2.10.1. Saw band size.....	28
2.10.2. Selection of the saw band tooth system.....	28
2.10.3. Saw band running-in.....	29

3. MACHINE CONTROL33

3.1. Starting the band saw.....	35
3.2. Control panel.....	36
3.2.1. Control panel description.....	37
3.3. Machine setup.....	38
3.3.1. SERVIS.....	39
3.3.2. SETUP.....	40
3.4. Machine error messages.....	42
3.5. Machine control.....	43
3.5.1. Semi-automatic cycle.....	43
3.5.2. Cycle breaking.....	44
3.6. Cutting speed adjustment.....	45
3.7. Angular cut setting.....	45
3.8. Optimal adjusting of the guide cubes span.....	46
3.9. Cutting pressure adjusting.....	46
3.10. Material insertion.....	47
3.10.1. Handling agent selection.....	47
3.10.2. Insertion.....	47
3.10.3. Bundle material cutting.....	47

4. MACHINE SERVICE.....49

4.1. Saw band dismantling.....	51
4.2. Saw band installation.....	53
4.3. Saw band stretching and inspection.....	54
4.3.1. Saw band stretching.....	54
4.3.2. Saw band inspection.....	55
4.4. Saw band run adjustment on stretching wheel.....	55
4.4.1. Saw band run inspection.....	55
4.4.2. Saw band run setting.....	56
4.5. Limit switch setting of the saw band stretching.....	56
4.6. Guide cubes adjustment.....	57

4.7. Hard metal guides adjustment.....	57
4.8. Saw frame lower stop position adjustment.....	58
4.9. Limit switch of the saw frame lower position adjustment.....	58
4.10. Adjustment of the securing cube of the turning lever.....	59
4.11. Pressure switch adjustment.....	59
4.12. Pressure adjustment of the hydraulic system.....	60
4.13. Brush adjustment.....	62
4.13.1. Adjustment of the cutting pressure regulation.....	62
4.13.2. Adjustment of a throttle valve.....	63
4.14. Cooling agents and chips disposal.....	64
4.14.1. Coolant device inspection.....	64
4.14.2. Chips disposal.....	64
4.15. Hydraulic, Greases and oils.....	65
4.15.1. Gearbox oils.....	65
4.15.2. Lubricant greases.....	65
4.15.3. Lubrication.....	66
4.15.4. Hydraulic oils.....	66
4.15.5. Hydraulic unit service.....	67
4.15.6. Hydraulic oil level check.....	67
4.16. Machine cleaning.....	68
4.17. Worn pieces replacement.....	68
4.17.1. Hard metal guides replacement.....	68
4.17.2. Pushing bearing replacement.....	70
4.17.3. Saw band guiding pulleys replacement.....	72
4.17.4. Round brush replacement.....	76
4.17.5. Stretching wheel replacement.....	76
4.17.6. Driving wheel replacement.....	78
4.17.7. Cooling pump replacement.....	79

5. ZÁVADY / TROUBLESHOOTING.....81

5.1. Mechanical problems.....	82
5.2. Electric and hydraulic problems.....	84
5.3. Hydraulic problems.....	85

6. SCHÉMATA / SCHEMAS / SCHEMATICS.....87

6.1. Elektrické schema 3x230V+PE, 50 Hz / Elektroschema 3x230V+PE, 50 Hz / Wiring diagrams 3x230V+PE, 50 Hz.....	88
6.2. Elektrické schema 3x400V+PE, 50 Hz / Elektroschema 3x400V+PE, 50 Hz / Wiring diagrams 3x400V+PE, 50 Hz.....	106
6.3. Elektrické schema 3x400V+PE+N, 50 Hz / Elektroschema 3x400V+PE+N, 50 Hz / Wiring diagrams 3x400V+PE+N, 50 Hz.....	124
6.4. Hydraulické schéma / Hydraulikschema / Hydraulic diagram.....	142

7. VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER..... 145

7.1. Pila / Säge / Saw – Transverse 610.440 DGH.....	146
7.2. Kusovník / Stückliste / Piece list Pila / Säge / Saw – Transverse 610.440 DGH.....	147
7.3. Rameno / Arm / Arm.....	148
7.4. Kusovník / Stückliste / Piece list Rameno / Arm / Arm.....	149
7.5. Rameno / Arm / Arm.....	150
7.6. Kusovník / Stückliste / Piece list Rameno / Arm / Arm.....	151
7.7. Svěrák / Schraubstock / Vice.....	152
7.8. Kusovník / Stückliste / Piece list Svěrák / Schraubstock / Vice.....	153
7.9. Podstavec svěráku / Schraubstockuntersatz / Vice Base.....	154
7.10. Kusovník / Stückliste / Piece list Podstavec svěráku / Schraubstockuntersatz / Vice Base.....	155
7.11. Konzola otočná / Drehkonsole / Turnable console.....	156
7.12. Kusovník / Stückliste / Piece list Konzola otočná / Drehkonsole / Turnable console.....	157
7.13. Konzola otočná / Drehkonsole / Turnable console – 2.....	158
7.14. Kusovník / Stückliste / Piece list Konzola otočná / Drehkonsole / Turnable console – 2.....	159
7.15. Vedení pásu / Bandführung / Band guiding.....	160
7.16. Kusovník / Stückliste / Piece list Vedení pásu / Bandführung / Band guiding.....	161
7.17. Napínání / Spannung / Tensioning.....	162
7.18. Kusovník / Stückliste / Piece list Napínání / Spannung / Tensioning.....	163
7.19. Kostka vodící / Führungsklotz / Lead cube – 1.....	164
7.20. Kusovník / Stückliste / Piece list Kostka vodící / Führungsklotz / Lead cube – 1.....	165
7.21. Kostka vodící / Führungsklotz / Lead cube – 2.....	166
7.22. Kusovník / Stückliste / Piece list Kostka vodící / Führungsklotz / Lead cube – 2.....	167
7.23. Kartáček / Bürste / Brush.....	168
7.24. Kusovník / Stückliste / Piece list Kartáček / Bürste / Brush.....	169
7.25. Ovládací panel / Bedienpult / Control panel.....	170
7.26. Kusovník / Stückliste / Piece list.....	171
Ovládací panel / Bedienpult / Control panel.....	171
Podstavec / Untersatz / Base.....	172
7.27. Převodovka / Getriebe / Transmission.....	173
7.28. Chlazení / Kühlung / Cooling.....	174

1. **Safety notes**

The operating instructions must be read by the person, who keeps in touch with the machine before transportation, installation, using, servicing, reparation, stocking or removal!

The operating instructions include relevant information. The operator must familiarise himself with the install and operation, safety notes and machine servicing, because reliability and service life must be reached. The operating instructions must avoid risks, which are linked to work on the machine. Before transporting and using of the machine, please read the instructions thoroughly!

Attention!

The operating instructions must be available at the machine! Keep the operating instructions in good condition!

1.1. Machine determination

The band saw **Transverse 610.440 DGH** is determined for cutting and shortening of rolled bars and drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **with cutting angle** from -60° to 60°.

Combustible materials are excepted for cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

The machine is equipped with safety and protective guarding for operator and machine protection. Nevertheless, this safety and protective guarding cannot prevent injury. Service personnel must read this chapter and comprehend it, before he starts to work on the machine. **Always keep instructions about work safety!** Service personnel must take into account other aspects of the risk, which refer to the ambient conditions and the material.

Attention!

Consider the safety signs on the machine. Do not remove or damage them!

1.2. Protective suit and personal safety

Wear tight fitting overalls! Loose fitting clothes may be caught with machine parts and cause serious injury.

Wear protective gloves! Material cuts and saw band have sharp edges and may cause serious injuries.

Attention!

Gloves you can use only at working material replacement (saw band)! The machine and accessories must be inactive! If the machine is running, you must not wear gloves! It is dangerous, because some parts of the machine can catch gloves!

Wear protective shoes with non-skid soles! The unsuitable shoes may cause balance loss and following injury. Falling work pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protections! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

1.3. Safety notes for machine operator

Attention!

**Machine can be operated by person older than 18 years!
Machine can be operated only person physically and mentally fit for this activity**

Machine can be operated only by one person. Machine operator is responsible for presence of other persons by the machine.

Keep instructions and orders about work safety!

Read the operating instructions, before you start to work on the machine! Keep the operating instructions in good condition!

Attention!

Do not connect the machine to electricity if the covers are removed. Do not touch the electrical equipment.

Close covers before the machine starting and check, if the covers are not damaged. Damaged covers must be repaired or changed. Do not start the machine, if the cover is removed! Check, if the electric cables are not damaged.

- Do not hold the material for clamping to the vice and for cutting!
- Do not operate with the buttons and the switches on the control panel, when you have gloves!
- For machine starting take care, that there is nobody in the working area of the machine (it means in the working area of the vice, the saw band, the saw arm etc.).
- In no circumstances touch the rotating elements.
- Work on the machine only when the machine is in good condition!
- Check at least once in a shift, if the machine is not damaged. If the machine is damaged, you must bring the machine in order and you must inform your superior!
- Keep your working area clean! Ensure sufficient lighting in the working area.
- Take off the spilt water or the oil from the floor and dry it. Do not touch the cooling liquid with bare hands! Do not set the nozzle of the cooling liquid, when the machine is started on
- Do not remove the chips from the working area of the machine, when the machine is started on!
- Do not use the compressed air for the machine cleaning or for the chips removing!
- Use the protective instruments for chips removal!

1.4. Safety notes for the servicing and repairs

Attention!

Only a qualified professional can carry out the servicing and repairs of the electric equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety! Otherwise, there is possibility of heavy injury!

Switch off the main switch and lock it, before you start service work! Otherwise, there is possibility of hazardous machine starting.

Only qualified person can do the servicing and repairs. For parts changing, use only parts, which are identical with the originals. Otherwise, there is possibility of health hazard. Use only recommended type of the hydraulic oils and oils and lubricants!

Do not remove or do not lock the limit switches or safety equipments! Any use of the saw, accessories or machine parts other than that intended by the BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be afterward lost and BOMAR, spol. s r.o. takes no responsibility for caused damages.

1.4.1. Safety notes for the servicing and repairs on hydraulic unit

Compliance with the the principles of cleanliness is basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are products made with high accuracy, and any contamination leads to a reduction lifetime or even malfunction. The consequences are very difficult to remove and expensive.

Always use clean tools. Parts and fasteners, which are part of a hydraulic circuit, never put away the dirty surface. The best cleaning agent is crepe paper, because the fibers of the cleaning cloths can also cause malfunction.

Protective cap from the threaded chamber remove just before the assembly of the unit.

Hoses and pipes before mounting flush with gasoline or other cleaning agent and blow compressed air.

All fittings must be properly tightened. However, do not raw power.

1.5. Safety machine accessories

The machine is equipped with safety accessories. It protects the operator from injuries and the machine before damage. The safety accessories are blocking accessories, emergency switches and covers. Check once in a week the function of the safety accessories. If the safety accessories are functionless, you must stop work and repair or change the safety accessories.

Enhanced risk!

**Do not come into or intervene in the cutting area.
Otherwise, there is possibility of heavy injury.**

1.5.1. Total Stop

TOTAL STOP button is used for emergency switching – off the machine in case defect or health hazard. By pressing **TOTAL STOP** button is interrupted the supply of the electrical power.

If any damages or fault appears, immediately press TOTAL STOP button! Release the pressing button is possible by twisting of the upper part of the button.

1.5.2. Saw arm cover


If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible to start in set mode.



The band saw is started to the operation, when the cover is closed!

1.5.3. Saw band stretching and rupture inspection

This device checks the saw band stretching and causes immediate machine shut – down in the event the band ruptures.



The device contains limit switch. Check the stretching carefully and periodically – eventually adjust.

1.5.4. Saw band cover

It covers the visible area of the saw band from left guiding cube to the frame.



Never switch on the saw band driver if this cover is not mounted!

1.6. Safety notes for the cooling


Attention!

- ***When handling cooling agents always wear hazardous fluid-proof gloves!***
- ***Wear protective goggles!***
- ***Cooling liquid can get in contact with your eyes and may cause permanent severe injuries***

1.6.1. Instructions for first help

1. Pull off and safely remove polluted, soaked clothing.
2. For breathing, go out in the fresh air or look for first aid treatment.
3. Wash with water or use crèmes for contact with the skin.
4. Flush with water for eyes and look for first aid treatment.
5. For swallowing, drink a lot of water and induce vomiting. Look for medical help.

1.7. Umístění štítku stroje /
Maschinenschild position /
Position of machine label



Štítek stroje
Maschinenschild
Machine label

1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols

NSS

Nebezpečí stlačení svérákem
Pressungsgefahr
Crushing hazard by vice



PO:

Noste pevnou pracovní obuv
Tragen Sie Sicherheitsschuhe
Wear fixed protective shoes



CZ:

Přečíst návod k použití
Bedienungsanleitung lesen
Read the operating instructions



OBS:

Noste ochranné brýle a sluchátka
Tragen Sie eine Schutzbrille und
Gehörschutz
Wear protective goggles
and headphones



NR:


Nebezpečí říznutí
Schnittgefahr
Cutting or severing hazard



**POZOR! Před uvedením do provozu
nutno demontovat zajištění ramene!**
**VORSICHT! Vor Inbetriebnahme
die Rahmensicherung demontieren!**
**ATTENTION! Before using the machine,
dismantle the saw frame lock!**

SP:

Směr pohybu
Bewegungsrichtung
Direction of motion



NR:

Nebezpečí zachycení
Erfassunggefahr
Tramping hazard






**POZOR! Před uvedením do provozu
nutno demontovat zajištění svéráku!**
**VORSICHT! Vor Inbetriebnahme
die Schraubstocksicherung demontieren!**
**ATTENTION! Before using the machine,
dismantle the vice lock**


Štítek stroje
Maschinenschild
Machine label

2. **Machine documentation**


2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:	
• Hmotnost / Gewicht / Weight	1007 kg
Rozměry stroje / Maschinengröße / Machine size :	
• Délka / Länge / Lenght	2560 mm
• Šířka / Breite / Width	1520 mm
• Výška / Höhe / Height	1450 mm
Elektrický vybavení / Elektrische Ausrüstung / Electical equipment:	
• Napájení / Versorgungsspannun / Supply voltage	~3 x 400 V (230 V), 50Hz, TN-C-S/TN-C
• Příkon / Gesamtschlusswert / Total Input	5,2 kW
• Max.jištění / Max. Vorschaltsicherung / Max.Fuse	16 A
• Krytí / Schutzart / Protection	IP 54
Akustický tlak / Schalldruckpegel / Acoustic pressure:	
• Transverse 610.440 DGH	L _{Aeqv} = 73 dB
Pohon / Atrieb / Drive:	
• Typ / Typ / Type	MDERAXX-100-32J
• Výkon / Leistung / Output	3 kW
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed	1420 min ⁻¹
Hydraulické zařízení / Hydraulikeinrichtung / Hydraulic equipment:	
• Typ / Typ / Type	870-1394
• Výkon / Leistung / Output	0,5 kW/4 MPa
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:	
• Výkon / Leistung / Output	0,05 kW
• Obsah nádrže / Volumen vom Kühlmittel / Capacity	40 l
Rozměr pásu / Sägebanddimension / Band size:	
5200×34 (32)×1,1 mm	
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:	
20–90 m/min.	
Řezné rozsahy / Schnittbereiche / Cutting size:	
	
0°	 Ø440 mm
	 610×440 mm
	 610×440 mm
	 440×440 mm
45° R	Ø440 mm
	500×190 mm
	360×440 mm
	420×420 mm
45° L	Ø440 mm
	510×180 mm
	460×390 mm
	390×390 mm
60° R	Ø330 mm
	330×170 mm
	170×440 mm
	300×300 mm
60° L	Ø350 mm
	350×170 mm
	330×310 mm
	310×310 mm
Level of acoustic pressure:	
Equivalent level of acoustic pressure A (noise) at operator position are L _{Aeqv} =73 dB. Mentioned values are levels of emission which doesn't have to represent safe levels. Factors which influence real level of acoustic pressure on machine operator are: working place characteristics, cut material, saw band. These factors have significantly influence on acoustic pressure.	

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Keep recommendations for the manufacturers for transportation and stocking! If the recommendations are not kept, damage can occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have license for it!
- Don't move under suspended loads! Fault in lifting device may cause serious injury.
- Keep a safe distance from the machine during the transport.
- Temperature of the air from -25°C to 55°C, for a *short term* (max. 24 hours) temperature of the air until 70°C
- Do not expose the machine to radiation (for example microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all blank surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.

Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.


Fix the stickers stating the minimum approximate machine weight to at least five well visible places.

2.4.3. Transport and stocking

The machine must be secured during transportation. Screw on the palette to the floor of the van or the trailer. Be careful that the machine is not damaged during transportation. Store the machine only under conditions mentioned in the manual, to avoid damage of the machine.

It is forbidden to handle the machine any other way, than it is written in this operating instructions, the machine can be damaged.

2.4.4. Transportní schéma / Transport schema / Transport scheme



2.5. Activation

2.5.1. Machine working conditions

Keep the conditions of the manufacturer for machine operating! If recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At temperature air from **5°C to 40°C**, the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the extend from 30% to 95% (not concentrate)
- Altitude lower than 1000 metres.
- Do not expose the machine to the radiation (for example microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.

Attention!

If the ambient temperature drops below 15 ° C is required before operating the machine to have switch on hydraulic unit around 10 minutes and then made several motion few times (for example, in manual mode) by all hydraulic cylinders. The reason is to heat hydraulic oil to the operating temperature for proper function of the pressure switches (and choke).


2.6. Band saw unpacking and assembling

Remove the packing from the machine and unpack all parts.

Attention!

Switch off the main switch and lock it, before you start assembly! Otherwise, there is possibility of hazardous machine starting.

If the hydraulic unit is outside the machine (the machine only connected hoses and cables), it needs to be placed and mounted on a solid basis (floors, etc.). The mounting holes are used on the bottom (bases) of the tank.

Picture	How-to
	Saw frame blocking: • Dismantle the saw frame blocking from the machine before band saw operation. • Store the holder and screws! Install the saw frame blocking on the machine for band saw displacement! You can avoid the saw frame damage.
	Vice blocking: • Dismantle the vice blocking from the machine before band saw operation. • Store the holder and screw! Install the vice blocking on the machine for band saw



displacement! You can avoid the vice damage.

Assembly of the draining metal plate

- Screw on the draining metal plate to the pedestal.

2.6.1. Machine installing and levelling

Check the floor supporting capacity before machine installing. If the floor capacity does not agree with requirements, you must prepare the necessary base for the machine.

Minimal requirement:

machine weight – Transverse 610.440 DGH – 1007 kg

+ weight of accessories

+ maximum weight of material

- The machine must be levelled at the horizontal position. All feet of the machine must touch with the floor after levelling
- The machine must be levelled by means of the calibrated spirit level. Spirit level is put on the vice area. Set the roller conveyors according to the spirit level.
- For machine levelling, take care that there is sufficient available space for operation, repair work, servicing of the machine and handling the material..
- The machine including appended parts and accessories must be visible from the place of operation.

2.6.2. Machine disposal after lifetime

Blown out all service fluids (cooling liquid, hydraulic oil) into designated reservoir. Dismantle machine into separate parts and dispose them in accordance with valid directives.

2.6.3. First run of the power pack

Before the first run check:

- The direction of the Pump, while run the power pack for max. 2seconds.
- The cooling fan of the motor has to rotate in the same direction as the arrow on the top of the motor cowling indicates.
- In case of wrong rotational direction, the electrical phase in the connection box is to be changed. This check is required after every disconnection from the power source
- Wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise

- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load
- test the electrical equipment
- during operation monitor measuring equipment, noise, height and temperature of oil in the tank
- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.6.4. Filling the reservoir with hydraulic oil

Oil regulations and recommendations of the manufacturer in the technical documentation (appendix) are to be carefully observed. For standard power packs we recommend the oiltype OH-HM32 (DIN 51524) of all known oil manufacturers.


Power packs have to be filled up with clean, pre-filtered oil! The purity of the hydraulic fluid must correspond to the class 10 NAS 1638 (reachable with filter $\beta = 75$)!

Filling from container, such as barrels, buckets, etc. is not recommended or permitted!

The maximum oil level will be shown on the upper marking at the dipstick or the sight level glass. Overfilling has to be prevent. The maximum filling rate of 15 l/min shouldn't be exceed.

Oil type	Kinematic viscosity ν in mm^2/s in relationship to the fluid temperatur					Freezing point
	0°C	20°C	40°C	60°C	80°C	°C
OH-HM 32	220	100	32	15	7	-40
OH-HM 46	400	170	46	18	11	-30
OH-HM 68	700	170	68	26	14	-28
OH-HV 32	180	67	32	17	11	-40
OH-HV 46	350	110	46	25	14	-36

2.6.5. Kotevní plan / Verankerungsplan / Grounding plan



Kotvící materiál / Verankerungsmaterial / Grouding material

- 4x Hmoždina / Dübel / Plug – $\varnothing 12$ mm
- Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 100 mm
- Šrouby / Schraube / Screws – 4xM12

Šrouby podložit deskami o min. rozměrech P10×100-100

- Die Schrauben mit Platten mit Minimaldimensionen P10×100-100 unterlegen
- Screw must be bottomed with plates (min. dimensions P10×100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.7. Electrical connection

Attention!

*Only a qualified professional must carry out the servicing and repairs of the electric equipment! **Take special care during work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety.***

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V}$, 50 Hz, TN-C-S
- Total input / Max. fuse: 5,2 kW / 16 A

Before connecting switch off the main switch of the power supply circuit for the machine and ensure dry place when doing connecting works!

Note:

The values of the crosscut of the conductor and the rated current are in the norms.

Service voltage must agree with the line voltage! Crosscut of the supply line must respond with rated current for max. machine load.

Note:

The socket with the fork can be used only at the machines with the rated current less than 16 A and total input less than 3 kW.

Attention!

In this case the extra main switch becomes primary and the main switch on the machine has only secondary function.

In case the machine is connected with a direct connection, an extra main switch must be added which can be locked in zero position.

2.7.1. Check the direction of the saw band



After the machine has been successfully connected, briefly switch on the machine and put the driving engine of the band in the running position. The direction must be in accordance with the arrow direction on the saw band cover. In case the direction of the saw band does not match, two phases at the terminal strip must be switched.

2.8. Filling of the cooling system

Prepare the mixture of the water and the cooling liquid. Keep the concentration specified by manufacturer. Shift away the cover from the drainage hole. Fill the mixture of the water and the cooling liquid to the tank of the cooling system. Area of the tank for the cooling liquid is discovered from the chapter *Technical data*.

Let the drainage hole opened and with the sieve during operation, because it secures the right work of the cooling system. Filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and the tank does not overflowed.

Attention!

When you connect the machine to the electrical network observe correct connection of all phases!
ENGINE IN IN HYDRAULIC AGGREGATE CANNOT BE OPERATED WITH REVERSE TURNING MORE THEN 10 SECONDS!!!

2.9. Check machine function

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if covers are installed and functional. Check by means of the Tenzomat if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Values of the saw band stretching are on the Tenzomat. Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to other outer position. Raise the saw frame to the top position and drop the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for the operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are right, the machine is ready for operation..

2.10. Saw band

Refit the saw band cover only after you have installed and tightened the saw band.

2.10.1. Saw band size

5200×34 (32)×1,1 mm



2.10.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth system. The important factor for selection of the tooth system is length of the cutting canal with respect to the size of the product

1. *Constant tooth system* – the saw band has parallel tooth pitch all over length. This way is suitable for cutting of solid material.

BOMAR recommended Variable tooth system for band saw.

2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cutting area.

In tables, there are advised type of the tooth system depending on sizes and form of the cutting material.

Footnotes:

Z₀ – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:


32 S – number „32“ means 32 teeth on one inch (that means constant tooth system), letter „S“ marks teeth with zero angle of the tooth.

4–6 K – number „4–6“ means 4 till 6 teeth on one inch (that means variable tooth system); letter „K“ marks teeth with positive angle of the teeth.

2.10.3. Saw band running-in








Running-in: Cut the material with the frame lowering reduced to 50% only. When vibrations occur increase or decrease the band speed.

When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for 15 minutes approximately. When the band has been run, increase the lowering-speed to normal speed. The running in of the saw band avoids micro-breaks on the cutting edges of new saw band ensuing from first excessive stress. This would decrease service life substantially. The optimal running in of the saw band produces ideal rounded cutting edges and therefore the conditions for an optimal service life.









Note: Run regrinding saw bands too.

Tables for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to 2xS). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10-14 S	10-14 S
4	24 S	14 S	10-14 S	10-14 S	8-12 S	8-12 S
5	18 S	10-14 S	10-14 S	8-12 S	6-10 S	6-10 S
6	18 S	10-14 S	8-12 S	8-12 S	6-10 S	6-10 S
8	14 S	8-12 S	6-10 S	6-10 S	5-8 S	5-8 S
10	-	6-10 S	6-10 S	5-8 S	5-8 S	5-8 S
12	-	6-10 S	5-8 S	5-8 S	4-6 K	4-6 K
15	-	5-8 S	5-8 S	4-6 K	4-6 K	4-6 K
20	-	-	4-6 K	4-6 K	4-6 K	3-4 K
30	-	-	-	3-4 K	3-4 K	3-4 K
50	-	-	-	-	-	3-4 K


Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10-14 S	10-14 S	8-12 S	6-10 S	5-8 S	5-8 S
3	8-12 S	8-12 S	6-10 S	5-8 S	4-6 K	4-6 K
4	6-10 S	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K
5	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K	3-4 K
6	5-8 S	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K
8	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K	3-4 K
10	4-6 K	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K
12	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K
15	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K
20	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K	2-3 K
30	3-4 K	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K
50	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K
75	-	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K	0,75-1,25 K
100	-	-	1,4-2 K	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
150	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
200	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K

SOLID MATERIAL ($D = \text{mm}$)						
						
Constant tooth system		Variable tooth system				
length of the cut D	tooth system (Z_p, Z)	length of the cut D	tooth system (Z_p, Z)			
to 3 mm	32	to 30 mm	10-14			
to 6 mm	24	20-50 mm	8-12			
to 10 mm	18	25-60 mm	6-10			
to 15 mm	14	35-80 mm	5-8			
15-30 mm	10	50-100 mm	4-6			
30-50 mm	8	70-120 mm	4-5			
50-80 mm	6	80-150 mm	3-4			
80-120 mm	4	120-350 mm	2-3			
120-200 mm	3	250-600 mm	1,4-2			
200-400 mm	2	500-3000 mm	0,75-1,25			
300-800 mm	1,25					
700-3000 mm	0,75					

3. **Machine control**

3.1. Starting the band saw

- » 1. Switch on the main switch of the band saw. The main switch is situated on the side of the switchboard.




2. Switch on the safety circuit of the band saw (button **3**– control panel of the band saw).




3.2. Control panel

Ovládání stroje
Bedienung der Maschine
Machine control



3.2.1. Control panel description

1	LCD Display On to display are described all running processes, control with functional buttons F1-F4
2	Control buttons / numeric keypad
	No function
	No function
	Clamp / release vice In manual cycle pressing and holding the button allows you to release pressure or clamping vise.
	Cooling system selection Cooling with Microniser (optional accessories) Cooling with water cooling pump runs even when the saw band drive is switched off.
	Movement of the arm Pressing and holding a button or trigger arm lifts the lifting hydraulic cylinder. When lifting the arm using the arm can be lifted in its entirety lifting cylinder. On the down can be activated by simultaneously pressing the rapid move functional button F1.
	No function
	Turn on / off the band drive In manual mode the button is displayed "I" switched band drive, the button with the symbol "0" switch off
	Turn on / off the hydraulic circuit Button with the symbol "I" turns the hydraulic circuit, the button with the symbol "0" disables the hydraulic circuit. The hydraulic circuit is automatically switched on when needed.
3	Safety circuit Switch on the safety circuit by pressing button.

4	Button START - Switch on the semi-automatic cycle After pressing the button will start the cutting cycle
5	Selecting a mode machines 0 for servicing and settings  manual mode  semi-automatic mode Note: The functions performed in both manual and semi-automatic mode are the same, but only in semi-automatic cycle it is possible to use the START / STOP (ie start / off cycle)
6	Button STOP - Switch off on the semi-automatic cycle After pressing the button will turn off the interruption or of cutting cycle
7	TOTAL – STOP button In emergency causes the machine must be immediately switched off.
8	Frequency convertor Turn to change the speed of the saw band in the range of 20-120 m / min
9	Governing valve for adjust the speed of the arm sinking to the cut Adjust the speed of the arm sinking to the cut by governing valve. Notice: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.3. Machine setup

Machine setup mode is activated by switch on control panel. Switch must be in “0” position.



After switching into position “0” is displayed on LCD this screen.





Reset to 0 a display showing angel on console by pressing **F2**.

3.3.1. SERVIS

After pressing the **F1** functional key can be set servis parameters that are password protected (947).




Control and movement in SERVIS can be set using the function keys **F1 - F4**.




On display	Description
	Blade speed correction - Constant for calculation of blade speed display values from analog input. F1 go back, F4 next menu screen, F2 enter value
	Sensor - Display variable sensor arm (optional accessories) - Use to check the functionality of the sensor on the arm - Read only F1 go back, F4 next menu screen
	Vice clamping time - Watch vice clamping time in ms. F1 go back, F4 next menu screen, F2 enter value
	The type of machine. - Display the machine type (the value set by the manufacturer) - Read only

3.3.2. SETUP

After pressing the **F4** functional key can be set setup parameters that are not password protected.



Control and movement in SETUP can be set using the function keys **F1 - F4**.

On display	Description
	Finish of cycle - At the top – arm after cut starts above the material and cutting cycle ends - At the bottom – arm after cut remains in the lower position, the above material does not exit F1 go back, F4 next menu screen, F2 enter value
	Turn off motor after cut - Up position – saw arm move up after cut and then turn off drive of saw blade. - Down position – drive of saw band turn off immediately after cut. F1 go back, F4 next menu screen
	Upper vice - Allows to able / disable the upper vice in the cutting process F1 go back, F4 next menu screen, F2 enter value
	Vice opening time - Watch vice opening time in ms. F1 go back, F4 next menu screen, F2 enter value



Upper vice opening time

- Watch upper vice opening time in ms.
- **F1** go back, **F4** next menu screen, **F2** enter value



Switch off hydraulic

- Setting the hydraulic unit off when idle machines
- **F1** go back, **F4** next menu screen, **F2** enter value



Language

- Choose menu language
- **F1** go back, **F4** next menu screen, **F2** enter value



Displaying of speed

- Displaying of band speed according to the selected units (m / min or ft / min)
- **F1** go back, **F4** next menu screen, **F2** enter value

3.4. Machine error messages

Error	Information
SAFETY BUTTON is OFF F1 F2 F3 F4	Safety button (pos. 3 on control panel) is not ON. Press F4 to confirm error.
TOTALSTOP pressed F1 F2 F3 F4	Total Stop button is active. Turn button TOTAL STOP according to the arrows. Press F4 to confirm error.
Blade tension faulty F1 F2 F3 F4	Saw blade in properly tensioned. Press F4 to confirm error.
Faulty motor protec. F1 F2 F3 F4	Engine temperature protection is active. Do not overload saw! Press F4 to confirm error.

3.5. Machine control


3.5.1. Semi-automatic cycle

1. Lift the saw arm to the top position by pressing button 
2. Open the vice by pressing button 
3. Clamp material to the vice by pressing button 
4. Lower the frame about 10 mm above the material by button 

Attention!

Do not move the saw frame to the material, when the saw band driving is not running! Do not move the saw frame to the material with accelerated motion! The saw band can be damaged!

5. Set the maximal height of saw arm by .
- If arm height was not set the screen below appears .



- Press button **F4** and then set the position of arm by buttons  and  and confirm by pressing **F2**.
6. Press button **START** (position **4**) of semi-automatic cycle.
Set the saw band speed according to the kind of the cutting material.
Set the speed of the arm sinking by adjust governing valve (position **9**).

Attention!

Press button „6“ (STOP of semi-automatic cycle). In risk of injury or damage of the band saw, press the emergency button TOTAL STOP „7“!

7. The band saw clamps the material to the vice and it makes the cut.

8. Open the vice. If the vice is not opened, you can open it by button .
Remove the blank ((cut off a piece of material).

9. You can repeat whole process.

3.5.2. Cycle breaking

»

STOP button

Semi-automatic cycle is interrupted by pressing button **STOP** (position **6**) of the semi-automatic cycle.

The arm is lifted to the top position and the saw band drive is stopped..

By pressing button **START** (position **4**) of the semi-automatic cycle, you can start the cycle.

TOTAL STOP button

In case of the risk, press button **TOTAL STOP** (position **7**).

After pressing **TOTAL STOP** button, saw band drive is immediately broken and the arm sinking is stopped.

Reactivation

1. Turn button **TOTAL STOP** according to the arrows (on the button).
2. Switch on the **Safety circuit** by button (position **3**).
3. By pressing button **START** (position **4**) of the semi-automatic cycle), you can start the cycle. The arm is lifted to the top position and the saw band starts the cycle.

3.6. Cutting speed adjustment


Speed of the saw band is possible change from 20 to 90 min⁻¹ using the frequency convertor. You can effect to adjusting speed of the saw band following.

Picture	How-to
	1. Turn the switch 18 to the position „□” (semi-automatic mode). 2. Press button 2 to switch on the drive of the saw band. 3. Use the frequency convertor 22 to adjust a requested speed of the saw band. Saw band speed is depicted on the display


3.7. Angular cut setting

The cut angle is possible set from -60° to +60°.


1. Lift the saw frame.



2. Loosen the securing lever of the console and set the desired cut angle. Setting cut angle is depicted on the display over the securing lever.
3. Tighten the securing lever of the console.
4. Shift the vice according to setting angle of the cutting. Shift the vice to the right for angle of the cut, which is less than 0°, shift the vice to the left for angle of the cut 0° or for angle of the cut, which is bigger than 0°.



Set the saw frame to the position 0° and press button zeroizing of the angle (on the distribution box under the main switch) after main switch starting of the machine. Angles admeasurement is secured.



3.8. Optimal adjusting of the guide cubes span

If you want to achieve a smooth and precise cut, it is helpful to position the guide cube as close as possible to the material.


1. Release the lever of the left listel and move left part of the guide apparatus so that the left guide cube edge is as close to the cut material as possible.
2. Lower the frame to the lower position and check the position of the guide cube towards vice loading area. The guide cube must be a distance of at least 10 mm from the vice loading area.
3. Tighten the lever of the gib and check the guide cube setting once more for possible collision with binding table or vice jaw.







3.9. Cutting pressure adjusting

The band saw Transverse 610.440 DGH is equipped with automatic down-feed regulator on both guiding cubes.

Adjusting the down-feed regulator is performed with regulating wheel on the guiding cube. Screw on the wheel, the pressure is increased. Screw off the wheel, pressure is lowered.



Picture	How-To
	1. One visible neck – Solid material over Ø300 mm.
	2. Two visible necks – Solid material to Ø100 -Ø300 mm.
	3. Three visible necks • Pipes and shapes material with surface from 10–15 mm. • I-shaped material from 200–500 mm. • Solid material to Ø100 mm

Picture	How-To
	4. Four visible necks • Pipes and shapes material with surface to 10 mm. • I-shaped material to 200 mm

3.10. Material insertion

- Never walk under a suspended load!
- Never climb onto the gravity-roller conveyor!
- Do not hold the material for clamping material to the vice! The vice can cause injury!

3.10.1. Handling agent selection


- Use the strong handling agents to lift and transfer the material!
- Handle with the material only with the lift truck or use the suspension strands and the crane!
- Do not use the lift truck or crane in case that you do not have the license to handle with it!

3.10.2. Insertion

Insert material to the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you cut long pieces of the material (for example rod, tube), you must use the roller conveyors for material shifting to the band saw. Contact Bomar for more information about roller conveyors

Make sure the conveyor is long enough and the material cannot tip off the conveyor.

Be especially careful with round materials that it always stays on two vertical rollers and that it cannot fall off the conveyor!



3.10.3. Bundle material cutting




If you want to cut the material in the bundle, there are suggestions for the positioning of bundles

Round material bundle: Take care especially with round material that the bars are put according to the picture. If the bars are put differently, you may have problems with movement.

Always weld the material at the rear end of the bundle to secure it from moving.

Before welding always, switch the machine off at the main switch! The magnetic fields, which often occur during welding, may damage the controls!

Square material bundle:




Attention:

Not all material shapes are suitable for bundle cuts. Keep the recommendation of your supplier of the saw bands for material insertion to the bundle.

4. **Machine service**

4.1. Saw band dismantling

1. Drive the saw frame by pressing button – „Raise saw frame “ into the top position. If the saw band is breaking, press buttons „Raise saw frame“ and „Start of aggregate hydraulics“.




2. Release the securing lever of the left guiding cube holder and whole left part of the guiding including left cover move to the right.




3. Dismantle left cover of the saw band. The cover is fastened by plastic-headed screw.



4. Loosen locks on the rear cover of the frame and lift it to the up.




5. Tighten the screw on both guiding cubes. The saw band is released in the guiding cubes.



6. Loosen the saw band stretching by means of the screw. The saw band is possible remove from the wheels.




7. Remove the saw band from wheels.



8. Carefully remove the saw band from the guide cubes.

4.2. Saw band installation


1. Before installation clean all track wheels and guide shoes thoroughly, removing all traces of chips and dirt.




2. Install the saw band to both guiding cubes. Make sure the saw band lies on both track wheels and it is pushed all the way to the top.



3. Insert the saw band on both guiding wheels. Make sure the rear part of the saw band suits to the edge of the wheels.



4. Stretch the saw band by means of the screw so it does not fall from the wheels.



5. Release the screw on the both guiding cubes so it was possible by saw band move in the guiding cubes.
6. Close the rear cover of the frame.




7. Install left protective cover of the saw band.

4.3. Saw band stretching and inspection

Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer.

- Switch on the hydraulic aggregate after the saw band installation check the saw band stretching on the manometer (arrow 1).



- Use the screw (arrow 2) to stretch the saw band until it is stretched to the recommended value.

4.3.1. Saw band stretching

For saw band stretching use Tenzomat – Special accessories

Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer

1. The saw band must not fall from the wheels after setting.



2. Install the Tenzomat on the saw band and secure it with screws
3. Stretch the saw band until it is stretched to the recommended value

4.3.2. Saw band inspection

Check the saw band in the guiding cubes and on the wheels

1. Check, if the saw band is right in the guiding cubes..
2. Switch on the saw band drive and then after 10 seconds switch off saw band drive. If the saw band drive is not possible to switch on, set the limit switch of the saw band stretching.
3. Switch off the main switch.
4. Open cover(s) of the wheels and check position of the saw band on the both wheels..
 - If the distance between backside of the saw band and the offset wheel is **1 mm**, setting is right.
 - If the distance is bigger than **1 mm**, or the saw band is on the offset of the wheel, set the saw band.
5. Close cover of the saw band.

4.4. Saw band run adjustment on stretching wheel

Saw band run on the stretching wheel must be regularly inspected. The inspection has to follow every saw band replacement.

4.4.1. Saw band run inspection

If the run is not correct, the following problems may occur:

- **The saw band falls off the wheel** – The saw band and protective cover can be damaged.
- **The saw band runs on the wheel rim** – The saw band and wheel rim can be damaged



1. Start and stop saw band drive.
2. Stop the main switch!.

3. Open rear cover of the saw frame.



4. Check saw band placing on the wheels.
 - If the distance of the rear part of the saw band from wheel rim is **1 mm**, setting is right.
 - If the distance is bigger than **1 mm**, or the saw band runs on the wheel rim, saw band run must be set.

4.4.2. Saw band run setting



Saw band run is set with screw (arrow) in the stretching cube on the saw arm. Right distance rear part of the saw band from wheel rim is **1 mm**.

- Turn with the screw to the right, the saw band is closer to the stretching wheel rim.
- Turn with the screw to the left, the saw band is far from the stretching wheel rim

Check saw band run adjustment again.

4.5. Limit switch setting of the saw band stretching

When the saw band is replaced, the saw band stretching must be checked by means of the TENZOMAT. Set the limit switch of the saw band stretching.



1. Screw off the cover of the saw band stretching.



2. Release nut and screw the limit switch screw, until the screw is unfastened.
3. Screw the screw towards the switch, until the switch is not clamped. Secure the screw with nut. The limit switch is set.

4.6. Guide cubes adjustment

The guiding cubes are set from the manufacturer. Cubes are secured with two pins. It is not necessary to set the guiding cubes all the while of the lifetime.

4.7. Hard metal guides adjustment

Hard metal guides adjustment is one of the most important criterions which influences cutting accuracy and saw band life. Therefore, it is essential to check regularly that hard metal guides adjustment is correct.


1. Release the screw. The screw holds the guide in the guiding cube. Make sure, that the guide of the hard metal does not falls



2. Press the guide on the saw band by tighten three screws. Check, if the hard metal guide does not put up to much resistance against the movement of the band. As soon as it is possible to move the band without resistance (and between saw band and the guide is not width) the hard metal guides are adjusted.




3. Tighten the screw. The screw holds the guide in the guiding cube. Make sure, that the guide is not damaged



Make sure that the hard metal guides do not put up to much resistance otherwise the lifetime of the saw band and drive decreases.

4.8. Saw frame lower stop position adjustment

The lower stop limits the lowest position of the saw frame. This stop point has to be checked at least once a month. If the lower stop point is incorrectly adjusted, the cutting table can be damaged or the material will not be cut completely.



1. Lift the saw frame to the top position.
2. Release the nut of the screw and set it to the desired value.
3. Secure the screw with nut.
4. Set the limit switch of the saw frame lower position.


4.9. Limit switch of the saw frame lower position adjustment

If the lower stop of the saw frame was set, the limit switch must be set again.

Check setting

Lower the saw frame to the bottom position. If the saw frame is on the lower stop and the limit switch was responded, the limit switch adjustment is right. If the limit switch is not right, it must be set.

Limit switch setting



1. Release the nut of the stop screw of the switch and screw the screw.
2. Lower the saw frame to the lower stop and start saw band drive.
3. Screw off the stop screw of the switch, until the saw band drive is not stopped.
4. Secure the screw with the nut and check limit switch adjustment again.

4.10. Adjustment of the securing cube of the turning lever

The securing cube is adjusted right from the manufacture, but if the saw frame is not secured, the securing cube must be adjusted. Check the functionality of this cube regularly; if the console is not fastened correctly, inaccuracy may occur.



1. Release the fixative screw of the securing lever. By lever is possible to move.
2. Turn by lever to the left side to the stop and fasten the fixative screw again.



3. Secure the console by lever and carry out the inspection.

If the adjustment is correct, the saw frame cannot be turned around.

4.11. Pressure switch adjustment

*Be careful for working on the hydraulic system!
In hydraulic system stays residual pressure after hydraulic
aggregate stopping!*

If you want to set the pressure switch, you must screw off the hydraulic aggregate from the pedestal and pull up if from the pedestal.



- The pressure switch is in the block of the hydraulic aggregate.



- Pull off the elastic cover of the pressure switch (carefully – outlets must not be broken).



- Set the sensitivity of the pressure switch by means of the screwdriver.
- Turn by screwdriver to the left, the sensitivity is bigger.
- Turn by screwdriver to the right, the switch will be clip with higher pressure.

Check limit switches adjustment:

- The vice is clamped – The pilot lights of the control system are lighted.
- The vice is opened – The pilot lights of the control system are not lighted.
- The vice is on the move – The pilot lights are not lighted, they are not winked.



- Return the cover on the pressure switch after adjustment.

4.12. Pressure adjustment of the hydraulic system

*Be careful for working on the hydraulic system!
In hydraulic system stays residual pressure after hydraulic
aggregate stopping!*




Remove the screw on the block of the pump. Screw on the manometer in place of the screw (thread G1/4") with range 0 – 60 bar.

*Switch on the machine; turn the switch with the key to the position „set mode”.
Work extremely carefully now!*



1. Release the nut of the adjusting screw.



2. Set the pressure by means of the adjusting screw and manometer.
3. If the pressure is adjusted, tighten the nut.
4. Switch off the main switch of the machine.
5. Dismantle the manometer and screw on the stopper to the slot.

4.13. Brush adjustment

The brush for chip removal from the saw band influences cutting durability, saw band lifetime and wheels lifetime, hard metal guides and finally the cut accuracy. Brush adjustment must be checked every shift.


1. Lift the cover of the saw frame.



2. Release screws on the brush holder.



3. The brush must touch with teeth of the saw band.



Notice!

The brush must not touch the bottom of the saw teeth!!

4. Tighten the screws on brush holder after brush adjustment.

4.13.1. Adjustment of the cutting pressure regulation

Set the body of the regulation by adjusting handle. It is under the handle. Set it on the second groove. There is visible one neck (pos. 1, 2).

Screw the stopper screw to the maximum, or the valve will be blocked (pos. 3).

Now the frame can be freely moved up only, because the saw frame movement is blocked with the governing valve.


Press button „saw frame down“, screw on the setscrew.

Screw in the stop screw as long as you reach the optimal speed of the frame sinking.

Optimal speed of the frame sinking is between 35 sec.


Secure the adjusting screw by means of the nut after reaching of the sinking speed.

Switch on the engine of the drive and check speed of the saw frame sinking again.



4.13.2. Adjustment of a throttle valve

1. Switch off the machine by its main switch. Let the sawing head down at the bottom. Close the throttle valve gently.



2. The worm screw (pos. A) must be next to the stop (pos. B), when the valve is closed.



3. Otherwise, you must loosen the worm screw, lift the plastic knob and close the throttle valve to the maximum. Next loosen the worm screw and take off the plastic knob. Put it back so that the worm screw must be next to the stop while the valve is closed. Then tighten the worm screw again.
4. Turn the machine on and test the down-feed control.

4.14. Cooling agents and chips disposal

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
• use of contaminated water • impurity • outside oil contamination (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration	• corrosion protection is diminished • lubrication decreases • microbial attack is more likely	• the cooling ability is decreased • foam behaviour increases • emulsions stability deteriorates • sticky residue develops

4.14.1. Coolant device inspection

The state of the cooling agent has significant influence on the cutting quality and on the operational life of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution cooling liquid (especially with oils) and on the other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be changed.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	after concentration check, refill with water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or renew coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides, or coolant renewal after added system cleanser*
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquiries to supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, ix with defoamer

* According to manufacturers' instructions

4.14.2. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Fill a watertight container with the chips! Be careful that the container does not leak, because even after a long dripping time, they still contain coolant residue.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micro-spray installation, the chips must also be handed over to a disposal company.

4.15. Hydraulic, Greases and oils

4.15.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Use oils with specification DIN 51517 in the gearboxes. Select the viscosity grade ISO VG according to the original oil fill.

Attention:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers.

Do not forget, that mineral and synthetic oils must not be mixed!

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Transverse 610,440 DGH	Shell Tivela S 320	1,8 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
ÖMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.15.2. Lubricant greases

We recommend using lithium based saponified grease, class NGLI-2 for lubrication. Different greases are mixable, if their oil bases and consistence type are identical.


Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energ grease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP

Manufacturer	Type of the lubricant grease
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.15.3. Lubrication

There are several placing on the machine, which are necessary to grease periodically. It secures the right function of the machine.

Lubrication place	Lubrication
	The guiding cubes leading – grease with oil from both sides once a week.

4.15.4. Hydraulic oils

Replace the hydraulic oil once in 2 years, because the oil can deteriorate its properties and cause problems the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity grade ISO VG 46 in hydraulic aggregates. Hydraulic oils quantity – see chapter **Hydraulic oil level check**.

Note:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils may not be mixed!

Comparative table of the hydraulic oils

Manufacturer	Type	Manufacturer	Type
Agip	Oso 46	Ina	Hidraol 46 HD
Aral	Vitam GF 46	Klüber	Lamora HLP 46
Avia	Avilub RSL 46	Hungary	Hidrokomol P 46
Benzina	OH-HM 46	Mobil	Mobil DTE 25
BP	Energol HLP 46	ÖMV	HLP 46
Bulgaria	MX-M/46	Poland	Hydrol 30
Castrol	Hyspin AWS 46	Rumania	H 46 EP
Čepro	Mogul HM 46	Russia	IGP 30
DEA	Astron HLP 4hy6	Shell	Tellus Oil 46
Elf	Elfolna 46	Sun	Sunvis 846 WR
Esso	Nuto H 46	Texaco	Rando HD B 46
Fam	HD 5040	Valvoline	Ultramax AW 46
Fina	Hydran 46		

4.15.5. Hydraulic unit service

After 50 hours working time, or the latest 3 month after the first run, the first service should be carried out. This includes:



- checking off all screws and connections, fixing points, tubes and hoses for leakage
- Check hydraulic oil level
- During time of duty the oil temperature shouldn't exceed 60-70°C
- check function of signaling components (thermometer, level gauge, dirty filter indicator)
- Check the adjustment of working pressure

To realise a high reliability of the power pack, the manufacturer lays down following inspection intervals

Interval	daily	weekly	monthly	three monthly	six monthly	annually
Hydraulic fluid						
Level	-	•	-	-	-	-
Temperature	-	•	-	-	-	-
Condition	-	-	•	-	-	-
Change interval	-	-	-	-	-	•
Filter						
Change interval	-	-	-	-	-	-
Other checks						
External Leakages	•	-	-	-	-	-
Contamination	•	-	-	-	-	-
Damages	•	•	-	-	-	-
Noise-(level)	•	-	-	-	-	-
Gauges	-	-	•	-	-	-

4.15.6. Hydraulic oil level check



Pull up the gauge and check the state of the oil. The oil level must be situated between water-glas.

Fill the hydraulic oil, if it is necessary. Use always the filter (10 μm or better) when you fill the oil. You avoid impurities penetration to the hydraulic system and troubles in hydraulic system.

4.16. Machine cleaning


Clean the machine from the cooling liquid and impurities after every shift stopping. Conserve the guiding surfaces, mainly.

- Clamping jaws guiding of the vice.
- The guiding of the feeder.
- Loading surface of the vice.

4.17. Worn pieces replacement

4.17.1. Hard metal guides replacement


If the hard metal guides cannot be adjusted, they have to be replaced.



1. Remove the hosepipe leading to the cooling agent and dismantle saw band and saw band guiding cube.



2. Fasten the guiding cube to the vice. Release clamping screws of both hard metal guides and remove them.



3. Screw out the adjusting screw of the adjustable hard metal guide.




4. Screw out the adjusting screw of the adjustable guide as far from the guiding cube so that it is not possible to see it from the inner side.



5. Remove the adjustable guide.




6. Insert new hard metal guides and screw on them.



7. Install the cube on the holder and connect the cooling.
8. Adjust hard metal guides.

4.17.2. Pushing bearing replacement

If it is impossible to adjust the bundle gripping assembly and the pushing bearing is worn, it needs to be replaced.



The bearing condition is possible discover, on the cube from the bottom side, for a better inspection is possible put out the holder of the bearing from the cube.

If the bearing is worn, there is a visible channel on it.

Bearing replacement

Disconnect the hosepipe from the cooling agent supply, screw off the cutting pressure regulation. The gripping assembly regulation should stay connected to the hydraulic system. Dismantle the guiding cube of the saw band.



1. Fasten the guiding cube to the vice by means of the wrench no.3, release fixative screw of the bearing holder.



2. Take out the bearing holder from the guiding cube.



3. Insert the pivot to the vice.

Attention:

The vice has aluminium jaws, eventually, there has to be an aluminium agent to protect the pivot from damage.

4. Remove the bearing pivot from the bearing holder by means of the swager.



5. Check all parts and remove the worn ones.



6. Fasten the holder to the vice.

Attention:

The vice has aluminium jaws, eventually, there has to be an aluminium agent to protect the pivot from damage.

7. Insert the bearing and washers and return the pivot to its original place.
8. The pivot may not extend past the holder, otherwise, the bundle gripping assembly regulator gets worse.



9. Insert the holder to the guiding cube and fasten it by means of the screw and wrench.



10. Install the cube on the holder of the guiding cube, fasten cutting pressure regulation and connect cooling distribution.
11. Set the guiding cube, hard metal guides and cutting pressure regulation.

4.17.3. Saw band guiding pulleys replacement

If the saw band is not sufficiently guided by guiding pulleys or if the pulleys are obviously worn, the pulleys should be replaced.

Attention:

Guiding pulleys must be replaced together on both guiding cubes!

1. Dismantle the saw band.
2. Disconnect the hosepipe from the cooling agent input, screw off the cutting pressure regulation.
3. The gripping assembly regulation should stay connected to the hydraulic system.
4. Dismantle the guiding cube of the saw band.



5. Tighten the guiding cube to the vice and dismantle both eccentrics with bearings following way.
6. Screw off nuts from the eccentric by means of the wrench no.14 and wrench no.16.



7. Remove the washers from the eccentrics.



8. Remove eccentrics from the bearings by means of the swager.



9. Pull up the eccentrics from the cube.



10. Change both bearings and other worn parts.



11. Install eccentrics to the cubes.
12. Insert washer on the shorter eccentric and insert ring on the longer eccentric. Further add both eccentrics of bearings and attach them to the eccentrics with the help of a pipe.

Attention:

Do not forget the eccentrics' position in the cube.

13. Shorter eccentric is located on the side of binding screws of the guide cube.



14. Put the washers on the bearings.



15. Screw on the securing nuts on the eccentrics by means of the two wrenches.



16. Insert piece of the saw band to the guiding cube (c. 15 – 20cm).

17. Set the eccentrics by means of the wrenches, the saw band must run in the centre. Guide pulleys must not press too much on the band, but must spin freely during the band run.

Optimal distance between the band and the pulley is 0,05 mm.

18. Remove the testing piece of saw band from the guide cube and attach the guide cube on the machine; adjust it.

4.17.4. Round brush replacement

If the chip removing brush is not able to fulfil its function, it has to be replaced

1. Hold shaft of the brush by wrench



2. Release the nut on the brush, replace worn brush on the new brush, screw on the nut
3. Set the brush to the saw band



4.17.5. Stretching wheel replacement

1. Dismantle the saw band.



2. Screw off the screw and take down the washer.




3. Pull off the wheel from the shaft by means of the three-armed puller. If bearing stayed on the shaft, pull off it too

4. Check score of the bearings of the stretching wheel and replace them for new.



5. Clean the shaft and grease it with oil. Insert retaining ring to the groove.



6. Install bearing on the shaft and move it to the retaining ring. Insert the distance ring on the shaft and move it to the bearing.



7. Insert the retaining ring to the hole in the wheel.



8. Insert the bearing to the hole in the wheel and press it to the retaining ring.



9. Put the wheel on the shaft and screw on the preparation to the wheel stretching to the hole in the shaft.



10. Pull on the wheel on the shaft.




11. Screw on washer and screw back..
12. Install the saw band. Wheel replacement is ready.

4.17.6. Driving wheel replacement


1. Dismantle the saw band



2. Screw off the screw and remove the washer.



3. Pull off the wheel from the shaft by means of the three-armed puller.



4. Install the wheel on the shaft. Insert the feather to the groove.



5. Screw on the preparation to the wheel stretching to the hole in the shaft. Pull on the wheel on the shaft.



6. Screw on washer and screw back.
7. Install the saw band. Wheel replacement is ready

4.17.7. Cooling pump replacement

Attention:

Only a qualified worker can carry out the connection!!

High-voltage shock may have fatal results.

Further instructions are needed for qualified personnel!

Do not do the work yourself!!!



- The tank with cooling agent is fastened to the pedestal by screws
- Screw off the screws and remove the tank from the pedestal
- Remove the hosepipe leading to the cooling agent from the plug on the pump
- Unscrew four screws on the cooling pump flange and pull out the pump from the sheet metal holder
- Remove the pump clamp box cover. Disconnect 4 clamps of the input cables
- Loosen the bushing and pull the cable out of the pump
- Dismantle new pump clamp box cover
- Push the cable through the bushing and fasten it
- Connect the cable clamps on the pump clamps as is described in the previous case
- Install again the clamp box cover; do not forget the rubber gasket
- Seal the hosepipe leading to the cooling agent connection
- Put the pump on the sheet metal holder and secure it to the pedestal with the four screws

5. **Závady / Troubleshooting**

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment“
	- Worn hard metal guides.	Replace to the chapter „Worn pieces replacement“
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment“
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment“
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement“
	- Insufficient saw band stretching.	Rise the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band and keep the instructions of manufacturer on new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Set the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding arm and guiding cube are loosened.	Clamp the guiding arm.
	- Guiding arm and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast cutting rate.	Lower the material feeding speed.
	- Unexpected oscillation in material quality.	Set the cut and feeding speed to the relevant material.
2. The cut is not cut upon desired angle	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment“.
	- Set angle does not match the cut angle.	Check the angle adjustment with a protractor and possibly set it according to chapter „Servicing and adjustment“.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment“.
	- Guiding arm and guiding cube are loosened.	Fasten the guiding arm and the cube.
	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
3. Short lifetime of the saw band	- Insufficient saw band stretching.	Raise the tightening of the saw band set the scanner of saw band tightening according to chapter „Servicing and adjustment“.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive use as described in chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment“
	- Over stretched saw band	Lower stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw band.	Check the condition of the hard metal guide and if it is too worn, replace hard metal guides according to chapter „Worn pieces replacement“

Problem	Possible causes	Repair
	- Worn saw band guide bearings.	Check guiding bearings and if you notice some sort of excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted down feed and saw band speed.	Adjust the feeding and speed of a saw band according to values published by saw band manufacturer.
	- Different material quality.	Adjust feeding and speed of a saw band according to desired material (try cut-test).
	- Low-class saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly adjusted tracking.	Check the space between top of a saw band and driving wheel. Perhaps adjust the tracking as described in chapter „Servicing and adjustment“
4. Insufficient cut output.	- Worn saw band.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrong saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly set down feed and speed of a saw band.	Set feed and speed of a saw band according to values published by saw band manufacturer.
5. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messed-up.	Cleanse stop point surface of the limit switch from debris and residue material.
6. By choke is not possible turn	- Metal clamps between valve and panel.	Clamps must be removed and put on the shaft O-Ring about 10x2 mm.
	- Metal clams are in body of valve.	Valve must be cleared or changed.
7. Saw band drive cannot be started.	- Pressure switch is adjusted wrong.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
8. The saw bands are cracked.	- In stretching wheel is wrong adjusting geometry.	Adjust distance band from recess wheel c.2 mm according to operating instructions.
	- Hard metal plates of circuit saw band are not adjusting.	Hard metal plates of circuit saw band must be adjusting according to operating instructions.
	- Guiding cubes are not adjusting (bearings + hard metal circuit)	Guiding cubes must be adjusting (bearings + hard metal circuit) according to operating instructions.
	- Bearings of guiding cubes are used (rolling elements are damaged or outside ring of bearing has conical form).	Bearings of guiding cubes must be replaced. Bearings must be adjusting according to operating instructions.
9. Damage tooth system of the saw band	- In gripping the lifting cylinder is backlash.	
	- Squeezed pin upper or downer holder of the lifting cylinder.	Exchange complete upper or downer holder of lifting cylinder.
10. The saw is cut downing.	- Geometry of hardmetal guiding cubes is wrong adjusted.	Hardmetal guiding cubes must be adjusted.
	- Bearings of guiding cubes are used.	Bearings of guiding cubes must be replaced.
11. Cleansing of the saw band is not functional.	- Elastic wheel of the brush drive is worn-down.	Elastic wheel of the brush must be changed.
	- Knurling of the driving wheel is worn-down.	Driving wheel must be changed.
	- The shaft of the brush drive is rusted.	The shaft of the brush must be cleaned and oiled.

Problem	Possible causes	Repair
	- The brush position and the brush cover is adjusted wrong – with the brush cannot be turned.	The brush cover must be posed, in order to the brush can be turned.
12. The saw arm periodically rise and fall during the cut; this cause short lifetime of the saw band.	- Backlash in driving wheel lodgement on the shaft.	Change the driving shaft for a long one, new bearings, distance ring, new driving wheel, spring, two covers on the forehead of the shaft + screws.
	- Worn channel for spring.	

5.2. Electric and hydraulic problems

Problem	Possible causes	Repair
1. Machine is not possible start.	- In socket is not voltage	Line voltage must be checked.
	- Transfer relay is closed (thermal protector)	Each FA relay must be checked.
	- Limit switch of saw band stretching, cover of frame or cover of saw band is not started.	Check of saw band stretching and covers closing.
2. When cut is finished, the frame is not raising.	- Bottom limit switch is adjusted wrong.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- In hydraulic (pneumatic) ring is error. HYTOS (BOSCH) is not acting to frame uplift.	Function of magnetic valve must be checked, valve must be closed, voltage of clamps and inductor must be checked.
3. Electric motor and pump are without voltage. Between contactor and thermal protector is not voltage.	- Wrong contactor.	Replace contactor of engine.
4. The indicator of speed saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be changed.
	- Wrong sensor – diode of indicator speed is not light.	Sensor must be changed and adjusted.
5. Protector is switched off from engine hydraulic aggregate MA3 sometimes.	- Into hydraulic system is high working pressure.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on motor starter FA1.
7. Hydraulic aggregate is switched on but the saw arm or the main vice is not functional	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer can do this.
8. Cooling is not active	Lack of cooling agent.	Fill the tank with cooling agent.
	- Thermal relay is defective	Change the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and perhaps cleanse cooling system.
	- Cooling pump protection is defective	Check the protection of cooling pump if need change it.
	- Cooling pump is defective.	Replace the cooling pump.

5.3. Hydraulic problems

Problem	Possible causes	Repair
1. Hydrogenerator not supplying oil	• reverse rotation	Check the connections of each phase. Reconnect properly connection of the electrical phases.
	• shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond prescribed viscosity value	Change hydraulic oil.
	• Hydrogenerator malfunction	Call service
	• Wrong power supply connection.	Check the connections of each phase. Reconnect properly connection of the electrical phases.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately deaerated	Make deaeration of hydraulic circuit.
	• Low oil level	Add hydraulic oil
	• the pump shaft seals damaged	Call service
3. Increased mechanical noise	• damaged joint drive	Call service
	• damaged or destroyed motor bearings	Call service
	• air intake	Check for leaks.
4. Low pressure, pump supplies oil	• problem in the safety valve	Wrong settings. Check the settings and adjust the safety valve.
	• pump wear	Call service
	• external or internal leakage	Call service
5. Hydrogenerator is seized	• damage by solid particles in oil	Make oil filtration, or call the service.
	• non-prescribed oil	Change hydraulic oil.
	• wrong type of oil	Change hydraulic oil.
	• exceeding the life of the pump	Call service
6. Overheating oil	• cooler malfunction	Check the cooler function or call service.
	• wear the pump, the energy is converted into heat	Call service
7. Hydraulic valve can not be readjusted	• electromagnet has no signal (voltage) - interrupted supply lines	Check again.
	• Electromagnet coil burnt	Replace coil – Call service.
	• spool valve sticking	Replace valve – Call service

6. **Schémata / Schemas / Schematics**


6.1. Elektrické schéma 3x230V+PE, 50 Hz /
 Elektroschema 3x230V+PE, 50 Hz /
 Wiring diagrams 3x230V+PE, 50 Hz

0	1	2	3	4	5	6	7	8	9	
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Transverse 610.440 DGH										
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Machine: Transverse 610.440 DGH		Název stránky/Name page/Name seller: Úvodní strana/Start page/Startseite		Číslo dok. Doc.No./Anzahl der Dokumente : Název/Power supply/Erzeugung: Zpracováni/Processed /Hat. verarbeitet: Datum/Date/Datum:		ES-1859-203/v6.2 3x230V+PE, 50Hz Posled. 7.11.2013		List/Page/ Seite: 00 List/Page/ Seiten: 18


0	1	2	3	4	5	6	7	8	9
Obsah/ Table of contents/ Inhaltsverzeichnis									
Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum							
00	Úvodní strana/Start page/Startseite	7.11.2013							
01	Obsah/ Table of contents/ Inhaltsverzeichnis	7.11.2013							
02	I/O řídicí systém / I/O Control station / I/O Steuerung	7.11.2013							
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	7.11.2013							
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	7.11.2013							
04	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013							
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013							
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013							
05	Silová část M1-M2/Power part M1-M2/Feld partie M1-M2	7.11.2013							
05.b	Silová část M4A, M4B/Power part M4A, M4B/Feld partie M4A, M4B	7.11.2013							
06	Deska zdroje/Power board/Netzgerat-Platte	7.11.2013							
07	Stykače motorů/Motor contactor/Motor-Schutzschalter	7.11.2013							
08	Hydraulické ventily/Hydraulic valve/Hydroventil	7.11.2013							
09	Vstupy/Inputs/Eingänge	7.11.2013							
10	Tlačítka ovládací panel/Button control panel/Taste Bedienpult	7.11.2013							
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	7.11.2013							
12	Řídicí systém/Control system/Steuersystem	7.11.2013							
13	Příslušenství/Accessories/Zubehör	7.11.2013							

00	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Transverse 610.440 DGH	Název stránky/Name page/Name seite: Obsah/ Table of contents/ Inhaltsverzeichnis	Číslo chr. Doc./No./Dossier der Dokumente: RS1-0150-2014/6.2 Název Power supply/Einspeisung: 3x230V-4HE, 50Hz Zpracoval/Processed /Hat verarbeitet: Pavlík Datum/Date/Datum: 7.11.2013	Účtový list/ Seite: 01 Účtový list/ Seite: 18
----	--	--	--	---	--

[illegible]



OP1



Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page,column)
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/06.2
-CU1	Touch-sensitive keyboard	31.R230-207	AKI ELECTRONIC spol.s.r.o.	31.R230-207	1	/12.0
-FA1	Manual motor starter - 0.25A	MS116-0,25	ABB	91.045.016	1	/05.4
-FA2	Manual motor starter - 1.6A	MS116-1,6	ABB	91.045.020	1	/05.7
-SN1	Incremental encoder	DHB	BOMAR s.r.o.	252.034	1	/09.8
-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.7
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/11.8
=OP1-SA1	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/10.3
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/10.1
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/11.4
-FU3	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.0
-FU4	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.1
-FU5	Tube fuse - 6.3A/250V, slow, 5x20	T6,3A/250V	ESKA	91.230.002	1	/06.4
-FU7	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/06.4
-RP1	Potentiometer 5k	TP195 4x7/1N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/05.b.5
-RP1	Potentiometer knob - 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/05.b.5
-RCF1	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.3
-RCF2	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.6
-RCF11	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-RCF12	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-FA1	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.4
-FA2	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.7
-FU1	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU2	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU2	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU3	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.0
-FU4	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.1

The manufacturer reserves right to use an equivalent replacement device.

03a

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojířská/Machine: Transverse 610.440 DGH	Název stránky/Name page/seiten: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dat. Dne/No/Date der Dokumentu: Název Projevu soub./Einsparung Zpracováno/Processed/Not. verarbeitet: Datum/Date/Datum:	ES-1859-2014/6.2 3x230V-4PE, 50Hz Použito: 7.11.2013	List/Page/ Seite: 04 List/Page/ Seiten: 18



Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page,column)
-FU5	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU6	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU6	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.4
-FU7	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU8	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU8	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/06.4
-FU9	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/13.1
-FU9	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/13.1
-KM1	Minicontactor - 4kW/400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KM2	Minicontactor - 4kW/400V, 3P	B65-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KM11	Contactor - 5.5kW/400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/11.6
-KM12	Contactor - 5.5kW/400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/11.7
-PA1	Fuse switch disconnector E90 - 3P	E 93/32	ABB	91.241.014	1	/05.b.1
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.b.5
=OP1-SA1	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.3
=OP1-SA1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.1
=OP1-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.2
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.2
=OP1-SB8	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.4
=OP1-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.2
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.1
-SQ21	Safety limit switch - 2xNC	QK58	KEDU	91.173.012	1	/11.2
-PA1	Cylindric fuse - 25A, 10x38 fast, gG characteristic	PV10 25A gG	OEZ	91.230.021	3	/05.b.1
-SQ2	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.2
-SQ4	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.3
-QS1	Main switch 3P, 32A	VCF1-32A	SCHNEIDER	91.170.012	1	/05.0
-BM1	Safety relay - 4xNO	SNA 4064K	WIELAND	91.051.026	1	/11.4

The manufacturer reserves right to use an equivalent replacement device.

04

	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojířská/Machine: Transverse 610.440 DGH	Název strojířské/Machine name: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dle DPG No./PGH of the Document: Název Power supply/Einspeisung: Zpracováno/Processed/Her verarbeitet: Datum/Date/Datum:	65-1809-203A/6.2 3x230V-4HE, 50Hz 7.11.2013	List page/ Seite:
						04 List/ Pages/ Seiten: 18

0

1

2

3

4

5

6

7

8

9

Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-CU1	Control circuit	PRO-5.X	Bomar	265.917	1	/12.0
-FM1	AC motor drive - 3.7kW, 3x230VAC	VFD037E23A + KPE-LE02	DELTA ELECTRONICS, INC.	91.012.090	1	/05.b.1
-RET1	Multifunction time relay	CRM-93H/UNI	ELKO	91.051.031	1	/07.4
-M4B	Cooling ventilator - 230V, 50Hz, 0.12A	RAH1278B1-C	XFAN	91.015.105	1	/05.b.8

The manufacturer reserves right to use an equivalent replacement device.

04.a



BOMAR, s.r.o.

Těšební 1236/1

CZ 627 00, Brno

Stroj/Machine/Maschine:

Transverse 610.440 DGH

Název stránky/Name page/seiten:

Kusovník artiklů/ Parts list/ Artikelstückliste

Číslo edit. Doc./No./Revisi der Dokumente:

ES-1859-2024/6.2

Název Procesi/Prozess/Einsparung:

3x230V-4E, 50Hz

Zpracování/Processed /Not. verarbeitet:

Použito

Datum/Date/Datum:

7.11.2013


List/Page/
Seite:

04

List/Page/
Seiten:

18























6.2. Elektrické schéma 3x400V+PE, 50 Hz /
 Elektroschema 3x400V+PE, 50 Hz /
 Wiring diagrams 3x400V+PE, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Transverse 610.440 DGH BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno Stroj/Machine/Machine: Transverse 610.440 DGH Název stránky/Name page/Name section: Úvodní strana/Start page/Startseite Číslo dok. Doc.No./Počet dok. Dokument: Název/Power supply/Enseignement: Zpracoval/Processed / Hat verarbeitelt: Datum/Date/Datum: ES-1859-203/v6.2 3x400V+PE, 50 Hz Bvili 7.11.2013 List/Page/ Seite: 00 List/Page/ Seiten: 18									

Obsah/ Table of contents/ Inhaltsverzeichnis

Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum
00	Úvodní strana/Start page/Startseite	7.11.2013
01	Obsah/ Table of contents/ Inhaltsverzeichnis	7.11.2013
02	I/O řídicí systém / I/O Control station / I/O Steuerung	7.11.2013
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	7.11.2013
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	7.11.2013
04	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
05	Silová část M1-M2/Power part M1-M2/Feld partie M1-M2	7.11.2013
05.b	Silová část M4A, M4B/Power part M4A, M4B/Feld partie M4A, M4B	7.11.2013
06	Deska zdroje/Power board/Netzgerät-Platte	7.11.2013
07	Stykače motorů/Motor contactor/Motor-Schutzschalter	7.11.2013
08	Hydraulické ventily/Hydraulic valve/Hydroventil	7.11.2013
09	Vstupy/Inputs/Eingänge	7.11.2013
10	Tlačítka ovládací panel/Button control panel/Taste Bedienpult	7.11.2013
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	7.11.2013
12	Řídicí systém/Control system/Steuersystem	7.11.2013
13	Příslušenství/Accessories/Zubehör	7.11.2013


00

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Transverse 610.440 DGH		Název stránky/Name page/Name seite: Obsah/ Table of contents/ Inhaltsverzeichnis	Číslo chr. Doc./No./Dossier der Dokumente: ES-1859-2024/6.2 Název Power supply/Einspeisung: 3x400 V/4E, 50 Hz Zpracoval/Processed / Hat. verarbeitet: Pavla Datum/Date/Datum: 7.11.2013	List/Page/ Seite 01 List/Page/ Seite: 18

Transverse 610.440 DGH



OP1



Parts list

Device Identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page,column)
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/06.2
-CU1	Touch-sensitive keyboard	31.R230-207	AKI ELECTRONIC, spol.s.r.o.	31.R230-207	1	/12.0
-FA1	Manual motor starter - 0.16A	MS116-0,16	ABB	91.045.015	1	/05.4
-FA2	Manual motor starter - 1A	MS116-1,00	ABB	91.045.019	1	/05.7
-SN1	Incremental encoder	DHB	BOMAR s.r.o.	252.034	1	/09.8
-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.7
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/11.8
=OP1-SA1	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/10.3
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/10.1
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/11.4
-TR2	Transformer 400V/230V, 0.13A, 30VA	JOC E2520-0022	ELEKTROKOV	91.080.027	1	/05.b.8
-FU5	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.0
-FU6	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.1
-FU7	Tube fuse - 6.3A/250V, slow, 5x20	T6,3A/250V	ESKA	91.230.002	1	/06.4
-FU9	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/06.4
-RP1	Potentiometer 5k	TP195 4x7/1N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/05.b.5
-RP1	Potentiometer knob - 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/05.b.5
-RCF1	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.3
-RCF2	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.6
-RCF11	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-RCF12	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-FA1	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.4
-FA2	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.7
-FU1	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU2	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU2	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU3	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8

The manufacturer reserves right to use an equivalent replacement device.

03a

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojířská/Machine: Transverse 610.440 DGH	Název stránky/Page name: Kusovník artiklů/ Parts list/ Artikelstückliste		Číslo dat. Dce./Data sheet: Název Power supply/Elektrotop Zpracoval/Processed/Ver. verarbeit.: Datum/Data/Datum:		List/Page/ Seite 04
		ES-1850-2024/6.2 3x200-AFE, 50Hz Použito: 7.11.2013		List/Page/ Seite 18		



Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page,column)
-FU3	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU4	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU4	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU5	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.0
-FU6	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.1
-FU7	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU8	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU8	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.4
-FU9	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU10	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU10	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/06.4
-FU11	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/13.1
-FU11	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/13.1
-KW1	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KW2	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KW11	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.6
-KW12	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.7
-PA1	Fuse switch disconnecter E-90 - 3P	E 93/32	ABB	91.241.014	1	/05.b.1
-QS1	Switch plate	G00275	Allen Bradley	91.180.001	1	/05.0
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.b.5
=OP1-SA1	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.3
=OP1-SA1	Attaching adapter + INO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB1	Attaching adapter + INO	M22-AK10	EATON	91.061.021	1	/10.1
=OP1-SB2	Attaching adapter + INO	M22-AK10	EATON	91.061.021	1	/10.2
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.2
=OP1-SB8	Attaching adapter + INO	M22-AK10	EATON	91.061.021	1	/11.4
=OP1-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.2
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.1

The manufacturer reserves right to use an equivalent replacement device.


04

BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Transverse 610.440 DGH	Název strojky/Machine page/Name seiten: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dle Dto No/Prostřel der Dokument: 65-1809-203A/6.2 Název Power supply/Einspeisung: 3x400-V/IE, 50Hz Zpracoval/Processed Hat: verfertigt: Datum/Date/Datum: 7.11.2013	Účel/Use/ Seite: 04.4 List/Pages/ Seiten: 18
























6.3. Elektrické schéma 3x400V+PE+N, 50 Hz /
Elektroschema 3x400V+PE+N, 50 Hz /
Wiring diagrams 3x400V+PE+N, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Transverse 610.440 DGH									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		Stroj/Machine/Machine: Transverse 610.440 DGH		Název stránky/Name page/Name seller: Úvodní strana/Start page/Startseite		Číslo dok. Doc.No./Počet dok. Doc.no.: Název Power supply/Einspeisung: Zpracováno/Processed / Hat. verarbeitet: Datum/Date/Datum:		List Page/ Seite: 00 List Page/ Seite: 18	

Obsah/ Table of contents/ Inhaltsverzeichnis

Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum
00	Úvodní strana/Start page/Startseite	7.11.2013
01	Obsah/ Table of contents/ Inhaltsverzeichnis	7.11.2013
02	I/O řídicí systém / I/O Control station / I/O Steuerung	7.11.2013
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	7.11.2013
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	7.11.2013
04	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	7.11.2013
05	Silová část M1-M2/Power part M1-M2/Feld partie M1-M2	7.11.2013
05.b	Silová část M4A, M4B/Power part M4A, M4B/Feld partie M4A, M4B	7.11.2013
06	Deska zdroje/Power board/Netzgerat-Platte	7.11.2013
07	Stykače motorů/Motor contactor/Motor-Schutzschalter	7.11.2013
08	Hydraulické ventily/Hydraulic valve/Hydroventil	7.11.2013
09	Vstupy/Inputs/Eingänge	7.11.2013
10	Tlačítka ovládací panel/Button control panel/Taste Bedienpult	7.11.2013
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	7.11.2013
12	Řídicí systém/Control system/Steuersystem	7.11.2013
13	Příslušenství/Accessories/Zubehör	7.11.2013

00

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Transverse 610.440 DGH		Název stránky/Name page/Name seite: Obsah/ Table of contents/ Inhaltsverzeichnis		Číslo chr. Doc./No./Rechn. der Dokumente: ES-18769-2014/6.2		List Page/ Seite 01	
					Nadřazený Power supply/Einspeisung 3x400V-4PE+N, 50Hz			
					Zpracováno/Processed /Hat. verarbeitet: Pavla			
					Datum/Date/Datum: 7.11.2013		List Page/ Seite 18	

Transverse 610.440 DGH



SB501



SB2

RP1

013a

Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/06.2
-CU1	Touch-sensitive keyboard	31.R230-207	AKI ELECTRONIC spol.s.r.o.	31.R230-207	1	/12.0
-FA1	Manual motor starter - 0.16A	MS116-0,16	ABB	91.045.015	1	/05.4
-FA2	Manual motor starter - 1A	MS116-1,00	ABB	91.045.019	1	/05.7
-SN1	Incremental encoder	DHB	BOMAR s.r.o.	252.034	1	/09.8
-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.7
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/11.8
=OP1-SA1	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/10.3
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/10.1
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/11.4
-FU2	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.0
-FU3	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.1
-FU4	Tube fuse - 6,3A/250V, slow, 5x20	T6,3A/250V	ESKA	91.230.002	1	/06.4
-FU6	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/06.4
-RP1	Potentiometer 5k	TP195 4x7/N20A	GES-ELECTRONICS, a.s.	91.283.015	1	/05.b.5
-RP1	Potentiometer knob - 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/05.b.5
-RCF1	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.3
-RCF2	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.6
-RCF11	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-RCF12	RCF filter	FBOPR1624	Ing. Miroslav Vlček	91.041.015	1	/05.b.0
-FA1	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.4
-FA2	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.7
-FU1	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/05.b.8
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/05.b.8
-FU2	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.0
-FU3	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.1
-FU4	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU5	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4

BOMAR

s.r.o.

Transverse 610.440 DGH

ŠtýpMachine Machine:

Transverse 610.440 DGH

Název stránky/Name page/Name sheet:

Kusovník artiklů/ Parts list/ Artikelstückliste

ES: 18500-201-V6.2

Nařízení/Power supply/Empfehlung:

3x400V/HE-1N, 50~Hz

Účel/Use/Intend:

Zpracování/Processed /Art. verarbeitet/

Page/

ES: 18500-201-V6.2

Nařízení/Power supply/Empfehlung:

3x400V/HE-1N, 50~Hz

Účel/Use/Intend:

Zpracování/Processed /Art. verarbeitet/

Page/

The manufacturer reserves right to use an equivalent replacement device.

The manufacturer reserves right to use an equivalent replacement device.

03a

 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Strojířské/Machine: Transverse 610.440 DGH	Název stránky/Name page/seiten: Kusovník artiklů/ Parts list/ Artikelstückliste		Číslo dat. Dne vydání/Dat. vydání: Název Provozu/Equipment Zpracovatel/Processed by Datum/Dat. Datum:		ES-1850-2014-6.2 3x400-4HE-N, 50Hz Použito: 7.11.2013		List/Page/ Str. 04 List/Page/ Str. 18




Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page,column)
-FU5	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.4
-FU6	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU7	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.4
-FU7	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/06.4
-FU8	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/13.1
-FU8	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/13.1
-KM1	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KM2	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KM11	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.6
-KM12	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.7
-PA1	Fuse switch disconnecter E 90 - 3P	E 93/32	ABB	91.241.014	1	/05.b.1
-QS1	Switch plate	G00275	Allen Bradley	91.180.001	1	/05.0
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.b.5
=OPI-SA1	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.3
=OPI-SA1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OPI-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.1
=OPI-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.2
=OPI-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.2
=OPI-SB8	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/11.4
=OPI-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.2
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.1
-SQ21	Safety limit switch - 2xNC	QK58	KEDU	91.173.012	1	/11.2
-PA1	Cylindric fuse - 12A, 10x38 fast, gG characteristic	PV10 12A gG	OEZ	91.231.007	3	/05.b.1
-SQ2	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.2
-SQ4	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.3
-QS1	Main switch 3P, 16A	194L-E12-1-753	Allen Bradley	91.170.003	1	/05.0
-BM1	Safety relay - 4xNO	SNA 4064K	WIELAND	91.051.026	1	/11.4
-CU1	Control circuit	PRO-5-X	Bomar	265.917	1	/12.0

The manufacturer reserves right to use an equivalent replacement device.

04


	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Transverse 610.440 DGH	Název strojů/Name page/Name seiten: Kusovník artiklů/ Parts list/ Artikelstückliste	Celostr. Doc.No./Prostř. der Dokument.: Název Power supply/Einspeisung: Zpracoval/Processed/Herz verfertigt: Datum/Date/Datum:	65-1809-20146.2 3x400-AE+1N, 50Hz Bwile 7.11.2013	Ústředí / Seite 04.4 Ústředí / Seite 18
--	--	--	--	---	--	--













07

	Stroj/Machine/Maschine: Transverse 610.440 DGH	Název strojky/Name page/Name seiten: Hydraulické ventily/Hydraulic valve/Hydroventil	Číslo dle Dvo./No./Nachr. der Dokument.: 65-1859-2014/6.2	List/Page / Seite: 08
			Nachr./Power supply/Einspeisung: 3x400V-4FE-N1, 50Hz	List/Page / Seite: 08
			Datum/Date/Datum: 7.11.2013	












6.4. Hydraulické schéma / Hydraulikschema / Hydraulic diagram



205.1816-100
TRANSVERSE 330 DGH
TRANSVERSE 440 DGH
04.11.2013

Pletí také pro řadu RB (330,440)

Typ / Type / Type

Transverse 330, 440 DGH, Transverse RB 330, 440

Hydraulický agregát / Hydroaggregat / Hydro aggregat

92.001.069, C.f.FMV: S001-059-4, PPM-ACO, 37-PG1/2,5-TM16-CB03-FR

Neuvedené světlosti / Unerwähnt Lichtbreite / Unlisted inside diameters

JS6

Výstupní šroubení / Ausgangsschraubung / Output screwing

G1/4"

Pmax

4 MPa

Q

3,3 dm³/min

n

1400 ot./min

P


0,25 kW

Poz.	Název položky		ks
Pos.	Bezeichnung		Menge
Pos.	Item		Pcs.
	Nádrž / Behälter / Tank	TM13,5/S	1
2	Elektromotor / Elektromotor / Electromotor	EM 71 0,25kW/3 B35	1
3	Hydrogenerátor / Hydraulikaggregat / Hydrogenerator	10A2,5X053G	1
4	Zpětný filtr /	MPF0301AG1	1
5	Nálevací zátka / Stopfen / Plug	CPT-MD-FA/1"	1
6	Přepouštěcí ventil / Bypassventil / By pass valve	SR1A-A/S10	1
7	Jednosměrný ventil / Einwegventil / One-way valve	SC1F-A2/1-1005	1
8	Rozváděč / Verteilungsventil / Distributor	RPEK1-03G3Z11/02400E1K1	1
9	Rozváděč / Verteilungsventil / Distributor	RPEK1-03G3Y11/02400E1K1	
10	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	RJV1-05-0	1
11	Rozváděč / Verteilungsventil / Distributor	SD3E-A2/S2L2+C13D-02400E1K1	
12	Ventil pojistný / Sicherungsventil / Retaining valve	VPNH 1/4"	1
13	Ventil škrticí / Drosselventil / Choke	V501-04/R2-OS	1
14	Kostka regulace / Regulationklotz / Regulation cube	manual	1
15	Tlakový spínač / Druckschalter / Pressure switch	Kód: 0166415031059, 20-50 bar	2/1
16	Kulový ventil / Kugelventil / Globe valve		1(0)
17	Redukční ventil / Reduktionsventil / Control valve	VRN2-06/S-6R	1(0)
18	Manometr / Manometer / Manometer	D68, RAD., 0-60 bar	1(0)
19			
20	Rozváděč / Verteilungsventil / Distributor	RPE3-042R11/02400E1K1	1(0)
21	Jednosměrný ventil / Einwegventil / One-way valve	VJ01-04/MP-30	1(0)
22	Redukční ventil / Reduktionsventil / Control valve	VRP-04-PS/6,3	1(0)
23	Deska / Platte / Plate	DK1-04/32-2	1(0)
24			

7. Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix 285.230 G manual) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. practix 285.230 G manual), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).
- For spare parts order, you must always to allege: type of machine (for example practix 285.230 G manual), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. Pila / Säge / Saw – Transverse 610.440 DGH



7.2. Kusovník / Stückliste / Piece list

Pila / Säge / Saw – Transverse 610.440 DGH

Cislo Sestavy 201.1800-050		Ver. 5	Nazev sestavy PILA PASOVA/BAND SAW/BANDSÄGE		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	201.1801-600 (5)	2	PODSTAVEC / BASE / UNTERSATZ	SESTAVA	1
2	201.1802-000	2	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
3	201.1803-000	2	SVERAK / VICE / SCHRAUBSTOCK		1
4	201.1809-000	0	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
5	201.4804-050	8	RAMENO / SHOULDER / SÄGERAHMEN		1
6	201.4807-200 (3)	4	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDE		1
7	201.R230-300 (5)	1	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1
8	30.1800-052 (5)	0	DRZAK / HOLDER / HALTER	P 5x30	1
9	30.1814-108 (4)	0	KRYT PASU / BELT COVER / BANDABDECKUNG		1
10	30.1899-002 (5)	0	STITEK / LABEL / SCHILD	P 0.5x65	1
11	30.9307-109	1	DRZAK / HOLDER / HALTER	HR 25x4	2
12	30.M201-005 (5)	2	DRZAK / HOLDER / HALTER	P 4x173	1
13	30.M201-006 (5)	2	DRZAK / HOLDER / HALTER	P 4x173	1
14	31.3199-005	0	SAMOLEPKA / STICKER / AUFKLEBER		1
15	92.001.069 (5)	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGGREGAT	FMV	1
16	99.900.040 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.043 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.047 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	99.900.048 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.049 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.053 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
22	99.900.055 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
23	99.900.056 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1
24	99.901.032 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNI SAMOLEPKA	1
25	99.901.070 (1)	0	SAMOLEPKA / STICKER / AUFKLEBER		1

1. DOPL.BEZPECNOSTNI STITKY- 1x99.900.040,1x99.900.043,1x99.900.046,1x99.900.047,1x99.900.048,1x99.900.049,1x99.900.053,1x99.900.055,1x99.900.056,1x31.3199-005,1xTYPOVY STITEK 31.1899-105. 324/ZM389 18.10.2007 SLEZACKOVA

2.DOPLNEN STITEK RYCHLOSTI PASU 30.0599-008. 367/ZM011 17.1.2008 SLEZACKOVA


3.PRID.CERTIFIKACNI SAMOLEPKA 99.901.032,ZRUS.VALEC 201.4807-000 A NAHR.201.4807-200. 071/ZM265 4.10.2010 SLEZACKOVA

4.PRIDAN KRYT PASU 30.1814-108. 071/ZM22 25.7.2012 SLEZACKOVA

5.ZRUS. PODSTAVEC 201.1801-000 NAHR.201.1801-600,ZRUS.OVL.PANEL+ROZVAD. 201.1814-020 NAHR.201.R230-300,ZRUS.CHLAZENI 201.1806-000,ZRUS.TYPOVY STITEK 31.1899-105 A NAHR.30.1899-002,PRID DRZAKK 30.1800--052,30.M201-005,30.M201-006. 095/ZM112 29.03.2013 MAJDIC

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednaci cislo/Purchase order number/Bestellnummer; Nazev polozky/Volume title/Name der Position; Rozmer/Stock size/Abmessung


7.3. Rameno / Arm / Arm



7.4. Kusovník / Stückliste / Piece list Rameno / Arm / Arm

Císlo Sestavy 201.4804-050		Ver. 5	Název sestavy RAMENO/SHOULDER/SÄGERAHMEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.1714-300	0	PANT / HINGE / TÜRBAND		1
2	201.1714-400	0	PANT / HINGE / TÜRBAND		1
3	201.4805-050	0	PREVODOVKA / TRANSMISSION / GETRIEBE		1
4	201.4808-000	3	NAPINANI / TENSIONING / SPANNUNG		1
5	201.4810-000	3	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
6	201.4814-400	0	KARTAC / BRUSH / BÜRSTE		1
7	30.0814-014	0	KLUZAK / GLIDER / GLEITER	HR 25x 30	1
8	30.0814-113	0	PLECH / PLATE / BLECH	P2-30	1
9	30.1804-002	2	KOLO HNACÍ / DRIVE WHEEL / ANTRIEBSRAD	ODLITEK	1
10	30.1804-010	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	d 70	1
11	30.1814-108 (5)	0	KRYT PASU / BELT COVER / BANDABDECKUNG		1
12	30.2904-059 (1)	0	VÍKO / COVER / DECKEL	250x20	1
13	30.4804-051	3	RAMENO / SHOULDER / SÄGERAHMEN		1
14	30.4814-102	3	KRYT NAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 1.5 - 556	1
15	30.4814-303	1	KRYT PASU / BELT COVER / BANDABDECKUNG		1
16	30.4814-309	0	KRYT KARTACKU / BRUSH COVER / BÜRSTENABDECKUNG		1
17	30.8404-055 (1)	0	ZATKA / PLUG / STOPFEN	150x100x5-8	1
18	30.8404-056 (4)	0	TYC ZAVITOVÁ / THREADED POLE / GEWINDESTANGE	M10	2
19	30.8504-060 (3)	0	VENTILATOR / VENTILATOR / VENTILATOR		1
20	30.8914-211	0	KRYT / COVER / ABDECKUNG	P 1.5 - 104	1
21	81.0804-005	0	KROUZEK / RING / RING	P 3-60	2
22	90.005.55.034	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X40	8
23	90.011.27.009	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M12X20	1
24	90.100.55.006 (4)	0	MATICE / NUT / MUTTER	MATICE - M10	6
25	90.150.50.007	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 13	8
26	90.151.50.002 (4)	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 12	2
27	90.300.02.010	0	KOLÍK VALCOVÝ KALENÝ / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLÍK 8X32	1
28	90.302.02.003	0	KOLÍK KUZELOVÝ / TAPER PIN / KEGELBOLZEN	KOLÍK 8X36	2
29	91.001.053	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	MĐERA 100-32pro	1
30	91.070.011	0	VÝVODKA / BUSHING / TÜLLE	M16x1.5	2
31	91.070.012	0	VÝVODKA / BUSHING / TÜLLE	M20x1.5	1
32	91.071.004	0	VÝVODKA / BUSHING / TÜLLE	VÝVODKA	1
33	91.071.005	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG		1
34	91.072.007	0	MATICE / NUT / MUTTER	MATICE	1
35	91.072.008	0	MATICE / NUT / MUTTER		1
36	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		1

7.5. Rameno / Arm / Arm



7.6. Kusovník / Stückliste / Piece list Rameno / Arm / Arm

Cislo Sestavy 201.4804-050		Ver. 5	Název sestavy RAMENO/SHOULDER/SÄGERAHMEN		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
37	91.173.012	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		1
38	94.204.002	0	DRŽÁK / HOLDER / HALTER		1
39	94.204.005	0	DRŽÁK / HOLDER / HALTER	LBG 14/14-PP	1
40	99.104.002 (3)	0	ZAMEK / LOCK / SCHLOSS	ZAMEK CÍNSKY	2

1. ZRUS. KRYT 30.4804-052 A NAHR. ZATKOU 30.8404-055, PRIDANO VIKO PREVODOVKY 30.2904-059. 351/ZM365 9.10.2007 SLEZACKOVA


2. ZRUS. KRYT PASU 30.4014-108 A NAHR. 30.1814-104. 439/ZM442 27.11.2007 SLEZACKOVA

3. PRIDAN VENTILATOR 30.8504-060., PRIDAN ZAMEK 99.104.002, DRŽÁKY 30.4807-092, 30.4807-091. 008/ZM008 23.1.2008 SLEZACKOVA

4. ZRUS. DRŽÁK 30.4807-092, 30.4807-091, PRID. 2xTYC ZAVITOVA 30.8404-056, 2xPODLOŽKA 12 (90.151.50.002), 6xMATICE M10 (90.100.55.006). 077/ZM100 17.4.2009 SLEZACKOVA

5. ZRUSEN KRYT PASU 30.1814-104 A NAHRAZEN 30.1814-108. 207/ZM220 15.7.2010 SLEZACKOVA

7.7. Svěrák / Schraubstock / Vice



7.8. Kusovník / Stückliste / Piece list Svěrák / Schraubstock / Vice

Císlo Sestavy 201.1803-000		Ver. 2	Název sestavy SVERAK/VICE/SCHRAUBSTOCK		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.1807-100	0	VALEC / ROLLER / ZYLINDER		1
2	30.0603-006 (2)	0	CELO / HEAD / STIRN	HR 150x 30	1
3	30.0803-004	0	LISTA SVERAKU / VICE TRIM / SCHRAUBSTOCKLEISTE	HR 20x 20	1
4	30.0803-005	0	DESKA / BOARD / PLATTE		2
5	30.1803-002	3	LISTA / TRIM / LEISTE	HR 50 x 20	2
6	30.1803-003	3	CELIST POHYBLIVA / MOVING JAW / BEWEGLICHE BACKE		1
7	30.1803-004	3	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	HR 50x 25	1
8	30.1803-005	1	DESKA / BOARD / PLATTE	HR 120 x 10	1
9	30.1803-006	0	CELIST POHYBLIVA / MOVING JAW / BEWEGLICHE BACKE	HR 200 x 20	1
10	30.1803-007	4	SVERAK / VICE / SCHRAUBSTOCK		1
11	90.001.25.029	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x12	1
12	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	3
13	90.001.25.047	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	20
14	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x35	4
15	90.001.25.060 (2)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x40	3
16	90.002.2D.012	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x16	2
17	90.151.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8	1
18	95.800.021	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNÝ KROUZEK 62	2

I. ZRUSENA DRZAK HADIC 94.204.005 NAHRAZENA V SESTAVE 201.1800-100 SOUCASTI 30.9307-109. 18.1.2006 SLEZACKOVA

2.VYMENA CEL - ZRUS.SOUC.30.0603-004 A NAHR. 30.0603-006.ZRUS.2xSROUB STAVECI M8x16 90.002.2D.012, 2xSROUB STAVECI M8x10 90.002.2D.011, PRIDAN SROUB IMBUS M12x40 90.001.25.060. 323/ZM366 2.10.2007 SLEZACKOVA


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;

Objednací číslo/Order number/Basis/Grundzahl; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

1. ZRUSENA DRZAK HADIC 94.204.005 NAHRAZENA V SESTAVE 201.1800-100 SOUCASTI 30.9307-109. 18.1.2006 SLEZACKOVA
2. VYMENA CEL - ZRUS.SOUC.30.0603-004 A NAHR. 30.0603-006,ZRUS.2xSROUB STAVECI M8x16 90.002.2D.012, 2xSROUB STAVECI M8x10 90.002.2D.011,
PRIDAN SROUB IMBUS M12x40 90.001.25.060. 323/ZM366 2.10.2007 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.9. Podstavec svěráku / Schraubstockuntersatz / Vice Base



NAZEV SESTAVY PODSTAVEC SVĚRÁKU	CÍSLO SESTAVY 001.1809-000	STROJ STG-440DGH
Konstruoval:		
Datum: 19. 01. 2010		
Meritko: 17:100		

7.10. Kusovník / Stückliste / Piece list


Podstavec svěráku / Schraubstockuntersatz / Vice Base

Cislo Sestavy 201.1809-000		Ver. 0	Nazev sestavy PODSTAVEC SVERAKU/VICE BASE/SCHRAUBSTOCKUNTERSATZ			
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks	
1	201.2903-100		DISPLEJ / DISPLAY / DISPLAY		1	
2	30.0809-002		VEDENI / GUIDE / BACKENFÜHRUNG	HR 150 x 30	1	
3	30.0809-003		DESKA / BOARD / PLATTE	ODLITEK	1	
4	30.0809-004		DESKA / BOARD / PLATTE	ODLITEK	1	
5	30.0809-010		PRILOZKA / STRAP / LASCHE	HR 30 x 25	2	
6	30.1809-002		CELIST PEVNA / SOLID JAW / FESTE BACKE	HR 245 x 25	1	
7	30.1809-003		CELIST PEVNA / SOLID JAW / FESTE BACKE	HR 250 x 25	1	
8	30.1809-004		KRYT / COVER / ABDECKUNG	P 0.5 - 500	1	
9	30.1809-005		KRYT / COVER / ABDECKUNG	P 05 - 500	1	
10	30.1809-101		STOJAN / STAND / STÄNDER		1	
11	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	4	
12	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X30	6	
13	90.001.25.049	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X35	4	
14	90.001.25.050	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X40	2	
15	90.001.25.054	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X60	2	
16	90.001.25.058	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X30	4	
17	90.001.25.065	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X80	4	
18	90.013.27.004	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5X12	4	

oz. - Pozice/Position/Position: Cislo vykresu/Drawing number/Zeichnungsnummer

Poz. - Pozice/Position/Position; Císlo vykresu/Drawing number/Zeichnungsnummer

7.11. Konzola otočná / Drehkonsole / Turnable console




NAZEV SESTAVY	CÍSLO SESTAVY	STROJ
KONZOLA OTOČNÁ	201.1802-000	STG 440DGH
Konstruoval:	8konstruoval	
Datum:	02. 06.2010	
Merítko:	1:5	

7.12. Kusovník / Stückliste / Piece list Konzola otočná / Drehkonsole / Turnable console

Císlo Sestavy 201.1802-000		Ver. 0	Název sestavy KONZOLA OTOČNA/TURNABLE CONSOL/DREHKONSOLE	
Poz.	Objednací číslo	Ver.	Název položky	Ks
1	201.0614-200	0	ODMEROVANI / MEASURING / GEHRUNGSMESSUNG	1
2	201.2902-200	0	SNIMAC / SENSOR / SENSOR	1
3	30.0702-004	0	DRŽAK / HOLDER / HALTER	1
4	30.0702-007 (1)	0	TYC / LEVER / HEBEL	1
5	30.0702-013	0	SROUB / BOLT / SCHRAUBE	1
6	30.0802-002	1	LOŽISKO / BEARING / LAGER	2
7	30.0802-004	1	VÍKO / COVER / DECKEL	1
8	30.0802-005	0	MATICE / NUT / MUTTER	1
9	30.0802-006	1	VÍKO / COVER / DECKEL	1
10	30.0802-010	2	CEP / LUG / BOLZEN	1
11	30.0802-011	0	CEP / LUG / BOLZEN	1
12	30.0802-013 (1)	0	PAKA / LEVER / HEBEL	1
13	30.0809-007	0	KOSTKA / CUBE / WÜFEL	1
14	30.0809-008	0	UPINKA / FASTENER / SPANWEISEN	1
15	30.0809-009	0	SROUB / BOLT / SCHRAUBE	1
16	30.2902-001	2	KONZOLA OTOČNA / TURNABLE CONSOL / DREHKONSOLE	1
17	30.2902-003	0	CEP / LUG / BOLZEN	1
18	30.2902-007	0	KOTOUC ODMEROVANI / MEASURING DISC / MESSSCHEIBE	1
19	30.2902-010	0	SEGMENT / SEGMENT / SEGMENT	1
20	30.2902-111	0	KRYT / COVER / ABDECKUNG	1
21	30.2902-112	0	DRŽAK / HOLDER / HALTER	2
22	90.001.25.003	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	2
23	90.001.25.033	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	3
24	90.001.25.034	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	6
25	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	1
26	90.001.25.055	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	1
27	90.001.25.064	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	4
28	90.001.25.105	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	16
29	90.005.55.050	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	1
30	90.100.55.005	0	MATICE / NUT / MUTTER	1
31	90.100.55.006	0	MATICE / NUT / MUTTER	1
32	90.100.55.009	0	MATICE / NUT / MUTTER	1
33	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	2
34	90.300.02.006	0	KOLÍK VALCOVÝ KALENÝ / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	2

7.13. Konzola otočná / Drehkonsole / Turnable console – 2




NAZEV SESTAVY KONZOLA OTOCNA	CISLO SESTAVY 201.1802-000	STUJ STG 440DGH
Konstruoval:	8konstruoval	
Datum:	02. 06. 2010	
Meritko:	1:5	

7.14. Kusovník / Stückliste / Piece list
Konzola otočná / Drehkonzole / Turnable konsole – 2

35	91.070.010	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG	M12x1.5 CERNÁ	1
36	94.004.502 (1)	0	RUKOJET / HANDLE / GRIFF	D22	1
37	95.001.005	0	LOŽISKO / BEARING / LAGER	6001 2RS	1
38	95.300.001	0	LOŽISKO KUZELIK / BEARING / LAGER	30312A	2
39	95.800.008	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 18	1
40	96.001.017	0	KROUZEK O STATICKY / STATIC O RING / O-RING STATISCH	60X3	1

I. ZRUSENA SOUCAST 30.0802-009 A NAHRAZENA 30.0802-013,ZRUS.AOUC.30.0702-005 A NAHR.30.0702-007,
ZRUS.SOUC.94.002.001 A NAHR.94.004.502. 167/ZM141 2.6.2010 SLEZACKOVA

7.15. Vedení pásu / Bandführung / Band guiding



7.16. Kusovník / Stückliste / Piece list
Vedení pásu / Bandführung / Band guiding

Cislo Sestavy 201.4810-000		Ver. 3	Nazev sestavy VEDENÍ PASU/BELT GUIDE/SÄGEBANDFÜHRUNG		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozmer	Ks
1	251.077	0	REGULACE PRITLAKU / PRESSURE REGULATION / SCHNITTDRUCKREGULATION		2
2	201.4810-200	1	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		1
3	201.6910-110	1	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		1
4	30.1804-901	0	PAS PÍLOVÝ 440 / SAW BELT / SÄGEBAND	34x1.1	1
5	30.1810-001	0	DRŽAK / HOLDER / HALTER		1
6	30.1810-002	0	DRŽAK / HOLDER / HALTER		1
7	30.1810-003	1	LISTA / TRIM / LEISTE	HR 90x20	1
8	30.1810-004	2	LISTA / TRIM / LEISTE	HR 30x10	1
9	30.1810-005	2	LISTA / TRIM / LEISTE	HR 30x10	1
10	30.1814-011	0	DRŽAK / HOLDER / HALTER	P 3- 76	2
11	30.1816-210	0	DRŽAK / HOLDER / HALTER	P 4x50	1
12	30.2016-006	0	DESKA / BOARD / PLATTE	HR 40x12	2
13	30.3510-004	0	TRUBKA / TUBE / ROHR	TR 8x 1	2
14	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X16	2
15	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	1
16	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	10
17	90.001.25.034	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	3
18	90.001.25.092	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X14	16
19	90.001.55.035	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X35	1
20	90.002.2D.018	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12X20	1
21	90.013.27.005	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5X16	4
22	90.150.50.007	0	PODLOZKA / WASHER / UNTERLEGSCHEIBE	PODLOZKA 13	2
23	90.302.07.001	0	KOLIK KUZELOVY / TAPER PIN / KEGELBOLZEN	KOLIK 6X36	4
24	90.303.07.021	0	KOLIK / PIN / BOLZEN	KOLIK 8X28	2
25	92.009.001	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG	24146	2
26	92.013.001	0	SROUBENI PRIME / DIRECT BOLTING / GERADE VERSCHRAUBUNG		4
27	92.014.001	0	KROUZEK TESNICI / SEAL RING / DICHTUNGSRING	372405	4
28	94.002.001	0	RUKOJET / HANDLE / GRIFF		1
29	94.008.003	0	PAKA UPINACI / ATTACHMENT LEVER / SPANNHEBEL	M8x40	2
30	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	4
31	94.204.001	0	DRŽAK / HOLDER / HALTER		2
32	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	2


I.DOPLNEN 2xKOLIK PRUZNÝ 8x28 90.303.07.021 . 344/ZM362 24.9.2007 SLEZACKOVA

2.ZRUS.KOSTKA 201.4810-100 A NAHR.KOSTKOU 201.6910-110. 142/ZM172 11.11.2009 SLEZACKOVA

1. DOPLNEN 2xKOLÍK PRUŽNÝ 8x28 90.303.02.021 . 344/ZM362 24.9.2007 SLEZACKOVA

2. ZRUS. KOSTKA 201.4810-100 A NAHR. KOSTKOU 201.6910-110. 142/ZM172 11.11.2009 SLEZACKOVA

7.17. Napínání / Spannung / Tensioning



NAZEV SESTAVY NAPÍNÁNÍ	ČÍSLO SESTAVY 201.4808-000	STROJ STG-440GA, DGH
Konstruoval: &konstruoval		
Datum: 18. 02.2010		
Meritko: 3:10		

7.18. Kusovník / Stückliste / Piece list Napínání / Spannung / Tensioning


Číslo Stavby 201.4808-000		Ver. 3	Název stavby NAPÍNÁNÍ / TENSIONING / SPANNUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0808-001	1	KOSTKA NAPÍNÁNÍ / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	80x30	1
2	30.0808-002	1	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLEISTE	30x20	2
3	30.0808-006	1	LISTA / TRIM / LEISTE	HR 30x10	2
4	30.1708-004	4	DRŽÁK / HOLDER / HALTER	HR 20x8	1
5	30.2908-001	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	d 50	1
6	30.2908-102	1	DRŽÁK / HOLDER / HALTER		1
7	30.3508-004	0	KROUZEK / RING / RING	d42	1
8	30.4008-001	1	SROUB / BOLT / SCHRAUBE		1
9	30.4808-101	3	CEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		1
10	30.4808-102	1	KOLO NAPÍNÁNÍ / TENSIONING WHEEL / UMLENKRAD	ODLITEK	1
11	30.4808-103	1	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	d 45	1
12	90.001.25.053	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x55	6
13	90.002.20.013	0	SROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x25	1
14	90.005.55.020	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x45	1
15	90.011.27.009	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M12x20	1
16	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
17	90.300.07.003	0	KOLÍK VALC. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLÍK 16x80	1
18	90.350.07.002	0	TALÍROVÁ PRUŽINA / DISC SPRING / TELLERFEDER	35,5x18,3x2,0x2,8	4
19	95.001.026	0	LOŽISKO / BEARING / LAGER	6307 2RS	2
20	95.800.014	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNÝ KROUZEK 35	1
21	95.801.013	0	KROUZEK POJIST.VNITR. / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 80	2

① ZMENA 30.1808-004 NA 30.4808-103, 1808-001 NA 4808-102, 1808-003 NA 4808-101, PRIDANA 1x 95801.013 14.5.2004 URICAR

2. DOPLNENA PODLOŽKA 30.2908-001, 3.12.04 STASTNY

3. ZRUSEN KALISEK 30.3508-002 A NAHRAZEN KALISKEM 30.2908-102. 076/ZM140 30.4.2008 SLEZACKOVA

7.19. Kostka vodící / Führungsklotz / Lead cube – 1




7.20. Kusovník / Stückliste / Piece list
Kostka vodící / Führungsklotz / Lead cube - 1

Císlo Sestavy 201.4810-200		Ver. 1	Název sestavy KOSTKA VODICI/LEAD CUBE/FÜHRUNGSKLOTZ		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1810-202	3	DRŽAK / HOLDER / HALTER	TYC 28	1
2	30.1810-203	0	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	TYC 80x50	1
3	30.C210-403	0	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
4	30.Y310-212	0	EXCENTR / CAM / EXCENTER	d 15	2
5	30.Y310-306	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
6	30.Y310-310	0	DRŽAK TVRDOKOVU / POA HOLDER / HW-HALTER		1
7	30.Y310-320	0	DRŽAK TVRDOKOVU / POA HOLDER / HW-HALTER		1
8	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
9	90.004.2D.002	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x12	1
10	90.005.55.017	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x30	1
11	90.011.27.017	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
12	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE - M8	1
13	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	2
14	90.150.50.006	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 10,5	2
15	90.301.02.009	0	KOLIK VALCOVY MEKKY / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLIK 10x26	1
16	90.350.02.005	0	PRUZINA TALIROVA / DISC SPRING / TELLERFEDER	20x10.2x1.1	7
17	95.001.004	0	LOZISKO / BEARING / LAGER	6000 2RS	1
18	95.001.014	0	LOZISKO / BEARING / LAGER	6200 2RS	4
19	95.800.002	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 8	1

1.ZRUS DRŽAK TVRDOKOVU 30.0810-005 A NAHR. 30.Y310-310,30.Y310-320,ZRUS.EXCENTR 30.0810-009,30.0810-010
A NAHR.30.Y310-212,ZRUS.KOSTKA 30.1810-201 A NAHR.30.1810-203,ZRUS.SOUC.30.0810-007,30.0810-103,30.0810-104,
90.001.55.082,90.011.27.022,PRID.SOUCASTI 30.C210-403,30.Y310-306,90.011.27.017,90.001.25.010,95.800.002.
ZM172 27.1.2010 SLEZACKOVA

1. ZRUS.DRŽAK TVRDOKOVU 30.0810-005 A NAHR. 30.Y310-310, 30.Y310-320, ZRUS.EXCENTR 30.0810-009, 30.0810-010
A NAHR. 30.Y310-212, ZRUS.KOSTKA 30.1810-201 A NAHR. 30.1810-203, ZRUS.SOUC. 30.0810-007, 30.0810-103, 30.0810-104,
90.001.55.082, 90.011.27.022, PRID.SOUCASTI 30.C210-403, 30.Y310-306, 90.011.27.017, 90.001.25.010, 95.800.002.
ZMI72 27.1.2010 SLEZACKOVA

7.21. Kostka vodící / Führungsklotz / Lead cube – 2




7.22. Kusovník / Stückliste / Piece list
Kostka vodící / Führungsklotz / Lead cube – 2

Cislo Sestavy 201.6910-110		Ver. 1	Nazev sestavy KOSTKA VODICI/LEAD CUBE/FÜHRUNGSKLOTZ		
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.1810-102	3	DRZAK / HOLDER / HALTER	TYC 28	1
2	30.6910-412	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
3	30.C210-403	0	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
4	30.Y310-212	0	EXCENTR / CAM / EXZENTER	d 15	2
5	30.Y310-310	0	DRZAK TVRDOKOVU / POA HOLDER / HM-HALTER		1
6	30.Y310-320	0	DRZAK TVRDOKOVU / POA HOLDER / HM-HALTER		1
7	30.Y310-401	2	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	1
8	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
9	90.004.20.002	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x12	1
10	90.005.55.017	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x30	1
11	90.011.27.017	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
12	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
13	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE _ M10	2
14	90.150.50.006	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 10,5	2
15	90.301.02.009	0	KOLIK VALCOVY MEKKY / CYLINDRICAL PIN SOFT / ZYLINDERSTIFT WEICH	KOLIK 10x26	1
16	90.350.02.005	0	PRUZINA TALIROVA / DISC SPRING / TELLERFEDER	20x10.2x1.1	6
17	95.001.004	0	LOZISKO / BEARING / LAGER	6000 2RS	1
18	95.001.014	0	LOZISKO / BEARING / LAGER	6200 2RS	4
19	95.800.002	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 8	1

1.ZRUS.KOSTKA 30.1810-121 A NAHR.KOSTKOU 30.Y310-401. 142/ZM172 11.11.2009 SLEZACKOVA

1. ZRUS. KOSTKA 30.1810-121 A NAHR. KOSTKOU 30.Y310-401. 142/ZM172 11.11.2009 SLEZACKOVA

7.23. Kartáček / Bürste / Brush




NAZEV SESTAVY KARTAC	CISLO SESTAVY 201.4814-400	STROJ STG 440DGH economic	Konstruoval: VINOHRADSKÝ
			Datum: 17. 02. 2010
			Meritko: 7:10

7.24. Kusovník / Stückliste / Piece list Kartáček / Bürste / Brush

Cislo Sestavy 201.4814-400		Ver. 0	Nazev sestavy KARTAC/BRUSH/BÜRSTE			
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks	
1	30.0814-204	0	KOLECKO / WHEEL / ROLLE	SESTAVA	1	
2	30.0814-207	0	KROUZEK / RING / RING	d 25	2	
3	30.4814-402	1	HRIDEL / SHAFT / WELLE	D 12	1	
4	30.9214-301	1	DRZAK / HOLDER / HALTER		1	
5	31.0305-211	0	PRUZINA / SPRING / FEDER	2x12x50x15,5	1	
6	31.0814-208	0	KARTAC / BRUSH / BÜRSTE		1	
7	31.1506-115	0	PRUZINA / SPRING / FEDER	1.6x12x25x7.5	2	
8	90.001.25.038	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X50	1	
9	90.001.25.040	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X60	2	
10	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1	
11	90.150.50.005	0	PODLOZKA / WASHER / UNTERLEGSCHEIBE	PODLOZKA 8,4	1	
12	95.001.005	0	LOZISKO / BEARING / LAGER	6001 2RS	2	

7.25. Ovládací panel / Bedienpult / Control panel



7.26. Kusovník / Stückliste / Piece list Ovládací panel / Bedienpult / Control panel

Císlo Sestavy 201.R230-300		Ver. I	Název sestavy OVLADACÍ PANEL/CONTROL PANEL/BEDIENPULT		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.6130-012	0	VÍKO / COVER / DECKEL	P 0.5x 30x30	2
2	30.6130-018	0	HLAVICE / HEAD / KOPF	VYLÍSEK	1
3	31.6130-008	0	HLAVICE / HEAD / KOPF		1
4	30.R230-010	0	MEZIKUS / INTERMEDIATE PIECE / PASSTÜCK	d 32	1
5	30.R230-201	3	SKRIN / BOX / KASTEN		1
6	30.R230-204	0	PLECH / PLATE / BLECH	P 1x220	1
7	30.R230-206	0	PLECH / PLATE / BLECH	P 1x220	1
8	30.R230-207	0	PANEL ELEKTRO / ELECTRO PANEL / PANEL	P 3x205	1
9	30.R230-208	0	DESKA / BOARD / PLATTE	P 3x150	1
10	31.R330-003	0	SKLO ORGANICKE / PLEXIGLASS / PLEXIGLAS	3x47.5	1
11	61.352.001	0	TESNENÍ / SEALING / DICHTUNG	TESNENÍ 19x10	1
12	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	4
13	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 6,4	4
14	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 10,5	2
15	91.060.030	0	HLAVICE TOTAL STOP / TOTAL STOP HEAD / TASTE TOTAL STOP		1
16	91.060.031	0	HLAVICE / HEAD / KOPF		1
17	91.060.035	0	HLAVICE / HEAD / KOPF		1
18	91.060.051	0	PREPINAC / SWITCH / UMSCHALTER		1
19	91.060.053	0	HLAVICE / HEAD / KOPF		1
20	91.071.005	0	PRŮCHODKA / LEADTHROUGH / DURCHFÜHRUNG		2
21	91.071.022	0	VÝVODKA / BUSHING / TÜLLE		1
22	91.072.008	0	MATICE / NUT / MUTTER		2
23	91.072.016	0	MATICE / NUT / MUTTER		1
24	91.170.003	0	SPINAC VÁKOVÝ / CAM SWITCH / SCHALTER	LE2-12-1763	1
25	91.180.001	0	DESKA SPINACE / ELECTRIC BOARD / PLATINE		1
26	91.283.015	0	POTENCIOMETR / POTENTIOMETER / POTENTIOMETER	TP 195 4K7/N 20A	1
27	92.002.103	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4" tr12	1
28	92.004.001	0	SROUBENÍ UHLOVE / ANGLE BOLTING / WINKELVERSCHRAUBUNG	37701	1
29	92.152.001	0	VENTIL SKRTICI / CHOKE VALVE / DROSSELVENTIL	VS01-04/R 2.5-0	1
30	96.082.002	0	TESNENÍ / SEALING / DICHTUNG	KROUZEK CU 13/17	1
31	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK ČINSKY	2
32	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
33	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
I.ZRUS.VÍKO 30.R230-203,PANEL 30.R230-202,2xČEP 30.7217-028,2XPOJ.KROUZEK 95.802.003 (PRIDANO DO SKRINE 30.R230-201).					
061/ZMI10 29.3.2012 SLEZÁČKOVÁ					

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Pos.)/Position/Position;
Objednací číslo/Order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

Podstavec / Untersatz / Base

Cislo Sestavy 201.1801-600		Ver. 2	Nazev sestavy PODSTAVEC / BASE / UNTERSATZ			
Poz.	Objednací číslo	Ver.	Nazev položky	Rozměr	Ks	
1	30.1801-201 (1)	1	PODSTAVEC / BASE / UNTERSATZ		1	
2	30.1801-602	1	DESKA / BOARD / PLATTE	SVARENEC	1	
3	30.1801-603	1	DRŽÁK / HOLDER / HALTER	SVARENEC	1	
4	30.M201-010	2	VANA / TANK / WANNE		1	
5	30.M301-020	0	SKLIZ / SLIDE / RUTSCH		1	
6	30.R201-056	1	VÍKO / COVER / DECKEL	P 4x100	1	
7	91.020.004	0	CERPADLO CHLÁZENÍ / COOLING PUMP / KÜHLMITTELPUMPE	230/400V	1	
8	91.070.012 (2)	0	VÝVODKA / BUSHING / TÜLLE		4	
9	91.071.022 (2)	0	VÝVODKA / BUSHING / TÜLLE		3	
10	91.072.012 (2)	0	MATICE / NUT / MUTTER		4	
11	91.072.016 (2)	0	MATICE / NUT / MUTTER		3	
12	91.074.013	0	UCPAVKA / PLUG / STOPFEN	M25x1,5	1	
13	94.101.039	0	ZASLEPKA / PLUG / BLINDFLANSCH	154x154x4	1	
14	95.800.016	0	SEGR HRDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUSSEN	POJISTNÝ KROUZEK 42	4	

1. ZRUSEN PODSTAVEC 30.1801-601 NAHRAZEN 30.1801-201. 084/ZMI70 11.6.2013 SLEZACKOVA

2. PRID.3xMATICE M50x1.5 91.072.016,3xVÝVODKA M50x1.5 91.071.022,1xVÝVODKA M20x1.5 91.070.012,1xMATICE M20x1.5 91.072.012 095/ZM264 1.11.2013 SLEZACKOVA




Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.27. Převodovka / Getriebe / Transmission

Cislo Sestavy 201.4805-050	Ver. 0	Nazev sestavy PREVODOVKA/TRANSMISSION /GETRIEBE			
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.1804-010	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	d 70	1
2	30.2904-002	0	PRIRUBA / FLANGE / FLANSCH	ODLITEK	1
3	30.2904-008	0	PERO / SPRING / FEDER	HR 12x8	1
4	30.4804-004	1	HRDEL / SHAFT / WELLE	d 65	1
5	30.4804-005	0	KROUZEK DISTANCNI / DISTANCE RING / DISTANZRING	TR 55x8	1
6	30.4804-006	0	PERO / SPRING / FEDER	HR 14x14	1
7	90.005.55.034	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X40	8
8	90.011.27.009	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M12X20	1
9	90.150.50.007	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 13	8
10	95.001.027	0	LOZISKO / BEARING / LAGER	6309 2RS	2
11	99.002.012	0	PREVODOVKA / TRANSMISSION / GETRIEBE	W110 U P100 B14	1

9 : 50

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednaci cislo/Purchase order number/Bestellnummer; Nazev polozky/Volume title/Name der Position; Rozmer/Stock size/Abmessung



Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.28. Chlazení / Kühlung / Cooling

Císlo Sestavy 201.1806-000		Ver. 1	Název sestavy CHLAZENÍ / COOLING / KÜHLUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1806-001	3	NADRŽ / CONTAINER / BEHÄLTER		1
2	30.1806-002	2	VÍKO / COVER / DECKEL	P 1.5x330x500	1
3	30.1806-003	0	VÍKO / COVER / DECKEL	P 1.5-330	1
4	91.020.004	0	CERPADLO CHLAZENÍ / COOLING PUMP / KÜHLMITTEL PUMPE	230/400V	1
5	94.202.005	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	3/4"-6	1

Exploded view diagram of a cooling unit assembly. The components are labeled as follows:

- 1: Rectangular container / tank.
- 2: Lid / cover for the container.
- 3: Circular opening / port on the lid.
- 4: Cooling pump assembly.
- 5: Pump adapter / reducer connecting the pump to the container.

