




Workline 410.280 GANC

Operating instructions

Before transporting and using the machine,
please read the instructions thoroughly!

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.05 / Apr. 2015
rev. 1

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

1) We

BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, The Czech Republic
Id.no: 48908827

declare herewith,

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government. In the event of any device modification not approved by us this declaration shall lose its validity.

Name: **Band Saw**

Type range: **Workline 410.280 GANC**

Serial number:

Manufacturer: **BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno**

Product data

Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics.

Description: stand, table, cutting unit with the saw band and drive, clamping device, cooling system, el. switch board with control panel.

Hydraulic YES ☒ NO ☐ Control system YES ☒ NO ☐

Technical data: Cutting rate 20–120 m.min⁻¹, from 0° to 60°
Total dimensions in mm (l×w×h) 2000×2430×1510
Supply voltage 400 V TN-C-S, TN-C
Total power requirement 4 kW, weight 1000 kg

The applied decrees of governments: **No. 176/2008 Coll.** (Directive 2006/42/EC)
No. 616/2006 Coll. (Directive 2004/108/EC)
No. 17/2003 Coll. (Directive 2006/95/EC)

The applied harmonized standards,

National standards and technical specifications: ČSN EN ISO 12100:2011, ČSN EN 13 898+A1:2009, ČSN EN ISO 13857:2008, ČSN EN ISO 4413:2011, ČSN EN 61000-6-2 ed. 2:2007, ČSN EN 61000-6-4:2002 ed.2:2007, ČSN EN 60204-1 ed.2:2007

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended

2) ²⁾ The declaration of conformity was carried out in the cooperation with the TUV SÜD Czech s.r.o., Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002

The inspection certificate no. 04.863.175 was issued.

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827

Alfred Pichlmann, Managing Director



Point of issue, datum

Name and function
of the responsible subject

Signature

1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)
2) The authorized or accredited body co-operating on the conformity judging



If the equipment is installed without safety equipment offered by BOMAR, spol. s r.o. or its agents and used by the customer (or buyer) then EC declaration loses validity.
EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.
All machine elements and components that were built into the device by BOMAR, spol. s r.o. have been declared "identical" to a safety device, as offered by BOMAR, spol. s r.o. or its agents.

Content

1. SAFETY NOTES.....	9
1.1. Machine determination	11
1.2. Protective suit and personal safety	11
1.3. Safety notes for machine operator	12
1.4. Safety notes for the servicing and repairs	13
1.5. Safety notes for the servicing and repairs on hydraulic unit	13
1.6. Safety machine accessories	14
1.6.1. Total Stop	14
1.6.2. Protective fencing	15
1.6.3. Arm covers	15
1.6.4. Band saw cover	16
1.6.5. Brush cover	16
1.6.6. Safety guidelines for laser sight line	16
1.7. Safety notes for the cooling	18
1.7.1. Instructions for first help	18
1.8. Umístění štítku stroje / Maschinenschild position / Position of machine label	19
1.9. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols	20
2. MACHINE DOCUMENTATION	21
2.1. Technická data / Technische Daten / Technical data	23
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram	26
2.3. Popis / Beschreibung / Description	27
2.4. Transportation and stocking	28
2.4.1. Conditions for transportation and stocking	28
2.4.2. Transport and stocking preparations	28
2.4.3. Transport and stocking	28
2.5. Transportní schéma / Transport schema / Transport schema	29
2.6. Activation	30
2.6.1. Machine working conditions	30
2.7. Band saw unpacking and assembling	30
2.7.1. Machine installing and levelling	32
2.7.2. Machine disposal after lifetime	32
2.7.3. First run of the power pack	32
2.7.4. Filling the reservoir with hydraulic oil	34
2.8. Kotevní plan / Verankerungsplan / Grounding plan	35
2.9. Electrical connection	36
2.9.1. Check the direction of the saw band	36
2.9.2. Check machine connection into electrical network	37
2.10. Filling of the cooling system	37
2.11. Check machine function	37
2.12. Saw band	38
2.12.1. Saw band size	38
2.12.2. Selection of the saw band tooth system	38
2.12.3. Saw band running-in	38
2.12.4. Tables for teeth selection	40
3. MACHINE CONTROL	41
3.1. Starting the band saw	43
3.2. Control panel	44
3.3. Machine referring	47
3.4. Machine control in manual mode	47
3.5. Machine control in automatic mode	48
3.5.1. Final cutting of material of short lengths at automatic cycle	52
3.5.2. Cycle breaking – automatic mode	53
3.6. Machine setup	53
3.6.1. SETUP	54
3.6.2. SERVIS (password)	55
3.7. Error messages	56
3.8. Band saw adjusting	57
3.8.1. Cutting speed adjusting	57
3.8.2. Speed adjustment of the arm lowering	57
3.8.3. Angular cut setting	57

3.8.4.	Electronic angular cut setting – optional accessories	58
3.8.5.	Saw frame upper stop position	61
3.8.6.	Saw frame lower stop position	63
3.8.7.	Adjusting band guides.....	63
3.8.8.	Brush adjustment.....	64
3.9.	Material insertion.....	64
3.9.1.	Handling agent selection	64
3.9.2.	Insertion.....	64
3.9.3.	Bundle material cutting	66
4.	MACHINE SERVICE.....	68
4.1.	Saw band dismantling.....	70
4.2.	Saw band instalation	70
4.3.	Saw band stretching and inspection.....	71
4.3.1.	Saw band stretching.....	73
4.3.2.	Saw band run adjustment on stretching wheel.....	73
4.3.3.	Saw band run inspection.....	73
4.3.4.	Saw band setting.....	74
4.3.5.	Adjusting of the limit switch of the saw band stretching	74
4.4.	Cooling agents and chips disposal	74
4.4.1.	Coolant device inspection	75
4.4.2.	Chips disposal.....	76
4.5.	Hydraulic, Greases and oils.....	76
4.5.1.	Gearbox oils	76
4.5.2.	Lubricant greases.....	78
4.5.3.	Lubrication.....	79
4.5.4.	Hydraulic oils.....	79
4.5.5.	Regulation of clamping pressure	81
4.5.6.	Hydraulic unit service.....	81
4.6.	Machine cleaning	83
4.7.	Worn pieces replacement.....	83
4.7.1.	Hard metal guides replacement.....	83
4.7.2.	Round brush replacement.....	84
4.7.3.	Saw band guiding rollers replacement.....	84
4.7.4.	Stretching wheel replacement.....	86
4.7.5.	Driving wheel replacement.....	89
4.7.6.	Replacing the coolant pump.....	91
5.	TROUBLESHOOTING.....	94
5.1.	Mechanical problems.....	96
5.2.	Electric problems.....	98
5.3.	Hydraulic problems	99
6.	SCHEMATICS.....	101
6.1.	Elektrické schéma / Elektroschema / Electric scheme – 3×400 V, PE+N, 50 Hz.....	103
6.2.	Elektrické schéma / Elektroschema / Electric scheme – 3×400 V, PE , 50 Hz.....	122
6.3.	Elektrické schéma / Elektroschema / Electric scheme – 3×230 V, PE , 50 Hz.....	142
6.4.	Hydraulické schéma / Hydraulikschema / Hydraulic diagram.....	162
7.	VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ/ ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER.....	165
7.1.	Workline 410.280 GANC	167
7.2.	Kusovník / Stückliste / Piece list – Workline 410.280 GANC.....	168
7.3.	Rameno / Sägerahmen / Saw arm 1.....	169
7.4.	Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 1.....	170
7.5.	Rameno / Sägerahmen / Saw arm 2.....	171
7.6.	Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 2.....	172
7.7.	Napínání / Spannung / Tensioning.....	173
7.8.	Kusovník / Stückliste / Piece list – Napínání / Spannung / Tensioning.....	174
7.9.	Vedení pásu / Sägebandführung / Belt guide	175
7.10.	Kusovník / Stückliste / Piece list – Vedení pásu / Sägebandführung / Belt guide.....	176
7.11.	Odměřování / Gehrungsmessung / Measuring	177
7.12.	Kusovník / Stückliste / Piece list – Odměřování/ Gehrungsmessung / Measuring.....	178
7.13.	Svěrák / Schraubstock / Vice	179
7.14.	Kusovník / Stückliste / Piece list – Svěrák / Schraubstock / Vice	180

7.15.	Svěrák / Schraubstockuntersatz / Vice base	181
7.16.	Kusovník / Stückliste / Piece list – Podstavec svěráku / Schraubstockuntersatz / Vice base.....	182
7.17.	Podavač / Vorschub / Feeder	183
7.18.	Kusovník / Stückliste / Piece list – Podavač / Vorschub / Feeder	184
7.19.	Podstavec / Untersatz / Base	185
7.20.	Kusovník / Stückliste / Piece list – Podstavec / Untersatz / Base	186
7.21.	Ovládací panel / Bedienpult / Control panel	187
7.22.	Kusovník / Stückliste / Piece list – Ovládací panel / Bedienpult / Control panel ..	188
7.23.	Válec zvedací / Hebezyylinder / Lifting cylinder	189
7.24.	Kusovník / Stückliste / Piece list – Válec zvedací / Hebezyylinder / Lifting cylinder	190
7.25.	Konzola otočná / Drehkonsole / Turnable console	191
7.26.	192	
7.27.	Kusovník / Stückliste / Piece list – Konzola otočná / Drehkonsole / Turnable console.....	192
7.28.	193	
7.29.	Plot / Zaun / Fence	193
7.30.	194	
7.31.	Kusovník / Stückliste / Piece list – Plot / Zaun / Fence	194
7.32.	Válec pomocný / Hilfszylinder / Auxiliary cylinder	195

1. **Safety notes**

The operating instructions must be read by the person, who keeps in touch with the machine before transportation, installation, using, servicing, reparation, stocking or removal!

Attention!

The operating instructions must be available at the machine! Keep the operating instructions in good condition!

The operating instructions include relevant information. The operator must familiarise himself with the install and operation, safety notes and machine servicing, because reliability and service life must be reached. The operating instructions must avoid risks, which are linked to work on the machine. Before transporting and using of the machine, please read the instructions thoroughly!

1.1. Machine determination

The band saw **Workline 410.280 GANC** is determined for cutting and shortening of rolled bars and drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **with cutting angle from 0° to 60°**.

Combustible materials are excluded for cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

Attention!

Consider the safety signs on the machine. Do not remove or damage them!

The machine is equipped with safety and protective guarding for operator and machine protection. Nevertheless, this safety and protective guarding cannot prevent injury. Service personnel must read this chapter and comprehend it, before he starts to work on the machine. **Always keep instructions about work safety!** Service personnel must take into account other aspects of the risk, which refer to the ambient conditions and the material.

1.2. Protective suit and personal safety

Wear tight fitting overalls! Loose fitting clothes may be caught with machine parts and cause serious injury.

Wear protective gloves! Material cuts and saw band have sharp edges and may

Attention!

Gloves you can use only at working material replacement (saw band)! The machine and accessories must be inactive! If the machine is running, you must not wear gloves! It is dangerous, because some parts of the machine can catch gloves!

cause serious injuries.

Wear protective shoes with non-skid soles! The unsuitable shoes may cause balance loss and following injury. Falling work pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protections! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

Attention!

*Machine can be operated by person older than 18 years!
Machine can be operated only person physically and mentally fit for this activity*

Keep instructions and orders about work safety!

Read the operating instructions, before you start to work on the machine! Keep the operating instructions in good condition!

1.3. Safety notes for machine operator

Machine can be operated only by one person. Machine operator is responsible for presence of other persons by the machine.

Close covers before the machine starting and check, if the covers are not damaged. Damaged covers must be repaired or changed. Do not start the machine, if the cover is removed! Check, if the electric cables are not damaged.

- Do not hold the material for clamping to the vice and for cutting!

Attention!

Do not connect the machine to electricity if the covers are removed. Do not touch the electrical equipment.

- Do not operate with the buttons and the switches on the control panel, when you have gloves!
- For machine starting take care, that there is nobody in the working area of the machine (it means in the working area of the vice, the saw band, the saw arm etc.).
- In no circumstances touch the rotating elements.
- Work on the machine only when the machine is in good condition!
- Check at least once in a shift, if the machine is not damaged. If the machine is damaged, you must bring the machine in order and you must inform your superior!
- Keep your working area clean! Ensure sufficient lighting in the working area.
- Take off the spilt water or the oil from the floor and dry it. Do not touch the cooling liquid with bare hands! Do not set the nozzle of the cooling liquid, when the machine is started on
- Do not remove the chips from the working area of the machine, when the machine is started on!
- Do not use the compressed air for the machine cleaning or for the chips removing!
- Use the protective instruments for chips removal!

Attention!

Only a qualified professional can carry out the servicing and repairs of the electric equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety! Otherwise, there is possibility of heavy injury!

1.4. Safety notes for the servicing and repairs

Switch off the main switch and lock it, before you start service work! Otherwise, there is possibility of hazardous machine starting.

Only qualified person can do the servicing and repairs. For parts changing, use only parts, which are identical with the originals. Otherwise, there is possibility of health hazard. Use only recommended type of the hydraulic oils and oils and lubricants!

Do not remove or do not lock the limit switches or safety equipments! Any use of the saw, accessories or machine parts other than that intended by the BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be afterward lost and BOMAR, spol. s r.o. takes no responsibility for caused damages.

1.5. Safety notes for the servicing and repairs on hydraulic unit

Compliance with the the principles of cleanliness is basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are products made with high accuracy, and any contamination leads to a reduction lifetime or even malfunction. The consequences are very difficult to remove and expensive.

Always use clean tools. Parts and fasteners, which are part of a hydraulic circuit, never put away the dirty surface. The best cleaning agent is crepe paper, because the fibers of the cleaning cloths can also cause malfunction.

Protective cap from the threaded chamber remove just before the assembly of the unit.

Hoses and pipes before mounting flush with gasoline or other cleaning agent and blow compressed air.

All fittings must be properly tightened. However, do not raw power.

1.6. Safety machine accessories

Enhanced risk!

Do not come into or intervene in the cutting area.

Otherwise, there is possibility of heavy injury.

The machine is equipped with safety accessories. It protects the operator from injuries and the machine before damage. The safety accessories are blocking accessories, emergency switches and covers. Check once in a week the function of the safety accessories. If the safety accessories are functionless, you must stop work and repair or change the safety accessories.

1.6.1. Total Stop

TOTAL STOP button is used for emergency switching – off the machine in case defect or health hazard. By pressing **TOTAL STOP** button is interrupted the supply of the electrical power.

If any damages or fault appears, immediately press TOTAL STOP button! Release the pressing button is possible by twisting of the upper part of the button.




1.6.2. Protective fencing

Protective fencing is used to prevent personal injury from moving parts.



Doors protective fencing are protected by a limit switch. If the limit switch is open, the machine shuts down ..



Terms of safety fencing:

0 ° - 15 ° , the automatic cutting cycle, the limit switch is closed, the rear doors are closed fence


15 ° - 60 ° , cutting in manual cycle limit switch is open, the rear doors are open fencing

Když bude obsluha řezat pod úhlem větším jak 15°, je nutné otevřít zadní dveře oplocení, aby bylo možné dosáhnout požadovaného natočení ramene. Pokud jsou dveře otevřeny, je funkce stroje omezena, svěrák je elektricky blokován a stroj nemůže pracovat v automatickém režimu. Plně funkční je pouze manuální (a nastavovací) režim.

When the operator is cut at an angle greater than 15 ° , it is necessary to open the back door fence in order to achieve the desired rotation of the arm. If the door is open, the function of the machine is limited, vice power is blocked and the machine can not operate in automatic mode. Fully functional only manual (and setup) mode

1.6.3. Arm covers

If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible to start in set mode.




Warning!

The band saw is stated to the operator, when the covers is closed! Limit switche on saw arm control if covers are open or not.

1.6.4. Band saw cover

It covers the visible area of the saw band from left guiding cube to the frame.



Never switch on the saw band driver if this cover is not mounted!

1.6.5. Brush cover


It covers the brush for saw blade.



Never switch on the saw band driver if this cover is not mounted!

1.6.6. Safety guidelines for laser sight line

In the vicinity of the feeding vice is situated near the laser, which is used to detect the presence of its material and its correct setup.



Near from laser bar is a safety sticker

The laser device is used for Class 1M.

Warning!

It is necessary to regularly check the patency of the laser beam on the sensor and after each shift laser cleaned from impurities (clean rag + spirit) due to properly functioning laser. Take care when cleaning the laser was scratched and

Attention!

- *When handling cooling agents always wear hazardous fluid-proof gloves!*
- *Wear protective goggles!*
- *Cooling liquid can get in contact with your eyes and may cause permanent severe injuries*

1.7. Safety notes for the cooling

1.7.1. Instructions for first help


1. Pull off and safely remove polluted, soaked clothing.
2. For breathing, go out in the fresh air or look for first aid treatment.
3. Wash with water or use crèmes for contact with the skin.
4. Flush with water for eyes and look for first aid treatment.
5. For swallowing, drink a lot of water and induce vomiting. Look for medical help.

- 1.8. Umístění štítku stroje /
Maschinenschild position /
Position of machine label




The label is placed on the arm of the machine.

1.9. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols



2. **Machine documentation**

2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:				
• Hmotnost / Gewicht / Weight	1000 kg			
Rozměry stroje / Maschinengröße / Machine size :				
• Délka / Länge / Lenght	2000 mm			
• Šířka / Breite / Width	2430 mm			
• Výška / Höhe / Height	1510 mm			
Elektrické vybavení / Elektrische Ausrüstung / Electical equipment:				
• Napájení / Versorgungsspannun / Supply voltage	~3 x 400 V, 50Hz, TN-C-S			
• Příkon / Gesamtschlusswert / Total Input	4 kW			
• Max.jištění / Max. Vorschaltsicherung / Max. Fuse	16 A			
• Krytí / Schutzart / Protection	IP 54			
Akustický tlak / Schalldruckpegel / Acoustic pressure:				
• Workline 410.280 GANC	L _{Aeqv} = 76,3 dB			
Pohon / Atrieb / Drive:				
• Typ / Typ / Type	TM90 4X B14-FT115			
• Napájení / Versorgungsspannung / Supply voltage	~3 x 400V, 50Hz			
• Výkon / Leistung / Output	2,2 kW			
• Jmenovité otáčky / Motornenndrehzahl / Nominal speed	1440 min ⁻¹			
Hydraulické zařízení / Hydraulikeinrichtung / Hydraulic equipment:				
• Typ / Typ / Type	PPM-AC0,13-PG11/61-1,6-TM20-CB03-FR			
• Výkon / Leistung / Output	4 MPa / 1,1 kW			
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:				
• Typ / Typ / Type	3-COA4-12 HP1			
• Obsah nádrže / Volumen vom Kühlmittel / Capacity	40 l			
Rozměr pásu / Sägebanddimension / Band size:				
3800×27x0,9mm				
Jeden Zdvih / Vorschublänge Einfachhub / One Upstroak:				
Jeden Zdvih –krátký kus /Vorschublänge Einfachhub –/ One Upstroak-short piece				
600 mm				
max. 550 mm				
Max. hmotnost podávaného materiálu / Materialmaximalgewicht / Material max. weight:				
2180 kg				
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:				
20–120 m/min.				
Řezné rozsahy / Schnittbereiche / Cutting size:				
				
0°	Ø280 mm	410×280 mm	410×280 mm	280×280 mm
45° R	Ø280 mm	310×150 mm	260×280 mm	270×270 mm
60° R	Ø210 mm	205×100 mm	175×280 mm	190×190 mm

Warning:

If the material detection device is installed on the machine then maximal workpiece height is 10 mm shorter

Level of acoustic pressure:


Equivalent level of acoustic pressure A (noise) at operator position are $L_{Aeqv}=76,3$ dB.

Mentioned values are levels of emission which doesn't have to represent safe levels.


Factors which influence real level of acoustic pressure on machine operator are:

working place characteristics, cut material, saw band. These factors have significantly influence on acoustic pressure.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Keep recommendations for the manufacturers for transportation and stocking! If the recommendations are not kept, damage can occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have license for it!
- Don't move under suspended loads! Fault in lifting device may cause serious injury.
- Keep a safe distance from the machine during the transport.
- Temperature of the air from **-25°C to 55°C**, for a *short term* (max. 24 hours) temperature of the air until 70°C
- Do not expose the machine to radiation (for example microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all blank surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.

Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.

Fix the stickers stating the minimum approximate machine weight to at least five well visible places.

2.4.3. Transport and stocking

Handle the machine only with the hand pallet truck or the forklift truck! Use the lifters of the truck according to the Transport schema.

Make sure that the hand pallet truck; the forklift truck have sufficient capacity. Use only shackles with appropriate capacity..

Make sure that the van or the trailer had sufficient capacity.

The machine must be properly secured during transport, to not tip over or fall from the transport vehicle.


Screw on the palette to the floor of the van or the trailer.

Be careful that the machine is not damaged during transportation.

It is forbidden to handle the machine any other way (for example by, lifting by the saw frame of the band saw), than it is written in this operating instructions, the machine can be damaged!

Store the machine only under the conditions specified in this manual to prevent damage to the machine

2.5. Transportní schéma /
Transport schema /
Transport schema



2.6. Activation

2.6.1. Machine working conditions

Keep the conditions of the manufacturer for machine operating! If recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At temperature air from **10°C to 40°C**, the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the extend from 30% to 95% (not concentrate). Altitude lower than 1000 metres.

Attention!

If the ambient temperature drops below 15 ° C is required before operating the machine to have switch on hydraulic unit around 10 minutes and then made several motion few times (for example, in manual mode) by all hydraulic cylinders. The reason is to heat hydraulic oil to the operating temperature for proper function of the pressure switches (and choke).

- Do not expose the machine to the radiation (for example microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.

2.7. Band saw unpacking and assembling

Attention!

Switch off the main switch and lock it, before you start assembly! Otherwise, there is possibility of hazardous machine starting.

Remove the packing from the machine and unpack all parts.

If the hydraulic unit is outside the machine (the machine only connected hoses and cables), it needs to be placed and mounted on a solid basis (floors, etc.). The mounting holes are used on the bottom (bases) of the tank.

Warning:



When transporting the machine may skew the ruler to adjust the height of the shoulder. Before you start using the machine, check the alignment of the rulers and the proper function of the limit switch in all positions.

2.7.1. Machine installing and levelling

Check the floor supporting capacity before machine installing. If the floor capacity does not agree with requirements, you must prepare the necessary base for the machine.

Minimal requirement:

machine weight – Workline 510.350 GANC – 1000 kg

+ weight of accessories

+ maximum weight of material

- The machine must be levelled at the horizontal position. All feet of the machine must touch with the floor after levelling
- The machine must be levelled by means of the calibrated spirit level. Spirit level is put on the vice area. Set the roller conveyors according to the spirit level.
- For machine levelling, take care that there is sufficient available space for operation, repair work, servicing of the machine and handling the material..
- The machine including appended parts and accessories must be visible from the place of operation.

2.7.2. Machine disposal after lifetime

Blown out all service fluids (cooling liquid, hydraulic oil) into designated reservoir. Dismantle machine into separate parts and dispose them in accordance with valid directives.

2.7.3. First run of the power pack

Before the first run check:

- The direction of the Pump, while run the power pack for max. 2seconds.
- The cooling fan of the motor has to rotate in the same direction as the arrow on the top of the motor cowl indicates.
- In case of wrong rotational direction, the electrical phase in the connection box is to be changed. This check is required after every disconnection from the power source
- Wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise
- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load
- test the electrical equipment
- during operation monitor measuring equipment, noise, height and temperature of oil in the tank

- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.7.4. Filling the reservoir with hydraulic oil

Oil regulations and recommendations of the manufacturer in the technical documentation (appendix) are to be carefully observed. For standard power packs we recommend the oiltype OH-HM32 (DIN 51524) of all known oil manufacturers.


Power packs have to be filled up with clean, pre-filtered oil! The purity of the hydraulic fluid must correspond to the class 10 NAS 1638 (reachable with filter $\beta_{=75}$)!

Filling from container, such as barrels, buckets, etc. is not recommended or permitted!

The maximum oil level will be shown on the upper marking at the dipstick or the sight level glass. Overfilling has to be prevent. The maximum filling rate of 15 l/min shouldn't be exceed.

Oil type	Kinematic viscosity ν in mm^2/s in relationship to the fluid temperatur					Freezing point
	0°C	20°C	40°C	60°C	80°C	°C
OH-HM 32	220	100	32	15	7	-40
OH-HV 32	180	67	32	17	11	-40

2.8. Kotevní plan / Verankerungsplan / Grounding plan



Kotvicí materiál / Verankerungsmaterial / Grounding material

- 6x Hmoždina / Dübel / Plug – $\varnothing 14$ mm
- Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 140 mm
- Šrouby / Schraube / Screws – M16x135

Šrouby podložit deskami o min. rozměrech P10x100x100
 Die Schrauben mit Platten mit Minimaldimensionen P10x100x100 unterlegen
 Screw must be bottomed with plates (min. dimensions P10x100x100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety.

2.9. Electrical connection

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V}$, 50 Hz, TN-C-S
- Total input / Max. fuse: 4 kW / 16 A

Note:

The values of the crosscut of the conductor and the rated current are in the norms.

Before connecting switch off the main switch of the power supply circuit for the machine and ensure dry place when doing connecting works!

Service voltage must agree with the line voltage! Crosscut of the supply line must respond with rated current for max. machine load.

Note:

The socket with the fork can be used only at the machines with the rated current less than 16 A and total input less than 3 kW.

Attention!

In this case the extra main switch becomes primary and the main switch on the machine has only secondary function.

In case the machine is connected with a direct connection, an extra main switch must be added which can be locked in zero position.

2.9.1. Check the direction of the saw band



After the machine has been successfully connected, briefly switch on the machine and put the driving engine of the band in the running position. The direction must be in accordance with the arrow direction on the saw band cover. In case the direction of the saw band does not match, two phases at the terminal strip must be switched.

2.9.2. Check machine connection into electrical network

2.10. Filling of the cooling system

Prepare the mixture of the water and the cooling liquid. Keep the concentration specified by manufacturer. Shift away the cover from the drainage hole. Fill the mixture of the water and the cooling liquid to the tank of the cooling system. Area of the tank for the cooling liquid is discovered from the chapter *Technical data*.

Note:

If machine is equipped with microniser, fill microniser with prescribed cooling liquid. This made the Microniser ready for use.

Let the drainage hole opened and with the sieve during operation, because it secures the right work of the cooling system. Filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and the tank does not overflowed.

2.11. Check machine function

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if covers are installed and functional. Check by means of the Tenzomat if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Values of the saw band stretching are on the Tenzomat. Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to other outer position. Raise the saw frame to the top position and drop the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for the operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are right, the machine is ready for operation..

Attention!

When you connect the machine to the electrical network observe correct connection of all phases!

ENGINE IN IN HYDRAULIC AGGREGATE CANNOT BE OPERATED WITH REVERSE TURNING MORE THEN 10 SECONDS!!!

2.12. Saw band

Refit the saw band cover only after you have installed and tightened the saw band.



2.12.1. Saw band size

3800×27x0,9mm

2.12.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth system. The important factor for selection of the tooth system is length of the cutting canal with respect to the size of the product

BOMAR recommended Variable tooth system for band saw.

1. *Constant tooth system* – the saw band has parallel tooth pitch all over length. This way is suitable for cutting of solid material.
2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cutting area.

In tables, there are advised type of the tooth system depending on sizes and form of the cutting material.

Footnotes:

Z_pZ – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:


32 S – number „32“ means 32 teeth on one inch (that means constant tooth system), letter „S“ marks teeth with zero angle of the tooth.

4–6 K – number „4–6“ means 4 till 6 teeth on one inch (that means variable tooth system); letter „K“ marks teeth with positive angle of the teeth.

2.12.3. Saw band running-in

Running-in: Cut the material with the frame lowering reduced to 50% only. When vibrations occur increase or decrease the band speed.















When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for 15 minutes approximately. When the band has been run, increase the lowering-speed to normal speed. The running in of the saw band avoids micro-breaks on the cutting edges of new saw band ensuing from first excessive stress. This would decrease service life substantially. The optimal running in of the saw band produces ideal rounded



Note: Run regrounding saw bands too.

cutting edges and therefore the conditions for an optimal service life.

2.12.4. Tables for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to $2 \times S$). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system (Z_pZ) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10–14 S	10–14 S
4	24 S	14 S	10–14 S	10–14 S	8–12 S	8–12 S
5	18 S	10–14 S	10–14 S	8–12 S	6–10 S	6–10 S
6	18 S	10–14 S	8–12 S	8–12 S	6–10 S	6–10 S
8	14 S	8–12 S	6–10 S	6–10 S	5–8 S	5–8 S
10	-	6–10 S	6–10 S	5–8 S	5–8 S	5–8 S
12	-	6–10 S	5–8 S	5–8 S	4–6 K	4–6 K
15	-	5–8 S	5–8 S	4–6 K	4–6 K	4–6 K
20	-	-	4–6 K	4–6 K	4–6 K	3–4 K
30	-	-	-	3–4 K	3–4 K	3–4 K
50	-	-	-	-	-	3–4 K
Size of the wall S [mm]	Tooth system (Z_pZ) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10–14 S	10–14 S	8–12 S	6–10 S	5–8 S	5–8 S
3	8–12 S	8–12 S	6–10 S	5–8 S	4–6 K	4–6 K
4	6–10 S	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K
5	6–10 S	5–8 S	4–6 K	4–6 K	4–6 K	3–4 K
6	5–8 S	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K
8	5–8 S	4–6 K	4–6 K	3–4 K	3–4 K	3–4 K
10	4–6 K	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K
12	4–6 K	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K
15	4–6 K	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K
20	3–4 K	3–4 K	2–3 K	2–3 K	2–3 K	2–3 K
30	3–4 K	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K
50	2–3 K	2–3 K	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K
75	-	2–3 K	1,4–2 K	1,4–2 K	1,4–2 K	0,75–1,25 K
100	-	-	1,4–2 K	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
150	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
200	-	-	-	0,75–1,25 K	0,75–1,25 K	0,75–1,25 K
SOLID MATERIAL ($D = \text{mm}$)						
						
Constant tooth system		Variable tooth system				
length of the cut D	tooth system (Z_pZ)	length of the cut D	tooth system (Z_pZ)			
to 3 mm	32	to 30 mm	10–14			
to 6 mm	24	20–50 mm	8–12			
to 10 mm	18	25–60 mm	6–10			
to 15 mm	14	35–80 mm	5–8			
15–30 mm	10	50–100 mm	4–6			
30–50 mm	8	70–120 mm	4–5			
50–80 mm	6	80–150 mm	3–4			
80–120 mm	4	120–350 mm	2–3			
120–200 mm	3	250–600 mm	1,4–2			
200–400 mm	2	500–3000 mm	0,75–1,25			
300–800 mm	1,25					
700–3000 mm	0,75					

3. **Machine control**

3.1. Starting the band saw


- » • Switch on the main switch of the band saw. The main switch is placed on the switchboard side.




- Refer the machine

3.2. Control panel

Ovládání stroje
Bedienung der Maschine
Machine control




1	LCD LCD displays status information and menu.
2	Control keys / numeric keypad.
	Feeder movement Pressing and holding button move with feeder to and from the machine (in manual mode)
	Open/Clamp feeder vice Pressing and holding button open or clamp feeder vice in manual mode.
	Open/Clamp main vice Pressing and holding button open or clamp full stroke vice in manual mode.
	Cooling system selection Top – Cooling with Microniser (optional accessories) Below – Cooling is switched on (even when the drive is not running).
	Move saw frame up/down Pressing and holding buttons rises or drops saw frame. As you move down, you can activate the rapid moving by pressing F1 button simultaneously with
	no function
	Turn on / off saw blade Button with symbol „I“ turn on saw blade drive, button with symbol „0“ turn off saw blade.
	Turn on /off hydraulic circuit Button with symbol „I“ turn on hydraulic circuit, button with symbol „0“ turn off hydraulic circuit. The hydraulic circuit is automatically switched on when needed.
3	Safety circuit Switch on the safety circuit by pressing button.
4	Start cycle After pressing the button will start the cutting cycle. To turn off when you press the STOP


5	Selecting a mode machines  pro manuální režim  for automatic mode
6	STOP button interrupts the cycle
7	Button TOTAL - STOP In emergency cases, the state machine immediately to rest
8	Frequency converter Turn to change the blade rotation speed in the range of 20-120 m / min.
9	Governing valve Adjust the speed of the arm sinking to the cut by governing valve. ATTENTION! If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.3. Machine referring


Before using the saw, you must refer machine. Referring is necessary for correct positioning of the saw feeders.



If the machine is not referred, it is not possible to move the feeder and on the LCD instead of a numeric value text REF.




Operator is informed that the machine is not referred after machine start. For machine referring switch into automatic mode. Then START button begin flash. Press START button for begin referring process. After this process press F4 to confirm.



3.4. Machine control in manual mode

- Switch machine into manual mode – key switch on control panel on .



- The LCD displays the following menu, where is information about the selected cutting speed.

- All movements are controlled by an operator using the control panel, see chapter Control panel.
- Manual mode serves primary for material loading into machine

Procedure for material loading before automatic cycle:

1. Before material insertion, open both vices into maximal to the position what is needed to insert material open.

Attention!

Feeder vice must be clamped before main vice.


2. Clamp material with both vices.
3. Switch the machine in automatic mode and follow the procedure for the automatic cycle.

3.5. Machine control in automatic mode

Attention!

Before the automatic cycle, the material must be clamped with both vices.

1. Switch machine into automatic mode – key switch on control panel on .



2. The LCD displays the following menu. The Preselect indicates the current program. The system can store up to 20 programs, move between them using the F1 and F4. F2 key (M +) saves all program values in the system. Press button F3 (Finish) on program what will be performed first in automatic mode.




3. After entering the programs values and after F3 (Finish), the operator is asked to perform trim cut. F4 not perform trim cut.







4. If the operator chose the trim cut on LCD is info about the progress. After the completion of trim cut, confirm by button F4.



5. Now begins the automatic cycle. It begins by pressing the START button. The work cycle begins on the program, where was editing completed by button F3 (END) and ends on the last non-zero program. *Example: I edited program no. 2 last time (F3 was pushed on program no.2), program no. 3 and 4 has correct values, programs no. 5, and more are empty. Control system loads program no. 2 then program no. 3 and last performed program is no. 4.*



6. The operator is informed about the automatic cycle on the LCD.



7. After completing automatic cycle, operator may enter new values for the next cycle (F4).



8. If the automatic cycle has finished and there is no material available for another cut, information on the material missing appears on the LCD.

9. To load the material, it is necessary to turn the mode switch (key) on the control panel to the manual mode position  and load the material in the manual mode by the above described procedure.
10. To proceed to the automatic mode after manual load-in, it is necessary to turn the mode switch (key) on the control panel back to the automatic mode position. 



11. The LCD shows information that the automatic cycle has been interrupted.


On this screen, you can choose

- F1 to enter another new automatic cycle
- or F4 to proceed with the automatic cycle entered.



12. If F4 is selected – the automatic cycle entered continues – a screen appears with the menu of how to start the cutting cycle:

- by pushing the **"Start"** button on the control panel, you choose beginning of the cutting cycle **with material cut-in**;
- **F4** is a choice of starting the cutting cycle **without material cut-in**.



13. If the operator has chosen material cut-in, the LCD shows information on its course; subsequently, after the cut-in has been completed, the operator is asked to confirm it by pushing the F4 button.

Further steps are identical with the above described steps No. 5, 6, 7.

3.5.1. Final cutting of material of short lengths at automatic cycle

If material with very short lengths is cut the end of the material is located behind the laser barrier at the feeder. The laser barrier can't detect the end of the material.

The machine reports "No material" and it is impossible to run the machine.

Thus it is necessary to cover the laser barrier by the shutter installed at the machine.

Then machine control can go in a standard way.



It is necessary to lift the shutter after final cut.




3.5.2. Cycle breaking – automatic mode

- »
- **STOP button**
Semi-automatic cycle is interrupted by pressing button **5 – STOP** of the cycle
The arm stops fall into cut and saw blade is stopped.
By pressing button **4 – START of the working cycle**, you can start the cycle.
 - **TOTAL STOP button**
In case of the risk, press button **TOTAL STOP**.
After pressing **TOTAL STOP** button, saw band drive is immediately broken and the arm sinking is stopped.
 - **Reactivation**
 4. Turn button **TOTAL STOP** according to the arrows (on the button).
 5. Lift saw arm above cut material and push **START** button.

3.6. Machine setup

Setup mode is activated by switching mode selection switch to position 0. After the switch is in position 0 on LCD is displayed:




Parameters in the menu SERVICE are password protected. The parameters in the SETUP menu are common and are not password protected.

Password:





947

3.6.1. SETUP

on LCD	Description
Switch off motor: * Up. position Down position <ESC> > F1 F2 F3 F4	Turn off saw blade drive after cut: - Up. position – saw blade lifts after cut and saw blade drive is turned off above material. - Down position – saw blade drive is turned off immediately after cut. - F1 back, F4 next option
Cooling: * Not use With bandsaw motor < > F1 F2 F3 F4	Cooling - Do not use – cooling is off, suitable for cutting special materials such as cast iron - With saw blade engine – when the blade is running, also cooling pump is running. - F1 back, F4 next option
Swarf conveyer: * Not use With bandsaw motor < Complete cycle > F1 F2 F3 F4	Swarf conveyer (optional accessories) - Do not use swarf conveyer - With band saw motor – when the blade is running, also swarf conveyer is running. - F1 back, F4 next option
Switch off hydraulic: * 5 min 30 min < don't switch off > F1 F2 F3 F4	Switch of time for hydraulic unit: 5 min. – 30 min. – do not turn off - F1 back, F4 next option
Piece cut of correction: 1.5 mm < <OK> > F1 F2 F3 F4	Piece cut off - The settings for the proper cut lengths in automatic mode - Saw blade thickness - F1 back, F4 next option
Language HMI: Cesky * English < Deutsch > F1 F2 F3 F4	Language: - Choose control menu language - F1 back, F4 next option
SPEED DISPLAYING: * m/min ft/min < > F1 F2 F3 F4	Units for saw blade speed - m/min or ft/min - restart machine to apply change - F1 back, F4 next option

on LCD	Description
	Units for lengths • mm or inches • restart machine to apply change • F1 back, F4 next option

3.6.2. SERVIS (password)

on LCD	Description
	• Feed length – Specifies the length of the feeder. Do not change parameter – is set from the factory. • F1 back, F4 next option, F2 save current option
	• Speed correction – could be set in range 0–250, displayed constant is for the calculation belt speed from the analog input. • F1 back, F4 next option, F2 save current option
	• ELGO – feeder position admeasurement. Do not change! • For service purposes. Displays a variable number of linear pulse measurements • F1 back, F4 next option, F2 save current option
	• Laser deviation • The laser is placed behind the feeder vise jaws • The value affects multiple feeding. Do not change! • F1 back, F4 next option, F2 save current option
	• Opening time for main vice. • Opening time is in milliseconds. • F1 back, F4 next option, F2 save current option
	• Opening time for feeding vice • Opening time is in milliseconds. • F1 back, F4 next option, F2 save current option

If you choose to change the keyboard units from "inch" to "mm", there is no automatic conversion of constants in machine setup „Servis“ and „Setup“.

It is necessary to calculate by the formula: 1 inch=25,4 mm a 3,28 ft/min=1m/min.

It is necessary to calculate these values:



Machine setup „Servis“:

- Piece cut of correction (when calculating the unit "inch" rounded to 1 decimal place = 0.0 inch)

Machine setup „Setup“:

- Feeder length (when calculating the unit "inch" it has to be rounded to 1 decimal place = 0.0 inch)
- Speed correction (when calculating the unit "inch" it has to be rounded to 1 decimal place = 0.0 inch)
- Divergence of laser (when calculating the unit "inch" it has to be rounded to 3 decimal places = 0.000 inch)
- Feeding correction (when calculating the unit "inch" it has to be rounded to 3 decimal places = 0.000 inch)

3.7. Error messages

Error	Description
 The screen displays a blue box with the text "SAFETY BUTTON is OFF". Below the box are four buttons labeled F1, F2, F3, and F4, each with a yellow triangle in the bottom-left corner.	The safety circuit is not turned on (pos. 2 on control panel). Push safety circuit button (on pos. no. 2 on control panel) to remove error message.
 The screen displays a blue box with the text "TOTALSTOP pressed". Below the box are four buttons labeled F1, F2, F3, and F4, each with a yellow triangle in the bottom-left corner.	Total Stop button is active – pushed. Turn TOTAL STOP button by the arrows, and disable it. Press F4 to confirm the disorder.
 The screen displays a blue box with the text "Blade tension faulty". Below the box are four buttons labeled F1, F2, F3, and F4, each with a yellow triangle in the bottom-left corner.	Saw belt not is properly tensioned. Remove the fault and press F4 to confirm.
 The screen displays a blue box with the text "Faulty motor protec.". Below the box are four buttons labeled F1, F2, F3, and F4, each with a yellow triangle in the bottom-left corner.	Motor overload, thermal protection is activated. Do not overload blade engine! Remove the fault and press F4 to confirm.

3.8. Band saw adjusting

3.8.1. Cutting speed adjusting

Speed of the saw band is possible change from **20 to 120 m/min**. You can effect to adjusting speed of the saw band following.



Use the frequency convertor to adjust requested speed of the saw band. You can see the speed on display..

3.8.2. Speed adjustment of the arm lowering

Band saw is equipped with cutting pressure regulation at one (fixed) lead cube.

Set the speed of the arm lowering to the cut by control valve for Cutting pressure regulation



- Set the lower speed of the arm lowering to the cut by turning the switch clockwise.
- Set the higher speed of the arm lowering to the cut by turning the switch anti-clockwise.


Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.8.3. Angular cut setting



1. Release securing lever of the console, Swivel the frame to the desired angle by pulling the saw arm. Angle is shown on scale. a páku znovu utáhněte. Then re-tighten the lever.
2. According to the cutting angle is needed to move the vice. For cutting angle less than 0° move vice to the right, for cutting angle more than 0° move vice to the left.



Attention!

Moving parts of the vice must be moved when saw arm has zero angle of rotation and closed vice jaws.

Moving vice jaw of vice must be in endmost position otherwise there is a danger of collision saw arm with vice.

3.8.4. Electronic angular cut setting – optional accessories

Desired cutting angle is shown on LCD. How to use electronic admeasurement is described in special instruction manual.

Intended for applications with frequent mitre cuts

The digital indicator of the arm turning angle prevents possible mistakes caused by inaccurate reading of an angle on the scale, and increases the speed of preparation for cutting. In connection with LaserLine, the digital indicator will make every band saw the most effective tool for mitre cuts.

A large, easy to read display and accurate measuring of the arm position with a magnetic tape allow the angle to be set with the maximum accuracy.

The measuring unit is set by the manufacturer. However, its further functions may be easily controlled with four keys.






Zero position setting

1. Turn the saw arm to a zero angle position.



2. Push the Incr/Abs key (even several times) until "0" is shown on the display.



Digital measuring adjustment

Position	Description
1	Current position
2	Unit, measuring mode
3	Active additional constant (* key)
4	Battery status
5	Reference record shall be made – after the apparatus is switched on.

Description of key functions:

Key	Stop mode	Setting mode
	Basic key	Entering parameters (3 sec) Saving parameters and returning (3 sec)
	Reference recording (P09 value)	-

Key	Stop mode	Setting mode
	Change of displaying in inches	Selection of following decade
	Absolute and incremental measuring	Change of active decade o +1
	Selection of additional constant	Change of sign ·

Description of key functions at measuring initialisation:

Key	Description
	Induces calibration of the apparatus when it is switched on (battery inserted).
	Induces calibration of the apparatus and sets default values when the apparatus is switched on.

Description of digital measuring parameters:

Parameter	Description	Default value
P01 A	Measuring configuration: A = 0: positive direction of measuring A = 1: negative direction of measuring	0
P02 A	Measuring unit: A = 0: mm / symbol "mm" A = 1: inch / symbol "Inch" A = 2: mm / symbol "m" A = 3: mm / symbol "o" A = 4: mm / no symbol	0
P03 A	Decimal point (0...4) > only for mm	2
P05 ABC	Key blocking: A: "Set" key (0 = active / 1 = inactive) B: "Incr/Abs" key (0 = active / 1 = inactive) C: "*/+/-" key (0 = active / 1 = inactive)	000
P08	Correction factor (0.0001...9.9999)	1.0000
P09	Reference (-9999999 ... +9999999)	0
P10	Additional constant 1 (-9999999 ... +9999999)	0
P11	Additional constant 2 (-9999999 ... +9999999)	0
P12	Additional constant 3 (-9999999 ... +9999999)	0

Parameter	Description	Default value
P13 A	Configuration of additional constants (0...3) A = 0: inactive (cannot be selected) A = 1: Additional constant 1 active A = 2: Additional constants 1 & 2 active A = 3: Additional constants 1 & 2 & 3 active	3
P90	No function	0
P99	Displaying firmware version	x.xx

3.8.5. Saw frame upper stop position


Arm Position is monitored by a limit switch.

If you want to shorten the time of operations in automatic cycle, you have to adjust the height of the saw arm according to the height of the cutting material.



1. Insert a material into the vice
2. Press button **Arm up**  and lift the saw arm to the upper position.
3. Carefully lower the saw arm button **Arm up**  to the material (or **+ F1** for **rapid move**). About 5-10 mm above the material stop 
4. Adjust arm height to the height of the material so that the top of the adjustable eccentric with a scale showing the desired value (the value corresponds to the height of the eccentric material)
3. Press **START** to begin the cutting process.


Setting the upper position of the arm using incrementa sensor (optional accessories):



1. Insert a material into the vice
2. Press button **Arm up**  and lift the saw arm to the upper position.
3. Carefully lower the saw arm button **Arm up**  to the material (or **+ F1** for **rapid move**). About 5-10 mm above the material stop 
4. In the case of the upper arm with the position incremental sensor is set, the on-screen control panel message that the upper arm position is adjusted.
5. Press **START** to begin the cutting process.
6. Sawband cuts material to the bottom position of arm and return to the top position of the arm, the arm that was before the work - before pressing **START**

3.8.6. Saw frame lower stop position

The lower stop limits the lowest position of the saw frame. This stop point has to be checked at least once a month. If the lower stop point is incorrectly adjusted, the cutting table can be damaged or the material will not be cut completely.



It is oriented so that the angle of the arm, possibly cutting band saws angle is 0.5° in the lower position.

The lower position of the arm can be adjusted with an imbus screw.

Limit switch is set by the manufacturer is not necessary to set it.

3.8.7. Adjusting band guides


If you want to achieve a smooth and precise cut, it is helpful to position the guide cube as close as possible to the material.



1. Release the stopping lever of the listel. Move the left part of the guide so that the left edge of the guide blocks is as close as possible cutted material.
2. Lower the frame to the lower position and check the position of the guide cube towards vice loading area. The guide cube must be a distance of at least 10 mm from the vice loading area.
3. Tighten the lever of the gib and check the guide cube setting once more for possible collision with binding table or vice jaw.

3.8.8. Brush adjustment

The brush for chip removal from the saw band influences cutting durability saw band lifetime and wheels lifetime, hard metal guides and finally the cut accuracy. Brush adjustment must be checked every shift.



1. Release the fixative screw of the brush. It is possible to move with the brush.
2. Set the brush to the saw band according to the picture.

Attention!

*The brush **must not** touch the bottom of the saw teeth!*

3. Tighten the fixative screw.
4. In case, that the brush is not turned right (driving wheel slips on the driving wheels of the saw band), push by means of the screw (see arrow) driving wheel of the brush to the driving wheel of the saw band.

Attention!

*The screw **must not** be tightened with heavy force, because driving wheel of the brush can be damaged or the lifetime of the bearings of the driving wheel of the band can be lowered!*


3.9. Material insertion

- Never walk under a suspended load!
- Never climb onto the gravity-roller conveyor!
- Do not hold the material for clamping material to the vice! The vice can cause injury!

3.9.1. Handling agent selection

- Use the strong handling agents to lift and transfer the material!
- Handle with the material only with the lift truck or use the suspension strands and the crane!
- Do not use the lift truck or crane in case that you do not have the license to handle with it!

3.9.2. Insertion



Insert material to the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you cut long pieces of the material (for example rod, tube), you must use the roller conveyors for material shifting to the band saw. Contact Bomar for more information about roller conveyors

Make sure the conveyor is long enough and the material cannot tip off the conveyor.

Be especially careful with round materials that it always stays on two vertical rollers and that it cannot fall off the conveyor!

When cutting short pieces to be used roller support, not to fall off the track.

Length submission is then limited = 550 mm (one stroke short piece)




3.9.3. Bundle material cutting


Attention:

Manual bundle clamping device is not standard equipment. Without this device is a not possible cut bundle.

If you want to cut the material in the bundle, there are suggestions for the positioning of bundles



Round material bundle: Take care especially with round material that the bars are put according to the picture. If the bars are put differently, you may have problems with movement.




Always weld the material at the rear end of the bundle to secure it from moving.

Before welding always, switch the machine off at the main switch! The magnetic fields, which often occur during welding, may damage the controls!

Attention:

Not all material shapes are suitable for bundle cuts. Keep the recommendation of your supplier of the saw bands for material insertion to the bundle.

In order to keep the cut material better in a vice, we recommend using hydraulic bundles material that does not belong to the standard equipment of the machine, but is an optional accessory. It is particularly suitable when cutting uneven material.



4. **Machine service**

4.1. Saw band dismantling

During the dismantling, take care that you do not damage the limit switch if the saw band stretching.

1. Lift the saw frame to the top position. Stop the saw frame in top position by control valve.



2. Dismantle yellow protective cover of the saw band. The cover is clamped with two screws.



3. Open the cover of the arm.
4. Turn by stretching star to the left side, release saw band stretching and pull saw band from blade wheels.



5. Pull up the saw band from the guiding cubes

4.2. Saw band instalation

During the installation, take care that you do not damage the limit switch if the saw band stretching!

1. Prior to installation, clean all track wheels, guide cubes and inner side of the arm thoroughly of all traces of chips and dirt. ***Keep in mind the teeth direction when installing the saw band.***



2. Insert new saw band in the guide cubes. Make sure the saw band runs between both guide rollers and it is pushed all the way to the top.



3. Put the saw band on both guide wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Then push the saw band as far back as possible.
4. By turning the stretching star to the right, you will stretch the saw band slightly. Remove the plastic cover of the saw band teeth.
5. Close the cover of the arm.



6. Install the yellow protective cover of the band. The arrow on the cover must match the direction of the arrow on the band. If it does not, you must turn the band round.

4.3. Saw band stretching and inspection

Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer.

Pilový pás Sägeband Saw band	Napětí pilového pásu Sägebandspannung Blade tension	Napětí pilového pásu PSI (pro Tenzomat) Sägebandspannung PSI (für Tenzomat) Blade tension PSI (for Tenzomat)
20 x 0,9 mm	160 N.mm ⁻²	23 500
27 x 0,9 mm	180 N.mm ⁻²	26 500
34 x 1,1 mm	210 N.mm ⁻²	30 500
41 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,3 mm	240 N.mm ⁻²	35 000
54 x 1,6 mm	280 N.mm ⁻²	40 600
67 x 1,6 mm	290 N.mm ⁻²	42 000
80 x 1,6 mm	300 N.mm ⁻²	43 500

4.3.1. Saw band stretching

- Switch on the hydraulic aggregate after the saw band installation check the saw band stretching on the Hydraulic blade tension indicator (optional accessories).



- Use the screw to stretch the saw band until it is stretched to the recommended value.



4.3.2. Saw band run adjustment on stretching wheel

Saw band run on the stretching wheel must be regularly inspected. The inspection has to follow every saw band replacement.

4.3.3. Saw band run inspection

If the run is not correct, the following problems may occur:

- **The saw band falls from the wheels** – The saw band and protective cover can be damaged.
 - **The saw band runs on the wheel rim** – The saw band and wheel rim can be damaged
1. Start and stop saw band drive.
 2. Stop the main switch!
 3. Open rear cover of the saw frame.



4. Check saw band placing on the wheels.
 - If the distance of the rear part of the saw band from wheel rim is 1 – 3 mm, setting is right.
 - If the distance is bigger than 3 mm, or the saw band runs on the wheel rim, saw band run must be set.

4.3.4. Saw band setting

The saw band run is set with screw in the stretching cube on the saw frame. Optimal distance has been determined at **1 – 3 mm**.

- Turn by screw to the right, the saw band approximates to the stretching wheel rim.
- Turn by screw to the left, the saw band departs from the stretching wheel rim.

Check saw band run again after setting.

4.3.5. Adjusting of the limit switch of the saw band stretching



After the saw band is replaced, the saw band stretching must be checked. If the limit switch is not adjusted correctly, the band is stretched too little or too much.

- Tighten the saw band on the optimal value
- If the drive engine is switched on, but it is not running, turn with the screw clockwise, until the engine begins run..
- If the drive engine is possible switched on, turn with the screw anticlockwise, until the engine is stopped and then turn with the screw clockwise, until the engine begins run.

4.4. Cooling agents and chips disposal

The quality of the cooling agent will deteriorate due to:

If the solution is too weak:

If the solution is too strong:

- use of contaminated water
- impurity
- outside oil contamination (hydraulics, gears)
- high operating temperatures
- lack of air circulation
- wrong concentration
- corrosion protection is diminished
- lubrication decreases
- microbial attack is more likely
- the cooling ability is decreased
- foam behaviour increases
- emulsions stability deteriorates
- sticky residue develops

4.4.1. Coolant device inspection

The state of the cooling agent has significant influence on the cutting quality and on the operational life of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution cooling liquid (especially with oils) and on the other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be changed.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	after concentration check, refill with water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or renew coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides, or coolant renewal after added system cleanser*
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquiries to supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, ix with defoamer

* According to manufacturers' instructions

4.4.2. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!.
- Fill a watertight container with the chips! Be careful that the container does not leak, because even after a long dripping time, they still contain coolant residue.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micro-spray installation, the chips must also be handed over to a disposal company.

4.5. Hydraulic, Greases and oils

4.5.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Attention:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers.

Do not forget, that mineral and synthetic oils must not be mixed!

Use oils with specification DIN 51517 in the gearboxes. Select the viscosity grade ISO VG according to the original oil fill.

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Workline 510.350 GANC	Shell Tivela S 320	1,0 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100	Alpha SP 220	
	Alpha MW 100	Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220	Reductelf SP 320
		Reductelf Synthese 220	
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220	Mobilgear 632
		Mobilgear 630	
OMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220	Shell Omala 320
		Shell Tivela S 220	Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.5.2. Lubricant greases

We recommend using lithium based saponified grease, class NGLI-2 for lubrication. Different greases are mixable, if their oil bases and consistence type are identical.

Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energol LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1
	Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP
	Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.5.3. Lubrication

There are several places on the machine, which are necessary to grease periodically. It secures the right function of the machine.

Lubrication place	Lubrication
	Band saw / the guiding cubes leading – grease with oil from both sides once a week.

4.5.4. Hydraulic oils

Replace the hydraulic oil once in 2 years, because the oil can deteriorate its properties and cause problems the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Note:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils may not be mixed!


Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity grade ISO VG 32 in hydraulic aggregates. Hydraulic oils quantity – see chapter **Hydraulic oil level check**.

Comparative table of the hydraulic oils

Manufacturer	Type	Manufacturer	Type
Agip	Oso 32	Ina	Hidraol 32 HD
Aral	Vitam GF 32	Klüber	Lamora HLP 32
Avia	Avilub RSL 32	Mađarsko	Hidrokomol P 32
Benzina	OH-HM 32	Mobil	Mobil DTE 25
BP	Energol HLP 32	ÖMV	HLP 32
Bulharsko	MX-M/32	Poljsko	Hydrol 30
Castrol	Hyspin AWS 32	Rumunsko	H 32 EP
Čepro	Mogul HM 32	Rusko	IGP 30
DEA	Astron HLP 32	Shell	Tellus Oil 32
Elf	Elfolna 32	Sun	Sunvis 846 WR
Esso	Nuto H 32	Texaco	Rando HD B 32
Fam	HD 5040	Valvoline	Ultramax AW 32
Fina	Hydran 32		

4.5.5. Regulation of clamping pressure

The hydraulic pressure device for pressure setting on the main vice and feed vise.



Warning !

Because the hydraulic pressure equipment pressure 2,2 – 4 MPa, loosen the screws with caution!

Settings:

1. First Release the pressure regulator valve
2. Adjust the pressure using the pressure relief valve and manometer
 - When turning the pressure valve *clockwise the pressure increases.*
 - When turning the pressure valve *counterclockwise lowers the pressure.*
3. Once you have set the desired pressure, pull the lock nut

Hydraulic pressure equipment is not needed to maintain.

4.5.6. Hydraulic unit service

After 50 hours working time, or the latest 3 month after the first run, the first service should be carried out. This includes:



- checking off all screws and connections, fixing points, tubes and hoses for leakage
- Check hydraulic oil level
- During time of duty the oil temperature shouldn't exceed 60-70°C
- check function of signaling components (thermometer, level gauge, dirty filter indicator)

- Check the adjustment of working pressure

To realise a high reliability of the power pack, the manufacturer lays down following inspection intervals

Interval	daily	weekly	monthly	three monthly	six monthly	annually
Hydraulic fluid						
Level	-	•	-	-	-	-
Temperature	-	•	-	-	-	-
Condition	-	-	•	-	-	-
Change interval	-	-	-	-	-	•
Filter						
Change interval	-	-	-	-	-	-
Other checks						
External Leakages	•	-	-	-	-	-
Contamination	•	-	-	-	-	-
Damages	•	•	-	-	-	-
Noise-(level)	•	-	-	-	-	-
Gauges	-	-	•	-	-	-

4.6. Machine cleaning

Clean the machine from the cooling liquid and impurities after every shift stopping. Conserve the guiding surfaces, mainly.

- Clamping jaws guiding of the vice.
- The guiding of the feeder.
- Loading surface of the vice.

4.7. Worn pieces replacement

4.7.1. Hard metal guides replacement

If the hard metal guides cannot be adjusted, they have to be replaced.

1. Dismantle the saw band. Remove the hosepipe leading the cooling agent. Dismantle guide cube of the saw band.



2. Loosen the adjusting screws of the metal guide.



3. Loosen the binding screw of first metal guide. Remove adjustable hard metal guide.



4. Loosen the binding screw of second metal guide. Remove the hard metal guide
5. Insert new hard metal guides and fasten them tightly.
6. Mount the saw band. Adjust the hard metal guides.

4.7.2. Round brush replacement

If the chip removing brush is so worn, that it does not fulfil its function, the brush must be replaced.



1. Release the nut of the brush, exchange old brush to new brush and screw on the nut of the brush.
2. Set the brush to the saw band.

4.7.3. Saw band guiding rollers replacement

ATTENTION!

Guiding pulleys must be replaced together on both guiding cubes!!

If the saw band is not sufficiently guided by guiding pulleys or if the pulleys are obviously worn, the pulleys should be replaced.

1. Dismantle the saw band.

2. Disconnect the hose from the cooling agent, screw off the pressure regulation. Let the pressure regulation connected to the hydraulic system. Dismantle the guiding cube of the saw band..



ATTENTION!

Mark both eccentrics placing and components on the eccentric! Eccentrics must not be replaced with each other!!

3. Tighten the guiding cube to the vice and dismantle both eccentrics with bearings following way.
4. Screw off nuts from eccentrics..



5. Remove eccentrics from bearings by means of the swager



6. Change all bearings and other worn parts.



7. Install eccentrics to the cubes. Install components on both eccentrics in given

ATTENTION!

Do not replace the eccentrics placing in the cube

order. Put bearings by means of the preparation on eccentrics.



8. Screw on nuts on both eccentrics and tighten them.



9. Insert the saw band to the guiding cube (ca. 15 – 20 cm). Set the eccentrics by means of the wrenches, the saw band must run in the centre. Guide pulleys must not press too much on the band, but must spin freely during the band run.
10. Tighten nuts on both eccentrics.
11. Remove the testing piece of saw band from the cube lead. Install the guiding cube on the machine and connect the pressure regulation to the cut and cooling. Install the saw band.

4.7.4. Stretching wheel replacement

1. Dismantle the saw band.




2. Screw off the screw and take down the washer.



3. Pull off the wheel from the shaft by means of the three-armed puller. If bearing stayed on the shaft, pull off it too
4. Check score of the bearings of the stretching wheel and replace them for new.



5. Clean the shaft and grease it with oil. Insert retaining ring to the groove.



6. Install bearing on the shaft and move it to the retaining ring. Insert the distance ring on the shaft and move it to the bearing.



7. Insert the retaining ring to the hole in the wheel.



8. Insert the bearing to the hole in the wheel and press it to the retaining ring.



9. Put the wheel on the shaft and screw on the preparation to the wheel stretching to the hole in the shaft.



10. Pull on the wheel on the shaft.




11. Screw on washer and screw back..
12. Install the saw band. Wheel replacement is ready.

4.7.5. Driving wheel replacement


1. Dismantle the saw band



2. Screw off the screw and remove the washer.



3. Pull off the wheel from the shaft by means of the three-armed puller.



4. Install the wheel on the shaft. Insert the feather to the groove.



5. Screw on the preparation to the wheel stretching to the hole in the shaft. Pull on the wheel on the shaft.



6. Screw on washer and screw back.

7. Install the saw band. Wheel replacement is ready.

4.7.6. Replacing the coolant pump

Only a qualified worker can carry out the connection!

High-voltage shock may have fatal results


1. Pull the tank with the liquid from the pedestal..
2. Remove the hosepipe leading to the cooling agent from the plug on the pump. Screw off four screws from the cooling pump flange and pull out the pump from the sheet metal holder.



3. Remove the cover of the pump terminal switchboard. Disconnect 4 terminal connectors of the input cables. Cables are identified according to the red clamps..



4. Loosen the bushing and pull the cable out from the pump.



5. Dismantle new pump switchboard cover. Push the cable through the bushing and fasten it.



6. Screw on the cable bushing and cover of the terminal block. Do not forget the rubber gasket! Tighten the cooling liquid hose with non-stick tape and screw it again. Install cooling liquid hose, place the pump on the sheet metal holder and screw it

5. Troubleshooting

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment“
	- Worn hard metal guides.	Replace to the chapter „Worn pieces replacement“
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment“
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment“
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement“
	- Insufficient saw band stretching.	Rise the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band and keep the instructions of manufacturer on new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Set the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding arm and guiding cube are loosened.	Clamp the guiding arm.
	- Guiding arm and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast cutting rate.	Lower the material feeding speed.
2. The cut is not cut upon desired angle	- Unexpected oscillation in material quality.	Set the cut and feeding speed to the relevant material.
	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment“.
	- Set angle does not match the cut angle.	Check the angle adjustment with a protractor and possibly set it according to chapter „Servicing and adjustment“.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment“.
	- Guiding arm and guiding cube are loosened.	Fasten the guiding arm and the cube.
3. Short lifetime of the saw band	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
	- Insufficient saw band stretching.	Raise the tightening of the saw band set the scanner of saw band tightening according to chapter „Servicing and adjustment“.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive use as described in chapter „Worn pieces replacement“

Problem	Possible causes	Repair
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment“
	- Over stretched saw band	Lower stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw band.	Check the condition of the hard metal guide and if it is too worn, replace hard metal guides according to chapter „Worn pieces replacement“
	- Worn saw band guide bearings.	Check guiding bearings and if you notice some sort of excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted down feed and saw band speed.	Adjust the feeding and speed of a saw band according to values published by saw band manufacturer.
	- Different material quality.	Adjust feeding and speed of a saw band according to desired material (try cut-test).
	- Low-class saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly adjusted tracking.	Check the space between top of a saw band and driving wheel. Perhaps adjust the tracking as described in chapter „Servicing and adjustment“
4. Insufficient cut output.	- Worn saw band.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrong saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly set down feed and speed of a saw band.	Set feed and speed of a saw band according to values published by saw band manufacturer.
5. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messed-up.	Cleanse stop point surface of the limit switch from debris and residue material.
6. By choke is not possible turn	- Metal clamps between valve and panel.	Clamps must be removed and put on the shaft O-Ring about 10x2 mm.
	- Metal clams are in body of valve.	Valve must be cleared or changed.
7. Saw band drive cannot be started.	- Pressure switch is adjusted wrong.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
8. The saw bands are cracked.	- In stretching wheel is wrong adjusting geometry.	Adjust distance band from recess wheel c.2 mm according to operating instructions.
	- Hard metal plates of circuit saw band are not adjusting.	Hard metal plates of circuit saw band must be adjusting according to operating instructions.

Problem	Possible causes	Repair
	- Guiding cubes are not adjusting (bearings + hard metal circuit)	Guiding cubes must be adjusting (bearings + hard metal circuit) according to operating instructions.
	- Bearings of guiding cubes are used (rolling elements are damaged or outside ring of bearing has conical form).	Bearings of guiding cubes must be replaced. Bearings must be adjusting according to operating instructions.
9. Damage tooth system of the saw band	- In gripping the lifting cylinder is backlash.	
	- Squeezed pin upper or downer holder of the lifting cylinder.	Exchange complete upper or downer holder of lifting cylinder.
10. The saw is cut downing.	- Geometry of hardmetal guiding cubes is wrong adjusted.	Hardmetal guiding cubes must be adjusted.
	- Bearings of guiding cubes are used.	Bearings of guiding cubes must be replaced.
11. Cleansing of the saw band is not functional.	- Elastic wheel of the brush drive is worn-down.	Elastic wheel of the brush must be changed.
	- Knurling of the driving wheel is worn-down.	Driving wheel must be changed.
	- The shaft of the brush drive is rusted.	The shaft of the brush must be cleaned and oiled.
	- The brush position and the brush cover is adjusted wrong – with the brush cannot be turned.	The brush cover must be posed, in order to the brush can be turned.
12. The saw arm periodically rise and fall during the cut; this cause short lifetime of the saw band.	- Backlash in driving wheel lodgement on the shaft.	Change the driving shaft for a long one, new bearings, distance ring, new driving wheel, spring, two covers on the forehead of the shaft + screws.
	- Worn channel for spring.	

5.2. Electric problems

Problem	Possible causes	Repair
1. Machine is not possible start.	- In socket is not voltage	Line voltage must be checked.
	- Transfer relay is closed (thermal protector)	Each FA relay must be checked.
	- Limit switch of saw band stretching, cover of frame or cover of saw band is not started.	Check of saw band stretching and covers closing.
2. When cut is finished, the frame is not raising.	- Bottom limit switch is adjusted wrong.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- In hydraulic (pneumatic) ring is error. HYTOS (BOSCH) is not acting to frame uplift.	Function of magnetic valve must be checked, valve must be closed, voltage of clamps and inductor must be checked.
3. Electric motor and pump are without voltage. Between contactor and thermal protector is	- Wrong contactor.	Replace contactor of engine.

Problem	Possible causes	Repair
not voltage.		
4. The indicator of speed saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be changed.
	- Wrong sensor – diode of indicator speed is not light.	Sensor must be changed and adjusted.
5. Protector is switched off from engine hydraulic aggregate MA3 sometimes.	- Into hydraulic system is high working pressure.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on motor starter FA1.
7. Hydraulic aggregate is switched on but the saw arm or the main vice is not functional	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer can do this.
8. Cooling is not active	Lack of cooling agent.	Fill the tank with cooling agent.
	- Thermal relay is defective	Change the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and perhaps cleanse cooling system.
	- Cooling pump protection is defective	Check the protection of cooling pump if need change it.
	- Cooling pump is defective.	Replace the cooling pump.

5.3. Hydraulic problems

Problem	Possible causes	Repair
1. Hydrogenerator not supplying oil	• reverse rotation	Check the connections of each phase. Reconnect properly connection of the electrical phases.
	• shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond prescribed viscosity value	Change hydraulic oil.
	• Hydrogenerator malfunction	Call service
	• Wrong power supply connection.	Check the connections of each phase. Reconnect properly connection of the electrical phases.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately deaerated	Make deaeration of hydraulic circuit.
	• Low oil level	Add hydraulic oil

	• the pump shaft seals damaged	Call service
3. Increased mechanical noise	• damaged joint drive	Call service
	• damaged or destroyed motor bearings	Call service
	• air intake	Check for leaks.
4. Low pressure, pump supplies oil	• problem in the safety valve	Wrong settings. Check the settings and adjust the safety valve.
	• pump wear	Call service
	• external or internal leakage	Call service
5. Hydrogenerator is seized	• damage by solid particles in oil	Make oil filtration, or call the service.
	• non-prescribed oil	Change hydraulic oil.
	• wrong type of oil	Change hydraulic oil.
	• exceeding the life of the pump	Call service
6. Overheating oil	• cooler malfunction	Check the cooler function or call service.
	• wear the pump, the energy is converted into heat	Call service
7. Hydraulic valve can not be readjusted	• electromagnet has no signal (voltage) - interrupted supply lines	Check again.
	• Electromagnet coil burnt	Replace coil – Call service.
	• spool valve sticking	Replace valve – Call service

6. Schematics

- 6.1. Elektrické schéma /
 Elektroschema /
 Electric scheme – 3×400 V, PE+N, 50 Hz

0	1	2	3	4	5	6	7	8	9
 Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic Workline 410.280 A-GANC									
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Stroji/Machine/Machine: Workline 410.280 A-GANC			Název stránky/Name page/Name section: Úvodní strana/Start page/Startseite			Číslo dok./Doc No./Anzahl der Dokumente.: ES-S000-201-V6.2 Napájení/Power supply/Einspeisung: 3x400V+N+PE 50Hz Zpracováno/Processed/Has been processed: Pavlik Datum/Date/Datum: 14.1.2014
 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno			Stroji/Machine/Machine: Workline 410.280 A-GANC			Název stránky/Name page/Name section: Úvodní strana/Start page/Startseite			List/Page/ Seite: 00 List/Page/ Seiten: 19




Obsah/ Table of contents/ Inhaltsverzeichnis

Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum /Date
00	Úvodní strana/Start page/Startseite	14.1.2014
01	Obsah/ Table of contents/ Inhaltsverzeichnis	14.1.2014
02	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	14.1.2014
03	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	14.1.2014
04	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
05	Silová část M1,M2/Power part M1,M2/Feld partie M1,M2	14.1.2014
05.a	Silová část M3/Power part M3/Feld partie M3	14.1.2014
06	Deska zdroje/Power board/Netzgerät-Platte	14.1.2014
07	Stykače motorů, M4/Motor contactor, M4/Motor-Schutzschalter, M4	14.1.2014
08	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
08.a	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
09	Vstupy/Inputs/Eingänge	14.1.2014
10	Tlačítka ovládací panel OP1/ Button control panel OP1/ Taste Bedienpult OP1	14.1.2014
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	14.1.2014
12	Řídicí systém/ Control system/ Steuersystem	14.1.2014
13	Příslušenství/Accessories/Zubehör	14.1.2014
14	Zapojení snímačů/Conection of sensors/Sensorsanschluss	14.1.2014

00

	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Workline 410.280 A-GANC	Název stránky/Name page/Name seiten: Obsah/ Table of contents/ Inhaltsverzeichnis	Cílová dok./Doc.No./Anzahl der Dokumente.: ES-S0000-201-V6.2 Název/Power supply/Einspeisung: 3x400V+N+PE 50Hz Zpracoval/Processed /Hat. verarbeitet: Pavlik Datum/Date/Datum: 14.1.2014	List/Page/ Seite: 01 List/Page/ Seite: 19
--	--	---	---	--	--





Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/06.3
-CU1	Touch-sensitive keyboard	31.R230-207	AKI ELECTRONIC, spol.s.r.o.	31.R230-207	1	/12.0
-FA1	Manual motor starter - 0.4A	MS116-0-4	ABB	91.045.017	1	/05.4
-FA2	Manual motor starter - 4A	MS116-4-0	ABB	91.045.022	1	/05.7
-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/08.a.5
-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/11.7
-SB3	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/11.3
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/10.2
=OP1-SB3	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/10.4
-FU1	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.1
-FU2	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/06.1
-FU3	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/06.5
-FU6	Tube fuse - 6.3A/250V, slow, 5x20	T6.3A/250V	ESKA	91.230.002	1	/06.5
-FU7	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/13.1
-RP1	Potentiometer 4k7	TP195 4k7/IN20A	GES-ELECTRONICS, a.s.	91.283.015	1	/05.a.5
-RP1	Potentiometer knob - 24mm	S8877 BLK	GES-ELECTRONICS, a.s.	91.060.063	1	/05.a.5
-RCF1	RCF filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/05.3
-RCF2	RCF filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/05.6
-RCF11	RCF filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/05.a.0
-RCF12	RCF filter	FBOPRL624	Ing. Miroslav Vlček	91.041.015	1	/05.a.0
-BM1	Safety relay - 3xNO	CS AR-02M024	PIZZATO	91.051.034	1	/11.5
-FA1	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.4
-FA2	Auxiliary Contact Block - 1xNO+1xNC	HKF1-11	ABB	91.046.002	1	/05.7
-FU1	Fuse terminal	WK4/7HSISU	WIELAND	91.251.102	1	/06.1
-FU2	Fuse terminal	WK4/7HSISU	WIELAND	91.251.102	1	/06.1
-FU3	Fuse terminal	WK4/7HSISU	WIELAND	91.251.102	1	/06.5
-FU4	Fuse terminal	WK4/7HSISU	WIELAND	91.251.102	1	/06.5
-FU4	Tube fuse - 800mA/250V, slow, 5x20	T800mA/250V	ESKA	91.230.010	1	/06.5

The manufacturer reserves right to use an equivalent replacement device.

03	 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Workline 410.280 A-GANC	Název stránky/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste	Cílová dok./Doc No./Anzahl der Dokumente.: ES-S0000-201-A6.2 Název/Power supply/Einspeisung: 3x400V+N+PE 50Hz Zpracováno/Processed /Hat verarbeitet: Datum/Date/Datum: 14.1.2014	Úroveň/Level: 04 List/Page/ Seite: 04 List/Page/ Seite: 19
----	---	--	--	--	---



Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-FU5	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.5
-FU5	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.5
-FU6	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.5
-KM1	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KM2	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KM11	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.7
-KM21	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.8
-PA1	Fuse switch disconnector E-90 - 3P	E 93/32	ABB	91.241.014	1	/05.a.1
-QS1	Disconnector - 3P, 16A	OT16FT3	ABB	91.170.018	1	/05.0
-QS1	Terminal shroud	OTS40T3	ABB	91.170.017	1	/05.0
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.a.5
-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/11.3
-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.1
=OP1-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.2
=OP1-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.3
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.4
=OP1-SB3	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.4
-TR1	Toroidal transformer - 0.230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.1
-SQ8	Safety limit switch - 2xNC	QKS8	KEDU	91.173.012	1	/11.1
-PA1	Cylindric fuse - 8A, 10x38 slow, gG characteristic	PV10 8A gG	OEZ	91.231.003	3	/05.a.1
-SQ3	Limit switch - 1NC+1NO, M20, slow	D4N-4A32	OMRON	91.173.010	1	/09.2
-SQ11	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.8
-SQ4	Limit switcher - 2NC, roller on doors(right), M2, slow action	FR 34C1-M2	PIZZATO	91.173.021	1	/09.3
-SQ5	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 60S-M2	PIZZATO	91.173.009	1	/09.4
-LQ1.A	Sensor cable	MOD.14/4 M12 SL LC10	STCK	91.142.001	1	/09.5
-LQ1.B	Sensor cable	MOD.15/4 M12 SL LC10	STCK	91.142.002	1	/09.6
-QS1	Handle switch - black	OHBS2RJ	ABB	91.180.015	1	/05.0

The manufacturer reserves right to use an equivalent replacement device.

04

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Workline 410.280 A-GANC	Název strojů/Name of the machine: Kusovník artiklů/ Parts list/ Artikelstückliste	Grafická úroveň/Doc No/Anzahl der Dokumente.: ES-50000-201-V6.2		List/Page /				
			Název/Power supply/Einspeisung: 3x400V+HN+PE 50Hz		Seite: 04/8				
						Zpracování/Processed /Fert. verarbeitet:		List/Page /	
						Datum/Date/Datum:		Seite: 19	

























121

- 6.2. Elektrické schema /
Elektroschema /
Electric scheme – 3×400 V, PE , 50 Hz



Bomar, spol. s r.o.
Těžební 1236/1
627 00 Brno
Czech republic

Workline 410.280 A-GA NC


 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stručná technická zpráva Workline 410.280 A-GANC	Název stránky/Name page/Name sheet Úvodní strana/Start page/Startseite	Číslo dok. / Doc. No/Versch. der Dokumentation: ES-5300-202-A0_2 Napájení/Power supply/Einspeisung 3x400V+PE, 50Hz Zpracování/Processed/Has verarbeitet: Pevák Datum/Date/Datum: 27.1.2014	Úroveň/Level Stránka / Page Seiten: 00 Úroveň/Level Stránka / Page Seiten: 10
---	---	---	---	--



Obsah/ Table of contents/ Inhaltsverzeichnis


Stránka/Page/Seite	Název stránky/Name page/Name Seite	/Date Datum/Date/Datum
00	Úvodní strana/Start page/Startseite	14.1.2014
01	Obsah/ Table of contents/ Inhaltsverzeichnis	14.1.2014
02	Rozmístění prvků v rozvaděči RS1	14.1.2014
03	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	14.1.2014
04	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
05	Slivá část M1,M2/Power part M1,M2/Feld partie M1,M2	14.1.2014
05.a	Slivá část M3/Power part M3/Feld partie M3	14.1.2014
06	Deska zdroje/Power board/Netzgerät-Platte	14.1.2014
07	Stykače motorů, M4/Motor contactor, M4/Motor-Schutzschalter, M4	14.1.2014
08	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
08.a	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
09	Vstupy/Inputs/Eingänge	14.1.2014
10	Tlačítka ovládací panel OP1/ Button control panel OP1/ Taste Bedienpult OP1	14.1.2014
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	14.1.2014
12	Řídicí systém/ Control system/ Steuersystem	14.1.2014
13	Příslušenství/Accessories/Zubehör	14.1.2014
14	Zapojení snímačů/Conection of sensors/Sensorsanschluss	14.1.2014

	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Workline 410.280 A-GANC	Název stránky/Name page/Name seiten: Obsah/ Table of contents/ Inhaltsverzeichnis	Cílová dok./Doc.No./Anzahl der Dokumente.: ES-S0000-202-V6.2 Název/Power supply/Einspeisung: 3x400V+PE, 50Hz Zpracoval/Processed./Hat verarbeitet: Datum/Date/Datum: 27.1.2014	Ústředí/Office: List/Page/ Seite: 01 Ústředí/Office: List/Page/ Seite: 19
--	--	---	---	--	--



01

	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Workline 410.280 A-GANC	Název stránky/Name page/Name sheet: Rozmístění prvků v rozvaděči RS1	Číslo dok./Doc No./Anzahl der Dokumente.: ES-S3000-202-A6.2 Název/Power supply/Einspeisung: 3x400V-HE, 50Hz Zpracováno/Processed/Has. verarbeitet: Pavlik Datum/Date/Datum: 27.1.2014	List/Page/ Seite: 02 Listo/Pages/ Seiten: 19



</

The manufacturer reserves right to use an equivalent replacement device.

03	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno		Stroj/Machine/Machine: Workline 410.280 A-GANC		Název stránky/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste		Číslo dok./Doc No./Anzahl der Dokumente.: ES-S000-202-V6.2 Název/Power supply/Einspeisung.: 3x400V-HE- 50Hz Zpracoval/Processed./Hat verarbeitet.: Pavlik Datum/Date/Datum: 27.1.2014		List/Page / Seite: 04 List/Page / Seiten: 19
----	--	--	--	--	---	--	--	--	---





Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-FU5	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.5
-FU5	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.5
-FU6	Fuse terminal	WK4/THSISU	WIELAND	91.251.102	1	/06.5
-KM1	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KM2	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KM11	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.7
-KM21	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/11.8
-PA1	Fuse switch disconnector E-90 - 3P	E 93/32	ABB	91.241.014	1	/05.a.1
-QS1	Disconnecter - 3P, 16A	OT16FT3	ABB	91.170.018	1	/05.0
-QS1	Terminal shroud	OTS40T3	ABB	91.170.017	1	/05.0
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.a.5
-S83	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/11.3
-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.1
=OP1-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.2
=OP1-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.3
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.4
=OP1-SB3	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.4
-TR1	Toroidal transformer - 0.230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.2
-SQ8	Safety limit switch - 2xNC	QKS8	KEDU	91.173.012	1	/11.1
-PA1	Cylindric fuse - 8A, 10x38 slow, gG characteristic	PV10 8A gG	OEZ	91.231.003	3	/05.a.1
-SQ3	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.2
-SQ11	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.8
-SQ4	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 60S-M2	PIZZATO	91.173.009	1	/09.3
-SQ5	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 60S-M2	PIZZATO	91.173.009	1	/09.4
-LQ1.A	Sensor cable	MOD.14/4 M12 SL LC10	STCK	91.142.001	1	/09.5
-LQ1.B	Sensor cable	MOD.15/4 M12 SL LC10	STCK	91.142.002	1	/09.6
-QS1	Handle switch - black	OHBS2RJ	ABB	91.180.015	1	/05.0

The manufacturer reserves right to use an equivalent replacement device.

04		BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Workline 410.280 A-GANC	Název strojů/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dok./Doc.No./Anzahl der Dokumente.: Napájení/Power supply/Einspeisung: Zpracování/Processed./Fert. verarbeitet: Datum/Date/Datum:	ES-S0000-202-V6.2 3x400V+PE, 50Hz Paylik: 27.1.2014	List/Page/ Seite: 04.4 Listo/Pages/ Seiten: 19




















 BOMAR s.r.o. Těšebná 1236/1 CZ 662 01, Brno	Stroj/Machine: Workline 410.280 A-GANC	Název stránky/Name page/Name sheet: Bezpečnostní okruh/Safety circle/Sicherheitsbereich	Číslo odk./DocNo./Inhalt der Dokumente.: ES-52000-202-V6.2	Headline/Power supply/Versorgung: 3x400 V AC, 50 Hz	Značení/Power processor/Markierung: 3x400 V AC, 50 Hz	Účastníci/Participants: 11	Stránky/Pages: 11	Seznam/Summary: 11
--	--	---	--	---	---	--	---------------------------------	----------------------------------





141

- 6.3. Elektrické schema /
Elektroschema /
Electric scheme – 3×230 V, PE , 50 Hz



Bomar, spol. s r.o.
Těžební 1236/1
627 00 Brno
Czech republic

Workline 410.280 GANC


 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stručná technická zpráva Workline 410.280 GANC	Název stránky/Name page/Name sheet Úvodní strana/Start page/Startseite	Číslo dok. /Doc No/Versch. der Dokumentation: ES-5300-203-A0.2 Napájení/Power supply/Einspeisung: 3x230V+PE, 50Hz Zpracování/Processed /Has verarbeitet: Pevák Datum/Dat./Datum: 14.1.2014	Úroveň/Level Stránka /Page Seiten: 00 Úroveň/Level Seiten: 10
---	---	---	---	---




Obsah/ Table of contents/ Inhaltsverzeichnis

Stránka/Page/Seite	Název stránky/Name page/Name Seite	/Date Datum/Date/Datum
00	Úvodní strana/Start page/Startseite	14.1.2014
01	Obsah/ Table of contents/ Inhaltsverzeichnis	14.1.2014
02	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	14.1.2014
03	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	14.1.2014
04	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.a	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
04.b	Kusovník artiklů/ Parts list/ Artikelstückliste	14.1.2014
05	Silová část M1,M2/Power part M1,M2/Feld partie M1,M2	14.1.2014
05.a	Silová část M3/Power part M3/Feld partie M3	14.1.2014
06	Deska zdroje/Power board/Netzgerät-Platte	14.1.2014
07	Stykače motorů, M4/Motor contactor, M4/Motor-Schutzschalter, M4	14.1.2014
08	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
08.a	Hydraulické ventily/Hydraulic valve/Hydroventil	14.1.2014
09	Vstupy/Inputs/Eingänge	14.1.2014
10	Tlačítka ovládací panel OP1/ Button control panel OP1/ Taste Bedienpult OP1	14.1.2014
11	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	14.1.2014
12	Řídicí systém/ Control system/ Steuersystem	14.1.2014
13	Příslušenství/Accessories/Zubehör	14.1.2014
14	Zapojení snímačů/Conection of sensors/Sensorsanschluss	14.1.2014

	BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Workline 410.280 GANC	Název stránky/Name page/Name seiten: Obsah/ Table of contents/ Inhaltsverzeichnis	Cílová dok./Doc.No./Anzahl der Dokumente.: ES-S0000-203-A6.2 Název/Power supply/Einspeisung: 3x230V+PE, 50Hz Zpracoval/Processed /Hat. verarbeitet: Datum/Date/Datum: 14.1.2014	Ústředí/ Seite: 01 Ústředí/ Listo/Pages/ Seiten: 19
--	--	---	---	---	---





<



Parts list

Device identification	Device description	Type number	Manufacturer	Part number	Quantity	Location (page.column)
-FU5	Fuse terminal	WK4/THSI5U	WIELAND	91.251.102	1	/06.5
-FU5	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.031	1	/06.5
-FU6	Fuse terminal	WK4/THSI5U	WIELAND	91.251.102	1	/06.5
-KM1	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.1
-KM2	Minicontactor - 4kW/400V, 3P	B6S-30-01-1.7-71	ABB	91.040.049	1	/07.3
-KM11	Contact - 5.5kW/400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/11.7
-KM12	Contact - 5.5kW/400V, 3P	AF12-30-01-11	ABB	91.040.051	1	/11.8
-PA1	Fuse switch disconnector E-90 - 3P	E 93/32	ABB	91.241.014	1	/05.a.1
-QS1	Disconnector - 3P,40A	OT40FT3	ABB	91.170.019	1	/05.0
-QS1	Handle switch - black	OHBS2RJ	ABB	91.180.015	1	/05.0
-RP1	Fastconnect clamp	WAGO 224-112	WIELAND	91.250.009	3	/05.a.5
-S83	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/11.3
-SB501	Emergency-stop mushroom push - button + 3xNC	YW1B-V4E02R	IDEC	91.060.084	1	/11.1
=OP1-SB1	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.2
=OP1-SB2	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.3
=OP1-SB2	Switch head - black	M22-D-S	EATON	91.060.035	1	/10.3
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/10.4
=OP1-SB3	Attaching adapter + 1NO	M22-AK10	EATON	91.061.021	1	/10.4
-TR1	Toroidal transformer - 0.230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/06.1
-SQ8	Safety limit switch - 2xNC	QKS8	KEDU	91.173.012	1	/11.1
-PA1	Cylindric fuse - 16A, 10x38 fast, gG characteristic	PV10 16A gG	OEZ	91.230.020	3	/05.a.1
-SQ3	Limit switch - 1NC+1NO, M20, slow	D4N-4A32	OMRON	91.173.010	1	/09.2
-SQ11	Limit switch - 1NC+1NO	D4N-4A31	OMRON	91.173.007	1	/09.8
-SQ4	Limit switcher - 2INC, roller on doors(right), M2, slow action	FR 34C1-M2	PIZZATO	91.173.021	1	/09.3
-SQ5	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 60S-M2	PIZZATO	91.173.009	1	/09.4
-LQ1.A	Sensor cable	MOD.14/4 M12 SL LC10	STCK	91.142.001	1	/09.5
-LQ1.B	Sensor cable	MOD.15/4 M12 SL LC10	STCK	91.142.002	1	/09.6
-QS1	Terminal shroud	OTS40T3	ABB	91.170.017	1	/05.0

The manufacturer reserves right to use an equivalent replacement device.

04		BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Machine: Workline 410.280 GANC	Název strojů/Name page/Name sheet: Kusovník artiklů/ Parts list/ Artikelstückliste	Číslo dok./Doc No./Anzahl der Dokumente.: ES-S0000-203-A6.2 Název/Power supply/Einspeisung: 3x230V+PE, 50Hz Zpracováno/Processed /Hst. verarbeitet: Datum/Date/Datum: 14.1.2014	List/Page/ Seite: 04.4 Listo/Pages/ Seiten: 19




















 BOMAR s.r.o. Těšební 1236/1 CZ 627 00, Brno	Strojí/Machine/Maschine: Workline 410.280 GANC	Název starého/Name page/Name seller: Bezpečnostní okruh/Safety circle/Sicherheitsbereich	Číslo dok./Doc.No./Anzahl der Dokumente.: ES-0000-2019-16.2	List/Page/ Seite.: 11
			Napájení/Power supply/Einspeisung: 3x230V+4PE, 50Hz	List/Page/ Seite.: 11
			Zpracováno/Processed./Jkt. verarbeitet: Pavlik	List/Page/ Seite.: 10
			Datum/Date/Datum: 14.1.2014	




11

	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Workline 410.280 GANC	Název stránky/Name page/Name sheet: Řídicí systém/ Control system/ Steuersystem	Cílová dok./Doc No./Anzahl der Dokumente.: ES-S000-203-A6.2 Název/Power supply/Einspeisung: 3x230V+PE, 50Hz Zpracování/Processed./Hat verarbeitet: Pavlik Datum/Date/Datum: 14.1.2014	List/Page / Seite: 12 List/Page / Seite: 19
---	---	---	---	--	--



161

6.4. Hydraulické schéma / Hydraulikschema / Hydraulic diagram



205.M216-250
(22.7.2011)

WORKLINE 280 var.: A / GA
 WORKLINE 350 var.: A / GA
 WORKLINE 450 var.: A / GA
 PROLINE 280 A
 PROLINE 350 A
 PROLINE 450 A

Typ / Type / Type

Workline 280, 350, 450 A/GA / Proline 280, 330, 450

Hydraulický agregát / Hydroaggregat / Hydro aggregat

92.001.070 (FMW), 5001-058-1, PPM-AC13-PG11/61-1,6-TM20-CB03-FR

Neuvedené světlosti / Unerwähnt Lichtbreite / Unlisted inside diameters

JS6

Výstupní šroubení / Ausgangsschraubung / Output screwing

G1/4"

Pmax	WL/PL 280 4 MPa, WL/PL 350 5 MPa, WL/PL 450 6 MPa
Q	8+2,1 dm ³ /min
n	1400 rpm
P	1,1 kW

Poz.	Název položky		ks
Pos.	Bezeichnung		Menge
Pos.	Item		Pcs.
1	Nádrž / Behälter / Tank	TS20, S309-009-1-02 20 l	1
2	Elektromotor / Elektromotor / Electromotor	EM 90 1,1 kW/3 B34 400/230 V, 50 Hz	1
3	Hydrogenerátor / Hydraulikgenerator / Hydrogenerator	11A10A6,1X181G/101, 6X182G, 1,6+6,1cm ³ /rpm	1
4	Zpětný filtr / Filter / Filter	MPF0301AG1 P10NBP01	1
5	Rozváděč / Verteilungsventil / Distributor	SD2E-A2/S2I11 C13D-02400E1	1
6	Přepouštěcí ventil / Bypassventil / By pass valve	SR1A-A/S10	1
7	Jednosměrný ventil / Einwegventil / One-way valve	RVZ-10LR, V205-008-1	1
8	Jednosměrný ventil / Einwegventil / One-way valve	SC1F-A2/H005	1
9	Manometr / Manometer / Manometer	D68, RAD., 0-100 bar	2/1
10	--	--	--
11	Rozváděč / Schaltschrank / Switchboard	RPEK1-03G3Z11/02400E1	3
12	Rozváděč / Schaltschrank / Switchboard	RPEK1-03G3Y11/02400E1	1
13	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	PC08-30-0-N	1
14	Rozváděč / Schaltschrank / Switchboard	SD3E-A2/S2L2 C13D-02400E1	1
15	Tlakový spínač / Druckschalter / Pressure switch	WL:10–20 bar PL:20–50 bar	2
16	Nalévací zátka / Stopfen / Fill stopper	CPT-MD-FA/1"	1
17	Škrťací ventil / Drosselventil / Throttle-valve	PL:VS01-04/R2,5,92.152.001 W:VS01-04/R2,5- OS,92.152.004	1
18	Pojistný ventil / Sicherungsventil / Safety valve	VPNH ¼ 92.151.001	2/0
19	Kostka regulace / Regulationklotz / Regulation cube		1
20	Rozváděč / Schaltschrank / Switchboard	PRM2-043Z11/04-24 MIKR	1
21	Blok filtru / Filterblock / Filter block	92.153.005	1/0
22	Kulový ventil / Kugelventil / Globe valve		4/0
23	Redukční ventil / Reduktionventil /	VRN2-06/S-6R	1
24	Šroub / Schraube / Screw	IMBUS M6×10 30.M216-201	1/0
25	Deska / Platte / Platte	DP4-04/32-4 G1/4"	1
26	Rychlospojka / Schnellkupplung / Gladhand	KM/S11 106007 92.060007/8	4/0


7. Výkresy sestav pro objednání náhradních dílů/ Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order

Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix Workline 410.280 GANC) , výrobní číslo (např. 125) a rok výroby (např. 1999).

In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Workline 410.280 GANC), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).

For spare parts order, you must always to allege: type of machine (for example Workline 410.280 GANC), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. Workline 410.280 GANC




NAZEV SESTAVY PILA PASOVA	ČÍSLO SESTAVY 201.S200-000	STROJ WL280GA
Konstruoval: ODVARKA		
Datum: 20. 07.2012		
Meritko: 7:100		

7.2. Kusovník / Stückliste / Piece list – Workline 410.280 GANC

Císlo Sestavy 201.S200-000	Ver. 0	Název sestavy PILA PASOVA/BAND SAW/BANDSAGE			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.S209-000	0	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
2	201.S201-000	0	PODSTAVEC / BASE / UNTERSATZ		1
3	201.M202-000	0	KONZOLA OTOCHA / TURNABLE CONSOL / DREHKONSOLE		1
4	201.M204-300	2	RAMENO / SAW ARM / SÄGERAHMEN		1
5	201.M207-050	2	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDER	SESTAVA	1
6	201.R311-100	0	CELO / /		1
7	201.S211-000	0	PODAVAC / FEEDER / VORSCHUB		1
8	201.R230-300	1	OVLADACI PANEL / CONTROL PANEL / BEDIENPULT		1
9	201.R314-250	0	VALEC POMOCNY / AUXILIARY CYLINDER / HILFSZYLINDER		1
10	201.0614-200	0	ODMEROVANI / MEASURING / GEHRUNGSMESSUNG		1
11	201.S214-030	0	PLOT / FENCE / ZAUN		1
12	92.001.070	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGREGAT	FHW	1
13	99.901.038	1	SAMOLEPKA / STICKER / AUFKLEBER		1
14	30.S299-001	0	STITEK TYPOVY / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
15	31.0104-026	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
19	31.0599-005	0	SAMOLEPKA / STICKER / AUFKLEBER		1
20	99.900.057	0	SAMOLEPKA / STICKER / AUFKLEBER		1
21	99.900.040	0	SAMOLEPKA / STICKER / AUFKLEBER		1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.3. Rameno / Sägerahmen / Saw arm 1




NAZEV SESTAVY RAMENO	CÍSLO SESTAVY 201.M204-300	STROJ WORK280DGH
Konstruoval: VINOHRADSKÝ		
Datum: 04. 10. 2012		
Měřítko: 1:5		

7.4. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 1

Císlo Sestavy 201.M204-300	Ver. 2	Název sestavy RAMENO / SAW ARM / SÄGERAHMEN			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.8114-630	0	KARTAC / BRUSH / BURSTE		1
2	201.M205-000	1	PREVODOVKA / TRANSMISSION / GETRIEBE		1
3	201.M208-000	0	NAPINANI / TENSIONING / SPANNUNG		1
4	201.M210-150	2	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
5	30.1814-011	1	DRŽAK / HOLDER / HALTER	P 3x76	1
6	30.3404-056	0	TYC ZAVITOVÁ / THREADED POLE / GEWINDESTANGE	M10	2
7	30.6607-103	0	CEP / LUG / BOLZEN	TYC 18	1
8	30.9204-004	1	DISTANC / DISTANCE / DISTANZ	TR 28x3	1
9	30.LD04-005	0	DRŽAK / HOLDER / HALTER		1
10	30.M204-006	0	CEP / LUG / BOLZEN	d 30	1
11	30.M204-009	0	KRYT KARTACKU / BRUSH COVER / BÜRSTENABDECKUNG		1
12	30.M204-011	1	KRYT / COVER / ABDECKUNG		1
13	30.M204-012	0	KRYT NAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P 1.5x280	1
14	30.M204-016	0	KRYT PASU / BELT COVER / BANDABDECKUNG		1
15	30.M204-201	1	RAMENO / SAW ARM / SÄGERAHMEN		1
16	30.R304-006	2	PANT / BOARD / PLATTE	PROFIL	2
17	30.R304-007	1	PANT / BOARD / PLATTE	PROFIL	2
18	31.9204-003	0	PRUŽINA / SPRING / FEDER	d2	1
19	44.103.002	0	PAS PÍLOVÝ 260 / SAW BELT / SÄGEBAND	3800x25(7)x0.90	1
20	90.001.25.007	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X10	8
21	90.100.55.003	0	MATICE / NUT / MUTTER	MATICE _ M5	4
22	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE _ M10	6
23	90.100.55.008	0	MATICE / NUT / MUTTER	MATICE _ M16	1
24	90.150.50.009 (1)	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 17	1
25	90.151.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 12	2
26	90.162.00.002 (2)	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	16 ZN	1
27	90.302.07.001	0	KUŽEL. KOLIK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 6x36	4
28	90.302.07.002	0	KUŽEL. KOLIK S ZAV. / TAPER PIN + THREAD / KEGELBOLZEN + GEWINDE	KOLIK 8x30	2
29	90.307.07.001	0	KOLIK / PIN / BOLZEN	D6	2
30	91.173.007	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER	-RIWK	2
31	91.173.012	0	SPINAC KONCOVÝ / END SWITCH / ENDSCHALTER		1
32	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	2

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.5. Rameno / Sägerahmen / Saw arm 2



NAZEV SESTAVY RAMENO	CISLO SESTAVY 201.M204-300	STROJ WORK280DGH
Konstruoval: VINOHRADSKY		
Datum: 04. 10. 2012		
Merk: 1:5		


7.6. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 2

33	95.800.008	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 18	2
34	95.800.013	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 30	2
35	96.081.001	0	KROUZEK TESNICI / SEAL RING / DICHTRING	23x15x3	1
36	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK CINSKY	2
37	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

1. PRID. 1xPODLOZKA 30.9204-006, 1xPODLOZKA 90.150.50.009. 170/ZM238 13.8.2012 SLEZACKOVA

2. ZRUS. PODLOZKA 30.9204-006 A NAHR. 90.162.00.002. 225/ZM288 4.10.2012 SLEZACKOVA

7.7. Napínání / Spannung / Tensioning




NAZEV SESTAVY NAPÍNÁNÍ	ČÍSLO SESTAVY 201.M208-000	STROJ WORK280
Konstruoval: VINOHRADSKÝ		
Datum: 18. 10.2010		
Měřítko: 3:10		

7.8. Kusovník / Stückliste / Piece list – Napínání / Spannung / Tensioning

Cislo Sestavy 201.M208-000		Ver. 0	Název sestavy NAPÍNÁNÍ / TENSIONING / SPANNUNG			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks	
1	30.0808-001	1	KOSTKA NAPÍNÁNÍ / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	80x30	1	
2	30.0808-002	1	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSEIESTE	30x20	2	
3	30.0808-006	1	LISTA / TRIM / LEISTE	HR 30x10	2	
4	30.0808-007	0	SROUB / BOLT / SCHRAUBE	M8x60	1	
5	30.1708-001	1	KOLO / WHEEL / UMLENKRAD	ODLITEK	1	
6	30.1708-002	2	CEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		1	
7	30.1708-003	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	d 40	1	
8	30.1708-004	4	DRŽÁK / HOLDER / HALTER	HR 20x8	1	
9	30.3508-004	1	KROUZEK / RING / RING	d42	1	
10	30.4108-001	1	SROUB / BOLT / SCHRAUBE		1	
11	30.4108-002	0	DISTANC / DISTANCE / DISTANZ	TR 28x6	1	
12	30.6908-102	1	DRŽÁK / HOLDER / HALTER		1	
13	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x20	1	
14	90.001.25.053	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x55	6	
15	90.002.20.015	0	SROUB STAVEC / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M10x20	1	
16	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1	
17	90.151.50.001	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 10	1	
18	90.300.07.003	0	KOLÍK VALC. KAL. / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHARTET	KOLÍK 16x80	1	
19	90.350.07.002	0	TALÍROVA PRUŽINA / DISC SPRING / TELLERFEDER	35,5x18,3x2,0x2,8	8	
20	94.001.005	0	RUKOJET / HANDLE / GRIF	M16	1	
21	95.001.019	0	LOŽISKO / BEARING / LAGER	6206 2RS	2	
22	95.801.010	0	KROUZEK POJIST.VNITR / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 62	1	

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Versio; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.9. Vedení pásu / Sägebandführung / Belt guide



7.10. Kusovník / Stückliste / Piece list –
Vedení pásu / Sägebandführung / Belt guide

Cislo Sestavy 201.M210-150		Ver. 2	Nazev sestavy VEDENÍ PASU/BELT GUIDE/SÄGEBANDFÜHRUNG		
Poz.	Objednací číslo	Ver.	Nazev položky	Rozměr	Ks
1	251.077	0	REGULACE PRITLAKU / PRESSURE REGULATION / SCHNITTDRUCKREGULATION		1
2	201.M210-120	2	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		1
3	201.M210-200	1	KOSTKA VODICI / /		1
4	30.3510-003	0	DESKA / BOARD / PLATTE	HR 30x12	1
5	30.3510-004	0	TRUBKA / TUBE / ROHR	TR 8x 1	2
6	30.9010-003	0	DRŽAK / HOLDER / HALTER	PI.5x10	2
7	30.M210-002	0	LISTA / TRIM / LEISTE	HR 80x20	1
8	30.M210-004	0	KONZOLA / CONSOLE / KONSOLE		1
9	30.M210-006	2	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x70	1
10	30.M210-007	1	KRYT PASU / BELT COVER / BANDABDECKUNG	P 2x70	1
11	30.M210-008	0	LISTA / TRIM / LEISTE	HR 25x6	1
12	30.Y310-008	0	DRŽAK / HOLDER / HALTER	P3-50	1
13	90.001.25.007	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x10	4
14	90.001.25.017	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x16	8
15	90.001.25.031	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	2
16	90.001.25.033	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	2
17	90.001.25.105	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x18	6
18	90.002.20.022	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x30	2
19	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	2
20	90.150.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 5,3	4
21	90.163.00.002	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 8	2
22	92.002.102	0	SROUBENÍ / BOLTING / VERSCHRAUBUNG	S-GEV-8LLR	2
23	94.008.003	0	PAKA UPINACÍ / ATTACHMENT LEVER / SPANNHEBEL	M8x40	1
24	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	2
25	96.081.001	0	KROUZEK TESNICÍ / SEAL RING / DICHTUNGSRING	23x15x3	1
26	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1



1 z ks. stroje zruseno 30.M210-003, 30.Y310-007 070/061 11.4.2011 VINOHRADSKY

2 z ks. stroje zruseno 201.M210-110 a nahrazena 201.M210-120 070/257 20.9..2011 VINOHRADSKY

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver..)Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz..)Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.11. Odměřování / Gehrungsmessung / Measuring



NÁZEV SESTAVY ODMĚŘOVÁNÍ	ČÍSLO SESTAVY 201.0614-200	STROJ
Konstruoval: &konstruoval		
Datum: 19. 02.2010		
Měřítko: 2:1		


7.12. Kusovník / Stückliste / Piece list – Odměrování/ Gehrungsmessung / Measuring

Císlo Sestavy 201.0614-200		Ver. 0	Název sestavy ODMĚROVÁNÍ / MEASURING / GEHRUNGSMESSUNG		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0614-201	0	CEP / LUG / BOLZEN	d 16	1
2	30.0614-203	0	CLONA / CURTAIN / SCHÜRZE	FOLIE 0.3	1
3	30.0614-204	0	POUZDRO / SLEEVE / BÜCHSE	TR 13x1	1
4	30.0614-208	0	ŠROUB / BOLT / SCHRAUBE	TYC M10	1
5	31.0614-202	0	KRABICE / BOX / DOSE	VYLISEK-PLAST	1
6	31.0631-201	0	SNIŽKOVÝ / SENSOR / SENSOR		1
7	90.002-20.027	0	ŠROUB STAVEČÍ / ADJUSTMENT BOLT / STELLSCHRAUBE	ŠROUB M5x25	1
8	90.011.27.019	0	ŠROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKWSCHRAUBE	ŠROUB M5x40	1
9	90.014.50.004	0	ŠROUB / BOLT / SCHRAUBE	M2.5x14	2
10	90.100.55.003	0	MATICE / NUT / MUTTER	MATICE - M5	2
11	91.070.010	0	PRŮCHODKA / LEADTHROUGH / DURCHFÜHRUNG	M12x1.5 ČERNA	1

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./)Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.13. Svěrák / Schraubstock / Vice



NAZEV SESTAVY SVERAK	CISLO SESTAVY 201.M203-250	STROJ WL
	Konstruoval: MAJZNER	
	Datum:	19. 07.2012
	Meritko:	33:100


7.14. Kusovník / Stückliste / Piece list – Svěrák / Schraubstock / Vice

Cislo Sestavy 201.M203-250		Ver. 1	Název sestavy SVERAK/VICE / SCHRAUBSTOCK	
Poz.	Objednací číslo	Ver.	Název položky	Ks
1	30.M203-003	3	TELESO SVĚRAKU / VICE BODY / SCHRAUBSTOCKKÖRPER	1
2	30.M203-005	0	CEP / LUG / BOLZEN	1
3	30.M203-042 (1)	0	DESKA / BOARD / PLATTE	1
4	30.M203-251	1	DORAZ / STOP PIECE / ANSCHLAG	1
5	90.001.25.016 (1)	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	2
6	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	4
7	95.802.005	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	2

I.ZRUSEN 2x STAVECI SROUB 90.004.2D.004, PRIDANA DESKA 30.M203-042, SROUB M6x12 90.001.25.016, 182/ZM232,
18.7.2012, ODVARKA

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.15. Svěrák / Schraubstockuntersatz / Vice base




NAZEV SESTAVY PODSTAVEC SVĚRÁK	CÍSLO SESTAVY S209-000	STROJ WL 280 GH
Konstruoval: ODVARKA	Datum: 13. 11. 2012	Meritko: 1:5

7.16. Kusovník / Stückliste / Piece list –
Podstavec svěráku / Schraubstockuntersatz / Vice base

Císlo Sestavy 201.S209-000	Ver. 0	Nazev sestavy PODSTAVEC SVERAKU/VICE BASE/SCHRAUBSTOCKUNTERSATZ			
Poz.	Objednací číslo	Ver.	Nazev položky	Rozměr	Ks
1	201.G209-020	0	ODMEROVANI / MEASURING / GEHRUNGSMESSUNG		1
2	201.M203-250	0	SVERAK / VICE / SCHRAUBSTOCK	SESTAVA	1
3	201.M207-100	0	VALEC SVERAKU / VICE CYLINDER / SCHRAUBSTOCKZYLINDER		1
4	201.M209-010	0	BRZDA / BRAKE / BREMSE		1
5	30.G209-002	1	CELIST PEVNA / SOLID JAW / FESTE BACKE		1
6	30.G209-003	1	CELIST / BOARD / PLATTE	HR 150x25	1
7	30.G209-007	0	KRYT / COVER / ABDECKUNG	P 1,5x165	1
8	30.G209-010	0	KRYT / COVER / ABDECKUNG	P 1x82	1
9	30.G209-012	0	DESKA / BOARD / PLATTE	P 20x180	1
10	30.G209-052	0	TELESO SVERAKU / VICE BODY / SCHRAUBSTOCKKÖRPER		1
11	30.G209-054	0	STUL / PLATE / BLECH	P 4x441	1
12	30.M203-002	1	LISTA VODICI / LEAD TRIM / FÜHRUNGSLISTE	HR 30x15	2
13	30.M203-040	0	DESKA / BOARD / PLATTE	HR 150x16	1
14	30.M203-201	0	DESKA / BOARD / PLATTE	P 35x100	1
15	30.S209-001	0	PODSTAVEC SVERAKU / VICE BASE / SCHRAUBSTOCKUNTERSATZ		1
16	90.001.25.031	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	6
17	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	16
18	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	2
19	90.001.25.039	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x55	4
20	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x30	4
21	90.001.25.058	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x30	4
22	90.002.2D.011	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x10	4
23	90.002.2D.014	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M10x16	2
24	90.002.2D.018	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x20	5
25	90.005.55.028	0	SROUB 6HRANNY / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M10x50	1
26	90.006.50.001	0	SROUB VRATOVY / /	M8x30	1
27	90.013.27.004	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	M5x12	6
28	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	3
29	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE _ M10	1
30	90.101.55.001	0	MATICE / NUT / MUTTER	MATICE M8	1
31	90.150.50.005	0	PODLOZKA / WASHER / UNTERLEGSCHEIBE	PODLOZKA 8,4	3
32	95.700.045	0	POUZDRO / SLEEVE / BÜCHSE	KU 40x20	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.17. Podavač / Vorschub / Feeder




NAZEV SESTAVY PODAVAC	CÍSLO SESTAVY 201.S211-000	STROJ WL280 GA
Konstruoval: ODVARKA		
Datum: 09. 07.2012		
Meritko: 23:100		

7.18. Kusovník / Stückliste / Piece list –
Podavač / Vorschub / Feeder

Císlo Sestavy 201.S211-000	Ver. 0	Název sestavy PODAVAC/FEEDER/VORSCHUB			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.M207-100	0	VALEC SVĚRAKU / VICE CYLINDER / SCHRAUBSTOCKZYLINDER		1
2	201.R311-030	0	ZAVORA OPTICKA / OPTICAL GATE / LICHTSCHRANKE		1
3	30.2911-029	0	DRŽAK / HOLDER / HALTER	HR 50x50	1
4	30.2911-030	0	STERAC / WIPER / ABSTREIFER	P 0.2-26.5	2
5	30.M203-201	0	DESKA / BOARD / PLATTE	P 35x100	1
6	30.R211-001	1	PODAVAC / FEEDER / VORSCHUB		1
7	30.R211-004	0	VEDENÍ / GUIDE / BACKENFÜHRUNG	TYC 20x20	4
8	30.R211-007	1	KRYTÝ / COVERS / ABDECKUNGEN	P 1x79	1
9	30.R311-113	0	KOSTKA / CUBE / WÜRFEL	TYC 80x30	1
10	30.S211-002	0	PODAVAC / FEEDER / VORSCHUB		1
11	30.S211-003	0	CELIST / BOARD / PLATTE	HR 130x25	1
12	30.S211-007	0	DISTANC / DISTANCE / DISTANZ	D 25	1
13	30.S211-008	0	LISTA / TRIM / LEISTE	HR 40x15	1
14	30.S211-009	0	LISTA / TRIM / LEISTE	HR 50x15	1
15	30.S211-010	0	LISTA / TRIM / LEISTE	HR 30x10	2
16	30.S211-013	0	CELIST / JAW / BACKE		1
17	30.S211-036	0	KRYT / COVER / ABDECKUNG	P 1.5x109	1
18	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	1
19	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	15
20	90.001.25.037	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x45	4
21	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x30	6
22	90.001.25.XXX	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x120	1
23	90.002.2D.013	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x25	8
24	90.004.2D.019	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M16x40	1
25	90.011.27.007	0	SROUB / /	M8x12	4
26	90.013.27.003	0	SROUB / BOLT / SCHRAUBE	M5x10	2
27	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	4
28	90.100.55.008	0	MATICE / NUT / MUTTER	MATICE _ M16	1
29	91.270.006	0	SNIMAC MAGNET. / MAGNETIC SENSOR / MAGNETSENSOR		1
30	95.700.004	0	POUZDRO / SLEEVE / BÜCHSE	20x20	2
31	95.700.026	0	POUZDRO / SLEEVE / BÜCHSE	50x50	4
32	95.860.001	0	HLAVICE MAZACI / HEAD / KOPF	KM5	2
33	96.040.004	0	KROUZEK STIRACI / SCRAPER RING / ABSTREIFRING	50x62x5	4

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.19. Podstavec / Untersatz / Base




NAZEV SESTAVY PODSTAVEC	CÍSLO SESTAVY 201.S201-000	STROJ WL 280 GA
Konstruoval: ODVARKA		
Datum: 27. 07.2012		
Meritko: 13:100		

7.20. Kusovník / Stückliste / Piece list – Podstavec / Untersatz / Base

Císlo Sestavy 201.S201-000	Ver. 0	Název sestavy PODSTAVEC/BASE/UNTERSATZ			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.M201-010	2	VANA / TANK / WANNE		1
2	30.M301-020	0	SKLUZ / SLIDE / RUTSCH		1
3	30.R201-056	1	VÍKO / COVER / DECKEL	P 4x100	1
4	30.R301-008	0	DRŽÁK / HOLDER / HALTER	P4x212	1
5	30.R412-055	1	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	6HR 19	2
6	30.S201-001	0	PODSTAVEC / BASE / UNTERSATZ		1
7	30.S201-010	0	KRYT / COVER / ABDECKUNG	P 3x516.4	1
8	90.001.25.038	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X50	1
9	90.001.25.175	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X90	2
10	91.020.015	0	CERPADLO / PUMP / PUMPE	3COA4-12	1
11	91.070.012	0	VÝVODKA / BUSHING / TÜLLE	M20x1.5	4
12	91.071.022	0	VÝVODKA / BUSHING / TÜLLE		3
13	91.072.012	0	MATICE / NUT / MUTTER		1
14	91.072.016	0	MATICE / NUT / MUTTER		3
15	91.074.013	0	UCPAVKA / PLUG / STOPFEN	M25x1,5	1
16	94.101.039	0	ZASLEPKA / PLUG / BLINDFLANSCH	154x154x4	1
17	95.800.016	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNÝ KROUZEK 42	4

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Versio; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.21. Ovládací panel / Bedienpult / Control panel




7.22. Kusovník / Stückliste / Piece list –
Ovládací panel / Bedienpult / Control panel

Císlo Sestavy 201.R230-300		Ver. I	Název sestavy OVLÁDACÍ PANEL/CONTROL PANEL/BEDIENPULT			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks	
1	30.6130-012	0	VÍKO / COVER / DECKEL	P 0.5x 30x30	2	
2	30.6130-018	0	HLAVICE / HEAD / KOPF	VYLÍSEK	1	
3	31.6130-008	0	HLAVICE / HEAD / KOPF		1	
4	30.R230-010	0	MEZIKUS / INTERMEDIATE PIECE / PASSTÜCK	ø 32	1	
5	30.R230-201	3	SKRIN / BOX / KASTEN		1	
6	30.R230-204	0	PLECH / PLATE / BLECH	P 1x220	1	
7	30.R230-206	0	PLECH / PLATE / BLECH	P 1x220	1	
8	30.R230-207	0	PANEL ELEKTRO / ELECTRO PANEL / PANEL	P 3x205	1	
9	30.R230-208	0	DESKA / BOARD / PLATTE	P 3x150	1	
10	31.R330-003	0	SKLO ORGANICKE / PLEXIGLASS / PLEXIGLAS	3x47,5	1	
11	61.352.001	0	TESNENÍ / SEALING / DICHTUNG	TESNENÍ 19x10	1	
12	90.100.55.004	0	MATICE / NUT / MUTTER	MATICE - M6	4	
13	90.150.50.004	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 6,4	4	
14	90.150.50.006	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5	2	
15	91.060.030	0	HLAVICE TOTAL STOP / TOTAL STOP HEAD / TASTE TOTAL STOP		1	
16	91.060.031	0	HLAVICE / HEAD / KOPF		1	
17	91.060.035	0	HLAVICE / HEAD / KOPF		1	
18	91.060.051	0	PREPINAC / SWITCH / UNSCHALTER		1	
19	91.060.053	0	HLAVICE / HEAD / KOPF		1	
20	91.071.005	0	PRUCHODKA / LEADTHROUGH / DURCHFÜHRUNG		2	
21	91.071.022	0	VÝVODKA / BUSHING / TÜLLE		1	
22	91.072.008	0	MATICE / NUT / MUTTER		2	
23	91.072.016	0	MATICE / NUT / MUTTER		1	
24	91.170.003	0	SPINAC VÁKOVÝ / CAM SWITCH / SCHALTER	LE2-12-1763	1	
25	91.180.001	0	DESKA SPINACE / ELECTRIC BOARD / PLATINE		1	
26	91.283.015	0	POTENCIOMETR / POTENTIOMETER / POTENTIOMETER	TP 195 4K7/N 20A	1	
27	92.002.103	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4" tr12	1	
28	92.004.001	0	SROUBENÍ UHLIVE / ANGLE BOLTING / WINKELVERSCHRAUBUNG	37701	1	
29	92.152.001	0	VENTIL SKRTICI / CHOKE VALVE / DROSSELVENTIL	VS01-04/R 2.5-0	1	
30	96.082.002	0	TESNENÍ / SEALING / DICHTUNG	KROUZEK CU 13/17	1	
31	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK CÍNSKY	2	
32	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1	
33	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1	

I.ZRUS.VÍKO 30.R230-203,PANEL 30.R230-202,2xCEP 30.7217-028,2XPOJ.KROUZEK 95.802.003 (PRIDANO DO SKRINE 30.R230-201).
061/ZM110 29.3.2012 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.23. Válec zvedací / Hebezyylinder / Lifting cylinder



NAZEV SESTAVY VÁLEC ZVEDACÍ	ČÍSLO SESTAVY 201.M207-050	STROJ WL-280-H
Konstruoval: MAJZNER		
Datum: 06. 05.2011		
Meritko: 1:1		


7.24. Kusovník / Stückliste / Piece list –
Válec zvedací / Hebezyylinder / Lifting cylinder

Cislo Sestavy 201.M207-050		Ver. 2	Název sestavy VALEC ZVEDACÍ / LIFTING CYLINDER / HEBEZYLLINDER	
Poz.	Objednací číslo	Ver.	Název položky	Ks
1	30.0807-006	2	DRŽAK / HOLDER / HALTER	TYC 25x25
2	30.2807-004	0	PIST / PISTON / KOLBEN	d 55
3	30.9107-501	3	VALEC / ROLLER / ZYLINDER	TR 55/50H8
4	30.9207-105 (2)	0	DISTANC / DISTANCE / DISTANZ	TR 28x3.6
5	30.K107-008	4	VIKO / COVER / DECKEL	d 55
6	30.LD07-001	2	PISTNICE / PISTON ROD / KOLBENSTANGE	d20
7	30.V307-003	3	VIKO / COVER / DECKEL	d 55
8	31.2807-006 (1)	0	VIKO / COVER / DECKEL	
9	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20
10	90.150.50.005	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 8,4
11	92.002.001	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	G 1/4"
12	92.002.001	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	GES 08LR
13	92.151.001	0	VENTIL POJISTNÝ / SAFETY VALVE / SICHERUNGSVENTIL	VPN-H 1/4"
14	95.801.018	0	KROUZEK POJISTNÝ VNITR / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNÝ KROUZEK 50
15	96.001.013	0	KROUZEK O STATICKÝ / STATIC O RING / O-RING STATISCH	45X2
16	96.002.007	0	KROUZEK O DYNAMICKÝ / DYNAMIC O RING / O-RING DYNAMISCH	16x2
17	96.002.019	0	KROUZEK O DYNAMICKÝ / DYNAMIC O RING / O-RING DYNAMISCH	46X2
18	96.041.002	0	TESNENÍ / SEALING / DICHTUNG	20/28x4
19	96.060.002	0	KROUZEK STÍRAČÍ / SCRAPER RING / ABSTREIFRING	20x28
20	96.082.002	0	TESNENÍ / SEALING / DICHTUNG	KROUZEK CU 13/17
21	96.084.001	0	KROUZEK VODÍČÍ / LEAD RING / FÜHRUNGSRING	GP6500500-T47
22	96.900.001	0	TESNENÍ KOMBINOVANÉ / COMBINATION SEALING / KOMBIDICHTUNG	

1.PRIDANO VIKO 31.2807-006. 095/ZM101 6.5.2011 SLEZACKOVA
2.ZRUSEN DISTANC 30.9107-504 A NAHR.30.9207-105. 160/ZM223 13.7.2012 SLEZACKOVA

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.25. Konzola otočná / Drehkonsole /Turnable console



NAZEV SESTAVY KONZOLA OTOCNA	CISLO SESTAVY 201.M202-000	STROJ WORK280
Konsfruoval: VINOHRADSKY		
Datum: 22. 02.2011		
Meritko: 33:100		


7.26.

7.27. Kusovník / Stückliste / Piece list –
Konzola otočná / Drehkonsole / Turnable console

Císlo Sestavy 201.M202-000		Ver. 0	Název sestavy KONZOLA OTOČNÁ/TURNABLE CONSOL/DREHKONSOLE		
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0802-002	1	LOŽISKO / BEARING / LAGER		2
2	30.0807-009	1	CEP / LUG / BOLZEN	d 16h9	1
3	30.0808-007	0	SROUB / BOLT / SCHRAUBE	M8x60	1
4	30.M202-001	0	KONZOLA OTOČNÁ / TURNABLE CONSOL / DREHKONSOLE		1
5	30.M202-008	0	DRŽÁK / HOLDER / HALTER	HR 40x40	1
6	31.0502-719		PRUŽINA / SPRING / FEDER	7.1x56.5x194.7x14.5	2
7	81.0804-005	1	KROUZEK / RING / RING	P 3-60	2
8	81.0804-013	1	KROUZEK / RING / RING	P 5-60	2
9	90.001.25.032	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	2
10	90.001.25.063	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X60	4
11	90.005.55.034	0	SROUB 6HRANNÝ / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X40	1
12	90.100.55.005	0	MATICE / NUT / MUTTER	MATICE _ M8	1
13	90.100.55.007	0	MATICE / NUT / MUTTER	MATICE _ M12	1
14	95.800.007	0	KROUZEK POJIST.VNĚJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNÝ KROUZEK 16	2

7.28.

7.29. Plot / Zaun / Fence



7.30.


7.31. Kusovník / Stückliste / Piece list –
Plot / Zaun / Fence

7.32. Válec pomocný / Hilfszylinder / Auxiliary cylinder

Císlo Sestavy 201.8214-050	Ver. 0	Název sestavy POMOCNÝ VALEC / AUXILIARY CYLINDER / HILFSZYLINDER			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.8214-031	0	VALEC / PULLEY / ZAUNILIARY CYLINDER / HILFSZYLINDER		1
2	30.5814-008	0	EXCENTRICKÝ ZEMNÍK	6HR 24	2
3	30.8214-032	0	PIVOT / POŘEČÍ STÁVA	d 15	1
4	99.160.607008	0	PODLOŽKA / WASHER / UNTERLEGSCHEIBE	PODLOŽKA 15	2
5	99.60140035	0	PODŠKOFNÍK / WÄRM LAGER	6202 2RS	2
6	30.8214-038	0	DRŽEK / VODNÍK / TRÖG	TR 44.5x6.3	2
7	90.0034203001	0	ŠROUB / STUPEL / ABSTUMENT BOLT / STELLSCHRAUBE	ŠROUB M5x6	2
8	90.00840034	0	DRŽÁK / NÖCKER / ANSCHLUSSEHEBEL / SPANNHEBEL	M6x40x20	6
9	30.S214-034	0	PLOT / FENCE / ZAUN		1
10	30.S214-038	0	TAHLO / GUY ROD / ZUGSTANGE		1
11	30.S214-045	6	DRŽÁK / HOLDER / HALTER		1
12	90.001.25.018	0	ŠROUB / IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x20	3
13	91.173.013	0	SPINAC / KONC. S KLADEK / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE		1
14	30.S214-046	0	DRŽÁK / HOLDER / HALTER	DR 40x5	4
15	90.001.25.012	5	ŠROUB / IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x30	1
16	90.100.55.003	0	MATICE / NUT / MUTTER	MATICE - M5	1
17	90.011.27.024	0	ZAPUSTNÝ IMBUS / COUNTERSINK BOLT / SENKSCHRAUBE	ŠROUB M5x20	2
18	30.S214-047	0	KONZOLA / KONSOLLE		1

Technical drawing of the auxiliary cylinder assembly. The drawing shows a side view of the assembly with various components labeled with numbers 1 through 8. 1 points to the main body of the cylinder. 2 points to a mounting bracket. 3 points to a lever arm. 4 points to a pin. 5 points to a nut. 6 points to a holder. 7 points to a bolt. 8 points to a roller.

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver./Version/Version: Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz./Position/Position; Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung



Cislo Sestavy/Number of assembly/Numer der Baugruppe; Verze (Ver.)/Version/Versio; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

